



Alcatel-Lucent 7705

SERVICE AGGREGATION ROUTER | RELEASE 1.1

8-PORT ETHERNET ADAPTER CARD INSTALLATION GUIDE

Alcatel-Lucent assumes no responsibility for the accuracy of the information presented, which is subject to change without notice.

Alcatel, Lucent, Alcatel-Lucent and the Alcatel-Lucent logo are trademarks of Alcatel-Lucent. All other trademarks are the property of their respective owners.

Copyright 2008 Alcatel-Lucent.
All rights reserved.

Disclaimers

Alcatel-Lucent products are intended for commercial uses. Without the appropriate network design engineering, they must not be sold, licensed or otherwise distributed for use in any hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life-support machines, or weapons systems, in which the failure of products could lead directly to death, personal injury, or severe physical or environmental damage. The customer hereby agrees that the use, sale, license or other distribution of the products for any such application without the prior written consent of Alcatel-Lucent, shall be at the customer's sole risk. The customer hereby agrees to defend and hold Alcatel-Lucent harmless from any claims for loss, cost, damage, expense or liability that may arise out of or in connection with the use, sale, license or other distribution of the products in such applications.

This document may contain information regarding the use and installation of non-Alcatel-Lucent products. Please note that this information is provided as a courtesy to assist you. While Alcatel-Lucent tries to ensure that this information accurately reflects information provided by the supplier, please refer to the materials provided with any non-Alcatel-Lucent product and contact the supplier for confirmation. Alcatel-Lucent assumes no responsibility or liability for incorrect or incomplete information provided about non-Alcatel-Lucent products.

However, this does not constitute a representation or warranty. The warranties provided for Alcatel-Lucent products, if any, are set forth in contractual documentation entered into by Alcatel-Lucent and its customers.

This document was originally written in English. If there is any conflict or inconsistency between the English version and any other version of a document, the English version shall prevail.

Table of Contents

Preface	9
Installing Adapter Cards	13
Provisioning Requirements	14
Ethernet Card Versions	14
Component Power Consumption	15
Provisioning an Adapter Card	16
Configuration Example	16
Installation Procedures	18
Warnings and Notes	18
Installing an Adapter Card	19
Removing and Replacing an Adapter Card	20
SFPs	23
Installing and Removing SFPs	24
Warnings and Notes	24
Fiber Cable Preparation	25
Locking Mechanisms	25
SFP Support	26
Installing SFPs	27
Removing SFPs	27
Connector and LED Descriptions	29
8-port Ethernet Adapter Card Connectors and LEDs	30

List of Tables

Preface **9**

Table 1: Information Symbols 11

Installing Adapter Cards **13**

Table 2: Component Power Consumption 15

Table 3: Adapter Card Installation Features 20

SFPs **23**

Table 4: SFPs for the 8-port Ethernet Adapter Card 26

Connector and LED Descriptions **29**

Table 5: 8-port Ethernet Adapter Card Features 30

Table 6: RJ-45 Port Pinouts—RJ-45 Female 32

List of Figures

Installing Adapter Cards	13
Figure 1: 7705 SAR-8 Slot Identification	19
Figure 2: Installing an Adapter Card	19
Figure 3: Removing an Adapter Card	21
Connector and LED Descriptions	29
Figure 4: 8-port Ethernet Adapter Card Connectors and LEDs	30
Figure 5: RJ-45 Connector Pin Orientation	32

About This Guide

This guide provides site preparation recommendations and step-by-step procedures to install, remove, and replace an 8-port Ethernet Adapter card.

There are two versions of the 8-port Ethernet Adapter card. The two versions are identical except that version 2 adds support for Synchronous Ethernet as a timing source and has more memory for storage of MPLS labels.

Each 8-port Ethernet Adapter card has six RJ-45 ports and two small form-factor pluggable (SFP) ports on its faceplate. The six RJ-45 ports are 10/100 Mb/s-capable ports that support autosense and autonegotiation. The two SFP ports support 10/100/1000 Mb/s copper SFPs or 100/1000 Mb/s fiber SFPs.

SFPs are hot-swappable input/output devices that plug into the adapter card ports, linking the ports to fiber-optic or copper networks. Refer to [SFPs on page 23](#) for a list of supported SFP modules.

After the hardware installation process is completed, refer to the [List of Technical Publications](#) for details on the boot process, software configuration, and Command Line Interface (CLI) information to configure system and network parameters.

List of Technical Publications

The 7705 SAR OS documentation set is composed of the following guides:

- 7705 SAR OS Basic System Configuration Guide
This guide describes basic system configurations and operations.
- 7705 SAR OS System Management Guide
This guide describes system security and access configurations as well as event logging and accounting logs.
- 7705 SAR OS Interface Configuration Guide
This guide describes card and port provisioning.

- **7705 SAR OS Router Configuration Guide**
This guide describes logical IP routing interfaces, IP-based filtering, and routing policies.
 - **7705 SAR OS MPLS Guide**
This guide describes how to configure Multiprotocol Label Switching (MPLS) and Label Distribution Protocol (LDP).
 - **7705 SAR OS Services Guide**
This guide describes how to configure service parameters such as service access points (SAPs), service destination points (SDPs), customer information, user services, and Operations, Administration and Management (OAM) tools.
 - **7705 SAR OS Quality of Service Guide**
This guide describes how to configure Quality of Service (QoS) policy management.
-

Warnings and Notes

Observe the warnings and notes to avoid injury or router damage during installation and maintenance. Follow the safety procedures and guidelines when working with and near electrical equipment. Warning statements and notes are provided in each chapter.






Audience

This guide is intended for network installers and system administrators who are responsible for installing, configuring, or maintaining networks. This guide assumes you are familiar with electronic and networking technologies.

Information Symbols

Table 1 describes symbols contained in this guide.

Table 1: Information Symbols

Symbol	Meaning	Description
	Danger	This symbol warns that improper handling and installation could result in bodily injury. Before you begin work on this equipment, be aware of hazards involving electrical circuitry, be aware of your networking environments, and instigate accident prevention procedures.
	Warning	This symbol warns that improper handling and installation could result in equipment damage or loss of data.
	Caution	This symbol warns that improper handling may reduce your component or system performance.
	Note	This symbol provides additional operational information.
		Class 1 laser products are listed in the Class 1 laser adapter card documents. Only approved Class 1 replaceable laser transceivers should be used with those products.

Technical Support

If you purchased a service agreement for your 7705 SAR-8 and related products from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance. If you purchased an Alcatel-Lucent service agreement, contact your welcome center at:

Web: http://www1.alcatel-lucent.com/comps/pages/carrier_support.jhtml

Installing Adapter Cards

In This Chapter

This chapter provides information about installing and removing the adapter cards in the 7705 SAR-8.

This chapter provides information on the following topics:

- [Provisioning Requirements on page 14](#)
 - [Ethernet Card Versions on page 14](#)
- [Component Power Consumption on page 15](#)
- [Provisioning an Adapter Card on page 16](#)
 - [Configuration Example on page 16](#)
- [Installation Procedures on page 18](#)
 - [Warnings and Notes on page 18](#)
 - [Installing an Adapter Card on page 19](#)
 - [Removing and Replacing an Adapter Card on page 20](#)

Provisioning Requirements

To configure cards and ports, you must be able to access the 7705 SAR-8 by console or Telnet connection. Refer to the 7705 SAR-8 Installation Guide for information and instructions on console and Telnet connections.

The CSM does not require provisioning. However, the IOM, which is an integral part of the CSM software module, must be activated before any adapter cards and port parameters can be provisioned and configured. The IOM is activated using the `card` and `card-type` CLI commands to specify its slot number and card type. Adapter cards must be provisioned before their ports can be configured.



Notes:

- IOMs are specified using the `card` and `card-type` commands (items 1 and 2 in the list below).
- Adapter cards are provisioned and configured using the `mda` and `mda-type` commands (items 3 and 4 in the list below).

Provision components in the following order:

1. Card slot number (use the `card` command)
2. Card type
3. Adapter card slot number (use the `mda` command)
4. Adapter card type
5. Ports

Ethernet Card Versions

There are two versions of the 8-port Ethernet Adapter card. The two versions are identical except that version 2 adds support for Synchronous Ethernet as a timing source and has more memory for storage of MPLS labels (more label space). For more information on Synchronous Ethernet, see the 7705 SAR OS Basic System Configuration Guide.

The CLI identifiers for the two versions are `a8-eth` and `a8-ethv2`.



Note: The electrical SFP (part number 3HE00062AA) does not support Synchronous Ethernet when used with version 2 of the 8-port Ethernet Adapter card. For more information, refer to the 7705 SAR OS Basic System Configuration Guide. For a list of supported SFPs, see [SFP Support on page 26](#).

Component Power Consumption

[Table 2](#) lists the power consumption for the chassis, CSM, and 8-port Ethernet Adapter card.

Table 2: Component Power Consumption

Component	Conservative Estimate (Watts)
SAR-8 chassis (unpopulated, all fans operating)	28 W
CSM	17 W
8-port Ethernet Adapter card	20 W

Refer to the 7705 SAR-8 Installation Guide for more information on the power consumption of other components.

Provisioning an Adapter Card

After the IOM has been activated on the CSM (Steps 1 and 2 below), continue in the `config` context with the following CLI commands to provision the adapter card. The steps below provision 8-port Ethernet Adapter cards in slots MDA 1 and 2. A maximum of two 8-port Ethernet Adapter cards can be configured on a 7705 SAR-8 chassis.

Command Syntax	Example
Step 1. <code>card slot-number</code>	<code>card 1</code>
Step 2. <code>card-type card-type</code>	<code>card-type iom-1g</code>
Note: The <i>slot-number</i> is always 1 and the <i>card-type</i> is always <i>iom-1g</i> .	
Step 3. <code>mda mda-number</code>	<code>mda 1</code>
Step 4. <code>mda-type mda-type</code>	<code>mda-type a8-eth</code>
Step 5. <code>exit</code>	<code>exit</code>

To provision an additional adapter card, continue the configuration process with Step 6:

Step 6. <code>mda mda-number</code>	<code>mda 2</code>
Step 7. <code>mda-type mda-type</code>	<code>mda-type a8-eth</code>
Step 8. <code>exit</code>	<code>exit</code>

Configuration Example

The following example displays the `card`, `card-type`, `mda` and `mda-type` commands to specify the IOM as an `iom-1g` type, and provision 8-port Ethernet Adapter cards in slots MDA 1 and 2.

```
ALU-1>config# card 1
ALU-1>config>card# card-type iom-1g
ALU-1>config>card# mda 1
ALU-1>config>card>mda# mda-type a8-eth
ALU-1>config>card>mda# exit
ALU-1>config>card# mda 2
ALU-1>config>card>mda# mda-type a8-eth
ALU-1>config>card>mda# exit
```


Sample Output

Use the `config>info` command to display card configuration information:

```
ALU-1>config# info
. . .
-----
echo "Card Configuration "
#-----
card 1
    card-type iom-1g
    mda 1
        mda-type a8-eth
    exit
    mda 2
        mda-type a8-eth
    exit
exit
-----
ALU-1>config#
```

Use the `config>show card state` command to display administrative and operational states for all cards:

```
ALU-1>config# show card state

=====
Card State
=====
Slot/ Provisioned   Equipped   Admin Operational  Num  Num  Comments
Id    Type           Type       State  State           Ports MDA
-----
1      iom-1g           iom-1g     up     up              6
1/1    a8-eth           a8-eth     up     up              8
1/2    a8-eth           a8-eth     down   provisioned     8
A      csm-1g           csm-1g     up     up              Active
B      csm-1g           csm-1g     up     down            Standby
=====
ALU-1>config#
```

Use the `config>show mda` command to display provisioned adapter card information:

```
ALU-1>config# show mda

=====
MDA Summary
=====
Slot Mda  Provisioned   Equipped   Admin   Operational
      Mda  Mda-type      Mda-type   State   State
-----
1     1    a8-eth        a8-eth     up      up
      2    a8-eth        a8-eth     down    provisioned
=====
ALU-1>config#
```

Installation Procedures

Warnings and Notes



Danger:

- Invisible laser radiation can be emitted from an adapter card's port apertures when no cable is connected. Avoid exposure and do not stare into open apertures.
- Always assume that fiber-optic cables are connected to a light source.



Warning:

- Electrostatic discharge (ESD) damage can occur if adapter cards are mishandled. Always wear an ESD-preventive wrist or ankle strap and always connect an ESD strap to a nearby ground point that is connected to the site grounding point when working with an adapter card. Typical ground points include the ground stud on the 7705 SAR-8 mounting bracket, or a properly grounded rack or work bench.
- Always place components on an anti-static surface.
- Do not power up a 7705 SAR-8 until all components are installed and verified as having been installed correctly.
- Slot covers are required in all empty slots to prevent excess dust accumulation and to help control airflow and electromagnetic interference.
- Use only approved small form-factor pluggable (SFP) fiber-optic devices in adapter card ports.
- To comply with the GR-1089-CORE requirement R4-9 [31] standard for electromagnetic compatibility and safety, all intra-building ports are specified for use with shielded and grounded cables at both ends.
- The intra-building port(s) of the equipment or sub-assembly is suitable for connection to intra-building or unexposed wiring or cabling only. The intra-building port(s) of the equipment or sub-assembly must not be metalically connected to interfaces that connect to the Outside Plant (OSP) or its wiring. These interfaces are designed for use as intra-building interfaces only (Type 2 or Type 4 ports as described in GR-1089-CORE) and require isolation from the exposed OSP cabling. The addition of primary protectors is not sufficient protection in order to connect these interfaces metalically to OSP wiring.



Notes:

- Ports cannot be configured until the adapter card is provisioned.
- Services cannot be provisioned until the ports are configured.
- Adapter card slot numbers are MDA 1 through MDA 6.

Installing an Adapter Card

A maximum of two 8-port Ethernet Adapter cards may be installed on the 7705 SAR-8 in MDA slots 1 through 6. [Figure 1](#) identifies the location of the MDA slots. [Figure 2](#) illustrates the installation of an adapter card. Ejector levers help install and remove the adapter card; captive screws secure the card in place.

Figure 1: 7705 SAR-8 Slot Identification


CSM A	CSM B	FAN	Batt A
MDA 1	MDA 2		Batt B
MDA 3	MDA 4		
MDA 5	MDA 6		

19635

The 8-port Ethernet Adapter card has six RJ-45 ports for copper connections and two SFP ports for fiber or copper connectivity via SFP modules. [Table 4 on page 26](#) lists the Alcatel-Lucent approved SFP modules supported by the 8-port Ethernet Adapter card. For more information on installing an SFP, see [SFPs on page 23](#).

Refer to [Connector and LED Descriptions on page 29](#) for information on the connectors and LEDs on the 8-port Ethernet Adapter card.

Figure 2: Installing an Adapter Card



19643

Table 3: Adapter Card Installation Features

Key	Description
1	Slot guide
2	Threaded receptacle
3	Captive screw
4	Ejector lever

Tools required:

- torque driver for Phillips screws

To install an adapter card:

- Step 1.** Remove the adapter card from the packaging and place on a flat anti-static work surface. Avoid touching the board components and connector pins.
- Step 2.** With the ejector levers rotated inward, hold the adapter card by the levers, align the card with the slot guides, and slide the adapter card into the slot (see [Figure 2](#)).
- Step 3.** Press the adapter card firmly into the slot. Make sure that the card connectors are seated in the backplane connectors.
- Step 4.** Tighten the captive screws to secure the card. Do not over-tighten. The recommended torque is 4-6 lbf.-in.
- Step 5.** Check the Power LED. If the adapter card is properly inserted and power to the 7705 SAR-8 has been applied, the Power LED is lit blue. See [Connector and LED Descriptions on page 29](#) for a description of LED activity.
- Step 6.** Install any SFPs and attach cables. Refer to [SFPs on page 23](#) for information on SFPs.

Removing and Replacing an Adapter Card

If you replace an adapter card with a different type, you must change the configuration to reflect the new adapter card type prior to removing the installed card. Each active port must be shut down before you shut down and remove an adapter card configuration (see [Changing an Adapter Card Configuration on page 21](#)). If you replace an adapter card with the same type, no configuration change is necessary. Refer to the 7705 SAR OS Interface Configuration Guide for details on configuring cards and ports.


If you are removing the card, but not replacing it, install a slot cover over the empty slot.

Changing an Adapter Card Configuration

Command Syntax	Example
Step 1. <code>port port-id</code>	<code>port 1/1/5</code>
Step 2. <code>shutdown</code>	<code>shutdown</code>
Note: The <code>port>shutdown</code> command must be repeated for all enabled ports on the adapter card.	
Step 3. <code>exit</code>	<code>exit</code>
Step 4. <code>card slot-number</code>	<code>card 1</code>
Step 5. <code>mda mda-slot</code>	<code>mda 1</code>
Step 6. <code>shutdown</code>	<code>shutdown</code>
Step 7. <code>exit</code>	<code>exit</code>
Step 8. <code>no mda mda-slot</code>	<code>no mda 1</code>
Step 9. <code>mda mda-slot</code>	<code>mda 1</code>
Step 10. <code>mda-type mda-type</code>	<code>mda a8-eth</code>
Step 11. <code>no shutdown</code>	<code>no shutdown</code>
Step 12. <code>exit</code>	<code>exit</code>

Figure 3 illustrates removing an adapter card. Table 3 on page 20 identifies the installation features.

Figure 3: Removing an Adapter Card



19649

Tools required:

- Phillips screwdriver
- torque driver for Phillips screws

To remove and replace an adapter card:

- Step 1.** If you are replacing an adapter card with a different type, change the configuration to reflect the new adapter card type. See [Changing an Adapter Card Configuration on page 21](#).
- Step 2.** Disconnect all cable connections to the adapter card.
- Step 3.** Use a Phillips screwdriver to loosen the captive screws and release the card.



Caution: Do not try to remove the adapter card from the slot before the captive screws are loosened.

- Step 4.** Simultaneously rotate both ejector levers outward to release the adapter card connectors from the backplane.
 - Step 5.** Hold the adapter card by the ejector levers and pull the card out of the slot.
 - Step 6.** Place the adapter card on a flat anti-static surface.
 - Step 7.** Immediately install a replacement adapter card in the slot or cover the slot with a slot cover.
 - Step 8.** Tighten the captive screws to secure the card or slot cover. Do not over-tighten. The recommended torque is 4-6 lbf.-in.
 - Step 9.** Check the Power LED on the adapter card faceplate. If the chassis is powered **ON**, the Power LED on the adapter card is lit blue. Refer to [8-port Ethernet Adapter Card Connectors and LEDs on page 30](#) for more information on the LEDs.
 - Step 10.** If you replaced the adapter card, reconnect all cable connections to the card.
-

In This Chapter

This chapter provides information about installing and removing SFP transceivers on adapter card ports that support these devices.

This chapter provides information on the following topics:

- [Installing and Removing SFPs on page 24](#)
 - [Warnings and Notes on page 24](#)
 - [Fiber Cable Preparation on page 25](#)
 - [Locking Mechanisms on page 25](#)
 - [SFP Support on page 26](#)
 - [Installing SFPs on page 27](#)
 - [Removing SFPs on page 27](#)

Installing and Removing SFPs

Warnings and Notes

**Danger:**

- Invisible laser radiation can be emitted from an adapter card's or SFP's port apertures when no cable is connected. Avoid exposure and do not stare into open apertures.
- Always assume that fiber-optic cables are connected to a light source.

**Warning:**

- Before using the optics on this adapter card, verify that the optical path is in compliance with the parameters of the optical components. In particular, pay close attention to any minimum attenuation requirements for the optics. If minimum attenuation requirements are not met, the optical receiver components may be permanently damaged. Contact the appropriate technical support center for assistance and further information about your Alcatel-Lucent products.
- Make sure any optical port on an adapter card is protected by a protective plug when there is no SFP installed in the port. Only remove the plug when you are ready to install an SFP.
- Make sure the ports on an SFP are protected by an SFP protective plug when you install or remove an optical SFP. Only remove the plug when you are ready to install an SFP.
- Electrostatic discharge (ESD) damage can occur if adapter cards are mishandled. Always wear an ESD-preventive wrist or ankle strap and always connect an ESD strap to a nearby ground point that is connected to the site grounding point when working with an adapter card. Typical ground points include the ground stud on the 7705 SAR-8 mounting bracket, or a properly grounded rack or work bench.
- Always place router components on a flat anti-static surface.
- Avoid bending fiber-optic cable beyond its minimum bend radius. Do not exceed the recommended 1.2 inches (30 mm) for fiber-optic cables.

**Caution:**

- Make sure the connector on the fiber cable is protected by a dust cover until you are ready to attach the cable to an SFP.
- Always replace the dust cover on the connector of a fiber cable when the cable is disconnected from an SFP.

**Notes:**

- Discard SFPs according to all local laws and regulations.
- SFPs can be installed and replaced without disabling the interfaces or removing the adapter card from the 7705 SAR-8.
- SFPs are keyed to prevent incorrect insertion. If an SFP is not seated properly, remove it and confirm that the orientation is correct before re-inserting it.

Fiber Cable Preparation

Clean the connector on the fiber cable before inserting it into the SFP to prevent transferring small particles and contaminating the transceiver.

If you switch SFPs from one port to another, ensure that you clean the fiber connectors before reinserting them.

Apply high standards when inspecting and cleaning fiber connectors. Use a “dry” cleaning method to clean fiber connectors.



Caution: Improper handling, cleaning, and inspection techniques can compromise the fiber connection, resulting in data transmission errors. Refer to Alcatel-Lucent's Online Support Documentation Service (OSDS) (<http://www.alcatel-lucent.com/support>) for the Optical Handling Reference Guide.

Locking Mechanisms

SFPs approved by Alcatel-Lucent can use different lock and release methods. Possible lock and release mechanisms include:

- locking handle—a locking handle or lever on the front of the SFP that you gently raise or lower to insert or remove the SFP from the port
- bail—a bar or latch in the front of the SFP that you pull down and outward to release the module
- tabs—tabs on the sides of the SFP that you press inward to release the module

SFP Support

Table 4 lists the Alcatel-Lucent approved SFPs for the 8-port Ethernet Adapter card.

Table 4: SFPs for the 8-port Ethernet Adapter Card

Part Number	Short Description	Ports	Media	Wavelength	Connector Type	Distance
3HE00062AA	PBA GigE TX SFP Copper Module (1000BASE-T, Category 5, 10/100/1000 Mbps) ⁽¹⁾	1	Copper	N/A	RJ-45	100 m
3HE00027AA	PBA GigE SX SFP Optics Module - LC (1000BASE-SX)	1	Fiber	850 nm	LC	220 m
3HE00028AA	PBA GigE LX SFP Optics Module - LC (1000BASE-LX)	1	Fiber	1310 nm	LC	10 km
3HE00867AA	KIT GigE EX SFP Optics Module - LC (1000BASE-EX)	1	Fiber	1310 nm	LC	40 km
3HE00029AA	PBA GigE ZX SFP Optics Module - LC (1000BASE-ZX)	1	Fiber	1550 nm	LC	70 km
3HE01389AA	GigE EZX SFP Optics Module - LC (1000BASE-EZX)	1	Fiber	1550 nm	LC	120 km
3HE00024AA	PBA 100FX SFP Optics Module - LC	1	Fiber	1310 nm	LC	400 m ⁽²⁾ 2 km ⁽³⁾
3HE01454AA	100FX SFP Optics Module - SM - LC 100BASE-FX Single Mode	1	Fiber	1310 nm	LC	40 km

Notes:

1. This electrical SFP (part number 3HE00062AA) does not support Synchronous Ethernet when used with version 2 of the 8-port Ethernet Adapter card. For more information, refer to the 7705 SAR OS Basic System Configuration Guide.
2. Half duplex, multimode fiber
3. Full duplex, multimode fiber

Installing SFPs

To install an SFP:

Step 1. Remove the SFP from the packaging and place it on a flat anti-static work surface.

Step 2. Hold the SFP by its sides and insert it into the appropriate port until it clicks into place.

Step 3. For optical SFPs, remove the protective plug from the SFP port when you are ready to attach the fiber cable.

Removing SFPs

When you are removing an SFP, have the following parts ready:

- a replacement SFP or protective plug for the adapter card port
- a protective plug for the SFP and a dust cover for the fiber cable connector
- an anti-static mat or electrostatic bag

To remove an SFP:

Step 1. Disconnect the cable from the SFP connector.

Step 2. Release the locking mechanism on the SFP with your thumb and forefinger. See [Locking Mechanisms on page 25](#) for descriptions of the different SFP lock and release methods. Slide the SFP out of the port.

Step 3. Place the SFP on an anti-static mat or in an electrostatic bag.

Step 4. Install a replacement SFP or insert a protective plug into the adapter card port.

Step 5. Connect the fiber or copper cable, or insert a protective plug into the optical port and place a dust cover on the fiber cable connector.

SFPs

Connector and LED Descriptions

In This Chapter

This chapter provides information on the following topics:

- [8-port Ethernet Adapter Card Connectors and LEDs on page 30](#)

8-port Ethernet Adapter Card Connectors and LEDs


Figure 4 shows the connectors and LEDs on the 8-port Ethernet Adapter card. Table 5 describes the features on the card.

Figure 5 shows the pin orientation for the RJ-45 ports (ports 1 through 6). Table 6 identifies the pinout assignments.



Caution: This is a Class 1 laser product. Only approved Class 1 replaceable laser transceivers should be used on this product.

Figure 4: 8-port Ethernet Adapter Card Connectors and LEDs



19594




Note: In Figure 4, port 1 is the left-most port on the card.

Table 5: 8-port Ethernet Adapter Card Features

Key	Label	Description
1	Stat(us)	Green (blinking): Initializing Green (solid): Operationally up, administratively up Amber: Operationally down, administratively up; or hardware booting up Unlit: Administratively down, shut down
2	Pwr	Blue: On Unlit: No power or faulty power

Table 5: 8-port Ethernet Adapter Card Features (Continued)

Key	Label	Description
3	RJ-45 ports	The RJ-45 port number (1 through 6) is displayed below the port, between the Link and the Act(ivity) silkscreen labels.
	Link	Green: Link is up Unlit: No link; operationally down; disabled or shut down
	Act	Amber (blinking): active (receiving or transmitting) Unlit: Down or disabled
4	SFP ports	The SFP port number (7 or 8) is displayed below the port. The associated Link and Act(ivity) LEDs are located above the port.
	Link	Green: Valid communication link established Unlit: Disabled, shut down; SFP optics installed but no link present; no SFP
	Act	Amber (blinking): active (receiving or transmitting) Unlit: No activity
5	Ejector lever	Rotate the ejector levers inward to insert the adapter card in the slot and outward to release the card from the slot.
6	Captive screw	Tighten both captive screws to secure the adapter card; loosen both screws to remove the card.


Figure 5: RJ-45 Connector Pin Orientation

19593

Table 6: RJ-45 Port Pinouts – RJ-45 Female

Pin	Signal	Direction	Description
1	TX+	Output	Differential transmit data - positive
2	TX-	Output	Differential transmit data - negative
3	RX+	Input	Differential receive data - positive
4	NC	—	Not connected
5	NC	—	Not connected
6	RX-	Input	Differential receive data - negative
7	NC	—	Not connected
8	NC	—	Not connected

Customer documentation and product support



Customer documentation

<http://www.alcatel-lucent.com/osds>

Product manuals and documentation updates are available through the Alcatel-Lucent Support Documentation and Software Download service at [alcatel-lucent.com](http://www.alcatel-lucent.com). If you are a new user and require access to this service, please contact your Alcatel-Lucent sales representative.



Technical support

<http://www.alcatel-lucent.com/support>



Customer documentation feedback

documentation.feedback@alcatel-lucent.com

