

GE Fanuc Automation

PowerMotion[™] Products

Power Mate H Motion Controller

Maintenance Manual

GFZ-62685EN/03

December 1997

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

PowerMotion is a trademark of GE Fanuc Automation North America, Inc.

©Copyright 1997 GE Fanuc Automation North America, Inc. All Rights Reserved.

DEFINITION OF WARNING, CAUTION, AND NOTE

This manual includes safety precautions for protecting the user and preventing damage to the machine. Precautions are classified into Warning and Caution according to their bearing on safety. Also, supplementary information is described as a Note. Read the Warning, Caution, and Note thoroughly before attempting to use the machine.

WARNING

Applied when there is a danger of the user being injured or when there is a damage of both the user being injured and the equipment being damaged if the approved procedure is not observed.

CAUTION

Applied when there is a danger of the equipment being damaged, if the approved procedure is not observed.

NOTE

The Note is used to indicate supplementary information other than Warning and Caution.

Q Read this manual carefully, and store it in a safe place.

PREFACE

Description of this manual

1.DISPLAY AND OPERATION

This chapter covers those items, displayed on the CRT, that are related to maintenance. A list of all supported operations (CRT and DPL) is also provided at the end of this chapter.

2.HARDWARE

This chapter covers hardware–related items, including the hardware configuration, connection, and Power Mate status indicated on printed circuit boards. A list of all units is also provided as well as an explanation of how to replace each unit.

3.INPUT AND OUTPUT OF DATA

This chapter describes the input/output of data, including programs, parameters, and tool compensation data, as well as the input/output procedures.

4. INTERFACE BETWEEN NC AND PMC

This chapter describes the PMC specifications, the system configuration, and the signals used by the PMC.

5.DIGITAL SERVO

This chapter describes the servo tuning screen and how to adjust the reference position return position.

6.TROUBLE SHOOTING

This chapter describes the procedures to be followed in the event of certain problems occurring, for example, if the power cannot be turned on or if automatic operation cannot be performed. Countermeasures to be applied in the event of alarms being output are also described.

APPENDIX

The appendix consists of a list of all alarms, as well as a list of maintenance parts. The I/O Unit–MODEL A is also described.

This manual does not provide a parameter list. If necessary, refer to the Connection Manual (B–62683EN).

This manual describes all optional functions. Refer to the manual provided by the machine tool builder for details of any options with which the installed machine tool is provided.

This manual describes following function.

The models covered by this manual, and their abbreviations, are :

Product Name	Abbreviations
Power Mate-MODEL H	Power Mate–H
	Power Mate

Related manuals

The table below lists manuals related to the Power Mate–H. In the table, this manual is marked with an asterisk(*).

Table 1 Manuals related to the Power Mate-H

Manual name	Specification Number	
FANUC Power Mate–MODEL H DESCRIPTIONS	B–62682EN	
FANUC Power Mate–MODEL H CONNECTION MANUAL	B–62683EN	
FANUC Power Mate–MODEL H OPERATOR'S MANUAL	B–62684EN	
FANUC Power Mate–MODEL H MAINTENANCE MANUAL	B–62685EN	*

For specifications and maintenance of FANUC SERVO MOTOR α series and β series, refer to the following manuals:

Document name	Document number	Major contents	Major usage	
FANUC AC SERVO MOTOR α series DESCRIPTIONS	B–65142E	 Specification Characteristics External dimensions Connections 	Selection of motorConnection of motor	
FANUC CONTROL MOTOR AMPLIFIER α series DESCRIPTIONS	B-65162E	 Specifications and functions Installation External dimensions and maintenance area Connections 	 Selection of amplifier Connection of amplifier 	
FANUC CONTROL MOTOR α series MAINTENANCE MANUAL	B–65165E	 Start up procedure Troubleshooting Maintenance of motor 	 Start up the system (Hardware) Troubleshooting Maintenance of motor 	
FANUC AC SERVO MOTOR α series PARAMETER MANUAL	B-65150E	 Initial setting Setting parameters Description of parameters 	 Start up the system (Software) Turning the system (Parameters) 	
FANUC SERVO MOTOR β series DESCRIPTIONS	B–65232EN	 Specification Characteristics External dimensions Connections 	Selection of motorConnection of motor	

Table of Contents

DE	EFIN		OF WARNING, CAUTION, AND NOTE	s–1
PF	REF	ACE		p–1
1.	DIS	BPLAY A	AND OPERATION	1
	1.1	FUNCT	TON KEYS AND SOFT KEYS	2
		1.1.1	Soft Keys	2
		1.1.2	DPL/MDI	15
	1.2	CONFI	GURATION DISPLAY OF SOFTWARE	17
		1.2.1	CRT/MDI	17
		1.2.2	DPL/MDI	18
	1.3	SYSTE	M CONFIGURATION SCREEN	19
		1.3.1	Display Method	19
		1.3.2	Software Configuration Screen	19
		1.3.3	Module Configuration Screen	20
	1.4	ALARN	M HISTORY SCREEN	21
		1.4.1	General	21
		1.4.2	Screen Display	21
		1.4.3	Clearing Alarm History	21
		1.4.4	Display of Special Alarms	21
	1.5	HELP F	FUNCTION	22
		1.5.1	General	22
		1.5.2		22
	1.6	DISPLA	AYING DIAGNOSTIC PAGE	25
		1.6.1	Displaying of CRT/MDI	25
		1.6.2	Contents Displayed (Common)	25 25
		1.6.4	Contens Displayed (Common)	25
	17	POWEI	R MATE STATUS DISPLAY	29
	1.0			20
	1.0	UPEKA	Server Director	20
		1.8.1	Setting the Input Signal or Output Signal to be Recorded in the Operation History	30
		1.8.3	Notes	37
	19	LIST O	F OPER ATIONS (CRT/MDI)	38
	1 10	LISTO		41
	1.10	LISTO	F OPERATIONS (DPL/MDI)	41
2.	HA	RDWAF	RE	44
	2.1	TOTAL	CONNECTION DIAGRAM	45
	2.2	INSTAI	LLATION	47
		2.2.1	Environmental Requirement	47
		2.2.2	Power Capacity	48
		2.2.3	Action Against Noise	48
	2.3	INTER	-MACHINE CONNECTION	55
		2.3.1	CRT/MDI Unit	55
		2.3.2	Reader/Puncher Interface	59
		2.3.3	External Pulse Input Interface	60
		2.3.4	I/O Link	62
		2.3.5	Servo Interface	64
		2.3.0	DELANDI INTERTACE	65
		2.3.7	Handy Operator's Panel Interface	68
			······································	55

		2.3.9	Touch Panel Interface	71
	2.4	LED D	DISPLAY/ SETTING AND MODULE CONFIGURATION OF UNIT	72
		241	LED Display of Control Unit	72
		2.4.2	Connector and Signal Name	73
		2.4.3	Fuse of Controller	73
		2.4.4	Battery of Controller	74
		2.4.5	Rotary Switch RSW	74
		2.4.6	Rotary Switch MTSW	75
		2.4.7	Location of Modules and Internal PC Boards	76
		2.4.8	LED display of I/O Link Connection Unit	78
	2.5	LIST (DE PC BOARD AND UNIT	79
	2.5	251	Regio Unit	70
		2.5.1	Control Unit PC Roard	79
		2.5.2	Module	70
		2.5.5	CRT/MDL DPL /MDL Unit	80
		2.5.4	CRT/MDL DPL /MDL PC Roard	81
	26			01
	2.0	ноw	IO REPLACE THE DATTERIES	02
		2.6.1	Replace the Battery for Memory Back Up	82
		2.6.2	Replacing Batteries for Absolute Pulse Coder (Servo Amplifier Built_in Type Battery/Servo Amplifier α Series)	84
		263	Replacing Batteries for Absolute Pulse Coder (ß Series Servo Amp Module/Built-in Type Battery)	85
		2.6.4	Replacing Batteries for Absolute Pulse Coder (Separate Battery Case)	86
	27	LOW		80
	2.1	0.7.1	D .	00
		2.7.1	Removing	88
	•	2.7.2		88
	2.8	REPLA	ACING PRINTED CIRCUIT BOARD AND UNIT	90
		2.8.1	The Base Printed Circuit Boards	90
		2.8.2	The Power Supply Printed Circuit Boards and Sub PC Board	91
		2.8.3	The Fan Motor	92
		2.8.4	The CRT Control Printed Circuit Board	92
		2.8.5	The MDI Keyboard	92
		2.8.6	The CRT Display	93
	2.9	MAIN	TENANCE OF HEAT PIPE TYPE HEAT EXCHANGER	94
	2.10	REPLA	ACING THE FUSE	97
		2.10.1	The Power Mate Controller Fuse	97
		2.10.2	The CRT/MDI Control PCB Fuse	98
		2.10.3	The I/O Card Fuses	99
		2.10.4	The I/O Unit-MODEL A Fuses	100
		2.10.5	Replacing the DPL/MDI Switcher Fuses	101
		2.10.6	Replacing the LCD Fuse	102
	2.11	ADJUS	STING THE PLASMA DISPLAY	103
		2.11.1	Adjusting the Color Liquid Crystal Display and Plasma Display	103
	2 12	7 2_IN	CH MONOCHROME I CD ADIUSTMENT	104
	2.12			104
	2.13	REPLA	ACING THE LCD BAKLIGHT	106
_				
3.	INF	PUT AN	ID OUTPUT OF DATA	107
	3.1	SETTI	NG PARAMETERS FOR INPUT/OUTPUT	108
	30	INDUT	TING/ OUTPUTTING DATA	111
	5.4	2.2.1	Confirming the Deremeters Deriving for Data in anti-	111
		3.2.1 3.2.2	Outputting Parameters	111
		3.2.2 3.2.2	Outputting PMC Decemeters	112
		3.2.3 3.2.1	Outputting Custom Macro Variable Values	113
		3.2.4	Outputting Tool Compensation Amount	114
		5.4.5		114

		3.2.6	Outputting Part Program	115
		3.2.7	Outputting Ladder Programs	116
		3.2.8	Inputting CNC Parameters	117
		3.2.9	Inputting PMC Parameters	119
		3.2.10	Inputting Custom Macro Variable Values	120
		3.2.11	Inputting Tool Compensation Amount	121
		3.2.12	Inputting Part Programs	122
		3.2.13	Inputting PMC Ladder	123
4.	ΙΝΤ	ERFAC	CE BETWEEN NC AND PMC	124
	4.1	GENE	RAL OF INTERFACE	125
	4.2	SPECI	FICATION OF PMC	126
		4.2.1	Specification	126
		4.2.2	Address	127
		4.2.3	Built-in Debug Function	127
		4.2.4	System Reserve Area of Internal Relay	128
		4.2.5	Execution Period of PMC	128
	4.3	OPER/	ATION ON THE CRT/MDI	129
		4.3.1	Display Method	129
		4.3.2	PMCLAD SCREEN	130
		4.3.3	PMCDGN SCREEN	131
		4.3.4	PMCRAM Screen	135
	4.4	OPER/	ATION ON THE DPL/MDI	140
		4.4.1	Selectingthe PMC Programmer Menu	142
		4.4.2	Setting and Displaying System Parameters (SYSTEM PARAM)	142
		4.4.3	Editing the Sequence Program (Edit)	143
		4.4.4	Editing Ladder Mnemonics	143
		4.4.5	Starting and Stopping the Sequence Program (Run/Stop)	148
		4.4.6	Error Messages (for Ladder Mnemonics Editing)	148
		4.4.7	Input/Output Ladder/PMC parameter by DPL/MDL	149
		4.4.8 4 4 9	On-line Debugging Function	150
		4.4.10	Error List	153
	45	LIST C	DE SIGNALS BY FACH MODE	154
	1.5			151
	4.0	ADDK	E22 [12]	150
	4.7	SIGNA	AL AND SYMBOL CORRESPONDENCE TABLE	164
5.	DIC	SITAL S	SERVO	169
	5 1		I SETTING SERVO DARAMETERS	170
	5.1			170
	5.2	SERVO	J TUNING SCREEN	1/4
		5.2.1	Parameter Setting	174
		5.2.2		1/4
	5.3	ADJUS	STING REFERENCE POSITION (DOG METHOD)	177
		5.3.1	General	177
	5.4	DOGL	ESS REFERENCE POSITION SETTING	179
		5.4.1	General	179
		5.4.2	Operation	179
		5.4.3	Associated Parameters	180
6.	TR	OUBLE		181
	61	CORR	ECTIVE ACTION FOR FAILURES	183
	5.1	611	Investigating the Conditions under which Failure Occurred	182
		0.1.1	investigating the conditions under which I and to occurred	105

6.2	POWER CANNOT BE TURNED ON	185
6.3	NO MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED	186
6.4	JOG OPERATION CANNOT BE DONE	190
6.5	EXTERNAL PULSE INPUT FUNCTION (SINGLE PHASE INPUT TYPE) CANNOT BE USED	193
6.6	AUTOMATIC OPERATION CANNOT BE DONE	195
6.7	CYCLE START LED SIGNAL HAS TURNED OFF	201
6.8	WHEN MANIPULATION IS NOT POSSIBLE WITH THE CRT/MDI	203
6.9	ALARM 85 TO 87 (READER/PUNCHER INTERFACE ALARM)	205
6.10	REFERENCE POSITION DEVIATES	209
6.11	ALARM 90 (REFERENCE POSITION RETURN IS ABNORMAL)	210
6.12	ALARM 300 (REQUEST FOR REFERENCE POSITION RETURN)	213
6.13	ALARM 301 TO 305 (ABSOLUTE PULSE CODER IS FAULTY)	214
6.14	ALARM 306 TO 308 (ABSOLUTE PULSE CODER BATTERY IS LOW)	215
6.15	ALARM 350 (SERIAL PULSE CODER IS ABNORMAL)	219
6.16	ALARM 351 (SERIAL PULSE CODER COMMUNICATION IS ABNORMAL)	220
6.17	ALARM 400 (OVERLOAD)	221
6.18	ALARM 401 (*DRDY SIGNAL TURNED OFF)	223
6.19	ALARM 404 AND 405 (*DRDY SIGNAL TURNED ON, REFERENCE POSITION RETURN ABNORMAL)	225
6.20	ALARM 410 (EXCESSIVE POSITION ERROR AMOUNT DURING STOP)	226
6.21	ALRAM 411 (EXECESSIVE POSITION ERROR DURING MOVE)	227
6.22	ALARM 414 (DIGITAL SERVO SYSTEM IS ABNORMAL)	229
6.23	ALRAM 416 (DISCONNECTION ALARM)	230
6.24	ALARM 417 (DIGITAL SERVO SYSTEM IS ABNORMAL)	231
6.25	ALARM 700 (OVERHEAT AT CONTROL SIDE)	232
6.26	ALARM 900 (ROM PARITY ERROR)	233
6.27	ALARM 912 TO 913 (RAM PARITY)	235
6.28	ALARM 920 TO 922 (WATCH DOG OR RAM PARITY)	236
6.29	ALARM 924 (SERVO MODULE MOUNTING ERROR)	238
6.30	ALARM 930 (CPU ERROR)	238
6.31	ALARM 950 (PMC SYSTEM ALARM)	239
6.32	ALARM 970 (NMI ALARM IN PMC MODULE)	240
6.33	ALARM 971 (NMI ALARM IN SLC)	241
6.34	ALARM 973 (NMI ALARM BY UNKNOWN CAUSE)	242
6.35	NO SIGNAL CHANGE IN FANUC I/O LINK MASTER	243

APPENDIX

I/O	UNIT MODEL A	247
A.1	SYSTEM CONFIGURATION	248
A.2	HARDWARE CONFIGURATION	248
A.3	LED INDICATION	249
A.4	FUSES	250
	I/O A.1 A.2 A.3 A.4	I/O UNIT MODEL AA.1SYSTEM CONFIGURATIONA.2HARDWARE CONFIGURATIONA.3LED INDICATIONA.4FUSES

	A.5	REMOVING A PRINTED CIRCUIT BOARD	251
В.	AL	ARM LIST	253
C.	LIS	T OF MAINTENANCE PARTS	267
	C.1	MAINTENANCE PARTS	268
D.	MA MF	INTENANCE AND INPUT/OUTPUT OF	272
	D 1	OVERVIEW	273
	D.1	D.1.1 Starting The Boot System	273
		D.1.2 System Files and User Files	274
	D.2	SCREEN CONFIGURATION AND OPERATING PROCEDURE	275
		D.2.1 System Data Loading Screen	277
		D.2.2 System Data Check Screen	279
		D.2.3 System Data Delete Screen	281
		D.2.4 System Data Save Screen	285
		D.2.6 Memory Card File Delete Screen	288
		D.2.7 Memory Card Format Function	289
		D.2.8 Load Basic System Function	290
	D.3	ERROR MESSAGES AND REQUIRED ACTIONS	292
E.	DA	TA INPUT/OUTPUT TO AND FROM A MEMORY CARD	294
	E.1	OVERVIEW	295
	E.2	FUNCTION DESCRIPTION	296
		E.2.1 Conditions for Enabling This Function	296
		E.2.2 Output to a Memory Card	296
		E.2.3 Input from a Memory Card	297
	E.3	OPERATION	298
		E.3.1 Outputting Data to a Memory Card	298
	E 4	E.3.2 Inputting Data from a Memory Card	298
	E.4	MEMORY CARD WRITE PROTECT SWITCH	300
F.	ME	MORY CARD OPERATOR'S MANUAL	301
	F.1	OUTLINE	302
	F.2	ADVICE FOR USE	303
		F.2.1 SRAM Memory Card	303
	F.3	NAMES AND FUNCTION OF MEMORY COMPONENTS	304
	F.4	OPERATING OF MEMORY CARD	305
		F.4.1 Connection of Memory Card	305
		F.4.2 Operation	305
		F.4.3 Disconnection of Memory Card	305
	F.5	BATTERY CHANGE	306
		F.5.1 Battery	306
		F.5.3 Procedure of Battery Change	306
	F.6	SPECIFICATIONS OF MEMORY CARDS THAT ARE NOT ALLOWED TO BE USED	308
G.	NO	TATION OF MDI KEYS	309

DISPLAY AND OPERATION

This chapter describes how to display various screens by the function keys. The screens used for maintenance are respectively displayed.

- 1.1 FUNCTION KEYS AND SOFT KEYS
- 1.2 CONFIGURATION DISPLAY OF SOFTWARE
- 1.3 SYSTEM CONFIGURATION SCREEN
- 1.4 ALARM HISTORY SCREEN
- 1.5 HELP FUNCTION
- 1.6 DISPLAYING DIAGNOSTIC PAGE
- 1.7 POWER MATE STATUS DISPLAY
- **1.8 OPERATION HISTORY**
- 1.9 LIST OF OPERATIONS (CRT/MDI)
- 1.10 LIST OF OPERATIONS (DPL/MDI)

1.1.1

Soft Keys

Operations and soft key display staturs for each function key are described below:

To display a more detailed screen of CRT, PDP, LCD, handy operator's panel, press a function key followed by a soft key. Soft keys are also used for actual operations.

The following illustrates how soft key displays are changed by pressing each function key.

The sym	nbols ir	n the follow	ving figures mean as shown below :
		:	Indicates screens
		:	Indicates a screen that can be displayed by pressing a function key(*1)
[]	:	Indicates a soft key(*2)
()	:	Indicates input from the MDI panel.
	•	:	Indicates the continuous menu key (rightmost soft key).

- *1) Press function keys to switch between screens that are used frequently.
- *2) Some soft keys are not displayed depending on the option configuration.
- *3) Japanese display function is not used in the handy operator's panel.

NOTE

When the DPL/MDI panel is connected, the keys on the CRT, PDP, LCD and handy operator's panels are disabled, and their screens are restricted to those for position display.

— 2 —

B-62685EN/03







— 5 —



L

PROGRAM SCREEN	Soft key transition triggered by the function key in the MDI mode
PROG	
[PRGRM] [(OPRT)]	[BG–EDT] ⇒ See"When the soft key [BG–EDT] is pressed"
[MDI] [(OPRT)]	$ \begin{array}{c} \hline [BG-EDT] & \Longrightarrow & See "When the soft key [BG-EDT] is pressed" \\ \hline [START] & \hline [CAN] \\ \hline [EXEC] \\ \hline (Address) & - [SRH \downarrow] \\ \hline (Address) & - [SRH \uparrow] \\ \hline [REWIND] \end{array} $
[Current block display sci [CURRNT] — [(OPRT)]	reen
[Next block display scree [NEXT] [(OPRT)]	n [BG–EDT]

PROGRAM SCREEN Soft key transition triggered by the function key in the STEP, JOG, or ZRN mode
PROG Program display
[PRGRM] — [(OPRT)] — [BG-EDT] \implies See"When the soft key [BG-EDT] is pressed"
Current block display screen [CURRNT] [(OPRT)] [BG-EDT] See"When the soft key [BG-EDT] is pressed"
[Next block display screen] [NEXT] — [(OPRT)] — [BG–EDT] => See "When the soft key [BG–EDT] is pressed"

1. DISPLAY AND OPERATION

PROGRAM SCREEN	Soft key transition triggered by the function key in the TJOG or TSTP mode
PROG Program display [PRGRM] — [(OPRT)] Program input screen	[BG–EDT] → See "When the soft key [BG–EDT] is pressed"
[MDI] [(OPRT)]	$[BG-EDT] \implies See "When the soft key [BG-EDT] is pressed"(O number) - [O SRH] \implies Return to the program(Address) - [SRH\downarrow](Address) - [SRH\downarrow][REWIND]$
[LIB] — [(OPRT)]	y - [BG–EDT] ⇒ See "When the soft key [BG–EDT] is pressed" - (O number) → [O SRH] ⇒ Return to the program











MESSAGE SCREEN Soft key transition	on triggered by the function key
MESSAGE	
Alarm display screen [ALARM]	
Message display screen [MSG]	
Alarm history screen [HISTRY] [(OPRT)]	
HELP SCREEN Soft key transition	on triggered by the function key
HELP	
Alarm detail screen [1 ALAM] — [(OPRT)] — [SELECT]	
Operation method screen	
[2 OPR] <u>[(OPRT)]</u> [SELECT]	

1.1.2 DPL/MDI



Fig.1.1.2 DPL/MDI Panel

(1) Function keys

Function keys indicate large items like chapters in a document.



— 15 —



Display of Alarm number and external message.

(2) Keyboard functions

Table 1.1.2 MDI Keyboard functions

Кеу	Functions		
Address /numerical key	Press these keys to input alphabetic, numeric, and other characters.		
INPUT (INPUT) key	When an address or a numerical key is pressed, the letter or the numeral is input once to the key input buffer, and it is displayed on the DPL. To input the data, press the INPUT key.		
Cancel (CAN) key	 Press this key to cancel character or sign input to the key input buffer. (Example) When the key input buffer displays N0001, N0001 is cancelled with this key. When an alarm is displayed, depressing CAN will reset the alarm message. 		
Cursor shift keys	There are two kinds of cursor shift key described below. Image: This key is used to shift the cursor a short distance in the forward direction. Image: This key is used to shift the cursor a short distance in the reverse direction.		
READ (READ) key WRITE (WRITE) key	Press this key to start I/O operation with an I/O device or memory card. Pressing a key activates the corresponding I/O device. Be careful not to press the wrong key.		

CAUTION

Press	ing	the	READ	or	WRITE	key	activates	the
corres	spon	ding	function.					
Be ca	reful	to pr	ess the	corre	ect key.			
If the	If the wrong key is pressed, data may be transferred in the					n the		
direct	ion c	ppos	ite to the	e des	sired direc	tion.		
READ	Po	wer N	late ←	I/O	device or	· mem	ory card	
	-							
WRITE	Po	wer Iv	'late →	I/O	device of	· mem	ory card	

(3) Caution on using the DPL/MDI

If the DPL/MDI, CRT (PDP, LCD)/MDI, and handy operator's panel are connected at the same time, the DPL/MDI takes precedence. The CRT (PDP, LCD)/MDI and handy operator's panel are disabled, and their functions are restricted to position display.

1.2 CONFIGURATION DISPLAY OF SOFTWARE



NOTE

If nothing appears on the screen, it indicates that the CRT/MDI has failed to start.

1.2.2 DPL/MDI

1) Upon normal start



Power Mate control software

2) When the DPL/MDI has started normally, but cannot communicate with the controller



NOTE

If nothing appears on the screen, it indicates that the DPL/MDI has failed to start.

1.3 SYSTEM CONFIGURATION SCREEN

After the system has been installed correctly, you can not display the system configuration screen. However, you can find the PCBs installed and the softwares integrated on the system configuration screen.

1.3.1 Display Method



- (2) Press soft key [system], then the system configuration screen is displayed.
- (3) The system configuration screen is composed of two screens and each
 - of them can be selected by the page key $\left| \begin{array}{c} \uparrow \\ \downarrow \end{array} \right| \left| \begin{array}{c} P^{AGE} \\ \downarrow \end{array} \right|$.

1.3.2 Software Configuration Screen

			Kind of software Software series
(SYSTEM CONFIG	G(SOFTWARE)	
	¥ ¥ SYSTEM 8880	0007	Software version
	SERVO 9050 PMC 4062	0001	Character written on
	LADDER PMA	0001	PMC title screen
	EDIT **** *** [PARMA][D(* *** GNOS 1[PMC 1[SYSTE	M 1 I

1.3.3 Module Configuration Screen

Configuration of the modules displayed on PCB.

SYSTEM CONFIG(MODULE)	01234 N56789
MODULE FLASH ROM DRAM	ТҮРЕ 2МВ 2.5МВ
PMC SCA (CRT) SERVO 1/2 AXIS SERVO 3/4 AXIS	MOUNTED 9"CRT MOUNTED <(2) MOUNTED
^	(1)
EDIT **** *** *** [PARMA][DGNOS][PMC][SYSTEM][]

Contents of display

- (1) Type of mounted module unit or hardware
- (2) Mounted or not, or type of module unit

Pressing the page keys $\begin{bmatrix} \uparrow \\ PAGE \end{bmatrix}$ $\begin{bmatrix} PAGE \\ I \end{bmatrix}$ displays the system configuration screen of other PCBs.

*Refer to "2.4.7 Location of Modules and Internal PC Boards" for correspondence with each module and display.

1.4 ALARM HISTORY SCREEN

1.4.1 Alarms generated in the Power Mate are recorded. The latest 25 alarms generated are recorded. The 26th and former alarms are deleted. General DPL/MDI can not display the alarm history screen. 1.4.2 **Screen Display** (1) Press MESSAGE key. (2) Press soft key [HISTRY] and an alarm history screen is displayed. (3) Other pages are displayed by $\left[\begin{array}{c} & \\ & \\ \end{array} \right]$ or $\left[\begin{array}{c} & \\ \end{array} \right]$ key. 00100 N00001 ALARM HISTORY 1 010 2 IMPROPER G-CODE 500 OVER TRAVEL : + X 417 SERVO ALARM : X AXIS DGTL PARAM AUTO **** *** 19:47:45 [ALARM][MSG][HISTORY][][(OPRT)] 1 Alarm No. 2 Alarm message (some contains no message) 1.4.3 (1) Press soft key [(OPRT)]. (2) Press soft key [(CLEAR], then the alarm history is cleared. **Clearing Alarm History** 1.4.4 **Display of Special** Alarms Alarms generated by Alarm numbers are 3000s and the messages are all "MACRO ALARM". custom macro (Ex) #3000=1(ERROR)⇒"3001 MACRO ALARM". • Alarms generated by Alarms of 1000s and the message is all "EXTERNAL ALARM". **DISP or DISPB** (Ex) DISP instruction A000.0 1000 ERROR1⇒"1000 EXTERNAL instruction of PMC. ALARM"

1.5 HELP FUNCTION

1.5.1 General

The help function displays alarm information, operation method and a table of contents for parameters. This function is used as a handbook. DPL/MDI and handy operator's panel can not use the help function.

1.5.2 Display Method

Display of help screen

Press |HELP| key on any screen other than PMC screen, then a help screen appears. (However, it is not available when PMC screen is displaying)

HELP (INITIAL MEN	J) 01234 N12345
***** 1. ALA 2. OPE 3. PAR	HELP **** RM DETAIL RATION METHOD AMETER TABLE
EDIT **** *** *** [1 ALAM] [2 OPE]	[3 PARA] [] []

• Help for alarm (1) When an alarm is generated, press soft key [1 ALAM], then a help message of the alarm is displayed.

```
HELP (INITIAL MENU)
                                01234 N12345
NUMBER
           : 010
M'SAGE : IMPROPER G CODE
FUNCTION :
ALARM :
 A G CODE NOT LISTED IN G-CODE TABLE
 IS BEING COMMANDED
 ALSO G-CODE FOR FUNCTION NOT ADDED
 IS BEING COMMANDED
>
EDIT **** *** ***
           [2 OPE]
                    [3 PARA] [
                                   ] [ OPRT ]
1
    ALAM
```

- (2) Pressing soft key **[OPRT]**,(alarm No.), and soft key **[SELECT]** in this order, a help message corresponding to the input alarm number is displayed.
- Help for operation
- (1) Press [2 OPR], then a menu for operation method is displayed.

```
HELP (OPERATION METHOD) 01234 N12345
1. PROGRAM EDIT
2. SEARCH
3. RESET
4. DATA INPUT WITH MDI
5. DATA INPUT WITH TAPE
6. OUTPUT
7. INPUT WITH FANUC CASSETTE
8. OUTPUT WITH FANUC CASSETTE
9. MEMORY CLEAR
>_
EDIT **** *** ***
[1 ALARM] [2 OPR] [3 PARA] [ OPRT ]
```

(2) Press **[OPRT]**, (an item number) and soft key **[SELECT]**, then an operation method of the item is displayed.

```
Pressing PAGE key
                          PAGE
                      or
                              displays another pages.
  HELP (OPERATION METHOD)
                                     01234 N12345
                                          1/4 - Current
  <<1.PROGRAM EDIT>>
                                                   page/ Total
  DELETE ALL PROGRAMS
                                                   page
    MODE :EDIT
    SCREEN : PROGRAM
    OPR :(0-9999) - (DELETE)
  DELETE ONE PROGRAM
    MODE : EDIT
    SCREEN: PROGRAM
    OPR :(0+PROGRAM NUMBER) - <DELETE>
  >___
  EDIT **** *** ***
  Γ
       1
            [
                 ]
                     [
                           ]
                               Γ
                                    1
                                         [SELECT]
```

• Parameter table

Press soft key [3 PARA], then a parameter table is displayed.

1			
(HELP (PARAMETER TABLE)	01234 N12345	
		1/4 ←	Current
	• SETTING	(NO.0000~)	page/ Total
	•READER/PUNCHER INTERFACE	(NO.0100~)	l
	•AXIS CONTROL/SETTING UNIT	(NO.1000~)	
	•COORDINATE SYSTEM	(NO.1200~)	
	• STROKE LIMIT	(NO.1300~)	
	•FEED RATE	(NO.1400~)	
	•ACCEL/DECELERATION CTRL	(NO.1600~)	
	• SERVO RELATED	(NO.1800~)	
	•DI/DO	(NO.3000~)	
	EDIT **** *** ***		
l	[1 ALAM] [2 OPR][<mark>3 PARA</mark>] [][SELECT])
	<		

Another screen can be selected by the PAGE key \bigcap_{PAGE} or \bigcup_{PAGE} .

1.6 DISPLAYING DIAGNOSTIC PAGE



1.6.3 Contents Displayed (Common)

 Causes when the machine does not travel in spite of giving a command 000 WAITING FOR FIN SIGNAL

001 MOTION

002 DWELL 003 IN–POSITION CHECK An auxiliary function is being executed. Travel command of cycle operation is being executed. Dwell is being executed. In–position check is being done.

Cause of the cycle start	004 FEEDRATE OVERRIDE 0% 005 INTERLOCK/START LOCK 010 PUNCHING 011 READING 013 JOG FEEDRATE OVERRIDE 0% 014 WAITING FOR RESET, ESP,RRW OFF 015 EXTERNAL PROGRAM NUMBER SEAF	Feedrate override is 0%. Interlock or start lock is input. Data is being output through reader/puncher interface. Data is being input through reader/puncher interface. Jog override is 0%. Power Mate is in reset state. RCH External Program Number Search								
LED turned off										
	020 CUT SPEED UP/DOWN 021 RESET BUTTON ON 022 RESET AND REWIND ON 023 EMERGENCY STOP ON 024 RESET ON 025 STOP MOTION OR DWELL	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$								
	Input of external reset signal									
	Reset button On of MDI									
	Input of reset & rewind									
	Servo alarm generation									
	Single block stop									
• State of TH alarm	030 CHARACTER NUMBER TH ALAF	M Position of the character that caused TH alarm. The position is counted from the head. Data of the character that caused TH alarm.								
Details of digital servo		110 110 111 110								
didi ili 414	Address #7 #6 #5 #4 DGN 0200 OVL LV OVC HCA	#3 #2 #1 #0 A HVA DCA FBA OFA								
 #7(OVL): Overload alarm (See DGN No. 201.) #6(LV) : Insufficient voltage alarm #5(OVC): Over current alarm #4(HCA): Abnormal current alarm #3(HVA): Overvoltage alarm #2(DCA): Regenerative discharge alarm #1(FBA): Disconnection alarm (See DGN No. 201.) #0(OFA): Overflow alarm 										
	Address #7 #6 #5 #4	#3 #2 #1 #0								
	Overload 0 Motor overheat									
	alarm 1 Amplifier overheat									
	Disconnec- tion alarm	nand)								
	0 Disconnection of puls	e coder (software)								
	DGN	Address	#7	#6 OFS	#5 MCC	#4 LDA	#3 PMS	#2	#1	#0
---	-----	---	--	--	---	---	--	--	--	--------------------------------------
		#6(OFS): #5(MCC) #4(LDA): #3(PMS):	Abno Conta Serial Feedl feedb	rmal cun acts of M l pulse c back is n ack cabl	rrent val ICC of oder LE not corre le.	lue resul servo an ED is abr ect due te	t of A/I nplifier normal o faulty	O conve is melte serial p	rsion of ed. pulse co	digital
 Detail of Alarm 350 of serial pulse coder 	DGN	Address 0202	#7	#6 CSA	#5 BLA	#4 PHA	#3 RCA	#2 BZA	#1 CKA	#0 SPH
		#6(CSA): #5(BLA): #4(PHA): #3(RCA): #2(BZA): #1(CKA) #0(SPH):	Hardy Batte Serial Serial Coun Batte Repla Serial Interr Serial	ware of a ry voltag l pulse c l pulse c ting of f ry voltag ice the b l pulse c hal clock l pulse c	serial pu ge is low oder or oder is t eedback ge becan oattery a oder is t stoppe	ulse code w (warni feedback faulty. c cable is me 0. nd set th faulty. d. feedback	er is abr ng) k cable s errone e refere k cable	ormal is erron ous. ence pos is faulty	eous. sition. 7.	
• Detail of Alarm 351 of serial pulse coder	DGN	Address 0203 [#7(DTE): #6(CRC): #5(STB):	Coun #7 DTE Comi There Comi Trans Comi Trans	ting of f #6 CRC nunicati e is no re nunicati ferred d nunicati ferred d	#5 STB STB on failu esponse on failu ata is er on failu ata is er	#4 Inter of ser for commune of ser troneous troneous troneous	#3 Fial puls municat Fial puls Fial puls	e coder. tion. e coder.	#1 (Data e (CRC e	#0 error) error) oit error)
 Position error amount 		Address	ITuno	lelled d	utu 15 01	roneous	•			
	DGN	0300 Position error=		Posit Feed rate servo loop	tion error ([mm/min] p gain [1/s	of an axis i sec]	in detectio 1 Detecti	on unit		
 Machine position 										
	DGN	Address 0301	Distanc	e from refe	erence po	sition of ar	n axis in d	etection u	ınit	
1.6.4 Contents Displayed (DPL/MDI)		The system on the DP Therefor, s Diagnostic 800 Rela 801 Skip 802 Rem	n config L/MDI see the c No. tive co positio aining	guration followin ordinate on travel	screen a ng diagr es	and the st nostic nu U L L (1	tate disp umber. Unit Least inp Least inp	olay etc. out incre out incre put incr	are not p ement ement ement)/	prepared

 804 Ending position of previous block 810 Number of program being executed 811 Number of sequence being executed 820 Group 01 G-code 821 Group 02 G-code 823 Group 05 G-code 825 Group 08 G-code 830 F-code being executed 831 Actual feedrate 831 Actual feedrate 832 Actual spindle speed 834 Actual feedrate 835 ROM version No. of NC system (Example) 01, 02, etc. 835 Servo system version No. (Example) 01, 02, etc. 835 PMC system series No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 836 PMC system version No. (Example) 01, 02, etc. 837 Ladder program No. (Example) 01, 02, etc. 838 Ladder program No. (Example) 01, 02, etc. 838 Ladder program No. (Example) 01, 02, etc. 835 PMC system series No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 836 PMC system version No. (Example) 01, 02, etc. 837 Ladder program version No. (Example) 01, 02, etc. 838 Ladder program version No. (Example) 01, 02, etc. 836 PMC system series No. (Example) 01, 02, etc. 837 Ladder program version No. (Example) 01, 02, etc. 838 Ladder program version No. (Example) 01, 02, etc. 838 Ladder program No. (Example) 01, 02, etc. 839 System RAM size (Example) 01, 02, etc. 840 System RAM size (Example) PMP (PMC-PA3 compatible) 841 Sub-PCB (Example) BIN (built-in I/O card) 	803	Acceleration/deceleration accumulation	Detection unit		
 810 Number of program being executed 811 Number of sequence being executed 820 Group 01 G-code 821 Group 02 G-code 822 Group 05 G-code 823 Group 06 G-code 825 Group 08 G-code 830 F-code being executed 831 F-code being executed 831 Actual feedrate 832 Actual spindle speed 833 Unit: mm/min, deg/min, or 0.01 inch/min.) 831 Actual spindle speed 840 Number of registered blocks 841 Amount of memory used by program 850 ROM version No. of NC system (Example) 851 ROM version No. of NC system (Example) 9060 854 Servo system series No. (Example) 90, 10, etc. 855 PMC system version No. (Example) 90, 10, etc. 855 PMC system series No. (Example) 90, 10, etc. 855 PMC system series No. (Example) 90, 10, etc. 856 PMC system series No. (Example) 90, 10, etc. 857 Ladder program No. (Example) 90, 10, 2, etc. 858 Ladder program version No. (Example) 90, 10, 2, etc. 858 Ladder program version No. (Example) 90, 10, 2, etc. 858 Ladder program No. (Example) 90, 26, etc. 858 860 PMC module (Example) 90, 10, 2, etc. 860 PMC module (Example) 90, 10, 2, etc. 87 Ladder program version No. (Example) 90, 26, etc. 860 PMC module (Example) 910, 10, 10, 20, etc. 	804	Ending position of previous block	(Least	t input increment)/2	
811Number of sequence being executed820Group 01 G-code821Group 03 G-code822Group 05 G-code823Group 06 G-code824Group 08 G-code830F-code being executedUnit: 0.001 mm/min or 0.00001 inch/m (When no decimal point is entered, units are 1 mm/min, or 0.01 inch/min.)831Actual feedrateUnit: $mm/min, deg/min, or$ 0.01 inch/min 832Actual spindle speedUnit: $trpm$ 840Number of registered blocksUnit: Blocks841Amount of memory used by programUnit: Characters program850ROM series No. of NC system (Example) 01, 02, etc.EDIT, etc.852Operation mode (Example) 9060854Servo system version No. (Example) 90, 10, etc.855PMC system version No. (Example) 01, 02, etc.856PMC system version No. (Example) 01, 02, etc.857Ladder program No. (Example) 01, 02, etc.858Ladder program version No. (Example) 01, 02, etc.856PMC system version No. (Example) 01, 02, etc.857Ladder program version No. (Example) 01, 02, etc.858Ladder program version No. (Example) 01, 02, etc.859System RAM size (Exa	810	Number of program being executed			
 820 Group 01 G-code 821 Group 02 G-code 822 Group 05 G-code 824 Group 08 G-code 825 Group 08 G-code 830 F-code being executed 831 F-code being executed 831 Actual feedrate 832 Actual spindle speed 834 Amount of memory used by 835 ROM version No. of NC system (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 835 PMC system version No. (Example) 01, 02, etc. 836 PMC system version No. (Example) 01, 02, etc. 836 PMC system version No. (Example) 01, 02, etc. 837 Ladder program No. (Example) 01, 02, etc. 838 PMC system version No. (Example) 01, 02, etc. 836 PMC system version No. (Example) 01, 02, etc. 837 Ladder program version No. (Example) 01, 02, etc. 838 Ladder program No. (Example) 01, 02, etc. 845 PMC module (Example) PMP (PMC-PA3 compatible) 846 Sub-PCB (Example) PMP (bmt-pha3 compatible) 	811	Number of sequence being executed			
 821 Group 02 G-code 822 Group 03 G-code 823 Group 05 G-code 824 Group 08 G-code 830 F-code being executed 830 F-code being executed 831 F-code being executed 831 Actual feedrate 832 Actual spindle speed 832 Actual spindle speed 8341 Amount of memory used by unit: mm/min, deg/min, or 0.01 inch/min 832 Actual spindle speed 841 Amount of memory used by unit: Blocks 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) 01, 02, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 Songram No. (Example) 01, 02, etc. 858 Ladder program No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	820	Group 01 G-code			
 822 Group 03 G-code 823 Group 05 G-code 824 Group 08 G-code 825 Group 08 G-code 830 F-code being executed 831 F-code being executed 831 Actual feedrate 831 Actual feedrate 832 Actual spindle speed 834 Number of registered blocks 835 ROM series No. of NC system (Example) 01, 02, etc. 835 ROM version No. of NC system (Example) 01, 02, etc. 835 Servo system version No. (Example) 09, 10, etc. 855 PMC system version No. (Example) 01, 02, etc. 857 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 PMC system version No. (Example) 01, 02, etc. 857 PMC system version No. (Example) 01, 02, etc. 858 PMC system version No. (Example) 01, 02, etc. 857 PMC system version No. (Example) 01, 02, etc. 858 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 Ladder program version No. (Example) 01, 02, etc. 858 Serve RAM size (Example) 01, 02, etc. 858 Ladder program Version No. (Example) 01, 02, etc. 858 Ladder program No. (Example) 01, 02, etc. 858 Ladder program No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	821	Group 02 G–code			
 823 Group 05 G-code 824 Group 06 G-code 825 Group 08 G-code 830 F-code being executed 831 F-code being executed 831 Actual feedrate 832 Actual spindle speed 832 Actual spindle speed 834 Amount of memory used by 835 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) 9060 854 Servo system version No. (Example) 4075 856 PMC system version No. (Example) 4075 857 Ladder program No. (Example) 1, 02, etc. 857 Ladder program No. (Example) 10, 02, etc. 858 858 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	822	Group 03 G–code			
 824 Group 06 G-code 825 Group 08 G-code 830 F-code being executed Unit: 0.001 mm/min or 0.00001 inch/m (When no decimal point is entered, units are 1 mm/min or 0.01 inch/min.) 831 Actual feedrate Unit: mm/min, deg/min, or 0.01 inch/min.) 832 Actual spindle speed Unit: mm/min, deg/min, or 0.01 inch/min 840 Number of registered blocks Unit: Blocks 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) 9060 854 Servo system version No. (Example) 90, 10, etc. 855 PMC system version No. (Example) 01, 02, etc. 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 Ladder program No. (Example) 01, 02, etc. 857 Ladder program version No. (Example) 01, 02, etc. 858 Actual error system version No. (Example) 01, 02, etc. 859 System RAM size (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) BIN (built-in I/O card) 	823	Group 05 G–code			
 825 Group 08 G-code 830 F-code being executed Unit: 0.001 mm/min or 0.00001 inch/m (When no decimal point is entered, units are 1 mm/min or 0.01 inch/min.) 831 Actual feedrate Unit: mm/min, deg/min, or 0.01 inch/min.) 832 Actual spindle speed Unit: rpm 840 Number of registered blocks Unit: Blocks 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 10, 02, etc. 858 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 10, 02, etc. 858 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 51, 02, etc. 858 PMC system Refies No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 860 Sub-PCB (Example) BIN (built-in I/O card) 	824	Group 06 G–code			
 830 F-code being executed Unit: 0.001 mm/min or 0.00001 inch/m (When no decimal point is entered, units are 1 mm/min or 0.01 inch/min.) 831 Actual feedrate Unit: mm/min, deg/min, or 0.01 inch/min.) 831 Actual spindle speed Unit: mm/min, deg/min, or 0.01 inch/min 832 Actual spindle speed Unit: rpm 840 Number of registered blocks Unit: Blocks 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system version No. (Example) 9060 854 Servo system version No. (Example) 4075 856 PMC system version No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 Ladder program No. (Example) 01, 02, etc. 859 System RAM size (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	825	Group 08 G–code			
 (When no decimal point is entered, units are 1 mm/min or 0.01 inch/min.) 831 Actual feedrate Wnit: mm/min, deg/min, or 0.01 inch/min 832 Actual spindle speed Wnit: rpm 840 Number of registered blocks 841 Amount of memory used by Wnit: Blocks 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system version No. (Example) 0960 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 01, 02, etc. 850 PMC module (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	830	F-code being executed	Unit:	0.001 mm/min or 0.00001 inch/m	
 831 Actual feedrate 831 Actual feedrate 832 Actual spindle speed 832 Actual spindle speed 834 Number of registered blocks 840 Number of registered blocks 841 Amount of memory used by 841 Unit: rpm 840 Number of registered blocks 841 Amount of memory used by 841 Unit: Blocks 841 Amount of memory used by 843 Unit: Characters 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system version No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 			(When entered	n no decimal point is ed, units are 1 mm/min 1 inch/min)	
 651 Freductive Control for the first second secon	831	Actual feedrate	Unit.	mm/min_deg/min_or	
 832 Actual spindle speed Unit: rpm 840 Number of registered blocks Unit: Blocks 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system version No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 Ladder program version No. (Example) 01, 02, etc. 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	0.51	Actual recurate	Unit.	0.01 inch/min	
 840 Number of registered blocks Unit: Blocks 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) 01, 02, etc. 858 Ladder program version No. (Example) 01, 02, etc. 858 Ladder program version No. (Example) 01, 02, etc. 858 Ladder program version No. (Example) 01, 02, etc. 858 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	832	Actual spindle speed	Unit:	rpm	
 841 Amount of memory used by Unit: Characters program 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	840	Number of registered blocks	Unit:	Blocks	
program850ROM series No. of NC system (Example)880851ROM version No. of NC system (Example)01, 02, etc.852Operation mode (Example)AUTO, JOG, STEP, EDIT, etc.853Servo system series No. (Example)9060854Servo system version No. (Example)09, 10, etc.855PMC system series No. (Example)4075856PMC system version No. (Example)01, 02, etc.857Ladder program No. (Example)858Ladder program version No. (Example)858Ladder program version No. (Example)859System RAM size (Example)859System RAM size (Example)860PMC module 	841	Amount of memory used by	Unit:	Characters	
 850 ROM series No. of NC system (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 		program			
 (Example) 8880 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	850	ROM series No. of NC system			
 851 ROM version No. of NC system (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 		(Example) 8880			
 (Example) 01, 02, etc. 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	851	ROM version No. of NC system			
 852 Operation mode (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 		(Example) 01, 02, etc.			
 (Example) AUTO, JOG, STEP, EDIT, etc. 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	852	Operation mode			
 853 Servo system series No. (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 		(Example) AUTO, JOG, STEP	, EDIT	, etc.	
 (Example) 9060 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	853	Servo system series No.			
 854 Servo system version No. (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 		(Example) 9060			
 (Example) 09, 10, etc. 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	854	Servo system version No.			
 855 PMC system series No. (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	0	(Example) 09, 10, etc.			
 (Example) 4075 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	855	PMC system series No.			
 856 PMC system version No. (Example) 01, 02, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	056	(Example) 4075			
 (Example) 61, 62, etc. 857 Ladder program No. (Example) FL01 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	830	(Example) 01 02 etc			
 (Example) FL01 kather program version No. (Example) 01, 02, etc. System RAM size (Example) 256K PMC module (Example) PMP (PMC-PA3 compatible) Sub-PCB (Example) BIN (built-in I/O card) 	857	(Example) 01, 02, etc.			
 858 Ladder program version No. (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	057	(Example) FL 01			
 (Example) 01, 02, etc. 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	858	Ladder program version No			
 859 System RAM size (Example) 256K 860 PMC module (Example) PMP (PMC-PA3 compatible) 861 Sub-PCB (Example) BIN (built-in I/O card) 	050	(Example) 01, 02, etc.			
(Example) 256K 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card)	859	System RAM size			
 860 PMC module (Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card) 	/	(Example) 256K			
(Example) PMP (PMC–PA3 compatible) 861 Sub–PCB (Example) BIN (built–in I/O card)	860	PMC module			
861 Sub–PCB (Example) BIN (built–in I/O card)		(Example) PMP (PMC–PA3 co	ompati	ble)	
(Example) BIN (built-in I/O card)	861	Sub–PCB			
		(Example) BIN (built-in I/O ca	ard)		

1.7 Power Mate STATUS DISPLAY

See the diagnostic screen for the DPL/MDI.



1.8	This function displays the key and signal operations performed by the NC
OPERATION HISTORY	operator upon the occurrence of a fault or the output of an NC alarm.
	together with the corresponding NC alarms.
	Operation history information cannot be displayed on the DPL/MDI.
	This function records the following data:
	(1) MDI key operations performed by the NC operator
	(2) Status changes (ON/OFF) of input and output signals (selected signals only)
	(3) Details of NC alarms

(3) Details of NC alarms

1.8.1

- Screen Display
- Displaying the operation history
- (1) Press the SYSTEM function key.
- (2) Press the continue menu key [\triangleright]. The **[OPEHIS]** (operation history) soft key are displayed.
- (3) Press the **[OPEHIS]** soft key twice. The operation history screen is displayed.

		N N
OPERATION HISTO	RY	01234 N12345
		Page : 123
No.DATA	No.DATA	No.DATA
01 [SF0]	11 F0000.7 ↑	21 F0001.0↓
02 [SF1]	12 F0000.5↑	22 <pos></pos>
03 <delete></delete>	13 F0001.0 [↑]	23 <prog></prog>
04 F0000.6 ^	14 F0000.5↓	24 <reset></reset>
05 MEM	15 P/S0010	25 EDIT
06 G0009.0↑	16 <pos></pos>	26 O
07 G0009.1↑	17 [SF1] 27	' 1
08 G0009.2↑	18 <prog></prog>	28 2
09 ST	19 <reset></reset>	29 3
10 st \downarrow	20 F0000.7 \downarrow	30 4
EDIT **** ***	* * *	
[TOP][BOTT	ОМ][][][PG.SRH]

On the operation history screen, the soft keys are configured as shown below:

\Rightarrow [\triangleright]	PARAM	[DGNOS]	[PMC]	[SYSTEM]	[(OPRT)][[>]
					↓push
[]	[]	[]	[]	[OPEHIS]	[(OPRT)][▷]
				↓ push	
[]	OPEHIS	[SG-SEL][]	[]	[(OPRT)][▷]
					↓push
[⊲][TOP] []	BOTTOM	[]	[]	[PG.SRH] [>]
		-			

(4) To display the next part of the operation history, press the page down key .Key . The next page is displayed.

To display the interface between two pages, press cursor key $| \rightarrow |$ or



. The screen is scrolled by one row.

These soft keys can also be used:

- 1) Pressing the **[TOP]** soft key displays the first page (oldest data).
- 2) Pressing the **[BOTTOM]** soft key displays the last page (latest data).
- 3) Pressing the [PG.SRH] soft key displays a specified page.
- Example) By entering 50 then pressing the [**PG.SRH**] key, page 50 is displayed.

Data displayed on the operation history screen

(1) MDI keys

Address and numeric keys are displayed after a single space.

Soft keys are displayed in square brackets ([]).

Other keys (RESET/INPUT, for example) are displayed in angle brackets (<>).

A key pressed at power-on is displayed in reverse video.

- 1) Function key: <POS>, <PROG>, <OFFSET>, etc.
- 2) Address/numeric key: A to Z, 0 to 9, ; (EOB), +, -, (, etc.
- 3) Page/cursor key: $\langle PAGE \uparrow \rangle$, $\langle CUR \downarrow \rangle$, $\langle CUR \leftarrow \rangle$
- 4) Soft key: [SF1], [SF2], etc.
- 5) Other key: <RESET>, <CAN>, etc.
- 6) Key pressed at power–on: **<RESET>**

(2) Input and output signals General signals are displayed in the following format:

 $G0000.7^{\uparrow}$



Some signals are indicated by their symbol names.

SBK \uparrow (Indicates that the single block switch is turned on.)

	Input	Name displayed		
MD1	ND2	MD4	ZRN	Name displayed
0	0	0	0	MDI
1	0	0	0	AUTO
0	1	0	0	NOMODE
1	1	0	0	EDIT
0	0	1	0	H/STEP
1	0	1	0	JOG
1	0	1	1	ZRN
0	1	1	0	TJOG
1	1	1	0	THND

Mode selection signals and rapid traverse override signals are displayed as indicated below:

Input	signal	Name displayed
RV1	RV2	
0	0	R 100%
1	0	R 50%
0	1	R 25%
1	1	R F0%

(3) NC alarms

NC alarms are displayed in reverse video.

P/S alarms, system alarms, and external alarms are displayed together with their numbers.

For other types of alarms, only the alarm type is displayed. (No details are displayed.)

Example) P/S0050, SV_ALM

- Input signal or output signal to be recorded in the operation history
- (1) P ress the SYSTEM function key.
- (2) Press the continue menu key $[\square]$. The **[OPEHIS]** (operation history) soft key is displayed.
- (3) Press the [OPEHIS] soft key, then press the [SG-SEL] soft key. The operation history signal selection screen is displayed.

OF	P_HIS	SI	GNAL	SELE	ECT				C	010	000	N0200	•)
:	No.	ADI	DRES	SIG	NAI		No.	A	DDRES	5	S	IGNAL	
	01	x00	000	000	010	000	11	G	0000		00	000001	
	02	x00	004	100	000	000	12	G	0004		00	000011	
	03	x00	800	000	011	00	13	G	8000		00	000111	
	04	x00	09	001	110	000	14	G	0003		00	0001111	
	05	x00)12	000	011	.11	15	G	0043		01	L100000	
	06	YOU	000	010	000	000	16				* *	******	
	07	YOU	004	001	100	000	17				* *	******	
	80	YOU	07	000	111	00	18				* *	******	
	09	YOU	800	000	111	00	19				* *	******	
	10	Y00	010	000	111	.00	20				* 1	******	
	>												
	EDI	т	****	***	*	* *							
[0	PEHI	S]	ISG-S	EL	Γ]	[1	[(OPRT)	1)

1.8.2

Setting the Input Signal or Output Signal to be **Recorded** in the **Operation History**

(1) On the operation history signal selection screen, press the [(OPRT)] soft key.

OP_HIS	S SIGNA	L SELECT		01000 N02000	
No.	ADDRES	SIGNAL	No.	ADDRES SIGNAL	
01	G0004	000000 <mark>1</mark> 0	11	* * * * * * *	
02		******	12	******	
03		******	13	* * * * * * *	
04		******	14	* * * * * * *	
05		******	15	* * * * * * *	
06		******	16	* * * * * * *	
07		******	17	* * * * * * *	
08		******	18	* * * * * * *	
09		******	19	* * * * * * *	
10		******	20	******	
>					
ED)IT ***	* *** ***	***		
[ALLI	DEL][DELETE][ON:1][OFF:0][] ノ

or 🖡

(2) Press the cursor key 1 to position the cursor to a desired

position.

(3) Key in a signal type (X, G, F, or Y) and an address, then press the key.



Signal address G0004 is set in the ADDRES column. The corresponding position in the SIGNAL column is initialized to 000000000.

(4) Select the bit to be recorded.

To select all bits of the specified signal address, press the **[ON:1]** soft key while the cursor is positioned to **[00000000]**.

To select a particular bit, position the cursor to that bit by pressing the

cursor key \leftarrow or \rightarrow , then press the **[ON:1]** soft key. To cancel

a selection made by pressing the **[ON:1]** soft key or to cancel a previously selected signal, press the **[OFF:0]** soft key.

- (5) Up to 20 addresses can be specified by means of this signal selection. These addresses need not always be specified at consecutive positions, starting from No.1.
- (6) Pressing the **[ALLDEL]** and **[EXEC]** soft keys deletes all data. If the **[ALLDEL]** key is pressed by mistake, it can be cancelled by pressing the **[CAN]** key.
- (7) To delete a selected signal address, position the cursor to the corresponding position then press the [DELETE] and [EXEC] soft keys. In the SIGNAL column, asterisks ******* are displayed in place of the deleted data. In the ADDRES column, the corresponding position is cleared.
 If the [DELET] key is pressed by mistake, it can be cancelled by pressing the [CAN] key.
- (8) Pressing the return menu key acauses the **[OPEHIS]** (operation history) soft key to be displayed again.
- Input signals and output signals to be recorded in the history

NOTE

- 1 A cross (×) indicates that a signal will not be recorded. Also, any signal for which an address is not specified will not be recorded, either.
- 2 A circle (\bigcirc) indicates that a signal can be recorded.
- 3 A signal indicated by its symbol name will also be displayed by its symbol name.

MT	→PMC							
	#7	#6	#5	#4	#3	#2	#1	#0
X000	0	0	0	0	0	0	0	0
to								
X127	0	0	0	0	0	0	0	0
PM	C→CNC	1						
	#7	#6	#5	#4	#3	#2	#1	#0
G000	0	0	0	0	0	0	0	0
to		-	_	-	-		-	-
G003	0	0	0	0	0	0	0	0
G004	0	0	0	0	FIN	0	0	0
G005	0	0	0	0	TFIN	0	0	MFIN
G006	0	0	0	0	0	*ABS	0	0
G007	RLSOT	0	*FLUP	0	0	ST	0	0
G008	ERS	RRW	*SP	*ESP	0	0	0	*IT
G009	0	0	0	0	0	0	0	0
to	_	_	_	_	_	_	_	_
G018	0	0	0	0	0	0	0	0
G019	RT	0	0	0	0	0	0	0
G020	0	0	0	0	0	0	0	0
to G042	\bigcirc	0	0	0	0	0	0	0
G043	\bigcirc	×	0	×	×	0	0	0
G044	0	0	0	0	0	0	MLK	BDT1
G045	BDT9	BDT8	BDT7	BDT6	BDT5	BDT4	BDT3	BDT2
G046	DRN	KEY4	KEY3	KEY2	KEY1	0	SBK	0
G047	\bigcirc	0	0	0	0	0	0	0
to						1		
G060	0	0	0	0	0	0	0	0
G061	0	0	0	0	0	0	0	0
G062	0	0	0	0	0	0	0	0
to								
G099	0	0	0	0	0	0	0	0
G100	0	0	+J6	+J5	+J4	+J3	+J2	+J1
			1					

	#7	#6	#5	#4	#3	#2	#1	#0
G101	0	0	0	0	0	0	0	0
C102	$\square \bigcirc$	\cap	16	15	14	12	12	11
6102	0	0	-10	-35	-J4	-13	-JZ	-J1
G103	0	0	0	0	0	0	0	0
to			1		I			
G105	0	0	0	0	0	0	0	0
			MIC	MIC	NAL 4	MID	MIO	NALA
G106	0	0	IVII6	IVII5	MI4	IVII3	MI2	MI1
G107	0	0	0	0	0	0	0	0
G108	0	0	0	0	0	0	0	0
C100					0	0		
G109	0	0	0	0	0	0	0	0
G110	0	0	+LM6	+LM5	+LM4	+LM3	+LM2	+LM1
G111	0	0	0	0	0	0	0	0
G112			_I.M6	_I M5	_I M4	_I M3	_LM2	_I M1
0112		0	-LIVIO				-LIVIZ	
G113	0	0	0	0	0	0	0	0
to								
G125	0	0	0	0	0	0	0	0
					0)/54	0)/52	0)/50	0)/54
GI20	0	0	5060	3753	3VF4	3713	SVFZ	SVFI
G127	0	0	0	0	0	0	0	0
to			1					I
G129	0	0	0	0	0	0	0	0
							+170	
G130	0	0	*IT6	*IT5	*IT4	*IT3	*IT2	*IT1
G131	0	0	0	0	0	0	0	0
G132	0	0	+MIT6	+MIT5	+MIT4	+MIT3	+MIT2	+MIT1
G133	0	0		0	0		0	U
G134	0	0	-MIT6	-MIT5	-MIT4	-MIT3	-MIT2	-MIT1
to	0	U			0			U
G255	$\Box \cap$	\cap	0	\cap	0	0	0	\cap
0200								\smile



1.8.3 Notes

- (1) While the operation history screen is displayed, no information can be recorded to the history.
- (2) An input signal having an on/off width of up to 16 msec is not recorded in the history. Some signals are not recorded in the history.
- (3) Once the storage becomes full, old data is deleted, starting from the oldest record. Up to about 500 key information items can be recorded.
- (4) The recorded data is retained even after the power is turned off. A memory all clear operation, however, erases the recorded data.

1.9 LIST OF OPERATIONS (CRT/MDI)

Reset

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation
Resetting run hour			-	POS	[(OPRT)] [RUNPRE]→[EXEC]
Resetting no. of machined parts			-	POS	[(OPRT)] [PTSPRE]→[EXEC]
Resetting OT alarm			At Power ON	_	<p> and <can></can></p>
Resetting alarm 100			—	—	<can> and <reset></reset></can>

Registration from MDI

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Inputting parameters		Yes	MDI or E.Stop	SYSTEM (PARAM)	Parameter no. \rightarrow [NO.SRH] \rightarrow Data \rightarrow <input/> \rightarrow PWE =0 \rightarrow <reset></reset>	
Inputting offset val- ues	OFF		-	OFFSET	Offset number→[NO.SRH]→Offset value→ <input/>	
Inputting setting data	OFF		MDI	SET- TING	Setting no.→[NO.SRH]Data→ <input/>	
Input of PMC parameters, counter and data table	OFF		MDI or	SYSTEM	[PMCPRM]→[COUNTR] or [DATA]→Data→ <input/>	
Inputting PMC parameters (Timer, keep relay)		0	E.Stop	(PMC)	[PMCPRM]→[TIMER] or [KEEPRL]→Data→ <input/>	

Input/Output with External I/O

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Heading a file			EDIT	PROG	<n>→File no.→[▶]→[F SRH]→[EXEC]</n>	
Deleting a file	OFF		EDIT	PROG	<n>→File no.→[▶]→[DELETE→[EXEC]</n>	
Collating a program			EDIT	PROG	Heading a file \rightarrow <o>\rightarrowProgram number\rightarrow[(OPRT)]</o>	
					\rightarrow [\blacktriangleright] \rightarrow [READ] \rightarrow [EXEC]	

Inputting From External I/O

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Inputting parameters		0	E.Stop	SYSTEM (PARAM)	[(OPRT)]→[▶]→[READ]→[EXEC]	
Inputting PMC parame- ters and ladder pro- grams		0	E.Stop	SYSTEM (PMC)	[▶]→[I/O]→(CHANNEL NO)<1> <input/> →(DEVICE NAME) [FDCAS]→(KIND OF DATA) [PARAM]→[READ]→(FILE NO) File no. <input/> →[EXEC]	
Inputting offset values	OFF		EDIT	OFFSET	(Heading a file no.)→[(OPRT)]→[►]→[READ]→[EXEC]	

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Registering a program	OFF		EDIT	PROG	$\langle N \rangle \rightarrow File no. \rightarrow \langle INPUT \rangle \rightarrow [\blacktriangleright] \rightarrow [READ] \rightarrow [EXEC]$	
Inputting macro vari- ables	OFF		EDIT	PROG	<n>→File no.→<input/>→[▶]→<o>→Program no. → [READ]→[EXEC]</o></n>	
			AUTO	PROG	<start></start>	

Output to External I/O

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Output of parameter			EDIT	SYSTEM (PARAM)	[(OPRT)]→[▶]→[PUNCH]→[EXEC]	
Output of PMC parameter			EDIT	SYSTEM (PMC)	[▶] \rightarrow [I/O] \rightarrow (CANNEL NO)<1> <input/> \rightarrow (DEVICE NAME) [FDCAS] \rightarrow (KIND OF DATA) [PARAM] \rightarrow [WRITE] \rightarrow (FILE NO) <-> <1> <input/> \rightarrow [EXEC]	
Output of ladder pro- grams			EDIT	SYSTEM (PMC)	$[▶] \rightarrow [I/O] \rightarrow (CANNEL NO) <1> \rightarrow (DEVICE NAME) [FDCAS] \rightarrow (KIND OF DATA) [PARAM] \rightarrow [WRITE] \rightarrow (FILE NO) <-> <1> \rightarrow [EXEC]$	
Output of offset			EDIT	OFFSET	[(OPRT)]→[▶]→[PUNCH]→[EXEC]	
Output of all pro- grams			EDIT	PROG	<0>→-9999→[▶]→[PUNCH]→[EXEC]	
Output of one pro- gram			EDIT	PROG	<o>→Program no.→[►]→[PUNCH]→[EXEC]</o>	
Output of macro variables			EDIT	OFFSET	$[\blacktriangleright] \rightarrow [MACRO] \rightarrow [(OPRT)] \rightarrow [\blacktriangleright] \rightarrow [PUNCH] \rightarrow [EXEC]$	

Search

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Searching a pro- gram number			AUTO or EDIT	PROG	<o>→Program no.→[O SRH]</o>	
Searching a sequence number			AUTO	PROG	Program no. search→ <n>→Sequence number→[NSRF</n>	
Searching an address word			EDIT	PROG	Data to be searched \rightarrow [SRH [↑]] or[SRH [↓]] or < [↑] > < [↓] > (cursor key)	
Searching an address only			EDIT	PROG	Address to be searched [SRH [↑]] or [SRH [↓]] or < ^> < +>	
Searching an offset number			-	OFFSET	Offset no.→[NO.SRH]	
Searching a diag- nostic number			-	SYSTEM (DGNOS)	Diagnostic number→[NO.SRH]	
Searching a param- eter number			_	SYSTEM (PARAM)	Parameter no.→[NO.SRH]	

Edit

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation
Display of memory capacity used			EDIT	PROG	[LIB]
Deleting all pro- grams	OFF		EDIT	PROG	<o>→-9999→<delete></delete></o>

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Deleting a program	OFF		EDIT	PROG	<o>→Program no.→<delete></delete></o>	
Deleting several blocks	OFF		EDIT	PROG	\rightarrow Sequence no. \rightarrow <delete> (Deleted up to a block with a specified sequence no.)</delete>	
Deleting a block	OFF		EDIT	PROG <eob>→<delete></delete></eob>		
Deleting a word	OFF		EDIT	PROG	Searching a word to be deleted→ <delete></delete>	
Changing a word	OFF		EDIT	PROG	Searching a word to be changed \rightarrow New Data \rightarrow <alter></alter>	
Inserting a word	OFF		EDIT	PROG	Searching a word immediately before a word to be searched \rightarrow New Data \rightarrow <insert></insert>	

Collation

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation	
Collating programs	ON		EDIT	PROG	[(OPRT)]→[►]→[READ]→[EXEC]	

Playback

Function	Data protec- tion key	Parame- ter write=1	Mode	Function button	Operation
Input of NC data			TEACH IN JOG/ HANDLE	PROG	Jog the machine \rightarrow <x>,<y> or <z>\rightarrow<insert> \rightarrow NC data \rightarrow <insert> \rightarrow <eob> \rightarrow <insert></insert></eob></insert></insert></z></y></x>

Clear

Function	Data prote- ction key	Parame- ter write=1	Mode	Function key	Operation
Memory all clear			At power ON		<reset>AND<delete> or <7> and <9></delete></reset>
Parameter/offset clear		0	At Power ON		<reset></reset>
Clearing a program		0	At Power ON		<delete></delete>
Alarm No. PS101 clear			_		<prog>AND<reset></reset></prog>
Parameter clear			At Power ON		<x>AND<o></o></x>

NOTE

- 1 After completion of ladder program input the power must be turned on again because the Ladder program is in halt state.
- 2 The above operating procedure also applies to the LCD, PDP, detachable LCD/MDI, and handy operator's panel. Note, however, that the handy operator's panel does not support some functions.

1.10 LIST OF OPERATIONS (DPL/MDI)

Classifi- cation	Function	KEY SW	SETTING PWE=1	Mode	Function key	Operation
Clear	All memory clear			Power ON	-	<7>AND<9>
	Parameter clear		0	Power ON	-	<param/>
	Program clear		0	Power ON	-	<delete></delete>
	Alarm clear			-		<can> or Power OFF/ON</can>
	Alarm No. P/S101 clear			-	-	<can>AND<alarm></alarm></can>
1	PMC parameter clear			Power ON	-	<o>AND<x></x></o>
Reset	OT alarm reset			Power ON	-	<p>AND<can></can></p>
Registra- tion from MDI	Parameter input		0	-	DGNOS/ PARAM	PARAM screen– [No.] \rightarrow Number \rightarrow <input/> \rightarrow Data \rightarrow <input/> \rightarrow PWE=0 \rightarrow <can></can>
	PMC parameter input		SETTING DWE=1	-	DGNOS/ PARAM	DGNOS screen \rightarrow [PMC address] \rightarrow Number \rightarrow <input/> Data \rightarrow <input/>
	Setting data input			-	VAR	Setting data screen→Cursor movement→Data→ <input/>
	Offset data input	0		-	VAR	Offset data screen – [No.]→Data number→ <input/> Data→ <input/>
	Macro variable data input	0		-	VAR	Macro variable scree – [No.]→ Data number <input/> Data→ <input/>
Search	Program number search			EDIT/ AUTO	PRGRM	$<$ O> \rightarrow Program number \rightarrow [\downarrow]
	Sequence number search			AUTO	PRGRM	After program number search; $\langle N \rangle \rightarrow Sequence number \rightarrow [\downarrow]$
	Address word search			EDIT	PRGRM	Word to be searched for \rightarrow [\downarrow]
	Search address only			EDIT	PRGRM	Address to be searched for \rightarrow [\downarrow]
	Parameter search			-	DGNOS/ PARAM	PARAM screen \rightarrow [No.] \rightarrow Number \rightarrow <input/>
	PMC parameter search			-	DGNOS/ PARAM	DGNOS screen→[PMC address] →Number→ <input/>
	Offset data search			-	VAR	Offset screen→[No.]→ Data number→ <input/>
	Macro variable data search			-	VAR	Macro variable screen→[No.]→ Data number→ <input/>
	Diagnosis search			_	DGNOS/ PARAM	DGNOS screen – [No.] \rightarrow Number \rightarrow <input/>

Classifi- cation	Function	KEY SW	SETTING PWE=1	Mode	Function key	Operation
Editing	All program delete	0		EDIT	PRGRM	$<$ O> \rightarrow –9999 \rightarrow <delete></delete>
	One program delete	0		EDIT	PRGRM	<o>→Program number→ <delete></delete></o>
	Multiple block delete	0		EDIT	PRGRM	<n>→Sequence number→ <delete></delete></n>
	One block delete	0		EDIT	PRGRM	<eob></eob>
	Word delete	0		EDIT	PRGRM	Search for word to be deleted \rightarrow <delete></delete>
	Word change	0		EDIT	PRGRM	After searching for word be deleted; New data \rightarrow <alter></alter>
	Word insertion	0		EDIT	PRGRM	After searching for word after which word is to be inserted; New data \rightarrow <insert></insert>
Collation	Program collation			EDIT	PRGRM	<read></read>
Registra- tion from extemal	Parameter input		0	EDIT or emergency stop	DGNOS/ PARAM	PARAM screen→ <read></read>
1/0	Program input	0		EDIT	PRGRM	<read></read>
	Offset data input	0		EDIT	VAR	Offset data screen→ <read></read>
	Macro variable data input	0		EDIT	PRGRM	$<$ READ> \rightarrow Mode AUTO \rightarrow Execute the loaded program.
Output to extemal	Parameter output			EDIT	DGNOS/ PARAM	PARAM screen → <write></write>
1/0	All program output			EDIT	PRGRM	<o>→−9999→<write></write></o>
	One program output			EDIT	PRGRM	<o>→Program number→ <write></write></o>
	Offset data output			EDIT	VAR	Offset screen→ <write></write>
	Macro variable data output			EDIT	VAR	Macro variable screen \rightarrow
Input/ output to and from P–G and PG–mate	Ladder program input/ output			_	DGNOS/ PARAM	DGNOS screen→ <read> or <write>→Operation on host Input/output is automatically iden- tified with operation on host. (The baud rate is fixed to 9600 bps.)</write></read>

Classifi- cation	Function	KEY SW	SETTING PWE=1	Mode	Function key	Operation
Input/ out- put to and	Program registration	0		EDIT	PRGRM	\rightarrow File number – $<$ READ $>\rightarrow$ $<$ READ $>$
from FANLIC	All program output			EDIT	PRGRM	<o>→9999→<write></write></o>
cassette	One program output			EDIT	PRGRM	<o>→Program number→ <write></write></o>
	Search for beginning of file			EDIT	PRGRM	<n>→Program number, –9999, or –9998→<read></read></n>
	File delete	0		EDIT	PRGRM	<n>→File number→<write></write></n>
	Program collation			EDIT	PRGRM	\rightarrow File number \rightarrow <read>\rightarrow<read></read></read>
	PMC parameter Ladder program input		O (Only when PMC parameter is input)	Emergency stop	DGNOS/ PARAM	DGNOS screen→ <no.> File number→<read> Data type is automatically identi- fied. (The baud rate is fixed to 4800 bps.)</read></no.>
	PMC parameter output			EDIT	DGNOS/ PARAM	PMC parameter display→ <no.> File number→<write></write></no.>
	Ladder program output			-	DGNOS/ PARAM	DGNOS screen→ <no.> File number→<write></write></no.>

NOTE

After completion of ladder program input, the power must be turned on again because the ladder program is in halt state.

2 HARDWARE

This chapter describes structure of CNC control section, connection of units and the functions of PCBs and modules mounted on PCBs.

- 2.1 TOTAL CONNECTION DIAGRAM
- 2.2 INSTALLATION
- 2.3 INTER-MACHINE CONNECTION
- 2.4 LED DISPLAY/SETTING AND MODULE CONFIGURATION OF UNIT
- 2.5 LIST OF PC BOARD AND UNIT
- 2.6 HOW TO REPLACE THE BATTERIES
- 2.7 HOW TO REPLACE THE MODULES
- 2.8 REPLACING P.C.BOARD AND UNIT
- 2.9 MAINTENANCE OF HEAT PIPE TYPE HEAT EXCHANGER
- 2.10 REPLACING THE FUSE
- 2.11 ADJUSTING THE PLASMA DISPLAY
- 2.12 7.2-INCH MONOCHROME LCD ADJUSTMENT
- 2.13 REPLACING THE LCD BACKLIGHT

2.1 TOTAL CONNECTION DIAGRAM

(a) At using internal I/O



— 45 —

(b) At using integrated I/O



— 46 —

2.2 INSTALLATION

2.2.1 The peripheral units, such as the control unit and CRT/MDI, have been designed on the assumption that they are housed in closed cabinets. In this manual "cabinet" refers to the following:
Cabinet manufactured by the machine tool builder for housing the control unit or peripheral units;
Cabinet for housing the flexible turnkey system provided by FANUC;

- Operation pendant, manufactured by the machine tool builder, for housing the CRT/MDI unit or operator's panel.
- Equivalent to the above.

The environmental conditions when inside of cabinets shall conform to the following table.

Room temperature	In operation	Unit:0°C to 55°C				
Room temperature	In store or transportation -20°C to 60°C					
Change in temperature	1.1°C/minute max.					
Relative humidity	30% to 95% (no condensation)					
Vibration	In operation: 0.5G or less					
Environment	Each unit should be placed in a cabinet to keep it from pollut- ants (such as dust, coolant, organic solvents, acid, corrosive gas, and salt).					
	Heat sink of outer of cabinet: The heat sinks should be pro- tected from direct exposure to coolant, lubricant, and metal chips.					
Radiation (ionizing or nonion- izing)	If a unit is to be used in an environment where it is likely to be exposed to radiations (such as microwave, ultraviolet rays, laser beams, and X–rays), a shielding provision should be available for it.					
Height above sea level	Up to 1,000 m					

2.2.2 Power Capacity

The units listed below require an external regulated supply voltage of 24 VDC \pm 10% (including an instantaneous value).

Table 2.2.2 Power supply capacity

Unit	Power supply capacity				
Power Mate–H control unit	1.8A (another 1 A required for the RS–232–C inter- face) (*)				
CRT/MDI unit Picture display CRT/MDI unit	1.0A				
Separate type CRT unit	0.8A				
Separate type MDI unit Picture display separate type MDI unit	0.2A				
Separate type PDP unit	2.0A				
Separate type LCD unit	0.8A				
Detachable LCD/MDI unit	1.0A				
Handy operator's panel	0.2A				
External I/O card	500 +7.3 x n (mA) where n is the number of input points that are turned on simultaneously (*)				
I/O Unit–A	The required current varies depending on the number of modules. Refer to the I/O Unit–MODEL A Connection and Maintenance Manual (B–61813E).				
I/O Link connection unit	0.2A				
DPL/MDI switching circuit	0.2A				

NOTE

The Power Mate–H requires an additional 24–V power supply for DOs.

2.2.3 Action Against Noise

The Power Mate has been steadily reduced in size using surface-mount and custom LSI technologies for electronic components. The Power Mate also is designed to be protected from external noise. However, it is difficult to measure the level and frequency of noise quantitatively, and noise has many uncertain factors. It is important to prevent both noise from being generated and generated noise from being introduced into the Power Mate. This precaution improves the stability of the Power Mate machine tool system.

The Power Mate component units are often installed close to the parts generating noise in the power magnetics cabinet. Possible noise sources into the Power Mate are capacitive coupling, electromagnetic induction, and ground loops.

When designing the power magnetics cabinet, guard against noise in the machine as described in the following section.

Separating signal lines

The cables used for the machine are classified as listed in the following table: Process the cables in each group as described in the action column.

Group	Signal line	Action				
	Primary AC power line	Bind the cables in group A separately				
A	Secondary AC power line	cover group A with an electromag-				
	AC/DC power lines (containing the	netic shield (Note 2).				
	power lines for the servo motors)	Connect spark killers or diodes with				
	AC/DC solenoid	nie solenolu anu relay.				
	AC/DC relay					
	DC solenoid (24VDC)	Connect diodes with DC solenoid				
	DC relay (24VDC)	Bind the cables in droup B separately.				
_	DC power line	from group A, or cover group B with				
В	DI/DO cable between the Power Mate	Separate group B as far from Group				
	and power magnetics cabinet	C as possible.				
DI/DO cable betwee and machine	DI/DO cable between the Power Mate and machine	It is more desirable to cover group B with the shield.				
	Cable between the Power Mate and servo amplifier	Bind the cables in group C sepa- rately from group A, or cover group C				
	Cable for position and velocity feed-	with an electromagnetic shield.				
	back	Separate group C as far from Group				
	External pulse input	Be sure to perform shield proces-				
	Cable between the Power Mate and the CRT/MDI	sing.				
	RS-232-C interface cable					
	Other cables to be covered with the shield					

NOTE

- 1 The groups must be 100mm or more apart from one another when binding the cables in each group.
- 2 The electromagnetic shield refers to shielding between groups with grounded steel plates.



— 49 —

Ground

The following ground systems are provided for the CNC machine tool:

• Signal ground system (SG)

The signal ground (SG) supplies the reference voltage (0V) of the electrical signal system.

• Frame ground system (FG)

The frame ground system (FG) is used for safety, and suppressing external and internal noises. In the frame ground system, the frames, cases of the units, panels, and shields for the interface cables between the units are connected.

System ground system

The system ground system is used to connect the frame ground systems connected between devices or units with the ground.



Notes on connecting the ground systems

- Connect the signal ground with the frame ground (FG) at only one place in the power motion controller control unit.
- The grounding resistance of the system ground shall be 100 ohms or less (class 3 grounding).
- The system ground cable must have enough cross-sectional area to safety carry the accidental current flow into the system ground when an accident such as a short circuit occurs. (Generally, it must have the cross-sectional area of the AC power cable or more.)
- Use the cable containing the AC power wire and the system ground wire so that power is supplied with the ground wire connected.

Connecting the Frame Ground (FG) of the Control Unit

Connect the 0 V line of the electronic circuit in the control unit with the ground plate of the cabinet via the frame ground (FG) terminal.

The SG terminal is located on the printed circuit board at the rear of the control unit.



• Most important matter

Use the Faston terminals (A65L–0001–0148/2) for the frame ground. Also use 100 to 300 mm stranded wire with a cross–section of 2 mm² or more. Otherwise, the Power Mate will be susceptible to noise. Ensure that the FG terminals of the Power Mate are connected to the grounded plates of the cabinet.

Noise Suppressor

Notes on selecting the spark killer

The AC/DC solenoid and relay are used in the power magnetics cabinet. A high pulse voltage is caused by coil inductance when these devices are turned on or off.

This pulse voltage induced through the cable causes the electronic circuits to be disturbed.

- Use a spark killer consisting of a resistor and capacitor in series. This type of spark killer is called a CR spark killer.(Use it under AC) (A varistor is useful in clamping the peak voltage of the pulse voltage, but cannot suppress the sudden rise of the pulse voltage. FANUC therefore recommends a CR spark killer.)
- The reference capacitance and resistance of the spark killer shall conform to the following based on the current (I (A)) and DC resistance of the stationary coil:
 - 1) Resistance (R) : Equivalent DC resistance of the coil

2) Capacitance (C) :
$$\frac{l^2}{10}$$
 to $\frac{l^2}{20}$ (µF)

I : Current at stationary state of the coil



• Diode is used for direct–current circuits



— 52 —

• Cable Clamp and Shield Processing

The power motion controller cables that require shielding should be clamped by the method shown below. This cable clamp treatment is for both cable support and proper grounding of the shield. To insure stable CNC system operation, follow this cable clamp method.

Partially peel out the sheath and expose the shield. Push and clamp by the plate metal fittings for clamp at the part. The ground plate must be made by the machine tool builder, and set as follows :



Fig.2.2.3 (a) Cable clamp (1)



Fig.2.2.3 (b) Cable clamp (2)

2.3 INTER-MACHINE CONNECTION

2.3.1 CRT/MDI Unit

• Connection of Power Mate

The following description also applies when the separate type MDI unit is combined with the separate type CRT unit, separate type PDP unit, or separate type LCD unit.

(1) When there is only one unit of Power Mate-MODEL



(2) When multiple power Mates share one CRT/MDI Max.16 Power Mates



• Cable connection

Se	epar	ate type	e ME	DI unit											
Power Mate				Saparate MDI unit CRT/MDI unit					_						
JD14				JD13											
	(PC	R-EV20	MDT	.)				(PC	R–EV20ľ	MDT	.)				
	1	RXD	11	0V				1	TXD	11	0)V			
	2	*RXD	12	0V				2	*TXD	12	0	V			
	3	TXD	13	(SI1)				3	RXD	13	(S	il1)			
	4	*TXD	14	(*SI1)				4	*RXD	14	(*5	SI1)			
	5	(ITPGA)	15	(SI2)				5	(ITPGA)	15	(S	512)			
	6	(*ITPGA)	16	(*SI2)				6	(*ITPGA)	16	(*5	SI2)			
	7	(ITPGB)	17	(SI3)				7	(ITPGB)	17	(S	513)			
	8	(*ITPGB)	18	(*SI3)	-			8	(*ITPGB)	18	(*8	513)			
	9	(SIO)	19	(+010)	-			9	(SI0)	19	(+ 6				
	10		20	(*SI0)				10		20	(*8	510)	1		
Cable connection (J45)				1								 	 		
JD14 RXD *RXD 3 TXD 4 *TXD 11 0V 12 0V					1	- 7 	hield			1 2 3 4 11 12	JD1 TXC *TXI RXC *RX 0V 0V	3) D .D			
						$\left(\frac{1}{2} \right)$									



Separate ty	/pe MDI	unit					
CRT/MDI	unit						
.IN1							
(PCR-EV	20MDT)						
1 *SEL	0 11 '	SEL4		Mae	chine ope	rator's pa	anel
2 0V	12	0V	147				
3 *SEL	1 13 '	SEL5	<u>אר אר</u>	-nn c	Device No	o. selectio	on switch
4 0V	14	ov					
5 *SEL							
6 0V	6 0V 16 0V						
7 *SEI	_3 17 *	SEL7		•	Separate	type LCl	D unit (15) to $0)/(16)$
8 0V	18	0V		-			5 (15) 10 UV (16).
9	19			•	$CRT link \rightarrow Conne$	longer th	an 50 m 5 (13) to 0V (14)
10	20				2 Oomic	OL OLLU	(13) (0 0 V (14).
Cable conn	ection (J	J47)		Device	No. sele	ction swi	tches
							1
			' ' [· /	·, /		
	JN1		· ~ ·	<u></u>	<u></u>	#0	#1
	*SEL0 3	┘┌╒╪╤┑				#4	#3 ' #5 '
	*SEL1 5			E		#6 #8	#7
	*SEL3 11	— III				#10	#9 , #11 .
	*SEL4 13	3			E	#12	#13
	*SEL6 17	; 		E		Comn	non #15 ¦
	*SEL7		· · · · · ·		•		
					1		
	0V 2,	4, 6, 8, 12	2, 14, 16, 1	8			
Relations	nip betwe	een sele	ction				
switches a	and devi	ce numb	ers				
Device No.	*SEL7	*SEL4	*SEL3	*SEL2	*SEL1	*SEL0	
#0	×	×	×	×	×	×	
#1	×	×	×	×	×	0	
#2	×	×	×	×	0	×	× : Switch open
#3	×	×	×	0	×	×	 : Switch closed
#4	×	×	0	×	×	×	 Either will do
#5	×	×	0	×	×	0	
#6	×	×	0	×	0	×	
#7	×	×	0	0	×	×	
#8	×	0	×	×	×	×	
#9	×	0	×	×	×	0	
#10	×	0	×	×	0	×	
#11	×	0	×	0	×	×	
#12	×	0	0	×	×	×	
#13	×	0	0	×	×	0	
#14	×	0	0	×	0	×	
#15	×	0	0	0	×	×	
Carl Carl	1						
Common display	0	-	-	-	-	-	

2.3.2 Reader/Puncher Interface

• Connection



Cable connection



NOTE

When the +24 V power is not to be supplied from the Power Mate itself, leave JD5 (10) and JD5 (19) open.

2.3.3 External Pulse Input Interface

• Connection



• Cable connection (Single phase input type)





• Cable wiring





• Power supply

For a device having power requirements not exceeding 5 V, 0.35 A, the power for the device can be supplied from the Power Mate itself. In such a case be careful to the supply voltage drop.

JA12 (9, 18, 20) : +5 V

JA12 (12, 14, 16): 0 V

Use 4.95 as +5V is used for Power Mate.

2.3.4 I/O Link

Connection



• Cable connection within group



CAUTION

Connect +5V when optical I/O link adapter is used. Do not connect when metal cable is used.

Otherwise, the +5V connectors will be short circuited, causing damage to the unit.
NOTE

When metal cable is used, cable length between units is extended by 10 m.

When optical I/O link adapter is used, cable length between units is extended by 200m.

 Connection between bases (with I/O unit–A)



• Cable connection in the terminator



NOTE

For multiple AIF01Bs within a group with I/O Unit–A, connect the terminator to connector JP2 of the last AIF01B. For connector JD1A of the last unit on the I/O link line, no terminal is required.

The servo interface for the Power Mate-H is type B.

2.3.5 Servo Interface

Connection

AC reactor T1 200VAC to 230VAC Servo amp. Power Mate AMPn Off by emergency stop - JSnB JSn Þ Power line JFx Servo PC motor





- 64 ----

NOTE

Suffix n in signal name is an axis number 1 to 6.

2.3.6 DPL/MDI Interface

Connection

(1) Connection using no junction cable



(2) Connection using junction cable J13



Cable connection

Details of cable J6

Power Mate M4,		DPL/MDI CNPR
(01)	0V 0V	((01)
(04)	ATCHPGM	1 (04)
(09)	ATCHOPP	> (09)
(10)) (12)
	KAND *TXE	<u>) (13)</u>
(12)		<u>) (10)</u>
		<u> </u>
(05)	<u></u>	(05)
(07)		/ _ (07)
_(06)		<u>(15)</u>
(14)		<u> </u>
(15)(<u>S (06)</u>
_(08)		<u>(14)</u>
Shell	Shield	Shell
Male	Always connect the shell of each connector to 0V.	Female

Details of cable J13



2.3.7 Detachable LCD/MDI Interface

See Connection Manual (B-62683EN) for details.

Connection



Cable connection



— 67 —

2.3.8 Handy Operator's Panel Interface

NOTE

- 1 If 24 V is not applied to emergency stop input EMGTP (CRS10–11) of the handy operator's panel, the handy operator's panel enters the emergency stop state.
- 2 The terminating unit connected to the JD15 connector of the Power Mate is not a CRT link terminating unit. This is the same as the touch panel terminating unit (2.3.9).
- 3 Set rotary switch MTSW of the Power Mate main unit to 3.

Connection Allowing the Handy Operator's Panel to be Detached

Connection



• Cable connection



— 69 —

Keeping the Handy Operator's Panel Connected at All Times

• Connection



• Cable connection

Handy operator's panel				
	(D	Connector panel	RXD	JD14 (01) Power
	D		*RXD	JD14 (02)
CRS10 (03) TX	D		TXD	JD14 (03)
	D		*TXD	JD14 (04)
+5V CRS10 (15) ATC	:H1		ATCH1	JD14 (09)
CRS10 (16) ATC	:H2		ATCH2	JD14 (20)
=			0V	JD14 (11, 12)
stop CRS10 (11) EMC	GTP		*ESP	to DI
Deadman's switch en- able switch CRS10 (13)	GEN	(Note1)	(Separate emerg	jency Operator's panel n as the Emergen-SB1 +24V
Deadman's switch (right)			SQ1	
switch (left) CRS10 (12) EMC	GDM			
+24V CRS10 (09, 10) +24	v	• · · · ·		0V 24VDC
CRS10 (19, 20) 0V			Safety KT1	
CRS10 (05)			relay	+24V
(Plastic case with Shi	ield	'		ESP

— 70 —

2.3.9 Touch Panel Interface

• Connection



Cable connection



2.4

LED DISPLAY/ SETTING AND MODULE CONFIGURATION OF UNIT

2.4.1 LED Display of Control Unit

If an alarm occurred, an alarm message is usually displayed on the DPL, CRT, PDP, LCD, or handy operator's panel screen. However, it is possible that no alarm appears, if the display function is in trouble. In such a case, the alarm occurrence are displayed by LED on the Controller.

LE	ED	Contonts	Countermeasures	
No.	Color	Contents	Countermeasures	
S0	Green	No alarm Blinks during automat- ic operation. Remains on or off while automatic opera- tion is not being per- formed.		
S1	Red	Lights with all alarms	An alarm No. is displayed in the DPL/MDI or CRT/MDI at the same time. Make a corrective measure by the alarm No.	
EN	Green	This show to turn on power.		
WD	Red	Watch dog alarm	When display unit is connected at alarm is occured, it may be dis- plaied the alarm number. Do some disposal of the alarm. If the all–clear operation does not release the alarm, replace the base PCB	

2.4.2 Connector and Signal Name



2.4.3 Fuse of Controller

Fuse	list
------	------

Ordering code	Symbol	Rating	Individual code
A02B-0124-K101	F1	5.0A	A60L–0001–0046#5.0 or A60L–0001–0046#5.0R

2.4.4 Battery of Controller

Lithium battery code : A20B–0118–K111

2.4.5 Rotary Switch RSW

When CRT/MDI common functions and RSW simultaneous block start are used, set device numbers from 0 to 15 with the rotary switch (RSW). Assign the number from the first Power Mate in order.

Device No.	RSW setting
0	0
1	1
2	2
3	3

When CRT/MDI common functions and RSW simultaneous block start are not used, set device number to 0.



— 74 —

2.4.6 Rotary Switch MTSW

Set MTSW to 0 for general use. When handy operator's panel is used, set MTSW to 3. Normally, do not set other number except [0] and [3].



2.4.7 Location of Modules and Internal PC Boards

	Name	Number Us	<u>se</u>
(8) Power supply PC board	Memorycard connector	CNMC Me	emory card
$ \begin{bmatrix} (10)\\ (2) (3)\\ Boot\\ ROM \end{bmatrix} $ $ \begin{bmatrix} (10)\\ (4) (5) (6) (7)\\ \\ Boot\\ ROM \end{bmatrix} $	LED Rotary switch Rotary switch AMP1 AMP2 AMP3 AMP4 AMP5 AMP6	S1 S0 WD EN RSW MTSW JS1 JS2 JS3 JS4 JS5 JS6	LED display CRT common function Maintenance function Axis 1 servo amplifier Axis 2 servo amplifier Axis 3 servo amplifier Axis 4 servo amplifier Axis 5 servo amplifier
(9) Built-in I/O PC board	ENC I/O LINK CRT/ PM PM/ TMNL IO LINK IO LINK I/O RS232C	JA12 JD1A1 JD14 JD15 JD1B JD1A JE1 JD5	External pulse input I/O Link (master) CRT / MDI CRT/ MDI common from former step CRT/ MDI common to latter Terminal resistance unit I/O Link (Slave)from previous step I/O Link(Slave)to latter Internal I/O RS-232-C
	DPL/ MDI SVCHK1 SVCHK2	M4 JA23 JA24	DPL / MDI Servo check board (1 to 4axis) Servo check board (5 to 6axis)

No.	Name		Specifications	Function	Display of system config- uration screen
(1)	Basic PC board	A	A20B-2100-0020	Max.4 axes can be increased.	
		В	A20B-2100-0021	Max.6 axes can be increased, or Macro exe- cuter/C language executer can be used.	
(2)	PMC module		A20B-2901-0660	With PMC	PMP+SLC
(3)	Memory module	А	A20B-2902-0301		RAM 256KB
		В	A20B-2902-0300	For external pulse input For high–speed DI	RAM 256KB POS LSI
		С	A20B-2902-0450	For C language executer With external pulse input	RAM 1MB POS LSI
(4)	CRT module		A20B-2901-0480	For CRT, LCD, PDP, Handy operator's panel	SCA (CRT)
			A20B-2902-0470	For touch panel	Note
			A20B-2902-0540	For HSSB	Note
(5)) Servo module		A20B-2902-0290	For 5th and 6th axis (Digital)	SERVO 5/6
			A20B-2902-0510	For 5th and 6th axis (Analog)	
(6)	Servo module		A20B-2902-0290	For 3rd and 4th axis (Digital)	SERVO 3/4
			A20B-2902-0510	For 3rd and 4th axis (Analog)	
(7)) Servo module		A20B-2902-0290	For 1st and 2nd axis (Digital)	SERVO 1/2
(8)) Power supply PC board		A20B-1004-0960	Power supply	
(9)) SubPC board		A20B-2001-0902	Built-in I/O card	BLT I/O SRC
			A20B-2100-0120 +A20B-8001-0500	Profibus card	PROFIBUS
			A20B-8100-0060	Genius card	GENIUS
			A20B-2100-0040	I/O Link–II	I/O LINK-2
(10))) Boot ROM		A02B-0211-H500#881A		

NOTE When touch panel and HSSB function are used, system configuration can not be displaied.

2.4.8 LED display of I/O Link Connection Unit



Fig.2.4.8 LED Installation Positions

	LED status		Description
1	LED1 LED1 IED1		Normal
			A RAM parity error occurred. The hardware is out of order.
	LED4	LRD2	Normal
2	LED4	LRD2	No voltage is applied to CP1. The voltage applied to CP1 is insufficient.
	LED4	LRD2	A communication error occurred in a channel connected to CP1.
	LED5	LRD3	Normal
3	LED5	LRD3	No voltage is applied to CP2. The voltage applied to CP2 is insufficient.
	LED5	LRD3	A communication error occurred in a channel connected to CP2.
	Lit :	🗌 : Not lit	

2.5 LIST OF PC BOARD AND UNIT

2.5.1 Basic Unit

Name	Specifications	Remarks
Basic unit A	A02B-0211-B511	Up to 4 axes/4 paths, when using the 3/4–axis servo module
Basic unit B	A02B-0211-B501	Up to 6 axes/6 paths, when using the 3/4–axis and 5/6–axis servo modules. The macro executor and C language executor can also be used.
Basic unit C	A02B-0211-B541	With I/O Link II for transformer

2.5.2

Control Unit PC Board

Name	Specifications	Remarks
Base PC board A	A20B-2100-0020	Up to 4 axes/4 paths, when using the 3/4–axis servo module
Base PC board B	A20B-2100-0021	Up to 6 axes/6 paths, when using the 3/4–axis and 5/6–axis servo modules. The macro executor and C language executor can also be used.
Power supply PC board	A20B-1004-0960	
Builte in I/O card	A20B-2001-0902	DI:32 DO:24 (source type)
I/O Link–II card	A20B-2100-0040 A20B-2100-0041	FANUC I/O Link–II
Profibus card	A20B-2100-0120 A20B-8001-0500	
Genius card	A20B-8100-0060	
I/O card D	A16B-2202-0733	DI:48 DO:32 (source type)
I/O card E	A16B-2202-0732	DI:96 DO:64 (source type)

2.5.3 Module

Name	Specifications	Remarks
PMC module	A20B-2901-0660	With PMC
Memory	A20B-2902-0301	
module	A20B-2902-0300	For external pulse input, for following control
	A20B-2902-0302	For external pulse input
	A20B-2902-0450	For C language executor with exernal pulse input
CRT module	A20B-2901-0480	For CRT, LCD, PDP, handy operator's panel
	A20B-2902-0470	For touch panel
	A20B-2902-0540	For HSSB

— 79 —

Name	Specifications	Remarks
Servo module	A20B-2902-0290	Digital
	A20B-2902-0510	Analog

2.5.4 CRT/MDI, DPL/MDI Unit

Name	Specifications	Remarks		
CRT/MDI unit	A02B-0166-C001	English key		
	A02B-0166-C201#R	English key		
	A02B-0166-C201#S	Symbol key		
LCD/MDI unit	A02B-0166-C271#R	English key		
	A02B-0166-C271#S	Symbol key		
Separate type MDI unit	A02B-0166-C010	English key		
	A02B-0166-C210#R	English key		
	A02B-0166-C210#S	Symbol key		
Picture display CRT/	A02B-0166-C221#R	English key For 32 screen		
MDI unit	A02B-0166-C221#S	Symbol key For 32 screen		
	A02B-0166-C222#R	English key For 64 scree	en	
	A02B-0166-C222#S	Symbol key For 64 screen		
Picture display	A02B-0166-C231#R	English key For 32 scree	en	
separate type MDI unit	A02B-0166-C231#S	Symbol key For 32 scree	en	
	A02B-0166-C232#R	English key For 64 scree	n	
	A02B-0166-C232#S	Symbol key For 64 screen		
Separate type CRT unit	A02B-0120-C111			
Separate type PDP unit	A02B-0120-C113	200V AC input		
	A02B-0200-C100	24V DC input		
Separate type LCD unit	A02B-0166-C251			
Detachable LCD/MDI	A02B-0166-C271#R	English key		
	A02B-0166-C271#S	Symbol key		
DPL/MDI unit	A02B-0168-K010	Table mount/FANUC	English key	
	A02B-0168-K011	Wall mount/FANUC	English key	
	A02B-0168-K012	Table mount/GE Fanuc	English key	
	A02B-0168-K013	Wall mount/GE Fanuc	English key	
Long distance type	A02B-0118-C030	Table mount/FANUC	English key	
	A02B-0118-C031	Wall mount/FANUC	English key	
	A02B-0118-C032	Table mount/GE Fanuc	English key	
	A02B-0118-C033	Wall mount/GE Fanuc	English key	
Dust protected type	A02B-0118-C130#R	Table mount/FANUC	English key	
	A02B-0118-C130#S		Symbol key	
	A02B-0118-C131#R	Wall mount/FANUC	English key	
	A02B-0118-C131#S		Symbol key	
	A02B-0118-C132#R	Table mount/GE Fanuc	English key	
	A02B-0118-C132#S		Symbol key	
	A02B-0118-C133#R	Wall mount/GE Fanuc	English key	
	A02B-0118-C133#S		Symbol key	
DPL/MDI switch circuit A16B–2600–0080				
CRT link terminal unit	A02B-0124-D001	For CRT, PDP, LCD	For CRT, PDP, LCD	
Handy operator's panel	A02B-0211-C020#R	English key		
	A02B-0211-C020#S	Symbol key		

Name	Specifications	Remarks
Touch panel end terminal unit	A02B-0166-D003	For touch panel and handy operator's panel
HSSB adaptor	A02B-0211-C220	
I/O Link–II relay terminal board	A08B-0048-C331	

2.5.5 CRT/MDI, DPL/MDI PC Board

Name	Specifications	Remarks	
CRT Control PC board	A20B-2000-0840		
	A20B-2100-0061	For picture display 32 screen	
	A20B-2100-0060	For picture display 64 screen	
DPL/MDI PC board	A20B-8000-0141		
DPI/MDI for Long distance PC board	A20B-8000-0490		
Dust protected DPL/MDI P.C.B	A20B-8001-0310		
DPL/MDI switch board	A16B-2600-0080		
Handy operator's panel	A20B-2002-0200		
HSSB adaptor	A20B-8001-0510		

2.6 HOW TO REPLACE THE BATTERIES

WARNING

1 Memory backup battery replacement

When replacing the memory backup batteries, keep the power to the machine (CNC) switched on, and hold the machine at an emergency stop. Because this work must be carried out while the power is kept switched on and the cabinet is open, only the personnel who have been trained for safety are allowed to engage in the work. When replacing the batteries, be careful not to touch the high–voltage circuit section (marked 🛆 and shielded with a shock hazard prevention cover). If you touch the high–voltage circuit section when it is uncovered, you will get an electric shock.

2 Absolute pulse coder battery replacement

When replacing the memory backup batteries, keep the power to the machine (CNC) switched on, and hold the machine at an emergency stop. Because this work must be carried out while the power is kept switched on and the cabinet is open, only the personnel who have been trained for safety are allowed to engage in the work. When replacing the batteries, be careful not to touch the high–voltage circuit section (marked \triangle and shielded with a shock hazard prevention cover). If you touch the high–voltage circuit section when it is uncovered, you will get an electric shock.

- 2.6.1 Replace the Battery for Memory Back Up
- 1.Lithium battery (Order number is *A02B–0118–K111) is required.
- 2. Replace battery in the status that Power Mate power supply is ON.
- 3. The battery used for memory back up is located in the front door.
- 4. Open the door of controller and remove the battery from folder.
- 5. Pinch and remove the connector in the side of battery towards you.
- 6. Connect the connector of new battery to the connector.
- 7. Mount a battery to folder and close the cover in side of cable.

WARNING

Using other than the recommended battery may result in the battery exploding.

Replace the battery only with the specified type (A02B–0118–K111).

CAUTION

Ensure that the power to the CNC is turned on before attempting to replace the battery. Replacing the battery while the power is turned off will result in the loss of stored data such as programs and parameters.



2.6.2 Replacing Batteries for	Prepare lithium battery A06B-6073-K001(*) in advance.	
Absolute Pulse Coder (Servo Amplifier	(*) FANUC specification: A98L-0001-0902	
Built–in Type Battery/Servo Amplifier		
α Series)		

Procedure for replacing batteries for absolute pulse coder

Procedure

- (1) Turn machine (CNC) power ON.
- (2) Remove the battery case on the front panel of α series Servo Amp Module (SVM).

The battery case can be removed by holding the top of the case and pulling the case towards you.



- (3) Remove the connector the battery.
- (4) Replace the battery, and connect the connector.
- (5) Attach the battery case.
- (6) Turn machine (CNC) power OFF.

WARNING

Using other than the recommended battery may result in the battery exploding.

Replace the battery only with the specified type (A06B–0073–K001).

- 84 ---

CAUTION

- 1 Replace the batteries for absolute pulse coder when NC power is ON.
 - Replacing the batteries with power OFF causes the absolute position stored in memory to be lost.
- 2 If your machine is equipped with a separate battery case, follow the instructions in 2.6.4.

2.6.3 Replacing Batteries for Absolute Pulse Coder (β Series Servo Amp Module/Built–in Type Battery) Prepare lithium battery A02B–0168–K111(*) in advance.

(*) FANUC specification: A98L-0031-0011

Procedure for replacing batteries for absolute pulse coder

Procedure

- 1 Turn machine (CNC) power ON.
- 2 Remove the battery case from under the β series servo amplifier module by holding the case at both sides and pulling downwards.



- **3** Remove the connector the battery.
- 4 Replace the battery, and connect the connector.
- 5 Attach the battery case.
- 6 Turn machine (CNC) power OFF.

WARNING

Using other than the recommended battery may result in the battery exploding.

Replace the battery only with the specified type (A02B–0168–K111).

CAUTION

- 1 Replace the batteries for absolute pulse coder when NC power is ON.
 - Replacing the batteries with power OFF causes the absolute position stored in memory to be lost.
- 2 If your machine is equipped with a separate battery case, follow the instructions in 2.6.4.

2.6.4 Replacing Batteries for Absolute Pulse Coder (Separate Battery Case) Prepare 4 alkaline batteries (UM-1type) commercially available in advance.

Procedure for replacing batteries for absolute pulse coder

Procedure

- (1) Turn machine (CNC) power ON.
- (2) Loosen screws on the battery case to remove the cover. For placement of the battery case, refer to the machine tool builder's manual.
- (3) Replace the batteries in the case. Insert 2 batteries each in the opposite direction as illustrated below.



- (4) After replacement, install the cover.
- (5) Turn machine (CNC) power OFF

WARNING

Using other than the recommended battery may result in the battery exploding.

Replace the battery only with the specified type (UM–1 type alkaline battery).

CAUTION

Replace the batteries for absolute pulse coder when NC power is ON.

Replacing the batteries with power OFF causes the absolute position stored in memory to be lost.

2.7 HOW TO REPLACE THE MODULES

2.7.1 (1) Check to Removing (2) Pull the (3) Pull out (3) Pull out 2.7.2 (1) Check to Insertion (2) Insert to

- (1) Check that the power supply is not off.
- (2) Pull the latches of the module socket outwards. (Fig.(a))
- (3) Pull out the module upward. (Fig.(b))
- (1) Check that the power supply is off.
- (2) Insert the new module board diagonally with B–SIDE outward (Fig.(b))
- (3) Hold both ends of the module with both hands, and raise it up until it locks. (Fig.(c))



CAUTION

- 1 Replacing the memory module results in the loss of stored data such as programs and parameters. Before attempting to replace the memory module, therefore, make a backup copy of the stored data.
- 2 Once the memory module has been replaced, any ladder programs must be reloaded.
- 3 Make sure that the latches on the both sides of the socket are securely hooked onto the module. Otherwise, the electrical contacts may fail to connect correctly, causing the NC unit to malfunction.

2.8 REPLACING PRINTED CIRCUIT BOARD AND UNIT

2.8.1 The Base Printed Circuit Boards

- (1) Make sure that the power supply unit is turned off.
- (2) Disconnect all cables connected to the printed circuit board in the control unit. Pinch the 20-pin half-pitch connector to release the latch. Draw out the connector.
- (3) Remove the control unit from the wall.
- (4) Place the control unit with its left face upward, and press the two points shown in Fig. 2.8.1 (a) to remove the cover of the case.
- (5) Remove the battery.
- (6) Release the three latches shown in Fig. 2.8.1 (b), and remove the PC board.
- (7) Mount a new base PC board by following the steps above in reverse order.
- (8) Reconnect the cables to their original positions.

CAUTION

Replacing the base printed circuit board results in the loss of stored data such as programs and parameters. Before attempting to replace the memory module, therefore, make a backup copy of the stored data.



2.8.2

The Power Supply Printed Circuit Boards and Sub PC Board

- (1) Make sure that the power supply unit is turned off.
- (2) As in 2.8.1 above, remove the base PC board.
- (3) Remove the screws from the base PC board or sub PC board that are securing the power PC board, and replace the power PC board.
- (4) Put the base PC board in the case, and return it to the original position.
- (5) Reconnect the cables to their original positions.

2.8.3			
The Fan Motor	(1) Remove the power PC board as in 2.8.2 above.		
	(2) Remove the two screws from the fan motor on the power PC board, and replace the fan motor with a new one.		
	(3) Mount the power PC board on the base PC board as in 2.8.2 above, and return the base PC board to the case.		
	(4) Reconnect the cables.		
2.8.4			
The CRT Control Printed Circuit Board	(1) Turn off the power to the CRT/MDI, separated type CRT/MDI unit and controller.		
	(2) The CRT control PC board is located behind the MDI. Remove all cables connected to the PC board.		
	(3) Remove the square screws from the CRT control PC board, and replace the PC board.		
	(4) Reconnect the cables.		
	CAUTION When the picture display CRT/MDI unit or separate picture display MDI unit is being used, reload the picture screen data.		

2.8.5 The MDI Keyboard

- (1) The CRT control PC board that is behind the MDI keyboard can be seen from the rear of the CRT/MDI unit and separate type MDI unit. Remove the CRT control PC board as in 2.8.4 above.
- (2) Remove the two connectors from the back of the keyboard.
- (3) Remove the four studs from the back of the keyboard.
- (4) Since the MDI keyboard has no setscrews, the keyboard can be removed at this point.
- (5) Mount a new keyboard, and secure it with four studs.
- (6) Reconnect the two cables of the CRT control PC board.



2.8.6 The CRT Display

- (1) Check that the power supply is off.
- (2) Disconnect the CRT unit power cable and the video signal cable.
- (3) Remove the chloridized veneer cover and the four screws from the front of the CRT unit.
- (4) Install the new CRT unit.
- (5) Reconnect the CRT power supply cable and video signal cable to their original positions.



Fig.2.8.6 Replacing the CRT Display

2.9 MAINTENANCE OF HEAT PIPE TYPE HEAT EXCHANGER

Air filter cleaning and replacement

It is necessary to regulary clean the heat transformer, because the heat transformation ability will be reduced by the accumulation of dust. The frequency of the cleaning needed differs according to the installation environment and therefore should be determined by your own judgment accordint to the degree of dirt.

WARNING

The heat pipe-based heat exchanger section is applied with a high voltage.

When maintaining the heat pipe–based heat exchanger, keep the power to the machine (CNC) switched off.

When replacing the heat pipe-based heat exchanger with the cabinet open, be careful not to touch the high-voltage circuit section (marked \triangle and shielded with a shock hazard prevention cover).

If you touch the high–voltage circuit section when it is uncovered, you will get an electric shock.

Air filter cleaning and replacement method

- **1** When cleaning and replacing the filter, be sure to cut off the fan's electric power source.
- 2 Detach the filter cover and take out the filter inside.



3 Protect the filter from silting due to dust by blowing air on both sides.



- 4 When dirt is conspicuous, press wash with a neutral detergent, rinse with fresh water, and the washing, allow to dry naturally. When replacing with the same product.
- **5** Insert the filter in the cover, align the flange in the groove, and install by pressing. Confirm that the cover will not come loose even if it is pulled.

Cleaning heat exchanger

Cleaning heat exchanger

- 1 When cleaning, be sure to cut off the fan power source.
- 2 Take out the external fan unit from the heat exchanger main unit.



• Cleaning fan unit

Method of cleaning fan unit

1 Wipe the dirt, condensation, etc., which has accumulated on the fan motor and fan installation case with a dry cloth, etc. When the condensation, etc. has accumulated and the dirt is difficult to remove, soak a cloth in neutral detergent, lightry squeze it and wipe away the dirt.

However, take care not to allow the detergent to enter the electrical sections such as the internal rotor of the fan motor.



Cleaning heat exchanger fan

Method of cleaning heat exchanger fan

1 Detach the heat exchanger format the unit and either blow off with air, wipe off with a dry cloth, or brush the accumulated dirt, condensation, etc.

When the dirt is especially severe

1 Detach the internal fan unit, the terminal unit, and the cable from the main unit.



- **2** Using a neutral detergent, remove the dirt from the main unit fan section by brushing. At this time, take care not to bend the fin of the element.
- 3 After cleaning, dry well.

Installation

Method of installation after cleaning

After completing cleaning of the fan unit and heat transformer.

- **1** Install the terminal unit and cable in the original position.
- 2 Install the fan unit in the original position. At this time, do not forget to connect the fan power cable and the earth cable.

— 96 —

2.10 REPLACING THE FUSE

WARNING

Before replacing a blown fuse, it is necessary to remove the cause of the blown fuse. For this reason, only the personnel who have a working knowledge of maintenance and safety are allowed to carry out this work. When replacing a fuse with the cabinet open, be careful not to touch the high–voltage circuit section (marked \triangle and shielded with a shock hazard prevention cover). If you touch the high–voltage circuit section when it is uncovered, you will get an electric shock.

2.10.1 The Power Mate Controller Fuse

This section describes the replacement of the Power Mate controller fuse.

The controller contains a +24 V power input fuse, F1. If LED EN does not light when +24 V power is supplied, fuse F1 may have blown. In such a case, remove the fuse from its socket, then check its continuity using a multimeter (or visually check whether it has blown). If the fuse has blown, investigate the cause, take appropriate action, then replace the fuse. The capacity, part number, and location of the fuse are as follows:

Table 2.10.1 Capacity and part number of Power Mate controller fuse

Name	Capacity	Part number
F1	5.0A	A60L-0001-0046#5.0R or
		A60L-0001-0046#5.0



Fig.2.10.1 Location of Power Mate controller fuse

2.10.2 The CRT/MDI Control PCB Fuse

This section describes the replacement of the CRT/MDI controller PCB fuse of the Power Mate. The table below lists the drawing number of the CRT/MDI control PCB. The CRT/MDI control PCB is mounted on the back of the CRT/MDI unit or separate MDI unit.

Table 2.10.2 (a) CRT/MDI control PCB drawing number

Name	Drawing number
CRT/MDI control PCB	A20B-2000-0840
	A20B-2100-0061
	A20B-2100-0060

The CRT/MDI control PCB contains a +24 V power input fuse, FU1. If nothing appears on the screen when +24 V power is supplied to the CRT/MDI control PCB, fuse FU1 may have blown. In such a case, remove the fuse from its socket, then check its continuity using a multimeter (or visually check whether it has blown). If the fuse has blown, investigate the cause, take appropriate action, then replace the fuse. The capacity, part number, and location of the fuse are as follows:

Table 2.10.2 (b) Capacity and part number of CRT/MDI control PCB fuse

Name	Capacity	Part number
FU1	3.2A	A60L-0001-0175#3.2A



Fig.2.10.2 (a) Location of CRT/MDI fuse


Fig.2.10.2 (b) Location of separate MDI unit fuse

2.10.3 The I/O Card Fuses

This section describes the replacement of the Power Mate external I/O card fuses. The table below lists the names and drawing numbers of the I/O cards.

Table 2.10.3 (a) I/O card drawing numbers

Name	Drawing number
I/O card D DI: 48 points, DO: 32 points	A16B-2202–0733
I/O card E DI: 96 points, DO: 64 points	A16B-2202–0732

The I/O card contains a +24 V power input fuse, FU1, and +5 V power output fuse, FU2. If +5 V is not output, fuse FU1 or FU2 may have blown. In such a case, remove the fuses from their sockets, then check their continuity using a multimeter (or visually check whether they have blown). If a fuse has blown, investigate the cause, take appropriate action, then replace the fuse. The capacity, part number, and location of the fuses are as follows:

Name	Capacity	Ordering specification
FU1	3.2A	A60L-0001-0175#3.2A
FU2	5.0A	A60L-0001-0290#LM50



Fig.2.10.3 Location of I/O card fuses

2.10.4 The I/O Unit–MODEL A Fuses

Each of the following modules contains a fuse. If the fuse has blown, eliminate the cause, then replace the fuse.

Module	Indication of blown fuse	Capa city	Part number
Interface module AIF01A	PWR does not light.	3.2A	A60L-0001-0290#LM32
Interface module AIF01B	PWR does not light.	3.2A	A60L-0001-0290#LM32
Output module (DC, 8 points) OD08C	F lights.	5A	A60L-0001-0260#5R00
Output module (DC, 8 points) OD08D	F lights.	5A	A60L-0001-0260#5R00
Output module (AC, 5 points) AOA05E	F lights.	3.15A	A60L-0001-0276#3.15
Output module (AC, 8 points) AOA08E	F lights.	3.15A	A60L-0001-0276#3.15
Output module (AC, 12 points) AOA12F	F lights.	3.15A	A60L-0001-0276#3.15

The fuse is mounted on the internal PCB of each module. For details, refer to the I/O Unit–MODEL A Connection and Maintenance Manual.

2.10.5 Replacing the DPL/MDI Switcher Fuses

This section describes the replacement of the DPL/MDI switcher fuses of the Power Mate. The table below lists the drawing number of the DPL/MDI switcher.

Table 2.10.5 (a) Drawing number of DPL/MDI switcher

Name	Drawing number
DPL/MDI switcher	A16B-2600-0080

The DPL/MDI switcher contains a +24 V power input fuse, F2, and +5 V power output fuse, F1. If the +5 V pilot lamp (green LED) does not light when +24 V power is supplied to the DPL/MDI switcher, fuse F1 or F2 may have blown. In such a case, remove the fuses from their sockets, check their continuity using a multimeter (or visually check whether they have blown). If a fuse has blown, investigate the cause, take appropriate action, then replace the fuse. The capacity, part number, and location of the fuses are as follows:

Table 2.10.5 (b)	Capacity and p	art number of the	DPL/MDI switcher fuses
------------------	----------------	-------------------	------------------------

Name	Capacity	Ordering specification
F1	2.0A	A60L-0001-0175#2.0A
F2	2.0A	A60L-0001-0175#2.0A



Fig.2.10.5 Location of DPL/MDI switcher fuses

2.10.6 Replacing the LCD Fuse

This section describes the location and replacement of the LCD fuse.

WARNING

Before replacing a blown fuse, it is necessary to remove the cause of the blown fuse. For this reason, only the personnel who have a working knowledge of maintenance and safety are allowed to carry out this work. When replacing a fuse with the cabinet open, be careful not to touch the high–voltage circuit section (marked A and shielded with a shock hazard prevention cover). If you touch the high–voltage circuit section when it is uncovered, you will get an electric shock.

• Location of the LCD fuse



Replacing the fuse

(1) If the fuse blows, first find and eliminate the cause. Then, replace the fuse.

- (2) Pull the old fuse up.
- (3) Push a new fuse into the fuse holder.
- Ordering information

Ordering code : A02B-0200-K104* Rating : 1.0 A

*In-house code: A60L-0001-0290#LM10

2.11 ADJUSTING THE PLASMA DISPLAY

2.11.1

Adjusting the Color Liquid Crystal Display and Plasma Display

Locations of switches and jumper pins

Adjustment

Fine adjustment of the video signal is supported to enable its use with plasma displays. This adjustment is necessary to compensate for errors resulting from the combination of NC devices and cables.

Adjustment of the video signal is necessary if you have replaced the display unit, cable, or a hardware component of the display circuit in the NC, either as part of regular field maintenance or the correct a failure.



Eliminating flicker

Switch TM1

If flicker occures, change the TM1 setting to another setting. Normally one of these settings will eliminate flicker.

Adjusting the horizontal position

Switch SW1

- (1) The screen can be shifted horizontally in units of dots.
- (2) Adjust the horizontal position such that the entire screen is visible. Only one setting can successfully realize this positioning.

CAUTION

- 1 Do not attempt to change any controls or settings other than those described above.
 - If any controls or settings other than those described above are changed, the appearance of the display will be abnormal.
- 2 The plasma display unit cannot be switched between the Power Mate and other NC units, because its cable length requires careful adjustment.

2.12 7.2–INCH MONOCHROME LCD ADJUSTMENT

The 7.2–inch monochrome LCD is provided with a contrast adjustment potentiometer and video signal adjustment switches.

The contrast is adjusted when the LCD adapter or panel is replaced. Otherwise, it should not be necessary to use the adjustment switches.

Adjustment points



Adjustment procedure

(1) Contrast adjustment

Potentiometer VRP1

This adjustment is made to compensate for variations between, individual LCD adapters and LCD panels. When an LCD adapter or panel is replaced, the following adjustment must be made. If the entire LCD unit is replaced, however, no adjustment is needed.

- (a) First, adjust potentiometer VRP1 until the displayed characters (all black areas) appear white.
- (b) Rotate the potentiometer in the opposite direction until the characters appear clear and black.
- (2) Flicker adjustment

Potentiometer VR1

This potentiometer is factory-set and normally need not be adjusted by the user. If the setting is changed by mistake, re-adjust it according to the following procedure. Note that some versions of this printed-circuit board do not have this potentiometer; adjustment is performed automatically.

- (a) Using the check pins, observe HS and CLK on an oscilloscope.
- (b) Over part of the range of potentiometer VR1, the positive–going edge of HS will be almost in phase with the positive–going edge of the CLK. Rotating the potentiometer a little does not change the phase difference. Set the potentiometer to the midpoint of this range.

— 104 —

(c) After completing the adjustment, confirm that the display does not flicker.



(3) Horizontal position adjustment

Switch SW1

This switch is factory-set and normally need not be adjusted by the user. If the setting is changed by mistake, re-adjust it according to the following procedure.

- (a) Switch SW1 is used to move the display horizontally in units of dots.
- (b) Set the switch to the point between 8 and B where the entire display is visible.
- (c) The default setting is 9.

2.13	The LCD backlight must be replaced periodically. Replace the unit in
	which the LCD backlight is mounted.
	The LCD backlight has a life of about 10,000 hours (54 hours guaranteed).
LCD BACKLIGHT	(During its lifetime, the backlight should maintain a brightness exceeding
	50% of that when new.)
	Upon reaching the end of its service life, the LCD backlight unit must be
	replaced. The unit can be replaced either by the user or by a FANUC
	service engineer.



INPUT AND OUTPUT OF DATA

Data must be re-set if the base printed-circuit board is replaced or the memory module is replaced (or removed then mounted again). This chapter describes the procedures to input and output the parameters, the part programs and the tool offset values.

- 3.1 SETTING PARAMETERS FOR INPUT/OUTPUT
- 3.2 INPUTTING/OUTPUTTING DATA

3.1 SETTING PARAMETERS FOR INPUT/OUTPUT

- Setting procedure of parameters (CRT/MDI)
- 1. Set to MDI mode or emergency stop state.
- 2. Press or press soft key [SETING] to display SETTING (HANDY) screen.
- 3. Set the cursor to **PARAMETER WRITE** and, press 1 and Keys in this order. Here alarm 100 will be displayed.
- 4. Press system key several times to display the following screen.

0000		S	EO			TNT	TSO	TVC
	0	0	0	0	0	0	0	0
0001								
	0	0	0	0	0	0	0	0
0012								MIR
х	0	0	0	0	0	0	0	0
Y	0	0	0	0	0	0	0	0
\mathbf{Z}	0	0	0	0	0	0	0	0
в	0	0	0	0	0	0	0	0
0020 3	I/O	CHAN	NEL					
WDT +	ىلەر بىلەر	ماه ماه ماه ماه						
MDI *			~~ 15			D DT D0		
L F. S.	кн]	L REA	ונ ע		11	DEFEJ	ж II	1

- 5. Press soft key[(**OPRT**)] and the following operation menu is displayed.
- 1) Soft key [NO. SRH] : Searched by number. Examination) Parameter number \rightarrow [NO. SRH].
- Examination) Parameter number → [NO. SRH].
 2) Soft key [ON : 1] : Item with cursor position is set to 1 (bit parameter)
 3) Soft key [OFF : 0] : Item with cursor position is set to 0 (bit parameter)
 4) Soft key [+INPUT] : Input value is added to the value at cursor (word type)
 5) Soft key [INPUT] : Input value is replaced with the value at cursor (word type)
 6) Soft key [READ] : Parameters are input from reader/puncher interface.
 7) Soft key [PUNCH] : Parameters are output to reader/puncher interface.
 6. After the parameters have been input, set PARAMETER WRITE on the SETTING screen to 0. Press RESET to release alram 100.

- 7. Convenient method
- To change parameters in bit unit, press cursor key ← or →, then the cursor becomes bit length and you can set parameters bit by bit (Bit parameter only).
- 2) To set data consecutively, use |EOB| key.



0.

- Setting parameters procedare (DPL/MDI)
- 1. Set MDI mode or emergency stop.
- 2. Press the $\begin{bmatrix} MENU \\ VAR \end{bmatrix}$ key to display the settings screen.
- 3. Use the cursor keys to position the cursor at PWE, then press the

key and the $\mathbb{I}^{\mathbb{I}\mathbb{P}\cup\mathbb{T}}$ key, in that order, to enable parameters to be written. The Power Mate will generate P/S alarm 100.

4. Press the P_{ARAM}^{DGNOS} key several time to display the parameter screen.



5. Move the cursor to the number of the parameter to change. **Method 1**

Use the cursor keys. The cursor will continue to move while a cursor key is being pressed.

Method 2

Press the following keys and enter data in the order shown :



- 6. Enter a parameter value with the data input keys.
- 7. Press the *INPUT* key. The parameter value is input and displayed.
- 8. After all parameters have been set and confirmed, return to the settings screen and set PWE to 0.
- 9. Normally, in order to release the alarm state, press the CAN key.

However, in order to release alarm No. 000, the power needs to be turned off and then on again.

3.2 Powe INPUTTING/ OUTPUTTING DATA (1) (2) 1

Power Mate memorized the following data.

Outputting the newest data I/O device while the CNC is running normally

- (1) CNC parameter
- (2) PMC parameter
- (3) Custom macro variable values
- (4) Tool compensation amount (offset data)
- (5) Part program
- (6) Ladder program

3.2.1 Confirming the Parameters Required for Data input/Output

Be sure that data output cannot be done in an alarm status.

Parameters required for output are as follows :

(To change parameters, set MDI mode or emergency stop status)

Address	#7	#6	#5	#4	#3	#2	#1	#0
0000							ISO	

#1 (ISO) 0 : Output with EIA code

1 : Output with ISO code (FANUC cassette)

Address

0020 Selection of I/O channel

0 : Channel 1 (Connector JD5)

1 : Channel 1 (Connector JD5)

1) I/O channel=0

Both I/O CHANNEL = 0 and I/O CHANNEL = 1 indicate channel 1. Separate parameters are, however, provided for each I/O CHANNEL, for setting the baud rate, stop bit, etc.

Address	#7	#6	#5	#4	#3	#2	#1	#0
0101	NFD				ASI			SB2

#7 (NFD) 0 : Feed is output when data is output.

1 : Feed is not output when data is output.

#3 (ASI) \approx 0 : EIA or ISO code is used for input data.

- 1 : ASCII code is used.
- **#0 (SB2)** 0 : No. of stop bits is 1.

 $\gtrsim 1$: No. of stop bits is 2.

 \Rightarrow : Standard setting

Address									
0102		Specification number of input/output device							
	0	RS–232–C (for other than the following)							
	1	Not used							
	2	FANUC Floppy cassette adapter F1							
	3	PROGRAM FILE Mate. FANUC Handy File ,FANUC Floppy cassette adapter, FSP–H							
	4	Not used							
	5	Not used							
	6	FSP–G, FSP–H							

	Address
	0103 Baud Rate
	 7: 600 9: 2400 11:9600 8: 1200 ☆10: 4800 12:19200 [BPS] 2) I/O cahnnel=1 Set parameters to 0111, 0112, 0113. Seeting contens are same as 0101, 0102, 0103.
3.2.2 Outputting Parameters	
• Procedure (CRT/MDI)	1. Select EDIT mode.
	2. Press system key and soft key [PARAM] to display parameter screen.
	3. Press soft key $[(OPRT)]$ and soft key $[\square]$
	 Press soft key [PUNCH] and [EXEC], and the parameters are started to be output.
• Procedure (DPL/MDI)	1. Select EDIT mode.
	2. Select the parameter display screen by PARAM key.
	3. Press the WRITE key.
	 4. Execute file heading when required. For which file the parameter is output to refer to Explanations (Output to a floppy). 5. While parameter, is being output, the display appears as below. >&0001 0000 0000 WRITE
	6. In order to stop output of data from a tape before it has finished, turn on external reset signal ERS (bit 7 of G008).Once data output from a tape has been stopped, it cannot be restarted.
Explanations (Output to a floppy)	
 File output location 	When output is conducted to the floppy, the program is output as the new file after the files existing in the floppy. New files are to be written from the beginning with making the old files invalid, use the above output operation after the N0 head searching.
 An alarm while a program is output 	When P/S alarm (No.086) occurs during program output, the floppy is restored to the condition before the output.
 Outputting a program after file heading 	When program output is conducted after N1 to N9999 head searching, the new file is output as the designated n–th position. In this case, 1 to $n-1$ files are effective, but the files after the old n–th one are deleted. If an alarm occurs during output, only the 1 to $n-1$ files are restored.

• Efficient use of memory

To efficiently use the memory in the cassette or card, output the program by setting parameter NFD (No.0101#7 or, No.0111#7) to 1. This parameter makes the feed is not output, utilizing the memory efficiently.

 On the memo record Head searching with a file No. is necessary when a file output from the CNC to the floppy is again input to the CNC memory or compared with the content of the CNC memory. Therefore, immediately after a file is output from the CNC to the floppy, record the file No. on the memo. 3.2.3 Outputting PMC **Parameters** Procedure (CRT/MDI) 1. Select EDIT mode. 2. Press key then soft key [SETTING] to select a setting screen. OFFSET 3. Set the cursor to **PARAMETER WRITE** and input and INPUT 1 At this time, alarm 100 will be generated. 4. Press system key and soft key [PMC]. 5. Press soft key [PMCPRM] and soft key [KEEPRL] 6. Set the cursor to K17 and set the first bit to 1. INPUT 1 \times X × $|\times||\times|$ X \times Where, mark x is a former value Thus, data input/output screen has been selected. 7. Press soft key $[\lhd]$ then key $[\triangleright]$. 8. Press soft key **[I/O]** and set the parameters on I/O. Item selection cursor moves to the following item after data of an item is set. 9. In CHANNEL NO item, input 1 INPUT to select I/O channel 1. 10. In DEVICE item, press soft key [FDCAS] to select the floppy cassette. It is also [FDCAS] for Handy File. 11. In KIND DATA item, press soft key [PARAM]. 12.In FUNCTION item, press soft key [WRITE]. 13. Press soft key [EXEC]. Then PMC parameters are started to be output. 14. After the PMC parameters have been output, set PARAMETER WRITE to 0. 15.Press RESET to release alarm 100. Procedure (DPL/MDI) 1. Select EDIT mode. 2. Press $\|_{VAR}^{MENU}\|$ key several time then select a setting screen. 3. Set the cursor to PWE and input | | and INPUT. At this time, alarm 100 will be generated. 4. Press BARAM key several time to select diagnosis screen. 5. Press 7 Т and INPUT kev.

6. Set the first bit to 1.

 X
 X
 X
 X
 I
 X
 INPUT

 Where, mark x is a former value
 Image: Source and the source a

- 7. Display the PMC parameter press $\begin{bmatrix} \& & @ \\ No, \end{bmatrix}$ key then set file number.
- 8. Press WRITE. Then PMC parameters are started to be output.
- 9. After the PMC parameters have been output, set PWE to 0.
- 10.Reset Power Mate to release alarm 100.

3.2.4 Outputting Custom Macro Variable Values

- Procedure (CRT/MDI)
- 1. Select **EDIT** mode.
- 2. Press OFFSET key.
- 3. Press > key and soft key [MACRO] to select custom macro variable screen.
- 4. Press soft key [(**OPRT**)] and then key \triangleright .
- 5. Press soft key [PUNCH] and [EXEC], then custom macro variable values are output.
- Procedure (DPL/MDI)
- 1. Select EDIT mode.
- 2. Select the tool offset data display screen by pressing $\left| \begin{smallmatrix} MENU\\ VAR \end{smallmatrix} \right|$ key.
- 3. Press the WRITE key.
- 4. While common variable is being output, the display appears as below.



5. In order to stop output of data from a tape before it has finished, turn on external reset signal ERS (bit 7 of G008). Once data output from a tape has been stopped, it cannot be restarted.

3.2.5 Outputting Tool Compensation Amount

- Procedure (CRT/MDI)
- 1. Select EDIT mode.
- 2. Press key and soft key [**OFFSET**] to display the tool compensation amount screen.
- 3. Press [(**OPRT**)] key and soft key \triangleright .
- 4. Press soft key [**PUNCH**] an [**EXEC**] key, and the tool compensation amount is started to be output.

- Procedure (DPL/MDI)
- 1. Select EDIT mode.
- 2. Select the offset data display screen by pressing VAR key.
- 3. Press the WRITE key.
- 4. While offset, is being output, the display appears as below.



5. In order to stop output of data from a tape before it has finished, turn on external reset signal ERS (bit 7 of G008). Once data output from a tape has been stopped, it cannot be restarted.

3.2.6 **Outputting Part** Program

- Procedure (CRT/MDI)
- 1. Confirm the following parameters. If 1 is set, set to the EDIT mode and set it to 0.

Address	#7	#6	#5	#4	#3	#2	#1	#0
3202				NE9				NE8

 $#4(NE9) \approx 0$: Programs of 9000s are edited.

1 : Programs of 9000s can be protected.

 $\#0(NE8) \approx 0$: Programs of 8000s are edited.

1 : Programs of 8000s can be protected.

2. Select EDIT mode.

- key and press soft key [PRGRM] to display program 3. Press PROG text.
- 4. Press [(**OPRT**)] key and press soft key $[\triangleright]$.
- 5. Input a program number to be output. To output all programs input as: 9 9 9 9

Ο

6. Press [PUNCH] and [EXEC] key, then program output is started.

Procedure (DPL/MDI)

A program registered in memmory can be punched using the procedure below.

- 1. Confirm parameter as like above 1.
- 2. Select EDIT mode.
- 3. Press PRGRM to display the program screen.
- 4. Key in address O.
- 5. Key in a desired program number.

9 9 9 Entering -/+ 9 causes all programs in memory to be output.

6. The number of input program is punched with pushing WRITE

3.2.7 Outputting Ladder Programs

•	Procedure	(CRT/MDI)
-	1 I O O O G G G G G G	

1. Select **EDIT** mode.

- 2. Press of key [SETTING] to select a setting screen.
- 3. Set the cursor to **PARAMETER WRITE** and input 1 and **INPUT** At this time, alarm 100 will be generated.
- 4. Press system key and soft key [PMC].
- 5. Press soft key [PMCPRM] and soft key [KEEPRL]
- 6. Set the cursor to K17 and set the first bit to 1.



Where, mark x is a former value

Thus, data input/output screen has been selected.

- 7. Press soft key \bigcirc then key \bigcirc .
- 8. Press soft key **[I/O]** and set the parameters on I/O. Item selection cursor moves to the following item after data of an item is set.
- 9. In CHANNEL NO item, input $1 \mid |I^{\text{INPUT}}|$ to select I/O channel 1.
- 10. In DEVICE item, press soft key **[FDCAS]** to select the floppy cassette. It is also **[FDCAS]** for Handy File.
- 11. In KIND DATA item, press soft key [PARAM].
- 12.In FUNCTION item, press soft key [WRITE].
- 13. Press soft key [EXEC]. Then ladder programs are started to be output.
- 14.After the ladder programs have been output, set PARAMETER WRITE to 0.
- 15.Press RESET to release alarm 100.
- Procedure (DPL/MDI)
- 1. Select EDIT mode.
- 2. Press parameters key several time to select diagnosis screen.
- 3. Press $\begin{bmatrix} & & \\ & N_{0_{\alpha}} \end{bmatrix}$ key in the diagnosis screen then set file number.
- 4. Press write, then ladder programs are started to be output.

3.2.8 Inputting CNC Parameters

• Procedure (CRT/MDI)

CAUTION

For a system using an absolute pulse coder, zero point setting is required once all parameters have been input.

- 1. Set to the emergency stop state.
- 2. Confirm that the patameters required to input data is correct.
- 1) Press OFFSET/SETTING key several times, and press [SETING] to display SETTING screen.
- 2) Parameters can be rewritten when PARAMETER WRITE ENABLE is 1.
- 3) Press SYSTEM key to select the parameter screen.
- 4)

Address 0020 Selection of I/O channel $\Rightarrow 0$: Channel 1 (Connector JD5) 1 : Channel 1 (Connector JD5) I/O channel=0 Set parameters 0101, 0102, 0103 I/O channel=1 Set parameters 0111, 0112, 0113. 5) Address #7 #6 #4 #3 #0 #5 #2 #1 0101 NFD ASI SB2 **#7(NFD)** 0: Feed is output when punching out. 1 : Feed is not output when punching out. 0 : EIA or ISO code is used. #3(ASI) 1 : ASCII code is used. **#0(SB2)** 0 : No. of stop bits is 1. \Rightarrow 1 : No. of stop bits is 2. 6) Address 0102 Specification number of I/O device RS-232-C (for other than the following) 0 Not used 1 2 FANUC Floppy cassette F1 PROGRAM FILE Mate, Handy File FANUC Floppy casette 3 adapter, FSP-H 4 Not used 5 Not used FANUC FSP-G, FSP-H 6 7) Address 0103 Baud rate 7: 600 2400 9: 9600 11: 8: 1200 ☆10: 4800 12: 19200 [BPS]

3. Press soft key [(**OPRT**)] and soft key \triangleright

- 4. Press soft key [**READ**] and [**EXEC**]. Then input of parameters are started.
- 5. After the parameters have been input, turn off the power once then turn it on because P/S alarm 000 is occured.
- 6. For a system using an absolute pulse coder, alarm 300 is issued. Perform zero point setting.

• Procedure (DPL/MDI)

- 1. Press the EMERGENCY STOP button on the machine side.
- 2. The parameter screen is selected by pressing the PARAM key.
- 3. Set PWE on the setting screen to 1. Alarm PS100 is displayed at this time.
- 4. Perform the same operation as for program input.
- 5. NC parameters are input to the memory by this operation. Normally, alarm PS000 will activate after completion of parameter reading. Nomally, P/S alarm 000 is generated after parameters have finished being read in.
- 6. Set PWE on the setting parameter to 0.
- 7. Turn on the Power Mate power again.
- 8. For a system using an absolute pulse coder, alarm 300 is issued. Perform zero point setting.

3.2.9 Inputting PMC Parameters

• Procedure (CRT/MDI)	1. Set the emergency stop state.
	2. Press Setting key and soft key [SETTING] to select the SETTING
	screen.
	3. Confirm that PARAMETER WRITE=1.
	4. Press system key and soft key [PMC].
	5. Press soft key [PMCPRM] and soft key [KEEPRL].
	6. Set the cursor to K17 and set bit 1 to 1.
	$\times \times \times \times \times \times 1 \times \mathbb{I} \times \mathbb{I}$
	\times means the setting value which is before input.
	7. Press \bigcirc key and \bigcirc key.
	8. Press soft key [I/O] and set the parameters required for I/O. Item selection cursor displays the next item after an item is set.
	9. In CHANNEL item , press 1 INPUT to select channel 1.
	10.In DEVICE item, press [FDCAS] key to select the floppy cassette.
	11. In FUNCTION item, press soft key [READ] to input data
	12. Press soft key [EXEC] and the PMC parameters are started to be input.
	13. After data has been read, turn off power and turn it on.
• Procedure (DPL/MDI)	1. Set the emergency stop state.
	2. Press $MENU \\ VAR$ key several times and soft key to select the SETTING
	screen.
	3. Confirm that DWE=1.
	4. Press $\frac{D_{GNOS}}{P_{ARAM}}$ key several times and set diagnosis screen (@).
	5. Press $\begin{bmatrix} & @ \\ N_{0,c} \end{bmatrix}$ then set the file number.
	6. Press \mathbb{R}^{EAD} and the PMC parameters are started to be input.

7. After data has been read, turn off power and turn it on.

3.2.10 Inputting Custom Macro Variable Values

 Procedure (CRT/MDI) 	1. Confirm that EDIT mode is selected.
	2. Turn off the program protect key (KEY2=1).
	3. Press PROG key then soft key [PRGRM] to display program contents.
	4. Press soft key [(OPRT)] and key \triangleright .
	5. Press address O, a program number (0001 for example), soft key
	[READ] and [EXEC] key, then custom macro variable values are started to be input.
	Input a program number that is not used.
	6. Select AUTO mode on the machine operator's panel and press cycle start button.
	When the program is executed, macro variables are set.
	7. Press $\left[\bigcup_{\text{BETTING}}^{\text{OFFSET}} \right]$ key, $\left[\bigcup$ key and soft key [MACRO] to select the custom
	macro variable screen.
	 8. Press 500 and soft key [NO SRH] to display variable number 500 and confirm the custom macro variables are set correctly. Of the data displayed, 0 and vacant differ in meaning. Vacant is an undefined variable. To set vacant, press soft key [INPUT].
	9. Select EDIT mode again.
	10.Press PROG key to select the program display screen.
	11. Press address \bigcirc and a program number (0001 for example) ,then
	press Delete the program.
Procedure (DPL/MDI)	1. Select EDIT mode.
	2. Perform the same operation as for program input and read in the custom macro statements like a program.
	3. After reading is finished, select AUTO mode. By executing the program that was read in, the values of the common variables will be stored in memory.

3.2.11 Inputting Tool Compensation Amount

- Procedure (CRT/MDI)
- 1. Select the EDIT mode.
- 2. Turn off the program protect (KEY=1).
- 3. Press PROG key, and press soft key[**PRGRM**] to display the program contents screen.
- 4. Press key, and soft key [**OFFSET**] to display the tool compensation amount screen.
- 5. Press soft key [(**OPRT**)] and \triangleright key.
- 6. Press **[READ]** key and **[EXEC]** key and data input is started.
- Procedure (DPL/MDI)
- 1. Select the **EDIT** mode.
- 2. Display the data display screen by pressing $\begin{bmatrix} MENU \\ VAR \end{bmatrix}$ key.
- 3. Perform the same operation as for program input.
- 4. The input offset data will be displayed on the screen after completion of input operation.

3.2.12 Inputting Part	Confirm the following parameters. If 1 is set, set it to 0. (Change it in Emergency stop or MDI mode).								
Programs	Address	#7	#6 NPE	#5	#4	#3	#2	#1 RAI	#0
	#6 (NPE #1 (RAI	 Wher M02, 0 : reg 1 : no Wher 1 : no Wher 1 : 0 : Al 1 : 0 : 0 : Al 	n progra M30 an garded a ot regard n progra Il progra nly one	ms are a d M99 a as the er ed as th ms are a ums are program	registere are: ad of pro registere registere n is regis	ed in par ogram. f porgra ed: ed. stered.	rt progra	am stora	ige area,
	Address	#7	#6	#5	#4	#3	#2	#1	#0
	3202				NE9				NE8
	#4 (NE9 #0 (NE8	1 : Pr 1 : Pr)☆0 : Pr 1 : Pr	ograms ograms ograms ograms	of 9000 of 9000 of 8000 of 8000	os can be os are pr os can be os are pr	e edited. otected. e edited. otected.			
• Procedure (CRT/MDI)	 Confirm that mode is EDIT mode. Turn off the program protect (KEY3=1). 								
	3. Press Prog key and press soft key [PRGRM] to select a part program file.								
	4. Press soft \bigcirc key ,[(OPRT)] and \bigcirc key.								
	5. Press	soft key	[REAI)] and []	EXEC]	, then da	ita inpu	t is start	ed.
Procedure (DPL/MDI)	1. Select EDIT mode.								
	2. Press	PRGRM to	display	the prog	gram scr	een.			
	3. When numb contro chang	the cont er is to b oller tap ed, this	troller ta be chang e has a operatio	pe does ed, ente program	not have er a desin n numbe necessa	e a progr red prog er and a ary.)	am num ram nur prograi	ber or a mber. (V n numb	program Vhen the er is not
	i) K	ey in ad	dress [lesired r]. program	number	r.			
	4 Press	the READ	key	- OF WILL					
	7. 11035		ney.						

3.2.13 Inputting PMC Ladder

Procedure (CRT/MDI)	1. Set the emergency stop state.
	2 Dross Press loan and soft how [SETTINC] to solve the SETTINC
	2. PIESS Key and soft key [SETTING] to select the SETTING
	screen.
	3. Confirm that PARAMETER WRITE=1.
	4. Press key and soft key [PMC].
	5. Press soft key [PMCPRM] and soft key [KEEPRL].
	6. Set the cursor to K17 and set bit 1 to 1.
	$\times \times \times \times \times \times \times 1 \times \mathbb{I} \times I$
	\times means the setting value which is before input.
	7. Press \bigcirc key and \bigcirc key.
	8. Press soft key [I/O] and set the parameters required for I/O. Item selection cursor displays the next item after an item is set.
	9. In CHANNEL item , press 1 INPUT to select channel 1.
	10.In DEVICE item, press [FDCAS] key to select the floppy cassette.
	11. In FUNCTION item, press soft key [READ] to input data. In DATA KIND item, not set the data.
	12.Press soft key [EXEC] and the PMC ladder are started to be input.
	13.Store the input ladder into flash EEPROM. (On the screen displayed by pressing the [PMC] key, then the [I/O] key, set FROM for DEVICE and press the [WRITE] key, in the same way as in steps 8 to 11.)
	14.Turn off power and turn it on.
Procedure (DPL/MDI)	1. Set the emergency stop state.
	2. Press M_{VAR}^{MENU} key several times and soft key to select the SETTING
	screen.
	3. Confirm that PWE=1.
	4. Press key several times and set diagnosis screen (@).
	5. Press $\begin{bmatrix} \& & \theta \\ N_{0_{\star}} \end{bmatrix}$ then set the file number.
	6. Press \mathbb{READ} and the PMC ladder are started to be input.
	7. Store the ladder into flash EEPROM. For an explanation of how to store data into flash EEPROM, refer to Subsection 4.4.7.

8. Turn off power and turn it on.

4

INTERFACE BETWEEN NC AND PMC

This chapter describes the signals between the machine operator's panel, magnetics cabinet and the PMC, connection of the signals between PMC and Power Mate, and confirmation method of on/off state of these signals. The chapter also describes how to display the PMC system configuration, parameters, and ladders on the CRT or DPL. It also describes a method of inputting/outputting PMC parameters to an

- 4.1 GENERAL OF INTERFACE
- 4.2 SPECIFICATION OF PMC
- 4.3 OPERATION ON THE CRT/MDI
- 4.4 OPERATION ON THE DPL/MDI
- 4.5 LIST OF SIGNALS BY EACH MODE
- 4.6 ADDRESS LIST

external device.

4.7 SIGNAL AND SYMBOL CORRESPONDENCE TABLE

4.1 GENERAL OF INTERFACE



— 125 —

4.2 SPECIFICATION OF PMC

4.2.1 Specification

	Model	PMC-RA3
Programming metho	d language	Ladder
Number of ladder lev	/el	2
Level-1 Cycle Time		8 ms
Basic Instruction Exe	ecution Time	0.15 (μs/step)
Program capacity		
Ladder (step)		Approx. 5,000 (Basic)
		Approx. 12,000 (Option)
Symbol/comment (Note)	1 to 128KB
Message		0.1 to 64KB
 Language only 		
Instruction (B (F	asic) unction)	14 kinds 64 kinds
Internal relay	(R)	1118 byte
Message request	(A)	25 byte
Non-volatile		
Var. Timer	(T)	80 byte
Counter	(C)	80 byte
 Keep relay 	(K)	20 byte
 Data table 	(D)	1860 byte
Fixed timer		Timer No. 100 devices specified
Input/output		
• I/O Link	(1)	1024 points max.
(master)	(O)	1024 points max.
• I/O Link	(I) (O)	256 points max.
(slave)	(U)	256 points max.
• Built-in I/O card	(1)	32 point max.
	(U)	24 point max.
Sequence program s	storage media	Flash memory

NOTE

- 1 To enable use of the PMC, the PMC module must be installed.
- 2 Normal size of a symbol, a comment, and a message are 1KB, and 0.1KB, respectively. Max. size of a symbol and a comment are each 64KB.

4.2.2 Address

	Туре	Byte	Address	Explanation
G	PMC⇒CNC	256	G000.0 to G255.7	
F	CNC⇒PMC	256	F000.0 to F255.7	
Y	PMC⇒MT	168	Y000.0 to Y127.7	FANUC I/O Link (master)
			Y1000.0 to Y1002.7	Built-in I/O card
			Y1020.0 to Y1051.7	FANUC I/O Link (slave)
Х	MT⇒PMC	167	X000.0 to X127.7	FANUC I/O Link (master)
			X1000.0 to X1003.7	Built-in I/O card
			X1020.0 to X1051.7	FANUC I/O Link (slave)
A	Massege dis- play	25	A000.0 to A024.7	
R	Internal relay	1100	R000.0 to R999.7	
			R9000.0 to R9117.7	Operation result, system reserve area
Т	Variable timer	80	T000.0 to T079.7	
К	Keep relay	20	K000.0 to K016.7	
			K017.0 to K019.7	System reserve area
С	Counter	80	C000.0 to C079.7	
D	Data table	1860	D0000.0 to D1859.7	

4.2.3 Built–in Debug Function

Function	Contents
Display of sequence pro- gram	Dynamic display of ladder diagram * This function is not provided by the handy operator's panel or DPL/MDI.
Diagnostic function	 Title data display Signal status (symbol can be displayed) PMC alarm display
Setting and displaying data	TimerCounterKeep relayData table
Sequence program edit function	Ladder diagram editing (A ladder edit module for memory card is required) * Ladder charts are edited using mnemonics on the DPL/MDI. * Ladder chart editing and mnemonic editing are not supported by the handy operator's panel.

4.2.4 **System Reserve Area** #7 #6 #5 #4 #3 #2 #1 #0 of Internal Relay Operation result R9000 V Ζ Ν register Zero Sign is minus Overflow #7 #6 #5 #4 #3 #2 #1 #0 R9002 R9003 Register for remainder (used by DIVB instruction) R9004 R9005

4.2.5 Execution Period of PMC



— 128 —

4.3 OPERATION ON THE CRT/MDI

4.3.1 Display Method

1. Press SYSTEM .

2. Press soft key **[PMC]**, then PMC screen is displayed and the following soft keys are displayed:

·			
PMC CONTROL SYSTEM 1	MENU	MONIT RUN	
SELECT ONE OF FOLLO	WING SOFT KE	YS	
PMCLAD: DYNAM:PMCDGN: DIAGNOPMCPRM: PARAMIRUN/STOP: RUN/STEDIT: EDIT: EDIT: EDIT: I/O: I/O SISYSPRM: SYSTEM	IC LADDER DIS DSIS FUNCTION ETER (T/C/K/I TOP SEQUENCE SEQUENCE PROG EQUENCE PROG M PARAMETER	SPLAY ()) PROGRAM GRAM 2AM	When built-in program- mer is run- ning.
$\left(\begin{array}{c} PMCLAD \end{array}\right) \left(\begin{array}{c} PMCDGN \end{array}\right) \left($	pmcprm) ()()
	System Status o Dynami	parameter screer lisplay of PMC I/C c display of seque) signal ence program
$\left(\begin{array}{c} \text{stop} \end{array} \right) \left(\begin{array}{c} \text{edit} \end{array} \right) \left(\end{array}$	I/O) (SYSE	PRM) ()
		— System para Input/output gram	ameter screen of sequence pro-
		— Editing sequ — RUN/STOP	ence program of sequence

The no. of menus to be displayed changes depending on presence/absence of built-in programmer.

	PMC-PA3 (Without memory card for editing)	PMC–PA3 (With memory card for editing)
RUN/STOP	0	0
EDIT	×	0
I/O	0	0
SYSPRM	×	0

 \times : Cannot be displayed nor used.

4.3.2 PMCLAD SCREEN

Press soft key **[PMCLAD]**, and a sequence program is displayed dynamically and operation monitoring can be confirmed :



- Contents displayed
- Search method

4.3.3 PMCDGN SCREEN

Press soft key [PMCDGN] then PMC's diagnostic screen is displayed.

• TITLE screen

The title data registered when a ladder program is prepared is displayed.

Page number

	1	1			
PMC	TITLE DATA #	1		MONIT RI	ИС
	PMC PRC EDITION	GRAM NO. I NO.	:		
	PMC CON	ITROL PRO	GRAM		
	SERIES	: 4061	EDITION	: 01	
	ME	MORY USEI) :	KB	
	LA	DDER	:	KB	
	SY	MBOL	:	KB	
	ME	SSAGE	:	KB	
	50.	AN IIME	•	MSEC	
(ті	TLE) (STATUS	$\Big) \Big($ alarm		ce) (
Other so	ft keys				
(M) ()) (٦
(M.,	SKCH J (ANALIS	λ	Jι	λί	J
1st page	PMC PROGRAM I EDITION NO.	NO. :			- Set when PMC is
	PMC CONTROL F	PROGRAM EDITION :	Z _s	eries and e	dition of PMC
	MEMORY USED	: [∠∠ кв	ontrol softwa	are
	LADDER	: 2	KB	Mer	nory used and
	MESSAGE			disp	cution time is layed.
	SCAN TIME	: [ZZ MSE	EC) '	,
2nd page	MACHINE TOOL E	BUILDER NA NAME :	ME :		
	CNC & PMC TYPE PROGRAM DRAV	E NAME : /ING NO. :		Set w	hen PMC
3rd page	DATE OF DRAWIN PROGRAM DESIG ROM WRITTEN B REMARKS :	NG : GNED BY : Y :			

• STATUS screen

On/Off state of input/output signals and internal relay is displayed. [Search Method]

- Page key :Forward and Backward by screen
- Cursor key :Forward and Backward by diagnostic number
- To search a specified address or signal name, input an address number or signal name and press [SEARCH].



Alarm screen

Displays an alarm generated in PMC.

/				
,	PMC ALARM MESSAGE MONIT	RUN		Alarm dis- play
	ER32 NO I/O DEVICE <			For details of alarms, refer to Appendix B List of Alarms.
		ALM	-	_ Blinked
	$\left(\begin{array}{c} \textbf{title} \end{array}\right) \left(\begin{array}{c} \textbf{status} \end{array}\right) \left(\begin{array}{c} \textbf{alarm} \end{array}\right) \left(\begin{array}{c} \textbf{trace} \end{array}\right) \left(\begin{array}{c} \end{array}\right)$			

TRACE screen

Every time a specified signal changes, the signal status is memorized in the trace memory. This function is useful for identifying intermittent troubles.

(1) Trace parameter screen



the next page)

Select each item by cursor key

- a. TRACE MODE: Select the trace mode
 0=Records changes of 1-byte signals
 1=Records changes of independent 2-byte signals
 2=Records changes of consecutive 2-byte signals
 - 2=Records changes of consecutive 2-byte signals
- b. ADDRESS TYPE:

0=PMC address is used for tracing address. 1=Physical address is used for tracing address. (Mainly used for C-language program)

- c. ADDRESS:Set a tracing address.
- d. MASK DATA: The bits to be traced are specified by a hexadecimal number (2 digits).

For example, to trace the signals at bit 7,6,5 and 0, set E1 (hexadecimal) to MASK DATA.

#7 #6 #5 #4 #3 #2 #1 #0

E1% 1 1 1 0 0 0 0 1

However, even if bit 4,3,2 and 1 changes, tracing (memory registration) cannot be done but signal status is memorized when a tracing is executed.

[Correspondence of binary and hexadecimal number]

$0000_2:0_{16}$	$0001_2:1_{16}$	$0010_2:2_{16}$	$0011_2:3_{16}$
$0100_2:4_{16}$	$0101_2:5_{16}$	$0110_2:6_{16}$	$0111_2:7_{16}$
$1000_2:8_{16}$	$1001_2:9_{16}$	1010 ₂ : A ₁₆	1011 ₂ : B ₁₆
$1100_2: C_{16}$	$1101_2 : D_{16}$	$1110_2: E_{16}$	$1111_2: F_{16}$

(2) Trace memory contents display screen

PMC SIGNAL TRACE	MONIT RUN	
1ST ADDRESS=X008(E1)	2ND ADDRESS=G000(FF)	
NO. 76543210	76543210	and mask
0000		data
0001 I******	* * * * * * *	
0002 II*****	* * * * * * *	
0003 * I * * * * * *	* * * * * * *	 Latest status
0004		I mark : 1
0005		* mark : 0
0006		
0007		
0008		
		1
(IRCPRM) (STOP)		J J
<u> </u>	40//1 00/4	
		1/// III is displayed

10"LCD/14"CRT is displayed by 1 and 0.

- a. Soft key [**TRCPRM**]: Return to the trace parameter setting screen (screen of previous page)
- b. Soft key [EXEC]: Starts tracing. Trace memory is cleared and each time a specified signal changes, its status is recorded. Trace memory is 256 bytes and if tracing is executed 128 times by 2–byte tracing, tracing is executed again from the head of memory.
 c. Soft key [STOP]: Ends the tracing.

*The tracing parameters are held even if the power is turned off.

Address	#7	#6	#5	#4	#3	#2	#1	#0
K017								

#5 0 : Tracing starts by **[EXEC]**.

1 : Tracing starts automatically after power on
one

one

4.3.4 PMCRAM Screen

Inputting PMC parameters from the MDI

- (1) Set to MDI mode or emergency stop state.
- (2) Set PARAMETER WRITE (on setting screen) to 1 or set the program protect signal (KEY4) to 1.

	PWE	KEY4	
Timer	0	-	Fither
Keep relay	0	-	Littlei
Data table	0	0	Either

(3) Press a soft key and select a required screen.

[TIMER]	:Timer screen
[COUNTR]	:Counter screen
[KEEPRL]	:Keep relay screen
[DATA]	:Data table screen

- (4) Press cursor key and move the cursor to a desired number.
- (5) Input a numeric key and press |NPUT| key and data is input.
- (6) After the data is input, set PARAMETER WRITE or KEY4 on setting screen to 0.

This screen is used for setting timer time of the functional instruction (SUB 3).

	Page No. (screen is scrolled by page key)									
	Timer No. specified by functional instruction									
					Addr	ess specified	by lade	der		
1				¥			$\overline{}$			
	PMC	PARAMETER	(TIMER)	#001	MO	NIT RUN				
				V	· 🖌					
	NO.	ADDRESS	DATA	NO.	ADDRE	ESS DATA				
	01	T 00	480	11	т20	0		 Timer 		
	02	T02	960	12	T22	0		delay		
	03	T04	0	13	т24	0		time (msoc)		
	04	T06	0	14	T26	0		(IIISEC)		
	05	T08	0	15	T28	0				
	06	T10	0	16	т30	0				
	07	T12	0	17	т32	0				
	08	T14	0	18	т34	0				
	09	T16	0	19	т36	0				
	10	T18	0	20	т38	0				
	(ті	mer] (cou	INTR) (KE	EPRL) (DATA) [
1	<u>`</u>	~ ~	/ \			/ \	Ĺ			

Timer set time : Timer no. 1–8 is max. 1572.8 sec and its accuracy is 48ms. Timer no. 9–40 is max. 262.1 sec and its accuracy is 8ms.

• TIMER screen

• COUNTER screen

This screen sets and displays max. value of counter and current value of the counter instruction (SUB 4).



• KEEP RELAY screen

					Address specified by la	adder
PMC PAR	AMETER	(KEEP REALA	Y) ‡	ŧ001	MONIT RUN	
NO.	ADDRESS	DATA	NO.	ADDR	ESS DATA	
01	к00	00000000	11	K10	00000000	
02	K01	00000000	12	K11	00000000	
03	K02	00000000	13	K12	00000000	
04	к03	00000000	14	K13	00000000	
05	K04	00000000	15	K14	00000000	
06	K05	00000000	16	K15	00000000	
07	К06	00000000	17	K16	0000000	
08	K07	00000000	18	K17	0000000	
09	K08	00000000	19	K18	0000000	
10	к09	00000000	20	K19	0000000	
		$TR \left(KEEPRL \right)$)(DATA		
	Ad	dress specified b	y lado	der	Used by PMC	system

(1) Nonvolatile memory control

Address	#7	#6	#5	#4	#3	#2	#1	#0
K016								

#7(MWRTF2): For checking the writing status in nonvolatile memory **#6(MWRTF1)**: Writing status in nonvolatile memory

(2) PMC system parameter

The following keep relays are used by the system, therefore they cannot be used in the sequence program.

Address	#7	#6	#5	#4	#3	#2	#1	#0
K017								

#5 TRCSTAT

- 0 : Signal tracing starts by soft key **[EXEC]** in signal trace function.
- 1 : Signal tracing starts automatically by power on in signal trace function.

#4 MEMINP

- 0 : Data input cannot be done in memory contents display function.
- 1 : Data input can be done in memory contents display function.

#2 AUTORUN

- 0 : Ladder is executed on the RAM operation after the power is turned on.
- 1 : Ladder is not executed on the RAM operation after the power is turned on.

#1 PRGRAM

- 0 : Built-in programmer is not used.
- 1 : Built–in programmer is used.

#0 LADMASK

- 0 : Dynamic display of ladder is executed.
- 1 : Dynamic display of ladder is not executed.



Address	#7	#6	#5	#4	#3	#2	#1	#0
K019								

These bits are used by system. Do not change the values. Usually all the bits are 0.

• DATA TABLE screen

(1) Data table setting screen



- a. Soft key [G.DATA] : Select data display screen of data table. (Next screen)
- b. NO. OF GROUPS [G.CONT] : Set the no. of groups of data table.
- c. Group No. [NO.SRH]: Move the cursor to a specified group.
- d. Soft key [INIT]: Initializes the setting of data table.
 No. of groups is 1, ADDRESS is D0000, PARAMETER is 0000000, TYPE is 0, NO. OF DATA is 1860.

This operation is done usually when a sequence program is prepared. When PMC parameters are set, internal parameters are not affected.

PARAMETER



TYPE

0 : 1-byte length 1 : 2-byte length 2 : 4-byte length

e. Using the page key, next screen/previous screen can be selected. (If the number of screens item is blank, screen switching cannot be performed.)

— 138 —

(2) Data	displa	y screen
----------	--------	----------

		V	Group nur Page num ▼	nber ber	
MC	PRM	(DATA) 001	/001	MONIT	RUN
	NO.	ADDRESS	DATA		
	000	D0000	0		
	001	D0001	0		
	002	D0002	0		
	003	D0003	0		
	004	D0004	0		
	005	D0005	0		
	006	D0006	0		
	007	D0007	0		
	008	D0008	0		
	009	D0009	0		
(c.	DATA	$\left(\text{ g-srch} \right)$	$\left(\begin{array}{c} \text{search} \end{array} \right) \left(\right.$)(

b. Group No. [G–SRCH] : Head of the specified group is selected.
c. Address [SEARCH] : Searches an address in a group currently selected.

4.4 OPERATION ON THE DPL/MDI

The DPL/MDI panel is used to set PMC system parameters and create and execute the sequence program.

- (1) Setting and displaying PMC system parameters (SYSTEM PARAM)
 - The type of counter data (BCD or binary) can be selected.
- (2) Editing the sequence program (EDIT)
 - The sequence program can be edited (input, addition, search, and deletion) by using the ladder mnemonics display.
- (3) Executing the sequence program (RUN/STOP)
 - The execution of the sequence program can be started and stopped.
- (4) Storing the sequence program into flash ROM (I/O)
 - The sequence program can be stored into flash ROM.

NOTE

- 1 The indication at the bottom left of each key applies to the PMC programmer (DPL/MDI) function.
- 2 For keys such as the $\mathbb{R}_{\mathcal{D}\mathcal{R}^{\mathcal{K}}}$ key, the indication on the left applies when the key is pressed once and that on the right applies when the key is pressed twice.

(Example) Pressing the $\mathbb{R}_{D/R^{K}}$ key once enters "D" and pressing it twice enters "R." However, only the indication on the left applies when the password is cleared.

The screen configuration for the PMC programmer (DPL/MDI) function is as follows:



4.4.1 Selectingthe PMC Programmer Menu

To operate the PMC programmer, set K17#1 of the keep relay area for PMC parameters to 1, then press the RGRM key two times on the DPL/MDI (press the RGRM key further when the program screen is selected), thus causing the PMC programmer menu to be displayed.

Program screen <O0001> N010 G90 G01 G43 X10; PMC programmer menu screen PMC PRG MENU 1/3 >RUN/STOP Can be switched only when K17#1 = 1. Can be switched only when K17#1 = 0.



4.4.2

Setting and Displaying System Parameters (SYSTEM PARAM) Selecting SYSTEM PARAM on the PMC programmer menu displays the system parameter screen. If the sequence program is running, selecting this function automatically stops the program.

- 1 Display the PMC programmer menu.
- 2 Display the SYSTEM PARAM item by pressing the **I** or **t** key.



3 Press the INPUT or READ key. The system parameter screen appears.



- 4 The current counter data type is displayed on the screen.
 - (a) Specify the type of the counter value to be used for the CTR functional instruction, as binary or BCD (enter o for binary or

```
| for BCD).
```



The counter data type is set.

5 Pressing the $\begin{bmatrix} CAN \end{bmatrix}$ or $\begin{bmatrix} WRITE \end{bmatrix}$ key displays the PMC programmer menu.

NOTE

When K19#0 of the keep relay area for PMC parameter is set to 1, the screen for storing the sequence program into flash EEPROM is displayed after ladder editing.

DEVICE=F-ROM >WRITE Y/N[YES]

Please refer to the Subsec. 4.4.7 and storing the sequence program into flash EEPROM.



r in r

4 When the password protection is performed, message requiring the release of password is displayed.

PASSWORD (R/W)

NOTE

A ladder program for which the password has been specified cannot be edited by ladder mnemonics editing until correct password is entered. Once password protection is released, the protection remains released until the power is turned off then on again.

5 Enter the password and press the I^{NPUT} key.

NOTE

The entered password is not displayed. (Echo back is not performed.)

When the password is not correctly specified, the error message is displayed.

FALSE PASSWORD

At this time, the display returns to the release requirement of password by pressing the \overline{INPUT} key.

Moreover, the display returns to the PMC editing menu by pressing the CAN key. When the password is correctly specified, the protection is released.

6 The sequence program is displayed.



- (2) Confirming the ladder mnemonics
- 1 Cursor scroll (scroll per step)

Pressing the t cursor key displays the instruction one step before that currently displayed. Pressing the t cursor key displays the instruction one step after that currently displayed.

2 Specifying the step number

Entering $\begin{bmatrix} \& & @ \\ No \end{bmatrix}$, <step number>, then $\begin{bmatrix} INPUT \end{bmatrix}$ displays the instruction having the entered step number.

(The **I** cursor key can be used instead of the **INPUT** key.)

(Example)	& @ No.	,			2		3],	F
-----------	------------	---	--	--	---	--	---	----	---

— 144 —

N0123 SUB 50 PSGNL
Relay search
Entering <address number=""> then I searches for the relay</address>
including the entered address.
(Example) $\left[\begin{smallmatrix} X \\ AXIS \\ x \end{smallmatrix} \right] $ $0 $ $\bullet $ $2 $, $\bullet $
N0105 AND X0000.2
Relay coil search
Entering $\begin{bmatrix} S \\ WR \\ SET \end{bmatrix}$, <address number="">, then \blacksquare searches for the relay</address>
coil including the entered address.
(Example) $\left[\begin{array}{c} S \\ WR \\ VSET \end{array} \right], \left[\begin{array}{c} O \\ V \end{array} \right] \left[\begin{array}{c} 3 \\ \end{array} \right] \left[\begin{array}{c} \bullet \\ \end{array} \right] \left[\begin{array}{c} \bullet \\ \end{array} \right], \left[\begin{array}{c} \bullet \\ \bullet \\ \end{array} \right] \left[\begin{array}{c} \bullet \\ \end{array} \right], \left[\begin{array}{c} \bullet \\ \bullet \\ \end{array} \right]$
N0187 WRT. NOT Y0033.5
Functional instruction search
Entering $[H]_{SUB}$, <functional instruction="" number="">, then \blacksquare searches</functional>
for the entered functional instruction.
(Example) $[H]_{SUB}$, 5 0, 4
N0123 SUB 50 PSGNL

NOTE

3

4

5

1 Relay search, relay coil search, and functional instruction search are started from the current screen. If the relay, relay coil, or instruction is not found by the end of the ladder program, search is performed from the beginning of the ladder program to the step at which search was started. If still not found, "NOT FOUND" is displayed.

N0105 NOT FOUND AND X0000.2

2 Display of some instructions may differ from that for FAPT LADDER.

P–G, personal–computer FAPT LADDER	Ladder mnemonics editing
(a) RD.NOT.STK	RD.N.STK
(b) TMR timer-number	SUB 03 TMR P001 timer–number
(c) DEC code–signal–address (PRM) decode–instruction	SUB 04 DEC P001 code–signal–address P002 decode–instruction

The above also applies when modifying the ladder mnemonics.

- (3) Modifying the ladder mnemonics
- **1** Changing an instruction
 - (a) Display the instruction to be changed.
 - (b) Enter a new instruction.



NOTE

If changing the instruction causes the memory capacity to be exceeded, the key is ignored without changing the instruction.

- 2 Deleting an instruction
 - (a) Display the instruction to be deleted.
 - (b) Press the DELET key.

The instruction is deleted and the next instruction is displayed.

- 3 Inserting an instruction
 - (a) Display the instruction after which an instruction is to be inserted.
 - (b) Enter the instruction to be inserted.

(c) Press the	NSRT key.				
(Example)	$\left(\begin{array}{c} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\$				
N1234 AND	R0123.4				
Before insertion					
N1234 AND.STK					

After insertion

	_
NOTE	

If inserting the instruc	tion causes the memory capacity to be
exceeded, the INSRT	key is ignored without inserting the
instruction.	

- 4 Deleting the ladder program
 - (a) Enter 9 9 9 9
 - (b) Press the **DELET** key.

The whole ladder program is deleted.

- (4) Ending ladder mnemonics editing
- 1 Press the CAN or WRITE key.
- 2 "EXECUTING" is displayed.

N0001	
EXECUTING	

3 The PMC editing menu appears.

NOTE

1 When K19#0 of the keep relay area for PMC parameter is set to 1, the screen for storing the sequence program into flash EEPROM is displayed after ladder editing.

DEVICE=F-ROM	
>WRITE	Y/N[YES]

Please refer to the Subsec. 4.4.7 and storing the sequence program into flash EEPROM.

2 If the sequence program contains an error, the PMC editing menu is not displayed but an error message appears on the screen.

(Example) Error message

END FUNCTION MISSING

Pressing the \checkmark or \checkmark cursor key displays the ladder mnemonics editing screen.

3 Pressing the POS, PREM, WENU, PARAM, or LARM key during the editing of the sequence program displays the CNC screen by forcibly terminating editing even if the program contains an error.

4.4.5 Selecting RUN/STOP on the PMC programmer menu displays the sequence program start/stop screen. **Starting and Stopping** Display the PMC programmer menu. the Sequence Program 1 (Run/Stop) 2 Display the RUN/STOP item by pressing the **4** or **4** key. PMC PRG MENU 1/3 >RUN/STOP Press the I^{INPUT} or R^{READ} key. The sequence program start/stop screen 3 appears. LADDER RUN/STOP MONITOR [RUN] 4 The current execution state of the sequence program is displayed on the screen. or **t** key switches the state between running and Pressing the ÷. stopped. Pressing the CAN or WRITE key displays the PMC programmer menu. 5

NOTE

When the sequence program cannot be started (RUN), the alarm of PMC occurred. Please confirm the alarm status referring to "4.4.10 Error List".

4.4.6 Error Messages (for Ladder Mnemonics Editing)

	Displayed error message	Error description (operator action)		
1	COIL NOTHING	No coil is specified for a functional instruction using a coil.		
2	COM FUNCTION MISSING	The use of the COM (SUB9) functional instruction is incorrect.		
3	END FUNCTION MISSING	The END1 or END2 functional instruction is missing (or ERROR NET).		
4	JUMP FUNCTION MISSING	The use of the JMP (SUB10) functional instruction is incorrect.		
5	LADDER BROKEN	The ladder program is corrupted.		
6	OBJECT BUFFER OVER	The user program RAM is full. (Note) (Perform condensation or reduce the size of the ladder program.)		
7	PLEASE CLEAR ALL	The sequence program has become unrecoverable due to power-off during editing.		
8	1ST LEVEL EXEC TIME OVER	The ladder first level is too great.		

NOTE

Use a memory card for ladder diagram editing or the CONDENSE function of FAPT LADDER (for personal computers). These methods may, however, not be effective.

4.4.7 Storing the Sequence Program into Flash Eeprom (I/O)

Selecting I/O on the PMC programmer menu displays the screen for storing the sequence program into flash EEPROM. Before attempting to store the sequence program into flash EEPROM, place the CNC in the emergency stop state.

- (1) Display the PMC programmer menu.
- (2) Display the I/O item by pressing the **v** or **t** key.





(4) When [NO] is displayed, pressing the x = x + y key displays the sequence

program storage screen. When [YES] is displayed, pressing the tweet key starts writing the sequence program into flash EEPROM.

"EXECUTING" is displayed during writing.

WRITE TO F-ROM EXECUTING "EXECUTING" BLINKS.

Once the sequence program has been written normally, "COMPLETE" is displayed.

WRITE TO F-ROM COMPLETE

NOTE

If an error occurs, an error message appears on the screen.

Example

Example error message

NOT EMG STOP

To return to the sequence program storage screen, press the I^{INPUT} or write key.

(1) Pressing the CAN key displays the PMC programmer menu.

Error details

The table below lists the details of the errors which may occur during storage into F–ROM using the DPL/MDI.

Error message	Description	
PROGRAM DATA ERROR	The ladder data in RAM is invalid. Alternatively, there is no RAM or ROM.	
SIZE ERROR	The program exceeds the maximum size which can be written into F–ROM.	
NOT EMG STOP	The CNC is not in the emergency stop state.	
OPEN ERROR	The OPEN processing has failed (IOCS library).	
ERASE ERROR	The ERASE processing has failed (IOCS library). The F–ROM cannot be erased. Alternatively, the F–ROM is defective.	
WRITE ERROR	The WRITE processing has failed (IOCS library). The F–ROM cannot be written. Alternatively, the F–ROM is defective.	

4.4.8

Input/Output Ladder/PMC– parameter by DPL/MDI

Input/Output method to office programmer (P–G Mate/Mark II) (Fixed 9600bit/sec.)

Input/Output method to FANUC FLOPPY CASSETE (Fixed 4800bit/sec.)

- Method of Inputting/Outputting Ladder
 - (1) Select "Diagnose screen" by key in $P_{\text{PARAM}}^{\text{DGNOS}}$ key.
 - (2) Key in READ key or WRITE key.
 - (3) Turn on <F8> key from the office programmer menu screen, and key in menu number "5<NL>" or "3<NL>".
- Method of Inputting Ladder and PMC–Parameter.
 - (1) Select "Diagnose screen" by key in $P_{\text{PARAM}}^{\text{DGNOS}}$ key.
 - (2) Key in $\begin{bmatrix} \& @ \\ NQ \end{bmatrix}$ key and optionally key in [File No.].
 - (3) Key in READ key.

NOTE

In case of input PMC–Parameter, it is necessary to set following conditions.

- (a) Emergency stop condition, and NC–Parameter PWE=1.
- (b) Stop condition the Ladder program.
- Method of Outoutting Ladder.
 - (1) Select "Diagnose screen" by key in $\frac{D_{\text{GNOS}}}{P_{\text{ARAM}}}$ key.
 - (2) Key in $\begin{bmatrix} & & \\ & No. \end{bmatrix}$ key and optionally key in [Files No.].
 - (3) Key in WRITE.

— 150 —

- Method of Outputting PMC-Patameter.
 - (1) Select "PMC STATUS screen" by key in β_{ARAM}^{DGNOS} key.
 - (2) Key in $\begin{bmatrix} & & @ \\ & No. \end{bmatrix}$ key and optionally key in [File No.].
 - (3) Key in WRITE

NOTE

In case of output PMC–Parameter, it is necessary to set following condition.

(a)Edit mode.

(b) Stop condition the Ladder program.

4.4.9 On–line Debugging Function

The on–line debugging function enables the monitoring and modification of ladder programs and signal status on personal computer's screen using a personal computer connected to the Power Mate through an RS–232–C cable.

FANUC FAPT LADDER–II is necessary to use the on–line debugging function. (This software is a programming system for developing FANUC PMC sequence programs which operate on IBM PC/AT and compatible computers.)

Software name	Specification	Personal computer	
FAPT LADDER–II A08B–9201–J503		IBM PC/AT and compatible	

In this section, only the parameter of on-line monitor driver for Power Mate-H and attention in use is described. Other points(connection of cable with personal computer, details of the operation, etc.) are described in the following manual.

Name of Manual	Spec.No.	Reference Items
FAPT LADDER-II OPERATOR'S MANUAL	B–66184EN	On-line function

Starting and stopping the on-line debugging function

When using the on-line debugging function to connect a personal computer to the PMC, first start the driver that provides the communication function of the PMC.

When starting or stopping the driver, it is necessary to set either of the following parameters.

• Parameter screen for on-line monitor([PARAMETERS FOR ONLINE MONITOR])

Pressing the [MONIT] then [ONLINE] soft keys on the PMC menu screen causes the on-line monitor parameter screen to appear.

Parameter[RS-232C] = [USE] : On–line monitor driver is used. [NOT USE |: On–line monitor driver is not

used.

NOTE

The CRT/MDI is necessary when the parameter is set on the "PARAMETERS FOR ONLINE MONITOR" screen. • Parameter in the Power Mate–H (No.0101#6)

	#7	#6	#5	#4	#3	#2	#1	#0
0101								

#6 = 0 : On-line monitor driver is not used. 1 : On-line monitor driver is used.

When either of the following conditions consists, the on-line monitor driver is started.

•Parameter "RS–232C" is "USE"

•Bit 6 of parameter No.0101 is "1"

NOTE

1	The on-line monitor driver occupies the line while it is
	uperaling.
	in this state, other input/output functions cannot use the
	If other input/output functions use the line, it is necessary to
	display the above-mentioned parameter and stop the
	on–line monitor driver.
2	While the on-line monitor driver is operating, the following
	functions cannot be used.
	[PMCLAD], [I/O], [EDIT], [SYSPRM] on CRT/MDI
	•[EDIT], [SYSTEM PARAM], [I/O] on DPL/MDI
3	In case of operating NC, the screen display of NC(Position.
	etc.) might be slow when using input/output functions(Load
	from PMC. Store to PMC, etc.) There is no problem in the
	operation of NC. It is recommended to using input/output
	functions while NC is not operating
Δ	When the screen made by C language executor is
-	displayed the communication speed decreases. It is
	uspiayed, the communication speed decreases. It is
	recommended to use input/output functions after moving to
	OTHER SCREENS(POSITION, ETC.).

4.4.10 Error List

If in alarm is issued in the PMC, the alarn message is displayed on the CRT (PMC ALARM MESSAGE screeen). But in case of DPL/MDI, it is displayed only by R-relay status (ON or Off).

Refer to the "APPENDIX B. ALARM LIST" for more information.

(1) Error ststus at power on or PROGRAM DOWN LOAD.



4.5 LIST OF SIGNALS BY EACH MODE

• Automatic operation

MODE		INPUT/OUTPUT SIGNAL		FEED RATE, ETC
	EDIT	[PMC ⇒ P KEY3(Proç	ower Mate] gram protect key)	
AUTOMATIC OPERATION	AUTO MDI	$\begin{array}{l} \mbox{[PMC} \Rightarrow \\ \mbox{ST} \\ \mbox{*SP} \\ \mbox{SBK} \\ \mbox{DRN} \\ \mbox{BDT1 to 9} \\ \mbox{MI} \\ \mbox{PN1 to 8} \\ \mbox{AFL} \\ \mbox{FIN} \\ \mbox{MFIN} \end{array}$	Power Mate) (Cycle start) (Feed hold) (Single block) (Dry run) (Optional block skip) (Mirror image) (External program number search) (Auxiliary function neglect) (Auxiliary function complete) (High speed M/S/T function complete)	[PMC ⇒ Power Mate] *FV0 to 7 (Feed rate override) OVC (Override cancel) ROV1,ROV2 (Rapid traverse over- ride)
		[Power Ma STL SPL MF, M00 to DEN OP	$\begin{array}{l} \text{te} \Rightarrow PMC]\\ (Cycle \ \text{start} \ LED)\\ (Feed \ hold \ LED)\\ o \ M31 (Miscellaneous \\ function)\\ (Distribution \ end)\\ (Automatic \ operating) \end{array}$	

Manual operation

M	MODE		INPUT/OUTPUT SIGNAL	FEED RATE, ETC		
M A N	JO	G	$\begin{array}{l} [PMC \Rightarrow Power Mate] \\ RT \qquad (Rapid traverse) \end{array}$	$\begin{array}{l} [PMC \Rightarrow Power Mate] \\ ^{*}JV0 \text{ to } 15 \\ (Manual feedrate \\ override) \end{array}$		
U A L O P E		Z	$\begin{array}{l} [PMC\RightarrowPower Mate]\\ ZRN(Reference position return mode)\\ [MT\RightarrowPower Mate]\\ ^*DEC\alpha & (Reference position deceleration) \end{array}$	+α, –α (Manual feed move com- mand) ROV1, ROV2 (Rapid traverse over- ride)		
R A T O N		N	[Power Mate \Rightarrow PMC] ZP α ZP2 α , ZP3 α (Reference position return completion)			

• Others

Others	$\begin{array}{l} [PMC \Rightarrow P^{i}\\ MD1 \text{ to } 4\\ *ESP\\ KEY1 \text{ to } 4\\ MLK\\ *IT,*IT\alpha\\ *\pm MIT\alpha\\ *ABSM\\ SVF\alpha\\ *FLWP\\ ERS\\ RRW\\ \pm LM\alpha, RL \end{array}$	ower Mate] (Mode selection) (Emergency stop) (Memory protection key) (All axes machine lock) (All axes/ each axis machine lock) (Interlock per axis and direction:) (Manual absolute) (Servo off) (Follow up) (External reset) (Reset & Rewind) SOT (Software limit external setting)
	[Power Ma MA SA AL RST BAL	te \Rightarrow PMC] (Ready) (Servo ready) (Alarm) (Resetting) (Battery alarm)
	INPα IPLα	(In–position) (Distribution signal)

4.6 ADDRESS LIST

Address of interface signal between Power Mate and PMC.



$MT \to PMC$	Bit No.								
(I/O card, I/O unit)	Address	#7	#6	#5	#4	#3	#2	#1	#0
	X000	SKIP	*RILK		*ESP		SKIP4	SKIP3	SKIP2
				*DE00	*DEOF	*DEC4	*DE00	*DE00	*DE04
	X002			"DEC6	DEC2	"DEC4	"DEC3	"DEC2	"DEC1
$MT \rightarrow PMC$ (Ruilt in VO cord)					Bit No				
(Built-III I/O Card)	Address	#7	#6	#5	#4	#3	#2	#1	#0
	X1000	SKIP	*RILK		*ESP		SKIP4	SKIP3	SKIP2
	X1002			*DEC6	*DEC5	*DEC4	*DEC3	*DEC2	DEC1

Bit No.

Address	#7	#6	#5	#4	#3	#2	#1	#0
G004					FIN			
G005		AFL						MFIN
G006				OVC		*ABSM		
G007	RLSOT		*FLWU			ST		
G008	ERS	RRW	*SP	*ESP				*IT
G009	PN7	PN6	PN5	PN4	PN3	PN2	PN1	PN0
G010	*JV7	*JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0
G011	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8
G012	*FV7	*FV6	*FV5	*FV4	*FV3	*FV2	*FV1	*FV0
G014							ROV2	ROV1
G018						HS1C	HS1B	HS1A
G019	RT		MP2	MP1				
G043	ZRN					MD4	MD2	MD1
G044							MLK	BDT1
G045	BDT9	BDT8	BDT7	BDT6	BDT5	BDT4	BDT3	BDT2
G046	DRN	KEY4	KEY3	KEY2	KEY1		SBK	
G053					UINT			
G054	UI7	UI6	UI5	UI4	UI3	UI2	UI1	UIO
G055	UI15	UI14	UI13	UI12	UI11	UI10	UI9	UI8
G058					EXWT	EXSTP	EXRD	
G066		EPCON						IGNVRY
G100			+J6	+J5	+J4	+J3	+J2	+J1
G102			–J6	-J5	-J4	–J3	-J2	-J1
G106			MI6	MI5	MI4	MI3	MI2	MI1
G110			+LM6	+LM5	+LM4	+LM3	+LM2	+LM1
G112			-LM6	–LM5	-LM4	–LM3	–LM2	–LM1
G124			DTCH6	DTCH5	DTCH4	DTCH3	DTCH2	DTCH1
G126			SVF6	SVF5	SVF4	SVF3	SVF2	SVF1
G130			*IT6	*IT5	*IT4	*IT3	*IT2	*IT1
G132			+MIT6	+MIT5	+MIT4	+MIT3	+MIT2	+MIT1

Bit No.

Address	#7	#6	#5	#4	#3	#2	#1	#0
G134			-MIT6	-MIT5	-MIT4	-MIT3	-MIT2	-MIT1
G136			EAX6	EAX5	EAX4	EAX3	EAX2	EAX1
G142	EBUFA	ECLRA	ESTPA	ESOFA	ESBKA			EFINA
G143	EMSBKA	EC6A	EC5A	EC4A	EC3A	EC2A	EC1A	EC0A
G144	EIF7A	EIF6A	EIF5A	EIF4A	EIF3A	EIF2A	EIF1A	EIF0A
G145	EIF15A	EIF14A	EIF13A	EIF12A	EIF11A	EIF10A	EIF9A	EIF8A
G146	EID7A	EID6A	EID5A	EID4A	EID3A	EID2A	EID1A	EID0A
G147	EID15A	EID14A	EID13A	EID12A	EID11A	EID10A	EID9A	EID8A
G148	EID23A	EID22A	EID21A	EID20A	EID19A	EID18A	EID17A	EID16A
G149	EID31A	EID30A	EID29A	EID28A	EID27A	EI26DA	EID25A	EID24A
G150	DRNE	RTE	OVCE				ROV2E	ROV1E
G151	*FV7E	*FV6E	*FV5E	*FV4E	*FV3E	*FV2E	*FV1E	*FV0E
G154	EBUFB	ECLRB	ESTPB	ESOFB	ESBKB			EFINB
G155	EMSBKB	EC6B	EC5B	EC4B	EC3B	EC2B	EC1B	EC0B
G156	EIF7B	EIF6B	EIF5B	EIF4B	EIF3B	EIF2B	EIF1B	EIF0B
G157	EIF15B	EIF14B	EIF13B	EIF12B	EIF11B	EIF10B	EIF9B	EIF8B
G158	EID7B	EID6B	EID5B	EID4B	EID3B	EID2B	EID1B	EID0B
G159	EID15B	EID14B	EID13B	EID12B	EID11B	EID10B	EID9B	EID8B
G160	EID23B	EID22B	EID21B	EID20B	EID19B	EID18B	EID17B	EID16B
G161	EID31B	EID30B	EID29B	EID28B	EID27B	EI26DB	EID25B	EID24B
G166	EBUFC	ECLRC	ESTPC	ESOFC	ESBKC			EFINC
G167	EMSBKC	EC6C	EC5C	EC4C	EC3C	EC2C	EC1C	EC0C
G168	EIF7C	EIF6C	EIF5C	EIF4C	EIF3C	EIF2C	EIF1C	EIF0C
G169	EIF15C	EIF14C	EIF13C	EIF12C	EIF11C	EIF10C	EIF9C	EIF8C
G170	EID7C	EID6C	EID5C	EID4C	EID3C	EID2C	EID1C	EID0C
G171	EID15C	EID14C	EID13C	EID12C	EID11C	EID10C	EID9C	EID8C
G172	EID23C	EID22C	EID21C	EID20C	EID19C	EID18C	EID17C	EID16C
G173	EID31C	EID30C	EID29C	EID28C	EID27C	EID26C	EID25C	EID24C
G178	EBUFD	ECLRD	ESTPD	ESOFD	ESBKD			EFIND
G179	EMSBKD	EC6D	EC5D	EC4D	EC3D	EC2D	EC1D	EC0D
G180	EIF7D	EIF6D	EIF5D	EIF4D	EIF3D	EIF2D	EIF1D	EIF0D

Bit No.

Address	#7	#6	#5	#4	#3	#2	#1	#0
G181	EIF15D	EIF14D	EIF13D	EIF12D	EIF11D	EIF10D	EIF9D	EIF8D
G182	EID7D	EID6D	EID5D	EID4D	EID3D	EID2D	EID1D	EID0D
G183	EID15D	EID14D	EID13D	EID12D	EID11D	EID10D	EID9D	EID8D
G184	EID23D	EID22D	EID21D	EID20D	EID19D	EID18D	EID17D	EID16D
G185	EID31D	EID30D	EID29D	EID28D	EID27D	EID26D	EID25D	EID24D
G206		ZPEXT1		ZR1		RTN31	RTN21	RTN11
G207		ZPEXT2		ZR2		RTN32	RTN22	RTN12
G208		ZPEXT3		ZR3		RTN33	RTN23	RTN13
G209		ZPEXT4		ZR4		RTN34	RTN24	RTN14
G210		ZPEXT5		ZR5		RTN35	RTN25	RTN15
G211		ZPEXT6		ZR6		RTN36	RTN26	RTN16
G212	SKIPP							
G213	ACT							
G214					WFN4	WFN3	WFN2	WFN1
G216			TRQ6E	TRQ5E	TRQ4E	TRQ3E	TRQ2E	TRQ1E
G217	TRQ17	TRQ16	TRQ15	TRQ14	TRQ13	TRQ12	TRQ11	TRQ10
G218	TRQ27	TRQ26	TRQ25	TRQ24	TRQ23	TRQ22	TRQ21	TRQ20
G219	TRQ37	TRQ36	TRQ35	TRQ34	TRQ33	TRQ32	TRQ31	TRQ30
G220	TRQ47	TRQ46	TRQ45	TRQ44	TRQ43	TRQ42	TRQ41	TRQ40
G221	TRQ57	TRQ56	TRQ55	TRQ54	TRQ53	TRQ52	TRQ51	TRQ50
G222	TRQ67	TRQ66	TRQ65	TRQ64	TRQ63	TRQ62	TRQ61	TRQ60
G225	PALM	PAL6	PAL5	PAL4	PAL3	PAL2	PAL1	PAL0
G226	EBUFE	ECLRE	ESTPE	ESOFE	ESBKE			EFINE
G227	EMSBKE	EC6E	EC5E	EC4E	EC3E	EC2E	EC1E	EC0E
G228	EIF7E	EIF6E	EIF5E	EIF4E	EIF3E	EIF2E	EIF1E	EIF0E
G229	EIF15E	EIF14E	EIF13E	EIF12E	EIF11E	EIF10E	EIF9E	EIF8E
G230	EID7E	EID6E	EID5E	EID4E	EID3E	EID2E	EID1E	EID0E
G231	EID15E	EID14E	EID13E	EID12E	EID11E	EID10E	EID9E	EID8E
G232	EID23E	EID22E	EID21E	EID20E	EID19E	EID18E	EID17E	EID16E
G233	EID31E	EID30E	EID29E	EID28E	EID27E	EI26DE	EID25E	EID24E
G238	EBUFF	ECLRF	ESTPF	ESOFF	ESBKF			EFINF

Bit No.

Address	#7	#6	#5	#4	#3	#2	#1	#0
G239	EMSBKF	EC6F	EC5F	EC4F	EC3F	EC2F	EC1F	EC0F
G240	EIF7F	EIF6F	EIF5F	EIF4F	EIF3F	EIF2F	EIF1F	EIF0F
C244								ГІГОГ
G241	EIFIDF		EIFISF	EIFIZF	EIFIIF	EIFIUF	EIF9F	EIFOF
G242	FID7F	FID6F	FID5F	FID4F	FID3F	FID2F	FID1F	FID0F
		LIBOI	LIDOI		LIBOI	LIDEI	LIDII	
G243	EID15F	EID14F	EID13F	EID12F	EID11F	EID10F	EID9F	EID8E
G244	EID23F	EID22F	EID21F	EID20F	EID19F	EID18F	EID17F	EID16F
G245	EID31F	EID30F	EID29F	EID28F	EID27F	EI26DF	EID25F	EID24F
G251	EDGN	EPARM	EVAR	EPRG				
0.050	EDC07		FDCOF		EDC02	EDC02		
G252	EDG07	EDG06	EDG05	EDG04	EDG03	EDG02	EDGUI	EDG00
G253	EDG15	FDG14	EDG13	EDG12	EDG11	EDG10	EDG09	EDG08
0200	LDOID	LDOIT	LDOID	LDOIZ	LDOII	LDOID	LDC00	LDOOD
G254	EDN07	EDN06	EDN05	EDN04	EDN03	EDN02	EDN01	EDN00
G255	EDN15	EDN14	EDN13	EDN12	EDN11	EDN10	EDN09	EDN08
			I			I		

$\text{CNC} \rightarrow \text{PMC}$

Bit No.

Address	#7	#6	#5	#4	#3	#2	#1	#0
F000	OP	SA	STL	SPL				RWD
F001	MA				DEN	BAL	RST	AL
F002		CUT						
F003	MTCHIN	MEDT	MAUT		MMDI	MJ		MSTP
F004			MZRN					
F007								MF
F009	DM00	DM01	DM02	DM30				
F010	M07	M06	M05	M04	M03	M02	M01	M00
F011	M15	M14	M13	M12	M11	M10	M09	M08
F012	M23	M22	M21	M20	M19	M18	M17	M16
F013	M31	M30	M29	M28	M27	M26	M25	M24
F053				BGEACT	RPALM	RPBSY		
F054	UO7	UO6	UO5	UO4	UO3	UO2	UO1	UO0
F055	UO15	UO14	UO13	UO12	UO11	UO10	UO9	UO8
F056	UO107	UO106	UO105	UO104	UO103	UO102	UO101	UO100
F057	UO115	UO114	UO113	UO112	UO111	UO110	UO109	UO108
F058	UO123	UO122	UO121	UO120	UO119	UO118	UO117	UO116
F059	UO131	UO130	UO129	UO128	UO127	UO126	UO125	UO124
F094			ZP6	ZP5	ZP4	ZP3	ZP2	ZP1
F096			ZP26	ZP25	ZP24	ZP23	ZP22	ZP21
F098			ZP36	ZP35	ZP34	ZP33	ZP32	ZP31
F104			INP6	INP5	INP4	INP3	INP2	INP1
F106			MVD6	MVD5	MVD4	MVD3	MVD2	MVD1
F110			MDTCH6	MDTCH5	MDTCH4	MDTCH3	MDTCH2	MDTCH1
F120			ZRF6	ZRF5	ZRF4	ZRF3	ZRF2	ZRF1
F129	*EAXSL		EOV0					
F130	EBSYA	EOTNA	EOTPA	EGENA	EDENA	EIALA	ECKZA	EINPA
								EMFA
F131								
F131 F132	EM28A	EM24A	EM22A	EM21A	EM18A	EM14A	EM12A	EM11A
F131 F132 F133	EM28A EBSYB	EM24A EOTNB	EM22A EOTPB	EM21A EGENB	EM18A EDENB	EM14A EIALB	EM12A ECKZB	EM11A EINPB

$\text{CNC} \rightarrow \text{PMC}$

Address	#7	#6	#5	#4	#3	#2	#1	#0
F135	EM28B	EM24B	EM22B	EM21B	EM18B	EM14B	EM12B	EM11B
F136	EBSYC	EOTNC	EOTPC	EGENC	EDENC	EIALC	ECKZC	EINPC
F137								EMFC
F138	EM28C	EM24C	EM22C	EM21C	EM18C	EM14C	EM12C	EM11C
F139	EBSYD	EOTND	EOTPD	EGEND	EDEND	EIALD	ECKZD	EINPD
F140								EMFD
F141	EM28D	EM24D	EM22D	EM21D	EM18D	EM14D	EM12D	EM11D
F180			CLRCH6	CLRCH5	CLRCH4	CLRCH3	CLRCH2	CLRCH1
F209					WAT4	WAT3	WAT2	WAT1
F210	K7	K6	K5	K4	K3	K2	K1	K0
F211	KCAN	KEOB	KSLH	KNO	KPRD	KMNS	K9	K8
F212		KRED		KWRT	KINP	KDLT	KINS	KALT
F213			KALM		KPRM	KVAR	KPRG	KPOS
F214		KH	KQ	KP			KUP	KDWN
F217				KX	KR	KG	KN	KO
F218	KSHRP	KT	KS	KM	KF			
F220					SVER1	IPL1	SUP1	
F221					SVER2	IPL2	SUP2	
F222					SVER3	IPL3	SUP3	
F223					SVER4	IPL4	SUP4	
F224					SVER5	IPL5	SUP5	
F225					SVER6	IPL6	SUP6	
F228	EBSYE	EOTNE	EOTPE	EGENE	EDENE	EIALE	ECKZE	EINPE
F229								EMFE
F230	EM28E	EM24E	EM22E	EM21E	EM18E	EM14E	EM12E	EM11E
F231	EBSYF	EOTNF	EOTPF	EGENF	EDENF	EIALF	ECKZF	EINPF
F232								EMFF
F233	EM28F	EM24F	EM22F	EM21F	EM18F	EM14F	EM12F	EM11F
F236	APBL1	APBV1	APBZ1	APPS1	APPE1	APFE1	APOV1	APCM1
F237	APBL2	APBV2	APBZ2	APPS2	APPE2	APFE2	APOV2	APCM2
F238	APBL3	APBV3	APBZ3	APPS3	APPE3	APFE3	APOV3	APCM3

Bit No.

$\text{CNC} \rightarrow \text{PMC}$

Bit No.

Address	#7	#6	#5	#4	#3	#2	#1	#0
F239	APBL4	APBV4	APBZ4	APPS4	APPE4	APFE4	APOV4	APCM4
E 240								
F240	APBLO	APBVO	APBZO	APP 55	APPED	APFED	APOVS	APCIVIS
F241	APBL6	APBV6	APBZ6	APPS6	APPE6	APFE6	APOV6	APCM6
F250		ALSV	ALOH	ALOT	ALPS	ALPS3	ALPS2	ALPS1
F251						ALPS4		ALAPC
F254						DPL2	DPL1	DPL0

4.7 SIGNAL AND SYMBOL CORRESPONDENCE TABLE

Refer to the Connection Manual (B–62683EN) for details.

Symbol	Signal name	PMC address
*ABSM	Manual absolute signal	G006#2
ACT	Temporary interrupt detection signal	G213#7
AFL	Auxiliary function lock signal	G005#6
AL	Alarm signal	F001#0
ALAPC	APC alarm	F251#0
ALOH	Over heat alarm	F250#5
ALOT	Over travel alarm signal (alarm classification signal)	F250#4
ALPS	P/S alarm signal (alarm classification signal)	F250#3
ALPS1	P/S alarm 100 signal (alarm classification signal)	F250#0
ALPS2	P/S alarm 000 signal (alarm classification signal)	F250#1
ALPS3	P/S alarm 101 signal (alarm classification signal)	F250#2
ALPS4	P/S alarm (from 5000 to 5999)	F251#2
ALSV	Servo alarm signal (alarm classification signal)	F250#6
APBL1 to APBL6	APC battery LOW alarm 2 signal (APC alarm type signal)	F236#7 to F241#7
APBV1 to APBV6	APC battery LOW alarm 1 signal (APC alarm type signal)	F236#6 to F241#6
APBZ1 to APBZ6	APC battery zero alarm signal (APC alarm type signal)	F236#5 to F241#5
APCM1 to APCM6	APC communication error signal (APC alarm type signal)	F236#0 to F241#0
APFE1 to APFE6	APC framing error signal (APC alarm type signal)	F236#2 to F241#2
FPOV1 to FPOV6	APC over time error signal (APC alarm type signal)	F236#1 to F241#1
APPE1 to APPE6	APC parity error signal (APC alarm type signal)	F236#3 to F241#3
APPS1 to AAPS6	APC pulse miss error signal (APC alarm type signal)	F236#4 to F241#4
BAL	Battery alarm signal	F001#2
BDT1, BDT2 to BDT9	Optional block skip signal	G044#0, G045
BGEACT	Background editing signal	F053#4
CLRCH 0 to 5	Torque limit condition signal	F180#0 to #5
CUT	Signal under cutting mode	F002#6
*DEC1 to *DEC6	Reference position return deceleration signal	X002#0 to #5 X1002#0 to #5
DEN	Distribution end signal	F001#3
DM00, DM01, DM02, DM30	M decode signals	F009#4 to #7
DPL0 to DPL2	Screen status signal	F254#0 to #2
DRN	Dry run signal	G046#7
DRNE	Dry run signal (Axis control by PMC)	G150#7
DTCH 1 to 6	Control axis detach signal	G124#0 to #5
EAX1 to EAX6	Controlled axis selection signal (Axis control by PMC)	G136# to #5
EAXSL	Control axis selection status signal	F129#7
EBSYA to EBSYF	Axis control command read signal (Axis control by PMC)	F130#7, F133#7, F136#7, F139#7, F228#7, F231#7
EBUFA to EBUFF	Axis control command completed signal (Axis control by PMC)	G142#7, G154#7, G166#7, G178#7, G226#7, G238#7

Symbol	Signal name	PMC address
(EC0A to EC6A) to (EC0F to EC6F)	Axis control command signal (Axis control by PMC)	G143#0 to #6, G155#0 to #6, G167#0 to #6, G179#0 to#6, G227#0 to #6, G239#0 to #6
ECKZA to ECKZF	Error zero checking signal (Axis control by PMC)	F130#1, F133#1, F136#1, F139#1, F228#1, F231#1
ECLRA to ECLRF	Reset signal (Axis control by PMC)	G142#6,G154#6, G166#6, G178#6, G226#6, G238#6
EDENA to EDENF	Miscellaneous function executing signal (Axis control by PMC)	F130#3, F133#3, F136#3, F139#3, F228#3, F231#3
EDG00 to EDG15	External punch start number signal (I/O device external control function)	G252, G253
EDGN	Diagnose selection signal (I/O device external control function)	G251#7
EDN00 to EDM15	Signal of external punch total number (I/O device external control function)	G254, G255
EFINA to EFINF	Miscellaneous function complete signal (Axis control by PMC)	G142#0, G154#0, G166#0, G178#0, G226#0, G238#0
EGENA to EGENF	Axis moving signal (Axis control by PMC)	F130#4, F133#4, F136#4, F139#4, F228#4, F231#4
EIALA to EIALF	Alarm signal (Axis control by PMC)	F130#2, F133#2, F136#2, F139#2, F228#2, F231#2
(EID0A to EID31A) to (EID0F to EID31F)	Axis move distance Dwell time Auxiliary function code (Axis control by PMC)	G146 to G149, G158 to G161, G170 to G173, G182 to G185, G230 to G233, G242 to G245
(EIF0A to EIF15A) to (EIF0Fto EIF15F)	Feedrate (Axis control by PMC)	G144, G145,G156, G157, G168, G169, G180, G181, G228, G229, G240, G241
EINPA to EINPF	In-positioning signal (Axis control by PMC)	F130#0, F133#0, F136#0, F139#0, F228#0, F231#0
(EM11A to EM28A) to (EM11F to EM28F)	Miscellaneous BCD code (Axis control by PMC)	F132, F135, F138, F141, F230, F233
EMFA to EMFF	Miscellaneous function read signal (Axis control by PMC)	F131#0, F134#0, F137#0, F140#0, F229#0, F232#0
EMSBKA to EMSBKF	Block stop inhibit signal (Axis control by PMC)	G143#7, G155#7, G167#7, G179#7, G227#7, G239#7
EOTNA to EOTNF	Overtravel in regative direction signal (Axis control by PMC)	F130#6, F133#6, F136#6, F139#6, F228#6, F231#6
EOTPA to EOTPF	Overtravel in positive direction signal (Axis control by PMC)	F130#5, F133#5, F136#5, F139#5, F228#5, F231#5
EOV0	Override 0% signal (Axis control by PMC)	F129#5
EPARM	Parameter selection signal (I/O device external control function)	G251#6
EPCON	External pulse input/output signal	G066#6
ERS	External reset signal	G008#7
ESBKA to ESBKF	Block stop signal (Axis control by PMC)	G142#3, G154#3, G166#3, G178#3, G226#3, G238#3
ESOFA to ESOFF	Servo off signal (Axis control by PMC)	G142#4, G154#4, G166#4, G178#4, G226#4, G238#4

Symbol	Signal name	PMC address		
*ESP	Emergency stop signal	X008#4, X000#4 or X1000#4		
ESTPA to ESTPF	Axis control stop signal (Axis control by PMC)	G142#5, G154#5, G166#5, G178#5, G226#5, G238#5		
EVAR	Variable selection signal (I/O device external control function)	G251#5		
EXF1 to EXF5	Speed changing function	X000#0, #1, #2, X011#4, #5, X1000#0, #1, #2		
EXPRG	Program selection signal (I/O device external control function)	G251#4		
EXRD	External read start signal	G058#1		
EXSTP	External read/punch stop signal	G058#2		
EXWT	External punch start signal	G058#3		
FIN	M,S,T,B function end signal	G004#3		
*FLWU	Follow-up signal	G007#5		
*FV0 to *FV7	Feedrate override signal	G012		
*FV0E to *FV7E	Override signal (Axis control by PMC)	G151		
HS1A, HS1B, HS1C	Manual handle feed axis select signal	G018#0, #1, #2		
IGNVRY	Speed control servo alarm ignore signal	G066#0		
INP1 to INP6	In-position signals	F104#0 to #5		
IPL1 to IPL6	Distribution signal (axis status signal)	F220#2 to F225#2		
*IT	Interlock signal	G008#0		
*IT1 to *IT6	Axis interlock signal	G130#0 to G130#5		
+J1 to +J6,]J1 to –J6	Feed axis direction select signal	G100#0 to G100#5 G102#0 to G102#5		
*JV0 to *JV15	Manual feedrate override signal	G010, G011		
K0 to K9, KMNS, KPRD, KNO, KSLH, KEOB, KCAN, KALT, KINS, KDLT, KINP, KWRT, KRED, KPOS, KPRG, KVAR, KPRM, KALM, KDWN, KUP, KP, KQ, KH, KO, KN, KG, KR, KX, KF, KM, KS, KT, KSHRP	Key data reference function by PMC	F210 to F218		
KEY1, KEY2, KEY3, KEY4	Memory protection key	G046#3 to #6		
+ LM1 to +LM6 -LM1 to -LM6	Software limit external setting	G110#0 to G110#5 G112#0 to G112#5		
M00 to M31	Miscellaneous function code signal	F010 to F013		
MA	Ready signals	F001#7		
MAUT	Auto confirmation signal	F003#5		
MD1 ,MD2, MD4	Mode select signal	G043#0 to #2		
MDTCH1 to MDTCH6	Controlled axis detach status signal	F110#0 to F110#5		
MEDT	Memory edit select check signal (EDIT)	F003#6		
MF	M code output complete signal	F007#0		
MFIN	M function complete signal	G005#0		
MI1 to MI6	Mirror image signal	G106#0 to G106#5		
+MIT1 to +MIT6, -MIT1 to -MIT6	Interlock signal for each axis and direction	G132#0 to G132#5 G134#0 to G134#5		
MJ	JOG feed select check signal (JOG)	F003#2		
MLK	Machine lock signal	G044#1		
MMDI	Manual data input select check signal (MDI)	F003#3		
MP1, MP2	Incremental feed magnification signal	G019#4, #5		
MSTP	Step feed confirmation signal	F003#0		

Symbol	Signal name	PMC address
MTCHIN	TECH IN JOG and STEP select check signal	F003#7
MVD1 to MVD6	Moving direction signals	F106#0 to F106#5
MZRN	Manual reference position return confirmation signal	F004#5
OP	Automatic operation signal	F000#7
OVC	Override cancel signal	G006#4
OVCE	Override cancellation signal	G150#5
PAL0 to PAL6	Alarm number specification signal (Display of alarms from PMC)	G225#0 to G225#6
PALM	PMC alarm generation selection signal (Display of alarms from PMC)	G225#7
PN0 to PN7	Workpiece number search signal	G009
∗RILK	High-speed interlock signal	X000#6, X1000#6,
RLSOT	Software limit external signal	G007#7
ROV1, ROV2	Rapid traverse override signal	G014#0, #1
ROV1E, ROV2E	Rapid traverse override signal (Axis control by PMC)	G150#0, #1
RPALM	Read/punch alarm signal	F053#3
RPBSY	Reading/punching signal	F053#2
RRW	Reset & rewind signal	G008#6
RST	CNC reset signal	F001#1
RT	Manual rapid traverse select signal	G019#7
RTN 11 to RTN 16	Return signal	G206#0 to G211#0
RWD	Rewinding signal	F000#0
RTE	Manual rapid traverse signal (Axis control by PMC)	G150#6
SA	Servo ready signal	F000#6
SBK	Single block signal	G046#1
SKIP, SKIP2, SKIP3, SKIP4	Skip signal	X000#7, #0, #1, #2 X1000#7,#0, #1, #2
SKIPP	Skip signal from PMC	G212#7
*SP	Feed hold signal	G008#5
SPL	Feed hold lamp signal	F000#4
ST	Cycle start signal	G007#2
STL	Cycle start lamp signal	F000#5
SUP1 to SUP6	Acceleration/deceleration signal (axis motion status signal)	F220#1 to F225#1
SVER1 to SVER6	Servo position deviation monitor signal	F220#3 to F225#3
SVF1 to SVF6	Servo off signal	G126#0 to G126#6
TRQ1E to TRQ6E	Torque limit enable signal	G216#0 to G216#5
TRQ10 to TRQ67	Torque limit signal	G217#0 to G222
UI0 to UI15	Input signal for custom macro	G054, G055
UINT	Interrupt signal for custom macro	G053#3
UO0 to UO15 UO100 to UO131	Output signal for custom macro	F054, F055, F056 to F059
WAT1 to WAT4	Waiting signal (waiting function)	F209#0 to #3
WFN1 to WFN4	Waiting complete signal (waiting function)	G214#0 to #3
WVRDY	Waiting V–READY signal	F209#4
ZP1 to ZP6	Reference position return end signal	F094#0 to F094#5
ZP21 to ZP26	2nd reference position return end signal	F096#0 to F096#5
ZP31 to ZP36	3rd reference position return end signal	F098#0 to F098#5

Symbol	Signal name	PMC address
ZPEXT1 to ZPEXT6	Reference position external setting signal	G206#6 to G211#6
ZR1 to ZR6	Dogless reference position setting signal	G206#4 to G211#4
ZRF1 to ZRF6	Reference position establishment signal	F120#0 to F120#5
ZRN	Manual reference position return selection signal	G043#7

5 DIGITAL SERVO

This chapter describes servo tuning screen required for maintenance of digital servo and adjustment of reference position.

- 5.1 INITIAL SETTING SERVO PARAMETERS
- 5.2 SERVO TUNING SCREEN
- 5.3 ADJUSTING REFERENCE POSITION (DOG METHOD)
- 5.4 DOGLESS REFERENCE POSITION SETTING

5.1 INITIAL SETTING SERVO PARAMETERS

This section describes how to set initial servo parameters, which is used for field adjustment of tool.

A servo adjustment screen is not provided by the DPL/MDI.

- 1. Turn on power at the emergency stop condition.
- 2. Set the parameter to display the servo tuning screen.

	#7	#6	#5	#4	#3	#2	#1	#0
3111								SVS

#0 (SVS) 0 : Servo tuning screen is not displayed.

- 1 : Servo tuning screen is displayed.
- 3. Turn off the power once then turn it on again.
- 4. Display the servo parameter setting screen by the following operation: wystem key [>>] [SV.PARA].
- 5. Input data required for initial setting using the cursor and page key.

SERVO SETTING						
	:	X AXIS	Y AXIS			
(1) INITIAL SET BIT	00	000000	00000000		S PRM	2000
(2) MOTOR ID NO.		47	47		$\triangleleft_{\text{PRM}}$	2020
(3) amr	00	000000	00000000		<> PRM	2001
(4) cmr		2	2		<⊐ prm	1820
(5) FEED GEAR N		1	1		<⊐ prm	2084
(6) (N/M)	м	125	125		<⊐ prm	2085
(7) DIRECTION SET		111	111		<⊐ prm	2022
(8) VELOCITY PULSE	NO.	8192	8192			2023
(9) POSITION PULSE	NO.	12500	12500		<⊐ prm	2024
(10)REF.COUNTER		8000	8000		<⊐ prm	1821
)		

(1) INITIAL SET BIT

	_	#7	#6	#5	#4	#3	#2	#1	#0
2000	[PRMCAL		DGPRM	PLC01

#3 (PRMCAL)	1:	Turns to 1 when the initial setting is done. The following parameters are set automatically in accordance with the no. of pulses of pulse coder: PRM 2043(PK1V), PRM 2044(PK2V), PRM 2047(POA1), PRM 2052(PRMAV)
		PRM 2047(POA1), PRM 2053(PPMAX), PRM 2054(PDDP), PRM 2056(EMFCMP), PRM 2057(PVPA), PRM 2059(EMFBAS), PRM 2074(AALPH),PRM 2076(WKAC)
#1 (DGPRM)☆	0:	Initial setting of digital servo parameter is done.
	1:	Initial setting of digital servo parameter is not done.
#0 (PLC01)	0:	Values of parameter 2023 and 2024 are used as they are:
	1:	Values of parameter 2023 and 2024 are multiplied by 10.
(2) MOTOR NUMBER

2020

Motor type no. per axis

Motor t	ype r	no. tha	t can	be	set	are	3	to	62.	
---------	-------	---------	-------	----	-----	-----	---	----	-----	--

Format number	3	4	5	7	8	9
Model name	α12HV	α22HV	α30HV	αC3/2000	αC6/2000	αC12/2000
Drawing number	0176	0177	0178	0142	0123	0127
Format number	10	13	15	16	17	18
Model name	αC22/1500	α0.5	α3/3000	α6/2000	α6/3000	α12/2000
Drawing number	0128	0142	0123	0127	0128	0142
Format number	19	20	21	22	23	24
Model name	α12/3000	α22/2000	α22/3000	α30/2000	α30/3000	αM3/3000
Drawing number	0143	0147	0148	0152	0153	0161
Format number	25	26	27	28	29	30
Format number Model name	25 αM6/3000	26 αM9/3000	27 α22/1500	28 α30/1200	29 α40/2000 with FAN	30 α40/2000 without FAN
Format number Model name Drawing number	25 αM6/3000 0162	26 αM9/3000 0163	27 α22/1500 0146	28 α30/1200 0151	29 α40/2000 with FAN 0158	30 α40/2000 without FAN 0157
Format number Model name Drawing number Format number	25 αM6/3000 0162 33	26 αΜ9/3000 0163 34	27 α22/1500 0146 35	28 α30/1200 0151 36	29 α40/2000 with FAN 0158 46	30 α40/2000 without FAN 0157 56
Format number Model name Drawing number Format number Model name	25 αM6/3000 0162 33 αE3/2000 β3/2000	26 αM9/3000 0163 34 αE6/2000 β6/2000	27 α22/1500 0146 35 αΕ1/3000 β1/3000	28 α30/1200 0151 36 αΕ2/3000 β2/3000	29 α40/2000 with FAN 0158 46 α2/2000	30 α40/2000 without FAN 0157 56 αL3/2000
Format number Model name Drawing number Format number Model name Drawing number	25 αM6/3000 0162 33 αE3/2000 β3/2000 0105	26 αM9/3000 0163 34 αE6/2000 β6/2000 0106	27 α22/1500 0146 35 αΕ1/3000 β1/3000 0101	28 α30/1200 0151 36 αΕ2/3000 β2/3000 0102	29 α40/2000 with FAN 0158 46 α2/2000 0372	30 α40/2000 without FAN 0157 56 αL3/2000 0561
Format number Model name Drawing number Format number Drawing number Format number	25 αM6/3000 0162 33 αE3/2000 β3/2000 0105 57	26 αM9/3000 0163 34 αE6/2000 β6/2000 0106 58	27 α22/1500 0146 35 αΕ1/3000 β1/3000 0101 59	28 α30/1200 0151 36 αE2/3000 β2/3000 0102 60	29 α40/2000 with FAN 0158 46 α2/2000 0372 61	30 α40/2000 without FAN 0157 56 αL3/2000 0561 62
Format number Model name Drawing number Model name Drawing number Format number Model name	25 αM6/3000 0162 33 αE3/2000 β3/2000 0105 57 αL6/3000	26 αM9/3000 0163 34 αE6/2000 β6/2000 0106 58 αL9/3000	27 α22/1500 0146 35 αΕ1/3000 β1/3000 0101 59 αL25/3000	28 α30/1200 0151 36 αΕ2/3000 β2/3000 0102 60 αL50/2000	29 α40/2000 with FAN 0158 46 α2/2000 0372 61 α1/3000	30 α40/2000 without FAN 0157 56 αL3/2000 0561 62 α2/3000

(3) CMR



1) For serial pulse coder A or B, and serial a pulse coder.

 $\frac{n}{m} = \frac{No. \text{ of feedback pulses per revolution of motor}}{1000000}$

For serial pulse coder B, set 250,000 pulses or less to parameter 2084.

Examples of calculation

		1/1000 mm
1 rotation of motor	8mm 10mm 12mm	n=1/m=125 n=1/m=100 n=3/m=250

2) For serial pulsecoder C

 $\frac{n}{m} = \frac{\text{No. of feedback pulses per revolution of motor}}{40000}$

Examples of calculation

		1/1000 mm
1 rotation of motor	8mm 10mm 12mm	n=1/m=5 n=1/m=4 n=3/m=10

(6) Direction of Travel

PRM

2022

Direction of motor rotation

111 : Positive (CCW) -111 : Reverse (CW)

- (7) No. of velocity pulses and position pulses
 - 1) For serial pulse coder A or B and serial α pulse coder

	Parameter no.	Resolution 1/1000mm			
High resolution setting	2000	xxxx xxx 0			
Separate detector	1815	00100010 00100000			
Velocity feedback pulses	2023	8192			
Position feedback pulses	2024	12500			

— 172 —

2) For serial pulse coder C

	Parameter no.	Resolution 1/1000mm
High resolution setting	2000	xxxx xxx1
Velocity feedback pulses	2023	4000
Position feedback pulses	2024	4000

For 5–0S to 3–0S motor, since the no. of poles is different, set parameter 2001.

(8) Reference counter

1821

PRM

Reference counter capacity(0 to 99999999)

1. Turn off power then turn on power.

5.2 SERVO TUNING SCREEN

5.2.1	Set a parameter to display the servo tuning screen.							
Parameter Setting	A serve aujustment screen is not provided by the DPL/MDI.							
	#7 #6 #5 #4 #3 #2 #1 #0							
	3111 SVS							
	#0 (SVS) 0 : Servo tuning screen is not displayed.							
	1 : Servo tuning screen is displayed.							
5.2.2	1 Durse was here the and soft here ICV DADA1 in this order							
Displaving Servo	1. Fless stored key [Sv. FARA] in uns order.							
Tuning Screen	2. Press soft key [SV.TUN] to select the servo tuning screen.							
-	SERVO TUNING 01234 N12345							
	(PAMAMETER) (MONITOR) (1) FIN BT 0000000 ALARM 1 0000000 (9)							
	(1) FOREBIT COUCOUC ALARM 1 COUCOUCO (2) (2) LOOP GAIN 3000 ALARM 2 00000000 (10)							
	(3) TURNING SET. 0 ALARM 3 10000000 (11) (4) SET PERIOD 50 ALARM 4 00000000 (12)							
	(5) INT.GAIN 113 ALARM 5 00000000 (13) (6) PROP.GAIN -1015 LOOP GAIN 2999 (14)							
	(7) FILER 0 POS ERROR 556 (15)							
	(b) VERCE GAIN 125 CORRENTS 10 (10) SPEED RPM 100 (17)							
	Image: Strain							
	1 Function bit : PRM 2003							
	2 Loop gain : PRM 1825							
	3 Tuning start : (Used by automatic servo tuning function)							
	4 Set period : (Used by automatic servo tuning function)							
	5 Integral gain : PRM 2043							
	6 Proportional gain : PRM 2044 7 Eilter : PDM 2067							
	/ FIIter : FKIVI 2007							
	8 Velocity gain : Set value= $\frac{(14412021)(256)}{256} \times 100$							
	9 Alarm 1 : DGN 200 (Details of alarm 400 and 414)							
	10 Alarm 2 : DGN 201 (Details of disconnection alarm,							
	Overload)							
	11 Alarm 5 : DGN 202 (Details of alarm 319)							
	12 Alarm 5 $DCN 203$ (Details of alarm 414)							
	15 Alarm 5 . DON 204 (Details of alarm 414)							
	14 Loop gain . Actual loop gain 15 Desition error Actual position error (DCN 200)							
	16 Current(%) · Indicate current with % to the rated value							
	17 Speed RDM Number of motor actual rotation							

	#7	#6	#5	#4	#3	#2	#1	#0
Alarm1	OVL	LV	OVC	HCA	HVA	DCA	FBA	OFA
DGN (20	0) :							
#7 (OVL) :	Overlo	ad alarn	n				
#6 (LV)	:	Insuffi	cient vo	ltage ala	arm			
#5 (OVC) :	Overcu	rrent al	arm				
#4 (HCA) :	Abnorr	nal curr	ent alar	m			
#3 (HVA)) :	Excess	ive volt	age alar	m			
#2 (DCA)) :	Discha	rge alar	m				
#1 (FBA)) :	Discon	nection	alarm				
#0 (OFA)) :	Overflo	ow aları	n				
	#7	#6	#5	#4	#3	#2	#1	#0
Alarm2	ALD			EXP				

DGN (201)↓

 \Downarrow

Over-	0	—	—	_	Amplifier overheat
alarm	1	—			Motor overheat
Discon- nection	1	—	—	0	Built-in pulse coder disconnec- tion (Hardware)
aiarm	0	_	_	0	Pulse coder disconnection (soft- ware)

	#7	#6	#5	#4	#3	#2	#1	#0
Alarm3		CSA	BLA	PHA	RCA	BZA	CKA	SPH
DGN (202	2) :							
#6 (CSA)	:	Hardw	are of se	erial pul	se code	r is abno	ormal.	
#5 (BLA)	:	Battery	voltage	e is in lo	w (war	ning).		
#4 (PHA)	:	Serial j	oulse co	der or f	eedback	cable is	s abnorr	nal.
		Counti	ng the f	eedback	signal	is in err	or.	
#3 (RCA)	:	Serial J	pulse co	der is fa	ulty.			
		Counti	ng is in	error.				
		If the F	RCA bit	is set to	1 when	both th	e FBA	oit (bit 1
		of aları	n 1) and	l ALD b	oit of ala	rm 2 are	e set to 1	and the
		EXP bi	t of ala	rm 2 (in	ternal h	ardware	discon	nection)
		is set to	o 1, a co	unt miss	s alarm (CMAL) occurs	in the α
		pulse c	oder.					
#2 (BZA)	:	Battery	voltage	e becom	les 0.			
		Replac	e batter	ies and s	set the r	eference	e positio	n.
#1 (CKA)	:	Serial J	pulse co	der is fa	ulty.			
		Interna	l block	has stop	ped.			
#0 (SPH)	:	Serial J	oulse co	der or f	eedback	cable is	s faulty.	
		Counti	ng the f	eedback	signal	is in err	or.	

	#7	#6	#5	#4	#3	#2	#1	#0
Alarm4	DTE	CRC	STB					
DGN (20 #7 (DTE)	3) :) :	Comm There i	unicatic s no res	on error sponse.	of serial	l pulse c	oder.	
#6 (CRC) :	Comm Transm	unication	on error ata is in	of serial error.	l pulse c	oder.	
#5 (STB)	•	Comm Transm	unication	on error ata is in	of serial error.	l pulse c	oder.	

	#7	#6	#5	#4	#3	#2	#1	#0
Alarm5		OFS	MCC	LDM	PMS			
DGN (204) :							
#6 (OFS)	:	A/D co abnorn	onversic nal.	on of cu	rrent va	alue of	digital s	ervo is
#5 (MCC)	:	Contac amplifi	ts of e er is blo	electro–1 own	nagneti	c conta	ctor of	servo
#4 (LDM)	:	LED of	f serial j	pulse co	der is a	bnormal	l.	
#3 (PMS)	:	No. of coder (feedbac C or feed	k pulses dback ca	are in e able is f	rror bec aulty.	ause ser	ial pulse

5.3 ADJUSTING REFERENCE POSITION (DOG METHOD)

5.3.1 General



• Parameter



No. of feedback pulses or its division by an integer is set.



bit setting from 0 to 1.

5.4.1

5.4 DOGLESS REFERENCE POSITION SETTING

When there are no dog nor limit switch for reference position return, this function enables the tool to return the reference position that is set by MTB.

When the absolute position detector is used, the reference position once set remains also during power off. When the absolute detector is replaced or absolute position is lost, perform this setting.



5.4.2 Operation

- 1 Move the tool near the reference position using a manual operation.
- 2 Select the reference position return mode or switch.
- 3 Press a button for an axis–and–direction–select–signal + or –, and the machine moves to the next grid, then stops.

(This position is set as the reference position).

After the reference position has been set, select the reference position return mode (ZRN signal is 1) and turn on an axis–and–direction–select signal, then the tool returns to the reference position.

5.4.3 Associated Parameters



6 TROUBLESHOOTING

This chapter describes troubleshooting procedure.

- 6.1 CORRECTIVE ACTION FOR FAILURES
- 6.2 POWER CANNOT BE TURNED ON
- 6.3 NO MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED
- 6.4 JOG OPERATION CANNOT BE DONE
- 6.5 EXTERNAL PULSE INPUT FUNCTION (SINGLE PHASE INPUT TYPE) CANNOT BE USED
- 6.6 AUTOMATIC OPERATION CANNOT BE DONE
- 6.7 CYCLE START LED SIGNAL HAS TURNED OFF
- 6.8 WHEN MANIPULATION IS NOT POSSIBLE WITH THE CRT/MDI
- 6.9 ALARM 85 TO 87 (READER/PUNCHER INTERFACE ALARM)
- 6.10 REFERENCE POSITION DEVIATES
- 6.11 ALARM 90 (REFERENCE POSITION RETURN IS ABNORMAL)
- 6.12 ALARM 300 (REQUEST FOR REFERENCE POSITION RETURN)
- 6.13 ALARM 301 TO 305 (ABSOLUTE PULSE CODER IS FAULTY)
- 6.14 ALARM 306 TO 308 (ABSOLUTE PULSE CODER BATTERY IS LOW)
- 6.15 ALARM 350 (SERIAL PULSE CODER IS ABNORMAL)
- 6.16 ALARM 351 (SERIAL PULSE CODER COMMUNICATION IS ABNORMAL)
- 6.17 ALARM 400 (OVERLOAD)
- 6.18 ALARM 401 (*DRDY SIGNAL TURNED OFF)
- 6.19 ALARM 404 AND 405 (*DRDY SIGNAL TURNED ON, REFERENCE POSITION RETURN ABNORMAL)
- 6.20 ALARM 410 (EXCESSIVE POSITION ERROR AMOUNT DURING STOP)

- 6.21 ALRAM 411 (EXECESSIVE POSITION ERROR DURING MOVE)
- 6.22 ALARM 414 (DIGITAL SERVO SYSTEM IS ABNORMAL)
- 6.23 ALRAM 416 (DISCONNECTION ALARM)
- 6.24 ALARM 417 (DIGITAL SERVO SYSTEM IS ABNORMAL)
- 6.25 ALARM 700 (OVERHEAT AT CONTROL SIDE)
- 6.26 ALARM 900 (ROM PARITY ERROR)
- 6.27 ALARM 912 TO 913 (RAM PARITY)
- 6.28 ALARM 920 TO 922 (WATCH DOG OR RAM PARITY)
- 6.29 ALARM 924 (SERVO MODULE MOUNTING ERROR)
- 6.30 ALARM 930 (CPU ERROR)
- 6.31 ALARM 950 (PMC SYSTEM ALARM)
- 6.32 ALARM 970 (NMI ALARM IN PMC MODULE)
- 6.33 ALARM 971 (NMI ALARM IN SLC)
- 6.34 ALARM 973 (NMI ALARM BY UNKNOWN CAUSE)
- 6.35 NO SIGNAL CHANGE IN FANUC I/O LINK MASTER

6.1 CORRECTIVE ACTION FOR FAILURES

When a failure occurs, it is important to correctly grasp what kind of failure occured and take appropriate action, to promptly recover the machine.

Check for the failure according to the following procedure :



6.1.1 Investigating the Conditions under which Failure Occurred

(1) When and how many times (frequency of occurrences)(2) With what operation(3) What failure occurred

1 When did the failure occur?

- Date and time?
- Occurred during operation? (how long was the operation?)
- Occurred when the power was turned on?
- Was there any lightening surge, power failure, or other disturbances to the power supply? How many times has it occurred
- Only once?
- Occurred many times ? (How many times per hour, per day, or per month?)
- 2 With what operation did it occur ?
 - What was the Power Mate mode when the failure occurred? Jog mode/AUTO operation mode /MDI mode /reference position return mode
 - If during program operation,
 - 1) Where in the program ?
 - 2) Which program No. and sequence No. ?
 - 3) What program ?
 - 4) Occurred during axial movement ?
 - 5) Occurred during the execution of an M code ?
 - 6) Failure specific to the program ?
 - Does the same operation cause the same failure ? (Check the repeatability of the failure.)
 - Occurred during data input/output ?

<Feed axes>

- For a failure related to feed axis servo
 - 1) Occurred at both low feedrate and high feedrate ?
 - 2) Ocurred only for a certain axis ?

- 3 What failure occurred ?
 - Which alarm was displayed on the alarm display screen on the CRT or DPL? (Check the axis along which an alarm has occurred for alarms 300)

(Check the axis along which an alarm has occurred for alarms 300 to 599.)

- For alarm 350 : Examine diagnostic 202
- For alarm 351 : Examine diagnostic 203
- For alarm 414 : What does diagnostic display 200,201,204 indicate ?
- Is the CRT or DPL screen correct ?
- If machining dimensions are incorrect
 - 1) How large is the error ?
 - 2) Is the position display on the CRT correct ?
 - 3) Are the offsets correct ?
- 4 Other information
 - Is there noise origin around machine? If the failure has not occurred frequently, the cause may be external noise to the power supply or inductive noise on machinery cables. Operate other machines connected to the same power line and see if noise come from the relays or compressors.
 - Is it taken any countermeasure for noise in machine side? Refer to subsec. 2.2.3.
 - Check the following for the input power supply voltage :
 - 1) Is there variation in the voltage ?
 - 2) Are the voltages different depending on the phase ?
 - 3) Is the standard voltage supplied ?
 - How high is the ambient temperature of the control unit? (0°C to 55°C during operation) Refer to manual about noise.
 - Has excessive vibration been applied to the control unit? (0.5 G or less during operation)
- 5 When you contact our service center, specify the following items :
 - 1) Name of the unit
 - 2) Name of the machine tool builder and type of machine
 - 3) Software series/version of the Power Mate
 - 4) Specifications of the servo amplifier
 - 5) Name and contact of the person who is most familiar with the failure conditions

(for a failure related to the servo)

- See the drawing issued by the machine tool builder for the locations of the Power Mate and servo/spindle amplifiers.
- We use the following specification codes : Servo amplifier : A06B–□□□−H□□□ Servo motor : A06B–□□□−B□□□ (□ represents a number)

The above information is required by FANUC to determine the cause of the failure. The information is used to attempt to reproduce the failure at the service center.

6.2 POWER CANNOT BE TURNED ON

Points

Causes and Remedies

Confirm the green LED EN on the front of controller. When green LED EN is turned on, power of Power Mate is ON.

- (1) Fuse F1 on the controller front panel is blown.
 - (a) Input power voltage is too high.
 - (b) External 24DCV power supply is faulty.
 - (c) 24–V power line short–circuit (line–to–line or line–to–ground)
- (2) Input voltage is low

Measure voltage at S terminals of 0V and 24V to confirm 24VDC $\pm\,100$ % is supplied.

If it is not normal, check machine side magnetics circuit.

(3) Power supply PC board in controller is faulty.

When 24 V is found to be input normally in step (2), but 5 V is not output to the 0 V and 5 V terminals, the power PCB in the controller may be defective.

(4) Power leakage from other units

Disconnect all cables other than the power cable of the Power Mate, then retry. When no defective condition is encountered, connect the cables one by one to determine which one causes a failure.

6.3 NO MANUAL OPERA-TION NOR AUTO-MATIC OPERATION CAN BE EXECUTED

Points

Causes and Countermeasures

1. Position display (relative, absolute, machine coordinate) does not change

- (1) Execute the following procedure when no manual nor automatic operation is done
- (2) Check whether position display shows correct position
- (3) Check Power Mate status display
- (4) Check Power Mate internal status using diagnostic function
- (1) Check CNC status display (Refer to 1.7 Power Mate STATUS DISPLAY FOR DETAIL)
 - (a) Emergency stop status (Emergency stop signal is turned on)
 - If status display shows **EMG** the emergency stop signal is input. Check the following signal using the PMC's diagnostic function (PMCDGN).
 - 1 When emergency stop is input from built–in I/O card internal I/O (Parameter No.3001#3=1).

	#7	#6	#5	#4	#3	#2	#1	#0
X1000				*ESP				
G0008				*ESP				
2	ESP=0 When e	indicate emergen	es that e cy stop 3001#3	emergen is input	cy stop from I/	signal is O card	s input.	
	#7	#6	#5	#4	#3	#2	" #1	#0
X1000				*ESP				
G0008				*ESP				
W th (F 1	/hen RE ne follo PMCDC An inp	ESET is wing s N). ut signa	display ignal u l from t	red, any using th he PMC	of a res e PMC	et is fur Vs diag	nctioned mostic	. Checl funcitor
	#7	#6	#5	#4	#3	#2	#1	#0
G0008	ERS	RRW						
2	When I When I RESET k When t	ERS is 1 RRW is ey on th he signa	l, exterr 1, reset ne MDI als in 1	hal reset & rewi keyboar are 0, R	signal i ng signa rd funct ₅₅₅⊤ key	s input. al is inpu ions 7 may be	ut. e functio	oning.
	Check	the cont	act of th	ne Reset	key usii	ng a test	er, or dis	sconnec
	the CR' When i	Γ/MDI j t is abn	panel et ormal, c	c. change t	he keyb	oard.		
		<u> </u>						

(c) Confirm the status of modes

Operation mode status is displayed on the lower part of CRT as follows :

If nothing is displayed, mode select signal is not input. Check mode select signal using PMC's diagnostic function (PMCDGN).

For details, refer to section 1.7 Power Mate STATUS DISPLAY.

(Example of display)

- JOG : Manual continuous feed (JOG) mode
- STEP : Step feed (STEP)
- MDI : Manual data input (MDI) mode
- AUTO: Automatic operation (Memory) mode
- EDIT : EDIT (Memory edit) mode

<Mode select signal>

	#7	#6	#5	#4	#3	#2	#1	#0
G0043						MD4	MD2	MD1
						Ļ	\downarrow	Ŷ
	Man	ual contin	uous (JO	G) mode		1	0	1
	Step	feed (ST	EP) mode	;		1	0	0
	Man	ual data ir	nput (MDI) mode		0	0	0
	Auto	matic ope	eration (Al	JTO) mod	le	0	0	1
	EDIT	(Memory	/ edit) mo	de		0	1	1
	TEA	CH IN ST	EP			1	1	1
	TEA	CH IN JO	G			1	1	0

(2) Check diagnostic data 000 to 025 of the CNC Check an item for which 1 is displayed

No.	Message	Display
000	WAITING FOR FIN SIGNAL	: 0
001	MOTION	: 0
002	DWELL	: 0
a.003	IN-POSITION CHECK	: 0
004	FEEDRATE OVERRIDE 0%	: 0
b.005	INTERLOCK	: 1
010	PUNCHING	: 0
011	READING	: 0
012	WAITING FOR (UN) CLAMP	: 0
c.013	JOG FEEDRATE OVERRIDE 0%	: 0
d.014	WAITING FOR RESET, ESP, RRW OFF	: 0
015	EXTERNAL PROGRAM NUMBER SEARCH	[:0

Items with a to d relate with manual and automatic operation and its detail is shown below.

a. In-position check is being done

b. Interlock signal is input

It shows that positioning is not yet completed. Check the contents of the following diagnostic number. (It is 1 in the following condition)

DGN 0300 Position Error >PARAM 1826 In–position width

1 Check the parameters according to the parameter list

1825 Servo loop gain per axis	(Normal : 3000)
-------------------------------	-----------------

2 Servo system may be abnormal. Refer to alarm 400, 410, and 411.

There are a plural interlock signals. Check at first which interlock signal is used by the machine tool builder at the parameters shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
3003					DIT	ITX	HITL	ITL

#0 ITL=0 shows interlock signal *IT is effective. To 1

#1 HITL = 1 shows interlock signal *RILK is effective. To 2

#2 ITX=0 shows interlock signal *ITn is effective. To 3

#3 DIT=0 shows interlock signal \pm MITn is effective. To 4

Check state of effective interlock signals using the diagnostic function (PMCDGN) of the PMC.

1 Interlock signal (*IT) is input

	#7	#6	#5	#4	#3	#2	#1	#0
G0008								*IT

*IT=0 shows that interlock signal is input.

2 High-speed interlock signal (*RILK) is input.

	#7	#6	#5	#4	#3	#2	#1	#0
X0000		*RILK						
or X1000								

*RILK = 0 shows interlock signal is input.

3 Axis interlock signal (*ITn) is input

	#7	#6	#5	#4	#3	#2	#1	#0
G0130			*IT6	*IT5	*IT4	*IT3	*IT2	+IT1

*ITn=0 shows interlock signal is input.

4 Interlock signal per axis and direction (\pm MITn) is input

	#7	#6	#5	#4	#3	#2	#1	#0
G0132			+MIT6	+MIT5	+MIT4	+MIT3	+MIT2	+MIT1
G0134			-MIT6	-MIT5	-MIT4	-MIT3	-MIT2	-MIT1

 \pm MITn=1 shows interlock signal per axis and direction is input.

c. Jog feedrate override is 0%

Check the signals using PMC's diagnostic function (PMCDGN)

	#7	#6	#5	#4	#3	#2	#1	#0
G0010	*JV7	*JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0
G0011	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8

When the override is 0% all bits of the above address becomes 1111 1111 or 0000 0000.

*IT-0 shows th

*JV15 JV0	Override
1111 1111 1111 1111	0.00%
1111 1111 1111 111	0.01%
:	:
1101 1000 1110 1111	100.00%
:	:
0000 0000 0000 0001	655.34%
0000 0000 0000 000	0.00%

- d. Power Mate is in a reset state
- 2. When machine coordinate value does not update on position display

In this case, RESET is also displayed on the status display. Check it using the procedure of 1 above.

(1) Machine lock signal (MLK) is input.

		110
G0044	MLK	

MLK : All axes machine lock

When the signal is 1, the corresponding machine lock signal is input.

6.4 JOG OPERATION CANNOT BE DONE

Points

Causes and Remedies

1. Position display (relative, absolute, machine cooordinate) does not change

- (1) Check whether position display is operating.
- (2) Check status display
- (3) Check internal status using Diagnostic funciton
- Check mode selection status (JOG mode is not selected) When status display shows JOG, it is normal. When status display does not show JOG, mode select signal is not selected correctly. Confirm the mode select signal using PMC's diagnostic function (PMCDGN).

<Mode select signal>



(2) Feed axis and direction select signal is not input Check the signal using PMC's diagnostic function (PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G0100			+J6	+J5	+J4	+J3	+J2	+J1
G0102			-J6	–J5	–J4	–J3	–J2	–J1

 \pm Jn=1 shows feed axis and direction select signal is input.

Example)

When +X button is pressed on the operator's panel, signal+J1 turns to 1.

This signal is effected at its rise. If axis selection signal is input before JOG mode is selected, axis movement does not occur. Turn the signal to off, then on.

(3) Check CNC's diagnostic function 000 to 015. Check the items for which 1 is displayed at right side. No. Message Display 000 WAITING FOR FIN SIGNAL :0 001 MOTION :0 002 DWELL :0 003 IN-POSITION CHECK :0 a. 004 FEEDRATE OVERRIDE 0% :0 b. 005 INTERLOCK / START LOCK (Example) :1 010 PUNCHING :0 011 READING :0 012 WAITING FOR (UN) CLAMP :0 c. 013 JOG FEEDRATE OVERRIDE 0% :0 d. 014 WAITING FOR RESET, ESP, RRW OFF :0 015 EXTERNAL PROGRAM NUMBER SEARCH :0 Items with a to d relate with manual and automatic operation and its detail is shown below. a. In-position check is It shows that positioning is not yet completed. Check the contents of the being done following diagnostic number. (It is 1 in the following condition) DGN 0300 Position Error >PARAM 1826 In-position width 1 Check the parameters according to the parameter list 1825 Servo loop gain per axis (Normal : 3000) 2 Servo system may be abnormal. Refer to alarm 400, 410, and 411. b. Interlock signal is input There are a plural interlock signals. Check at first which interlock signal is used by the machine tool builder at the parameters shown below. #3 #2 #7 #6 #5 #4 #1 #0 3003 DIT ITX ITL #0 ITL=0 shows interlock signal *IT is effective. To 1 #2 ITX=0 shows interlock signal *ITn is effective. To 3 #3 DIT=0 shows interlock signal \pm MITn is effective. To 4 Check state of effective interlock signals using the diagnostic function (PMCDGN) of the PMC. 1 Interlock signal (*IT) is input #7 #6 #5 #4 #3 #2 #1 #0 G0008 *IT *IT=0 shows that interlock signal is input. 2 Axis interlock signal (*ITn) is input #7 #6 #5 #4 #3 #2 #1 #0 G0130 *IT6 *IT5 *IT4 *IT3 *IT2 +IT1

*ITn=0 shows interlock signal is input.

3 Interlock signal per axis and direction (+/– MITn) is input

	#7	#6	#5	#4	#3	#2	#1	#0
G0132			+MIT6	+MIT5	+MIT4	+MIT3	+MIT2	+MIT1
G0134			-MIT6	-MIT5	-MIT4	-MIT3	-MIT2	-MIT1

 \pm MITn=1 shows interlock signal per axis and direction is input.

c. Jog feedrate override is 0%

C neck the signals using PIVIC s diagnostic function (PIVIC)	DCND
entern me signais asing i me s anagnostie ranetion (i me	DGN)

	#7	#6	#5	#4	#3	#2	#1	#0
G0010	*JV7	*JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0
G0011	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8

When the override is 0% all bits of the above address becomes 1111 1111 or 0000 0000.

*JV15 JV0	Override
1111 1111 1111 1111	0.00%
1111 1111 1111 111	0.01%
:	:
1101 1000 1110 1111	100.00%
:	:
0000 0000 0000 0001	655.34%
0000 0000 0000 000	0.00%

d.NC is in a reset state

In this case, RESET is also displayed on the status display. Check it using the procedure of 1 above.

(4) Jog feed rate setting (Parameter) is not correct

1423 Jog feedrate per axis [mm/min]	
---------------------------------------	--

(5) Check whether a torque limit is in effect.

6.5 EXTERNAL PULSE INPUT FUNCTION (SINGLE PHASE INPUT TYPE) CANNOT BE USED

Points

(1) Check another manual operation (JOG) is accepted.

(2) Check status display

Causes and Countermeasure

- 1 JOG operation is not acceptable, either
- 2 When only external pulse input function (single phase input type) cannot be done

Consult with item 8.3 and 8.4.

(1) Check CNC status display at lower left corner of the CRT

(Refer to 1.7 Power Mate STATUS DISPLAY for details)When the status display shows STEP, mode selection is correct.If it is not STEP, mode select signal is not input correctly. Check the mode select signal using the PMC's diagnostic function(PMCDGN).

	 #7	#6	#5	#4	#3	#2	#1	#0
G0043						MD4	MD2	MD1
						Ŷ	\downarrow	Ŷ
	Step feed mode						0	1

(2) Manual handle feed axis select signal is not input

Check the signals using PMC's diagnostic function (PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G0018						HS1C	HS1B	HS1A

When axis select switch for manual handle feed is selected on the machine operator's panel, if the signals are input as follows, it is normal.

Selected axis	HS1C	HS1B	HS1A
no selection 1st axis 2nd axis 3rd axis 4th axis 5th axis 6th axis	0 0 0 1 1	0 0 1 1 0 0	0 1 0 1 0 1 0

(3) Incremental feed signal is not correct

Check the following signals using PMC's PCDGN. Also confirm the following parameters based on the parameter list.



MP1	MP2	Multiplication
0	0	× 1
0	1	×10
1	0	×m
1	1	×n

7113	Magnification of external pulse input m(1 to 127)
7114	Magnification of external pulse input n(1 to 1000)

- (4) Checking external input pulse generator Check disconnection of cable or short circuit.
 - (a) Incorrect of cable

Power Mate side ENC (JA12)		External pulse generator
HA (03) HB (04) (+5V) (9, 18, 20) 0V (12, 14, 16)		- HA - HB - (+5V) - 0V
Connector:half pitch 20pins (HIROSE)	shield	

(b) Wave form of external input pulse generator HA: A phase signal HB: B phase signal

Confirm wave form of external input pulse.



Check on and off ratio and phase difference of HA and HB.

(5) Check of the torque limit Check whether a torque limit is in effect.

— 194 —

6.6 AUTOMATIC OPERATION CANNOT BE DONE

Points

Causes and Remedies

1. When cycle operation is not started (Cycle start LED does not light) (1) Check manual operation is possible.

- (2) Check the status of cycle start LED on machine operator's manual.
- (3) Check status of Power Mate.

When manual operation is either impossible, perform countermeasure, based on the previous item "Jog operation cannot be done".

Confirm that a correct mode is selected according to the mode select status of Power Mate status display. Also, by confirming the automatic operation status it is possible to identify cycle operation, feed hold and cycle stop state.

"****" is displayed at status display on CRT.

(1) Mode select signal is not correct.

When the mode select signal is input correctly, following status display is done.

MDI :Manual data input mode (MDI)

AUTO :Automatic operation mode

If status display does not show a correct status, check the mode signal with following diagnosis function of PMC side (PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G0043						MD4	MD2	MD1
		MD4	MD2	MD1	М	ode sele	ect]
		0	0	0	Mem	orv data	input	1

0	0	0	Memory data input mode (MDI)
0	0	1	Automatic operation mode (AUTO)

(2) Cycle start signal is not input

This signal turns 1 when cycle start button is pressed and turns 0 when it is released. The cycle start actuates when it changes from 1 to 0. Check the state of the signal using PMC's diagnostic function(PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G0007						ST		

#2 (ST) : Cycle start signal

The cycle is allowed to start by setting of parameter (No. 3001#1) when it changes from 1 to 0.

(3) Feed hold signal is input

Under normal state, the feed hold signal is 1 when the feed hold button is not pressed.

Check the state of this signal using the PMC's diagnostic function (PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G0008			*SP					

#5 (***SP**): Feed hold signal

— 195 —

2. When an automatic operation is in progress (Cycle start LED is lit)

a. An auxiliary function is being executed (waiting for FIN signal)

Power Mate's status display shows "STRT" on the CRT.

(1) Check the contents of diagnostic nos. 000 to 015. No. Message Display a. 000 WAITING FOR FIN SIGNAL (Example) :1 b. 001 MOTION :0 c. 002 DWELL :0 d. 003 IN-POSITION CHECK :0 e. 004 FEEDRATE OVERRIDE 0% :0 f. 005 INTERLOCK / START LOCK :0 010 PUNCHING :0 011 READING :0 012 WAITING FOR (UN) CLAMP :0 g. 013 JOG FEEDRATE OVERRIDE 0% :0 h. 014 WAITING FOR RESET, ESP, RRW OFF :0 015 EXTERNAL PROGRAM NUMBER SEARCH :0

Items with a to h relate with an automatic operation and their details are as follows :

An auxiliary function (M) specified in a program is not ended. Check according to the following procedure.

At first, confirm the kind of interface of an auxiliary function.

	#7	#6	#5	#4	#3	#2	#1	#0
3001	MHI							

#7(MHI) 0 : M is of normal interface.

1 : M is of high-speed interface.

1 Normal interface

When the auxiliary function finish signal turns from 1 to 0, the auxiliary function is supposed to be ended and the next block is read for operation. Confirm the status of this signal using PMC's diagnostic function(PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G0004					FIN			

#3 (FIN) : Auxiliary function finish signal

2 High-speed interface

The auxiliary function is supposed to be ended when the signals are in the following state. Confirm it using PMC's diagnostic function (PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G0005								MFIN

#0(MFIN): Miscellaneous function finish signal

	#7	#6	#5	#4	#3	#2	#1	#0
F0007								MF

#0(MF) : Miscellaneous function strobe signal

Signal	End	state
Finish signal	0	1
store signal	0	1

- b. Travel command is being executed
- c. A dwell command is being executed
- d.In–position check (confirming positioning) is being done

e. Feedrate override is at 0%

CNC is reading an axis command (X,Y,Z,...) in a program and giving the command to the axis.

CNC is reading a dwell command (G04) in a program and is executing the dwell command.

Positioning (G00) to a specified position of a specified axis is not completed.

Whether positioning is completed or not is checked as the servo position error amount. Check it CNC's diagnostic function as follows:

|--|

Position error amount almost becomes 0, when positioning of an axis completes and when the amount becomes within the in–position width, it is assumed that positioning completes and the next block is exected.

If position error amount does not become within the in–position width, refer to alarm 400, 4n0 and 4n1.

Actual feedrate is overridden by the override signals to a programmed feedrate. Check the override signals using the PMC's diagnostic function (PMCDGN).

<Normal override signal>

	 #7	#6	#5	#4	#3	#2	#1	#0
G0012	*FV7	*FV6	*FV5	*FV4	*FV3	*FV2	*FV1	*FV0

***FVn** : Feedrate override

<State of override signal>

*F	۰7V	• • • • • •	·*FV0	
1 [·] 1 ·	1 1 1 1	1 1 1 1 1 1 :	1 1 1 0	0% 254%
1 (0 0	110	1 1	100%
00	00000	0 0 0 0 0 0	0 1 0 0	1% 0%

— 197 —

f. Interlock signal or start lock signal is input

There are a plural number of interlock functions. Parameters are set by machine tool builders for which interlock function is used. Therefore, confirm the following parameters at first:

	#7	#6	#5	#4	#3	#2	#1	#0
3003					DIT	ITX		ITL

#0 (ITL) 0: shows interlock signal *IT is effective. To 1

#2 (ITX) 0: shows interlock signal *ITn is effective. To 3

#3 (DIT) 0: shows interlock signal \pm MITn is effective. To 4

Check state of effective interlock signals using the diagnostic function (PMCDGN) of the PMC.

1 Interlock signal (*IT) is input

	#7	#6	#5	#4	#3	#2	#1	#0
G0008								*IT

#0 (***IT**) : When this bit is 0, interlock signal is input.

2 High-speed interlock signal (*RILK) is input.

		#7	#6	#5	#4	#3	#2	#1	#0
X0000			*RILK						
I OF I	_								



***RILK** 0: shows interlock signal is input.

3 Interlock signal per each axis (*ITn) is input

	#7	#6	#5	#4	#3	#2	#1	#0
G0130			*IT6	*IT5	*IT4	*IT3	*IT2	*IT1

***ITn** When the bit is 0, the corresponding axis's interlock signal is input.

4 Interlock signal per axis and direction(\pm MITn) is input

	#7	#6	#5	#4	#3	#2	#1	#0
G0132			+MIT6	+MIT5	+MIT4	+MIT3	+MIT2	+MIT1
G0134			-MIT6	-MIT5	-MIT4	-MIT3	-MIT2	-MIT1

MITn Interlock signal is input to the corresponding axis and direction with the signal being 1.

5 Controlled axis detach function is running. A detached axis is specified for travelling.

*This function is valid when Power Mate parameter RMB No.1005#7=1. For whether this function is running or not, confirm the following signal using PMC's diagnostic function (PMCDGN). Check the axis concerned.

	#7	#6	#5	#4	#3	#2	#1	#0
F0110			MDTCH6	MDTCH5	MDTCH4	MDTCH3	MDTCH2	MDTCH1

When signal MDTHn is "1", the axis detach function is in valid. The control axis detach function becomes valid by the following signal issued from the PMC or a Power Mate side parameter. Check as in the following procedure :

— 198 —

1) The control axis detach signal (DTCHn) is input.

	#7	#6	#5	#4	#3	#2	#1	#0
G0124			DTCH6	DTCH5	DTCH4	DTCH3	DTCH2	DTCH1

If it is 1, the corresponding axis is detached.

2) The following parameter enables the control axis detach function to the corresponding axis.

	#7	#6	#5	#4	#3	#2	#1	#0
0012	RMVx							

#7(RMVx) 0 : Controlled axis is connected

1 : Controlled axis is detached

g. Manual feedrate override is 0% (dry run)

Normally manual feedrate override function is used for jog feed. But when DRN(dry run) signal turns on during an auomatic operation, override values set with these signals become valid to the following speed set by a parameter.

	#7	#6	#5	#4	#3	#2	#1	#0
G0046	DRN							

#7(DRN) : Dry run signal is input with this signal being 1.

1410 Dry run rate [mm/min]	
----------------------------	--

The rate when the following override value is 100%.

	#7	#6	#5	#4	#3	#2	#1	#0
G0010	*JV7	*JV6	*JV5	*JV4	+JV3	*JV2	*JV1	*JV0
G0011	*JV15	*JV14	*JV13	*JV12	+JV11	*JV10	*JV9	*JV8

When override value is 0%, all bits of the above address is [1111 1111] or [0000 0000].

*JV15 JV0	Override
1111 1111 1111 1111	0.00%
1111 1111 1111 111	0.01%
1101 1000 1110 1111	100. <u>0</u> 0%
0000 0000 0000 0001	655.34%
0000 0000 0000 0000	0.00%

h.NC is in a reset state

In this case, the CNC's status display shows RESET. Refer to item 1.

- (1) Only rapid traverse in positioning (G00) does not function Confirm the following parameter and signals from the PMC.
 - (a) Setting value of rapid traverse rate

1420	Rapid traverse rate per axis [mm/min]

(b) Rapid traverse override signals

	#7	#6	#5	#4	#3	#2	#1	#0
G0014							ROV2	ROV1

		_
ROV1	ROV2	Override
0 1 0 1	0 0 1 1	100% 50% 25% Fo

1421 Rapid traverse override F0 rate [mm/min]					
(2) Onl (a)	y N	feed (other than G00) does not function Iaximum feed rate set by parameter is incorrect.			
1422		Maximum feedrate [mm/min]			
1430		Maximum feedrate in each axis [mm/min]			

Feed rate is clamped at this upper feed rate.

6.7 CYCLE START LED SIGNAL HAS TURNED OFF

Causes and Remedies

Points

(1) After cycle operation is started, then stopped, check as follows:

(2) Confirm cycle start LED on machine operator's panel.

(3) Confirm Power Mate's diagnostic function

The reason why cycle start LED signal (STL) has turned off are displayed on Power Mate's diagnostic numbers 020 to 025 as follows:



Details of signals a to g are as follows:

Confirm the signals concerned using diagnostic function (PMCDGN).

a. Emergency stop is input

1 When input from Built–in I/O card internal I/O (Parameter No. 3001#3=0) :

	#7	#6	#5	#4	#3	#2	#1	#0
X1000				*ESP				
	#7	#6	#5	#4	#3	#2	#1	#0
G0008				*ESP				

***ESP=0** : Emergency stop signal is input :

2 When input from Built-in I/O card internal I/O (Parameter No. 3001#3=1):

	#7	#6	#5	#4	#3	#2	#1	#0
X0000				*ESP				
	#7	#6	#5	#4	#3	#2	#1	#0
G0008				*ESP				

***ESP=0** : Emergency stop signal is input :

b.External reset signal is input	60008	#7	#6	#5	#4	#3	#2	#1	#0
	00000	LKS							
	#7(ERS)	: When	the bi	t is 1, ex	ternal re	eset sign	al is inp	out.	63.600
		This when	signal i an M	s usually 02 is sn	used fo	or a cont in a pro-	firmatio	n signal as the e	of M02 and of a
		progr	am.	02 15 SP	centea	in a pr	ogram		ind of d
		There	efore, v	when M0	2 is exe	cuted, th	is signa	ıl is inpu	ıt.
c. Reset button on the MDI is pressed	An auton	natic op	eration	is put in	ito a res	et status	when	reset ke	ey on the
	MDI pan	el is pre	ssed.						
d. Reset & rewind signal is									
input		#7	#6	#5	#4	#3	#2	#1	#0
	G0008		RRW						
	#6(RRW	7): W	hen thi	s signal	is 1, the	reset &	rewind	signal i	s input.
		TI	nis sigr	nal is usu	ually us	ed for a	confirm	nation s	signal of
		M a i	.30 whe	n an M3 n	0 is spe	c111ed 1n	a progr	am as tr	ie end of
		TÌ	herefor	e, when I	M30 is e	executed	l, this si	gnal is i	nput.
e. Servo alarm has	When any	y servo a	alarm h	as genera	ated, cy	cle opera	ation is	put into	the reset
generated	state and	operation	on stop		·	•			
f. Cycle operation is in a	The cycle	e operat	ion bec	omes fee	ed hold	state in t	the follo	wing ca	ases:
feed hold state	1 Modes are switched from an automatic operation mode to a manual								
	operat	tion mo	de.			-			
	2 Feed l	nold sig	nal is ii	nput.					
	<mode se<="" th=""><th>elect sig</th><th>nal></th><th></th><th></th><th></th><th></th><th></th><th></th></mode>	elect sig	nal>						
	G0043	#7	#6	#5	#4	#3	#2 MD4	#1 MD2	#0
	00043								
				memory	edit(ED	IT)	0	1	
		Autor opera	natic ation	Automatic operation (AUTO)			0	0	1
				Manual data input (MDI)			0	0	0
		Mar	ual	Jog feed	d (JOG)		1	0	0
		opera	ation	TEACH	IN STEE)	1	1	1
				TEACH	IN JOG		1	1	0
	<feed ho<="" th=""><th>Id signs</th><th>1</th><th></th><th></th><th></th><th></th><th></th><th></th></feed>	Id signs	1						
		40 sigin #7	#6	#5	#4	#3	#2	#1	#0
	G0008			*SP					
	#5(*SP)	: When	n this si	ignal is 0	, the fee	ed hold s	signal is	input.	
g. It become single block									
operation		#7	#6	#5	#4	#3	#2	#1	#0



#1(SBK) When this signal is 1, the single block signal is input.

6.8 WHEN MANIPULATION IS NOT POSSIBLE WITH THE CRT/MDI

Points

Judgement of the point

Check whether it is a trouble of display or a trouble of the system. Check the STATUS LED on the controller shows the following state.



If the status shows the above state, the system is normal.

Therefore, display system may be faulty.

If you have a DPL/MDI, check whether it can be used to manipulate the system.

If the status shows other state, a hardware other than the display system may be troublesome.

If the message "WAITING FOR CRT DATA" appears on the CRT/MDI unit, it indicates that the CRT/MDI unit has started normally.

Causes and remedies

1. When the display system is in toruble

(1) Confirmation item

Determine which of the following problems are evident.

- 1. Nothing is displayed on the CRT/MDI unit.
- 2. Only the message "WAITING FOR CRT DATA" appears on the CRT/MDI unit.
- 3. A position display appears on the CRT/MDI unit, and the keys are ineffective.
- (2) Causes and remedies
 - 1. If nothing is displayed on the CRT/MDI unit.
 - The power being supplied to the CRT/MDI unit is abnormal (check the power supply).
 - The CRT/MDI unit is defective (replace the CRT/MDI unit).
 - 2. If only the message "WAITING FOR CRT DATA" appears on the CRT/MDI unit.
 - Incorrect cable connection (correct)
 - Defective cable (repair or replace)
 - Defective CRT control module (replace)
 - No CRT control module installed (install)
 - Touch panel connection module or HSSB connection module installed in place of the CRT control module (install the CRT control module)
 - Incorrect setting of rotary switches RSW and MTSW (correct the setting)
 - 3. A position display appears on the CRT/MDI unit, and the keys are ineffective.
 - DPL/MDI left connected (remove)
 - Defective cable (repair or replace)

<CRT control module mounting position>



2. When system is in trouble

EN (green)	ON
WD (red)	OFF
S0.S1	ON or OFF

When STATUS LED on the controller is other than above, check identify the trouble and make an appropriate action. See 2.4 for LED display.

6.9 ALARM 85 TO 87 (READER/PUNCHER INTERFACE ALARM)



Causes

Countermeasures

- (a) Parameters on reader/puncher interface are not correct. Check the following setting data and parameters.
- (b) External I/O device or host computer is faulty.
- (c) Cable between Power Mate and I/O device is faulty.
- (d) Base PC board is faulty.

(a) Parameters on reader/puncher interface are not correct. Check the following setting data and parameters:
<Setting>
PUNCH CODE=0 OR 1 (0: EIA,1:ISO)
Select ISO or EIA according to the type of I/O device. If punch code does not match, alarm 86 will generate.

<Parameter>

Value of parameter 0020	0	1	
Feed	0101#7	0111#7	
Data input code	0101#3	0111#3	
Stop bit	0101#0	0111#0	
Type of I/O device	102	112	
Baud rate	103	113	
Communication method	RS-232C		

Numbers in the table indicate parameters and bit numbers. Example) 101#7:bit7 of parameter 101.

	#7	#6	#5	#4	#3	#2	#1	#0	
0101	NFD				ASI			SB2	
0111									
#7(NFD)	0 :	Feed is (FANU	Feed is output before and after data in data output (FANUC PPR)						
	1 :	Feed is	not out	put (sta	ndard).				
#3(ASI)	0 :	Data in	put cod	e is EIA	or ISO	(automa	atic reco	gnition)	
	1 :	Data ir	put cod	e is AS	CII.				
#0(SB2)	0 :	No. of	stop bits	s is 1.					
	1 :	No. of	stop bits	s is 2.					

Type of I/O device

01	02
01	12

Value	TYPE OF I/O DEVICE						
0	RS-232-C (for other than the following)						
1	Not used						
2	FANUC CASSETTE F1 (Old type FLOPPY CASSETTE ADAPTOR)						
3	FANUC PROGRAM FILE Mate, FANUC FLOPPY CASSETTE ADAPTOR, FANUC SYSTEM P–MODEL H, FANUC Handy File						
4	Not used						
5	Not used						
6	FANUC SYSTEM P–MODEL G, FANUC SYSTEM P–MODEL H						
0103	Baud rete						
------	-----------	-----------	--	--	--	--	--
0113							
	Value	Baud rate					
	7	600					
	8	1200					
	9	2400					
	10	4800					
	11	9600					
	12	19200					

- (b) External I/O device or Host computer is in trouble
 - (i) Check whether the setting on communication of external I/O device or host computer is the same as that of the Power Mate. (baud rate, stop bits, etc.) If they are not the same, change the setting.
 - (ii) When spare I/O device presents, check whether it is possible to realize communication using the spare I/O device.
- (c) Cable between Power Mate and I/O device is faulty. Check the cable for disconnection or wrong connection.



- (d) Base PC board of Power Mate is faulty. Replace the Power Mate unit.
- < Cable connection>



NOTE

- 1 When CS is not used, connect it to RS.
- 2 Always use a twisted pair cable.

6.10 REFERENCE POSITION DEVIATES



6.11 ALARM 90 (REFERENCE POSITION RETURN IS ABNORMAL)

Contents

An attempt was made to return to the reference position without satisfying the condition that, when the tool is moving toward the reference position with a positional deviation (DGN. 300) of 128 or more pulses, at least a one–turn signal is received.

Moreover, for the α absolute pulse coder, a reference position return was attempted without first turning the power off then on again after rotating the motor one turn when the system is started, or when the battery is replaced in response to a battery zero alarm.

Countermeasures





CAUTION

- 1 After the pulse coder or motor is exchanged, reference position or machine's standard point may be different from former one. Please set it correctly.
- 2 When the base PC board is exchanged, all the data stored in memory is lost. Reset all the data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA". The data includes reference position information. Reference position setting must also be performed, therefore.

Reference

A speed more than 128 pulses is required because if speed is lower that this, one–rotation signal does not function stably, causing improper position detection.

6.12 ALARM 300 (REQUEST FOR REFERENCE POSITION RETURN)

Remedies

 When dog reference position return function is present

- When dog reference position return function is not present
- When serial pulse coder is changed

Related parameters

Absolute position data in the serial pulse coder was lost.

[This alarm occurs if the serial pulse coder is replaced, the position feedback signal line is removed from the serial pulse coder, the battery or its cable is removed, or parameters are loaded into the Power Mate as a batch.]

Machine position must be memorized using the following method:

If a battery alarm (306) occurs in the α pulse coder, recover the normal battery status, rotate the motor through at least one turn, then turn the power off then on again.

- (1) Execute manual reference position return only for an axis for which this alarm was generated.
- (2) Press RESET key at the end of reference position return to release the alarm.

Execute dogless reference position setting to memorize the reference position.

Since the reference position is different from the former one, change the grid shift value (PRM 1850) to correct the position.

	#7	#6	#5	#4	#3	#2	#1	#0
1815			APC x	APZx				
#5(APCx) 0 : Position detector is incremental pulse coder.								
	1 :	Positio	n detect	or is ab	solute p	ulse cod	ler.	

#4(APZx) Reference position of absolute pulse coder is :

- 0 : not established
- 1 : established

System configuration



6.13 ALARM 301 TO 305 (ABSOLUTE PULSE CODER IS FAULTY)

Countermeasures

Absolute pulse coder, cable or servo module is faulty.

- **1** Agitate the cable connected to JSn of servo amplifier. If an alarm is issued, replace the cable.
- 2 Replace the servo module.

Replace the module corresponding to the axis indicated by the alarm, as shown in the figure below.

• Replace following modules of the controller.

<Location of servo module> Base PC board



6.14 ALARM 306 TO 308 (ABSOLUTE PULSE CODER BATTERY IS LOW)

Absolute pulse coder battery replacement

This alarm is generated when absolute pulse coder battery becomes low. If alarm 306 occurs, the reference position has been lost. After replacing the battery, re–set the reference position.

WARNING

When replacing the memory backup batteries, keep the power to the machine (CNC, servo amplifier) switched on, and hold the machine at an emergency stop. Because this work must be carried out while the power is kept switched on and the cabinet is open, only the personnel who have been trained for safety are allowed to engage in the work. When replacing the batteries, be careful not to touch the high–voltage circuit section (marked \triangle and shielded with a shock hazard prevention cover). If you touch the high–voltage circuit section when it is uncovered, you will get an electric shock.

Procedure

Replace the batteries in the α series servo amplifier module, the β series servo amplifier, or the separate battery box.

CAUTION

- 1 When replacing the built–in batteries for the α series servo amplifier module or β series servo amplifier module, keep the power to the servo amplifier switched on.
- 2 When replacing the batteries in the separate type battery box, keep the power to the NC and servo amplifier switched on.
- 3 Note that we are not supposed to replace the batteries for the control unit (for memory backup).

Procedure for replacing batteries for absolute pulse coder (α series servo amplifier module)

1 Prepare lithium battery A06B–6073–K001^(*) in advance.

(*) FANUC specification : A98L-0001-0902

- 2 Turn machine (servo amplifier) power ON.
- 3 Remove the battery case on the front panel of α series Servo Amp Module (SVM).

The battery case can be removed by holding the top of the case and pulling the case towards you.



- 4 Remove the connector the battery.
- **5** Replace the battery , and connect the connector.
- 6 Attach the battery case.
- 7 Turn machine (servo amplifier) power OFF.

CAUTION

Replace the batteries for absolute pulse coder when machine (servo amplifier) power is ON. Replacing the batteries with power OFF causes the

absolute position stored in memory to be lost.

Procedure for replacing batteries for absolute pulse coder (β series servo amplifier)

Prepare lithium battery A02B–0168–K111(*) in advance.

(*) FANUC specification: A98L-0031-0011

Procedure

- **1** Turn machine (servo amplifier) power ON.
- 2 Remove the battery case from under the β series servo amplifier module by holding the case at both sides and pulling downwards.



- **3** Remove the connector the battery.
- 4 Replace the battery, and connect the connector.
- 5 Attach the battery case.
- 6 Turn machine (servo amplifier) power OFF.

CAUTION

- Replace the batteries for absolute pulse coder when machine (servo amplifier) power is ON.
 Replacing the batteries with power OFF causes the absolute position stored in memory to be lost.
- 2 If your machine is equipped with a separate battery case, follow the instructions in 2.6.4

Procedure for replacing separate type batteries for absolute pulse coder

- 1 Prepare 4 alkaline batteries (UM–1type) commercially available in advance.
- 2 Turn machine (CNC, sevo amplifier) power ON.
- 3 Loosen screws on the battery case to remove the cover. For placement of the battery case, refer to the machine tool builder's manual.
- 4 Replace the batteries in the case. Insert 2 batteries each in the opposite direction as illustrated below.



- 5 After replacement, install the cover.
- 6 Turn machine (CNC, sevo amplifier) power OFF

CAUTION

Replace the batteries for absolute pulse coder when machine (CNC, servo amplifier) power is ON. Replacing the batteries with power OFF causes the absolute position stored in memory to be lost.

6.15 ALARM 350 (SERIAL PULSE CODER IS ABNORMAL)

An error is generated in the control section of the serial pulse coder.

Points

- 1 Alarm No. 351 has also generated \Rightarrow Refer to alarm 351.
- 2 Only alarm No. 350 has generated⇒Refer to the following Confirm the details by diagnostic number 0202 and 0204.

When diagnostic number 0202 shows 1

		_	#7	#6	#5	#4	#3	#2	#1	#0
DGN	0202	[CSA		PHA	RCA		CKA	SPH

#6(CSA) Check sum alarm has generated.

#4(PHA) Phase data abnormal alarm has generated.

#3(RCA) Speed count abnormal alarm has generated.

#1(CKA) Clock alarm has generated.

#0(SPH) Soft phase data abnormal alarm has generated.

- 1 Check the contens using the above diagnostic function if the alarm generates repeatedly. If diagnostic data is the same, serial pulse coder may be faulty.⇒Refer to following **Caution**
- 2 When diagnostic result does not the same, or other abnormality is detected, an external noise may be generated.
- When diagnostic number 0204 shows 1

		#7	#6	#5	#4	#3	#2	#1	#0	
DGN	0204				LDA	PMS				

#4(LDA) LED of serial pulse coder is abnormal

#3(PMS) Feedback pulses are not issued correctly.

(1) #4(LDA): LED in the serial pulse coder is abnormal.

- Serial pulse coder is faulty⇒Refer to following Caution
- For an analog servo, this may indicate that the parallel-serial converter has malfunctioned.
- (2) #3(PMS): Pulses are not issued correctly by abnormality of feedback cable.
 - 1 Fault of serial pulse coder \Rightarrow Refer to following **Caution**
 - 2 Feedback cable is faulty. \Rightarrow Refer to following Caution

CAUTION

Reference position and machine's standard position are different from the ones before, adjust and set them correctly.

6.16 ALARM 351 (SERIAL PULSE CODER COMMUNICATION IS ABNORMAL)

Points

Causes

Check the details by the diagnostic function of the Power Mate

An error is generated in communication with serial pulse coder.

	CHECK III	e uctans	by the	unagnosi	ine runet	ion or u		i mate.	
		#7	#6	#5	#4	#3	#2	#1	#0
DGN	0202	DTE	CRC	STB					
	#7(DTE #6(CRC #5(STB) 1) #7(D 1 Sig 2 Se 3 +5 2) #6(CI 1 Sig 2 Se 3 B) Data) Serial) Serial (TE):Resp gnal cab rial puls (V to the RC),#5(S agnal cab erial puls ase PC b	error ha l commu l commu ponse fr le is disc e coder serial p STB):Se ble is disc se coder poard or	s genera inication om seria connecta is faulty pulse coor rial com sconnect is faulty servo m	tted. a error han al pulse of ed $x \Rightarrow See$ der is low amunication red. $y \Rightarrow See$ anodule is	as gener as gene coder is Cautio wered. tion is in cautio	ated. (C rated. (S absent. n 1. n faulty n 1. ⇒ See (RC chec Stop bit	2
	CAUTI 1 Afte or m repl 2 All t boa 3 "II The Refe ther	ON r the se nachine acemer the data rd is cha rd is cha	erial pul 's stanc nt. The a stored anged. ND OL inclue positic	lse cod lard poi refore r d in me Set NO JTPUT des re on sett	er is ch nt is dif eset an emory is C data a OF DAT eference ing mu	anged, ferent f d adjus s lost v again, r GA". e pos ust als	referent rom the st it aga when the referring sition so be	nce po e one b in. ne base g to Ch informa perfor	sition efore e PC apter ation. med,

6.17		Amplifier or overheat of motor is detected.
ALARM 400 (OVERLOAD)		400 SERVO ALM :X OVERLOAD
Points		Confirm the detail by the diagnostic function of Power Mate.
	DGN	#/ #6 #5 #4 #3 #2 #1 #0 0200 OVL <
		#7(OVL) : 1 OVERLOAD ALARM is displayed.
		Check details of alarms by DGN 201.
		#7 #6 #5 #4 #3 #2 #1 #0
	DGN	0201 ALD
		1 Overheat of servo motor
		0 Overheat of servo amplifier
Overheat of servo moto	r	
		(START) Is it hot ? YES Overheat of motor Defective thermostat (Next page) (1)

CAUTION

After the motor is changed, reference position or machine's reference point is different from the one before replace ment. Set it again.

Overheat of servo amplifier





6.18 ALARM 401 (*DRDY SIGNAL TURNED OFF)

Ready signal (*DRDY) of servo amplifier is not turned on or turned off during operation.



NOTE

When the base PC board is replaced, all the data stored in memory is lost. Set data again, referring to chapter 3. "INPUT AND OUTPUT OF DATA".



Power on sequence (Power Mate⇔Servo amplifier)



CAUTION

This alarm may occur when two or more Power Mates share a single servo amplifier. In such a case, set bit 2 (NOFVY) of parameter No. 1803.

6. TROUBLESHOOTING

6.19 ALARM 404 AND 405 (*DRDY SIGNAL TURNED ON, REFERENCE POSITION RETURN ABNORMAL)

- Alarm 404 (* DRDY ON)
- Causes

DRDY signal is turned on before *MCON signal is turned on, or DRDY is not turned off after *MCON signal is turned off.

- 1 Servo amplifier is faulty.
- 2 Between servo amplifier and Power Mate is faulty.
- 3 Base PC board or servo module is faulty. (Refer to Sec. 6.13)

CAUTION

When the base PC board is replaced, all the data stored in memory is lost. Set the NC data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".



When automatic reference position return (G28) ended, grid signal is

- Alarm 405 (Reference positin return is abnormal)
- Causes

Base PC board or servo module is faulty. (Refer to Sec. 6.13)

CAUTION

turned on.

When the base PC board is replaced, all the data stored in memory is lost. Set the NC data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".

— 225 —

6.20 ALARM 410 (EXCESSIVE POSITION ERROR AMOUNT DURING STOP)

Position error amount at stop (DGN 300) exceeds a value set by parameter No. 1829.



NOTE

When the base PC board is replaced, all the data stored in memory is lost. Set NC data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".

6.21 ALARM 411 (EXECESSIVE POSITION ERROR DURING MOVE)

Position error amount during movement (DGN 300) execeeds a value set by parameter 1828.





CAUTION

When the base PC board is replaced, all the data in memory is lost. Reset NC data, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".

NOTEFeed rate (mm/min)11Position error= $60 \times PRM1825$ 12Parameter 1828 \geq Position error at rapid traverse 1.2



6.23 ALARM 416 (DISCONNECTION ALARM)

Point

Position detection signal line is disconnected or short-circuited.

Check the details using the Power Mate's diagnostic function. #7 #6 #5 #4 #3 #2 #1

		#7	#6	#5	#4	#3	#2	#1	#0
DGN	0201	ALD			EXP			DLZ	
		V			Ŷ				
		1	-	-	0	Built–in disconne	serial puls ection	e coder	→ENC _X

Causes

- 1 Signal cable is disconnected or short-circuitted.
- 2 Serial pulse coder or position detector is faulty. Refer to Caution 1
- 3 Base PC board or servo module is faulty. (Refer to Sec. 6.13.) Refer to Caution 2

CAUTION

- After the pulse coder is replaced, reference position or machine's standard position is different from former one. Adjust and set it correctly.
- 2 When the base PC board is replaced, all the data stored in memory is lost. Set NC data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".

6.24 ALARM 417 (DIGITAL SERVO SYSTEM IS ABNORMAL)

• Causes

Digital servo parameters are abnormal.

(Digital servo parameters are set incorrectly.)

When alarm 315 is occured at the same time, check the cause of alarm 351 of Sec. 6.16.

PRM 2020 : Motor format number
PRM 2022 : Motor rotation direction
PRM 2023 : Number of pulses of velocity feedbacks
PRM 2024 : Number of pulses of position feedback
PRM 1023 : Servo axis number
PRM 2084 : Flexible feed gear ratio
PRM 2085 : Flexible feed gear ratio
Confirm the details with diagnosis function of CNC side.

1 Confirm the setting value of the following parameters:

- 2 Change the setting of this parameter to 0. PRM 2047 : Observer parameter
- Perform initial setting of digital servo parameters.
 Refer to Sec. 5.1 "initial setting of servo parameters".

6.25 ALARM 700 (OVERHEAT AT CONTROL SIDE) Remedies

Because an ambient temperature of Power Mate becomes high, a thermostat mounted on Power Mate and informs an alarm.



6.26 ALARM 900 (ROM PARITY ERROR)

Causes and Remedies

ROM parity error occurred.

(1) Based PC board mounted on the base PC board or BOOT ROM is defective.

SYSI	EM ALARM	8880-01	
900	ROM PARITY CNC ROM		
	F82	Defective file or ROM is displayed	

Confirm the series and versions of control software those are displayed on upper right of the screen.

*Memory module (2) may be written data (ladder program) by machine tool builder.

*Mounting position of ROM/MEMORY module

- (2) : Memory module (CNC control software, Control soft for digital servo, Ladder program produced by MTB, macro executer program produced by MTB, and C language executer produced by MTB)
- (9) : BOOT ROM (ROM for CNC system boot)



CAUTION

When the memory module is replaced, all the data stored in memory is lost. Set data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".

6.27 ALARM 912 TO 913 (RAM PARITY)

Points

Parity error of RAM (in memory module) that stores part programs.

A parity bit is prepared for writing data in memory correctly. There are odd–number parity and even–number parity.

_	#7	#6	#5	#4	#3	#2	#1	#0	#P	
	1	0	1	1	0	1	1	1	0	(Parity bit)
										 (Even-number parity)

Causes and Remedies

(1) When this alarm occurs immediately after power is turned on, once turn off power, then turn on power while pushing RESET and DELETE key

to perform memory all clear

If parity error is not released by clearing all memory, RAM or backup circuit of RAM may be faulty. Change memory module or base PC board.

CAUTION

When the base PC board or memory module is replaced, all the data stored in memory is lost. Set data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".

 Memory module mounting position Memory module (Part program editing, parameters etc...)



(2) Low voltage of memory back up battery.

A battery alarm occurs if a voltage rated at 3.0V drops to 2.5V typical (2.3 to 2.7V).

When the memory back up battery voltage is lowered, BAT is displayed at lower part of the screen.

When battery alarm is lit, replace with new lithium batteries as soon as possible.

Refer to 2.6 battery replacing item and change the batteries.

(3) Power supply PC board is faulty When alarm turns off by an operation of clearing all the memory, power supply PC board may also be faulty. **Points**

6.28	92
ALARM 920 TO 922	92
(WATCH DOG OR	92
RAM PARITY)	

920:	Watch dog alarm or RAM parity in servo module
	has occurred in the 1st or 2nd axis
921:	Above alarm has occurred in the 3rd or 4th axis
922:	Above alarm has occurred in the 5th or 6th axis

Watch dog timer alarm Watch dog timer alarm The timer used to monitor the operation of CPU is called the watch dog timer. The CPU resets timer time every time a constant time has passed. When an error occurs in CPU or peripheral device, timer is not reset but the alarm is informed. RAM parity error Refer to alarm 910 to 911. RAM in servo module has been checked. Servo module is faulty The servo module includes servo RAM, watch dog timer circuit, etc. Defectiveness of hardware, abnormality or malfunctioning of detection circuit or the like is considered. Therefore, replace servo module. Base PC board is faulty Base PC board is faulty Base PC board may be faulty. Replace the base PC board.

- Memory module is faulty Software may not work properly due to failure of memory module. Change memory module.
- Power supply PC board DC output voltage of power supply PC board may be faulty. Replace the power supply PC board.

<Location of module> Main CPU board



CAUTION

When the base PC board and memory module are replaced, all the data stroed in memory is lost. Set data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".

6.29 ALARM 924 (SERVO MODULE MOUNTING ERROR)

The servo module is not mounted.

ERROR)	NOTE This alarm may not occur during normal operaion. This alarm may be generated when a PCB is changed for maintenance.				
 Causes and remedies 	Check installation and kinds of servo module on base PC board. For location of servo module, refer to an installation diagram of alarm 920 to 922.				
	Unless these boards are mounted correctly, if this alarm still generates, change base PC board or servo module.				
Module location	Refer to Sec. 6.28.				
 Kinds of servo module 	A20B–2902–0290 (Digital servo) A20B–2902–0510 (Analog servo)				
6.30 ALARM 930 (CPU ERROR)	CPU error (illeagal interrupt) has generated.				
Causes and Remedies	1) Base PC board is faulty				
	An interrupt which will not occur during usual operation has generated. Peripheral circuit of the CPU may be abnormal. Change the base PC board. If operation is performed normally by power off and on, noise may be a cause. Refer to Subsec. 2.2.3 "Suppressing Noise".				
	2) Memory module is faulty				
	Replace the memory module. For location of memory module see the section of alarm 910 to 911.				
	CAUTION When the base PC board and memory module are replaced, all the data stroed in memory is lost. Set data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".				

6.31 ALARM 950 (PMC SYSTEM ALARM)

Causes and Remedies

An error occurred when RAM used for PMC test is being executed.

The following causes are considered :

- PMC module (1) is faulty.
- Memory module (2) is faulty.
- Base PC board is faulty.

Module mounting position



6.32 ALARM 970 (NMI ALARM IN PMC MODULE)

Causes and Remedies Module mounting

position

RAM parity error or NMI has occurred in the PMC module.

Fault of PMC module is considered.



- 240 -

6.33 ALARM 971 (NMI ALARM IN SLC)

Causes and Remedies

A communication error is detected between Power Mate and I/O unit I/O card at SLC in the PMC module.

Fault of PMC module or fault of I/O unit or I/O card.



- PMC control module (1) is faulty. Refer to Sec. 6.32 for the module mounting position.
- I/O unit or I/O card is faulty.
- +24V power to the I/O unit or I/O card is faulty.

Interface module AF01A/AF01B			
	CP32	1	+24V
		2	GND
		3	Unused

Disconnection or broken of cable.

6.34 ALARM 973 (NMI ALARM BY UNKNOWN CAUSE)

An unknown NMI has generated.

This alarm may also be issued when the FANUC I/O link is disconnected while the Power Mate is being used as the slave of the I/O link.

Causes and Remedies

Module location

1) Base PC board or power supply PC board is faulty

- Base PC board is faulty.
- Memory module is faulty.
- Power supply PC board is faulty.
- 2) The power to those units connected to the I/O link is turned off, or a system alarm is issued.

Turn the power off, then back on again. This clears the alarm.

Refer to Sec. 6.27.

CAUTION

When the base PC board is replaced or the memory module is replaced (or removed then mounted again) all the data stored in memory is lost. Set data again, referring to Chapter 3 "INPUT AND OUTPUT OF DATA".
6.35 NO SIGNAL CHANGE IN FANUC I/O LINK MASTER

Causes and Remedies

Point

Determine whether the FANUC I/O link is established.

Turn on the power to the Power Mate and the slave of the FANUC I/O link (such as an I/O card or I/O unit). Make sure that the Power Mate screens can be switched using the CRT or DPL keys, then turn off the power to the Power Mate only. If a communication alarm is issued by the slave unit (the red LED lights), the FANUC I/O link has already been established.

(1) When the FANUC I/O link has not yet been established

• Slave unit allocation error on the Power Mate

→ Refer to the PMC documentation or "Power Mate–Model H Connection Manual" (description of the FANUC I/O link function in "PMC Interface") to set the slave unit correctly.

• Faulty cable contact

→ Make sure that the Power Mate connector is JD1A1 and that the slave connector is JD1B (refer to Subsection 2.3.4). Alternatively, after turning the power off, disconnect the cable, then connect it again.

- Wrong cable
 - → The cable used for the FANUC I/O link function features pins that are not connected straight through. For example, pin 1 of one connector is connected to pin 3 of the other connector. Refer to Subsection 2.3.4 for details of the cable.
- Defective Power Mate or slave unit
 → Replace the Power Mate or slave unit.
- (2) When the FANUC I/O link has already been established Check the connection between the machine and slave unit, I/O signal X/Y to the PMC, ladder, and others.

APPENDIX



- A.1 SYSTEM CONFIGURATION
- A.2 HARDWARE CONFIGURATION
- A.3 LED INDICATION
- A.4 FUSES
- A.5 REMOVING A PRINTED CIRCUIT BOARD

A.1 SYSTEM CONFIGURATION

Up to 16 FANUC I/O Unit–MODEL A groups can be connected to a Power Mate through the FANUC I/O Link high–speed serial interface.



- * The number and types of slave units that can be connected for each group are as follows :
- Up to two I/O Units
- One Power Mate
- One I/O card

A.2 HARDWARE CONFIGURATION



A.3 LED INDICATION

Modules having up to 16 input/output points are provided with LEDs to indicate their statuses.

Use these LED's to assist you with troubleshooting.

AIF01A



AIF01B



Input / Output modules (with up to 16 input / output points)

	A 0 1 2 3 4 5 6 7 B 0 1 2 3 4 5 6 7
\sim	A00000

Symbol	Description
A0 to 7 B0 to 7	Indicate the state of an input / output signal (LED on : signal on, LED off : signal off)
F	Indicates that the internal fuse has blown

A.4 FUSES

The following modules provide the corresponding protection fuses. If a fuse blows for any reason, such as the short–circuiting of a cable connected to a load, first remove the cause of the problem, then replace the fuse.

Module	Indication of whether a fuse has blown	Parts number of fuse	Rated cur- rent
AIF01A Interface module	PWR off	A60L-0001-0290#LM32	3.2A
AIF01B Interface module	PWR off	A60L-0001-0290#LM32	3.2A
A0D08C Output module (8 DC points)	F on	A60L-0001-0260#5R00	5A
A0D08D Output module (8 DC points)	F on	A60L-0001-0260#5R00	5A
A0A05E Output module (5 AC points)	F on	A60L-0001-0276#3.15	3.15A
A0A08E Output module (8 AC points)	F on	A60L-0001-0276#3.15	3.15A
A0A12F Output module (12 AC points)	F on	A60L-0001-0276#3.15	3.15A

WARNING

Before replacing a blown fuse, it is necessary to remove the cause of the blown fuse. For this reason, only the personnel who have a working knowledge of maintenance and safety are allowed to carry out this work. When replacing a fuse with the cabinet open, be careful not to touch the high–voltage circuit section (marked \triangle and shielded with a shock hazard prevention cover). If you touch the high–voltage circuit section when it is uncovered, you will get an electric shock.

A.5 REMOVING A PRINTED CIRCUIT BOARD

- Removing a terminal-box-type input/output module
- 1 Remove the terminal box, if necessary.
- **2** Remove the LED cap by pulling it in the direction indicated by the arrow.



3 While pushing the connector in the direction indicated by the arrow, use a screwdriver to release the two claws on the module case.



4 As shown on the right, insert a screwdriver into the gap between the module case and the connector of the terminal box. To remove the printed circuit board, push the connector in the direction indicated by arrow B while pushing the screwdriver in the direction indicated by arrow A



- Removing a connector-type input/output module
- **1** To remove the cover, pull it in the direction indicated by the arrow, while using a screwdriver to release claws A and B on both sides.



2 To remove the LED cap, pull it in the direction indicated by the arrow.



3 While pushing the connector in the direction indicated by the arrow, use a screwdriver to release the two or four claws on the module case. Then, remove the printed circuit board by pushing the connector in the direction indicated by the arrow.



— 252 —



ALARM LIST

1) Program errors (P/S alarm)

Number	Message	Contents		
000	PLEASE TURN OFF POWER	A parameter which requires the power off was input, turn off power.		
001	TH PARITY ALARM	TH alarm (A character with incorrect parity was input). Correct the tape.		
002	TV PARITY ALARM	TV alarm (The number of characters in a block is odd). This alarm will be generated only when the TV check is effective. Correct the tape.		
003	TOO MANY DIGITS	Data exceeding the maximum allowable number of digits was input. (Refer to the item of max. programmable dimensions.)		
004	ADDRESS NOT FOUND	A numeral or the sign " – " was input without an address at the beginning of a block. Modify the program .		
005	NO DATA AFTER ADDRESS	The address was not followed by the appropriate data but was fol- lowed by another address or EOB code. Modify the program.		
006	ILLEGAL USE OF NEGATIVE SIGN	Sign " $-$ " input error (Sign " $-$ " was input after an address with which it cannot be used. Or two or more " $-$ " signs were input.) Modify the program.		
007	ILLEGAL USE OF DECIMAL POINT	Decimal point " ." input error (A decimal point was input after an ad- dress with which it can not be used. Or two decimal points were in- put.) Modify the program.		
009	ILLEGAL ADDRESS INPUT	Unusable character was input in significant area. Modify the program.		
010	IMPROPER G-CODE	An unusable G code or G code corresponding to the function not provided is specified. Modify the program.		
011	NO FEEDRATE COMMANDED	Feedrate was not commanded to a cutting feed or the feedrate was inadequate. Modify the program.		
027	NO AXES COMMANDED IN G43/G44	No axis is specified in G43 and G44 blocks for the tool length offset. Offset is not canceled but another axis is offset for the tool length offset. Modify the program.		
028	ILLEGAL PLANE SELECT	In the plane selection command, two or more axes in the same direc- tion are commanded. Modify the program.		
029	ILLEGAL OFFSET VALUE	The offset values specified by H code is too large. Modify the program.		
030	ILLEGAL OFFSET NUMBER	The offset number specified by H code for tool length offset is too large. Modify the program.		
031	ILLEGAL P COMMAND IN G10	In setting an offset amount by G10, the offset number following ad- dress P was excessive or it was not specified. Modify the program.		
032	ILLEGAL OFFSET VALUE IN G10	In setting an offset amount by G10 or in writing an offset amount by system variables, the offset amount was excessive. Correct the offset value.		
046	ILLEGAL REFERENCE RETURN COMMAND	Other than P2 and P3 are commanded for 2nd and 3rd reference position return command.		
059	PROGRAM NUMBER NOT FOUND	In an external workpiece number search, a specified program num- ber was not found. Otherwise, a program specified for searching is being edited in background processing. Check the program number and external signal. Or discontinue the background eiting.		

Number	Message	Contents
060	SEQUENCE NUMBER NOT FOUND	Commanded sequence number was not found in the sequence number search. Check the sequence number.
070	NO PROGRAM SPACE IN MEMORY	The tape memory area is insufficient. An attempt to input a ladder program using the DPL/MDI failed be- cause the program was too big. Delete any unnecessary programs, then retry.
071	DATA NOT FOUND	The address to be searched was not found. Or the program with specified program number was not found in program number search. Check the data.
072	TOO MANY PROGRAMS	The number of programs to be stored exceeded 63 (basic), 125 (option), 200 (option), or 400 (option). Delete unnecessary programs and execute program registeration again.
073	PROGRAM NUMBER ALREADY IN USE	The commanded program number has already been used. Change the program number or delete unnecessary programs and execute program registeration again.
074	ILLEGAL PROGRAM NUMBER	The program number is other than 1 to 9999. Modify the program number.
075	PROTECT	An attempt was made to register a program whose number was pro- tected.
076	ADDRESS P NOT DEFINED	Address P (program number) was not commanded in the block which includes an M98, G65, or G66 command. Modify the program.
077	SUB PROGRAM NESTING ERROR	The subprogram was called in five folds. Modify the program.
078	NUMBER NOT FOUND	A program number or a sequence number which was specified by address P in the block which includes an M98, M99, M65 or G66 was not found. The sequence number specified by a GOTO statement was not found. Otherwise, a called program is being edited in back- ground processing. Correct the program, or discontinue the back- ground editing.
079	PROGRAM VERIFY ERROR	In memory or program collation, a program in memory does not agree with that read from an external I/O device. Check both the programs in memory and those from the external device.
085	COMMUNICATION ERROR	When entering data in the memory by using Reader / Puncher inter- face or FANUC I/O Link, an overrun, parity or framing error was gen- erated. The number of bits of input data or setting of baud rate or specification No. of I/O unit is incorrect.
086	DR SIGNAL OFF	When entering data in the memory by using Reader / Puncher inter- face or FANUC I/O Link, the ready signal (DR) of reader / puncher was off. Power supply of I/O unit is off or cable is not connected or a P.C.B. is defective.
087	BUFFER OVERFLOW	When entering data in the memory by using Reader / Puncher interface or FANUC I/O Link, though the read terminate command is specified, input is not interrupted after 10 characters read. I/O unit or base P.C.B. is defective.
090	REFERENCE RETURN INCOMPLETE	The reference position return cannot be performed normally because the reference position return start point is too close to the reference position or the speed is too slow. Separate the start point far enough from the reference position, or specify a sufficiently fast speed for reference position return.
091	REFERENCE RETURN INCOM- PLETE	An attempt was made to return to the reference position during feed hold. If it becomes necessary to return to the reference position dur- ing feed hold, reset the system to release the feed hold state before returning to the reference position.
092	AXES NOT ON THE REFERENCE POINT	The commanded axis by G27 (Reference position return check) did not return to the reference position.

Number	Message	Contents
093	EXTERNAL SETTING INCOMPLETE	The reference position external setting cannot be performed because the reference position external setting signal is set to 1 in the follow-
		 When the jog feed mode (JOG) is not selected. When the jog feed mode (JOG) is selected, however the signal ZRN is 0.
		4) When the parameter APC No.1815 bit 5 is 0.
100	PARAMETER WRITE ENABLE	On the PARAMETER(SETTING) screen, PWE(parameter writing enabled) is set to 1. Set it to 0, then reset the system.
101	PLEASE CLEAR MEMORY	The power turned off while rewriting the memory by program edit op- eration. If this alarm has occurred, press <reset> while pressing <prog>, and only the program being edited will be deleted. Register the deleted program.</prog></reset>
110	DATA OVERFLOW	The absolute value of fixed decimal point display data exceeds the allowable range. Modify the program.
111	CALCULATED DATA OVERFLOW	The result of calculation result is out of the allowable range. $(-10^{47} \text{ to } -10^{-29}, 0, \text{ and } 10^{-29} \text{ to } 10^{47})$. Check the calculated data.
112	DIVIDED BY ZERO	Division by zero was specified. (including tan 90°) Check the calculated data.
113	IMPROPER COMMAND	A function which cannot be used in custom macro is commanded. Modify the program.
114	FORMAT ERROR IN MACRO	There is an error in other formats than <formula>. Modify the program.</formula>
115	ILLEGAL VARIABLE NUMBER	A value not defined as a variable number is designated in the custom macro. Modify the program.
116	WRITE PROTECTED VARIABLE	The left side of substitution statement is a variable whose substitution is inhibited. Modify the program.
118	PARENTHESIS NESTING ERROR	The nesting of bracket exceeds the upper limit (quintuple). Modify the program.
119	ILLEGAL ARGUMENT	The SQRT argument is negative, BCD argument is negative, or other values than 0 to 9 are present on each line of BIN argument. Modify the program.
122	DUPLICATE MACRO MODAL-CALL	The macro modal call is specified in double. Modify the program.
124	MISSING END STATEMENT	DO – END does not correspond to 1 : 1. Modify the program.
125	FORMAT ERROR IN MACRO	<formula> format is erroneous. Modify the program.</formula>
126	ILLEGAL LOOP NUMBER	In DOn, $1 \le n \le 3$ is not established. Modify the program.
127	NC, MACRO STATEMENT IN SAME BLOCK	NC and custom macro commands coexist. Modify the program.
128	ILLEGAL MACRO SEQUENCE NUMBER	The sequence number specified in the branch command was not 0 to 9999. Or, it cannot be searched. Modify the program.
129	ILLEGAL ARGUMENT ADDRESS	An address which is not allowed in <argument designation=""> is used. Modify the program.</argument>
130	ILLEGAL AXIS OPERATION	An axis control command was given by PMC to an axis controlled by part program of Power Mate. Or an axis control command was given by part program of Power Mate to an axis controlled by PMC. Modify the program.
131	TOO MANY EXTERNAL ALARM MESSAGES	Five or more alarms have generated in external alarm message. Consult the PMC ladder to find the cause.
132	ALARM NUMBER NOT FOUND	No alarm No. concerned exists in external alarm message clear. Check the PMC ladder.

Number	Message	Contents
133	ILLEGAL DATA IN EXT. ALARM MSG	Small section data is erroneous in external alarm message or exter- nal operator message. Check the PMC ladder.
139	CAN NOT CHANGE PMC CONTROL AXIS	An axis is selected in commanding by PMC axis control. Modify the program.
199	MACRO WORD UNDEFINED	Undefined macro word was used. Modify the custom macro.
224	RETURN TO REFERENCE POINT	Reference position return has not been performed before the automatic operation starts. Perform reference position return only when bit 0 of parameter 1005 ZRN_X is 0.
231	ILLEGAL FORMAT IN G10 OR L50	 Any of the following errors occurred in the specified format at the programmable-parameter input. 1) Address N or R was not entered. 2) A number not specified for a parameter was entered. 3) The axis number was too large. 4) An axis number was not specified in the axis-type parameter. 5) An axis number was specified in the parameter which is not an axis type.
233	DEVICE BUSY	When an attempt was made to use a unit such as that connected via the RS-232-C interface, other users were using it.
239	BP/S ALARM	While punching was being performed with the function for controlling external I/O units ,background editing was performed.
240	BP/S ALARM	Background editing was performed during MDI operation.
5010	END OF RECORD	The end of record (%) was specified.
5011	PARAMETER ZERO (CUT MAX)	The parameter (No. 1422) for the maximum cutting feedrate is set to 0.

2) Background edit alarm

Number	Message	Contents
???	BP/S alarm	BP/S alarm occurs in the same number as the P/S alarm that occurs in ordinary program edit. (070, 071, 072, 073, 074 085,086,087 etc.)
140	BP/S alarm	It was attempted to select or delete in the background a program be- ing selected in the foreground. (Note) Use background editing correctly.

NOTE

Alarm in background edit is displayed in the key input line of the background edit screen instead of the ordinary alarm screen and is resettable by any of the MDI key operation.

3) Absolute pulse coder (APC) alarm

Number	Message	Contents
300	nth-axis origin return	Manual reference position return is required for the nth-axis $(n=1-2)$.
301	APC alarm: nth-axis communication	nth–axis (n=1 – 2) APC communication error. Failure in data trans- mission Possible causes include a faulty APC, cable, or servo module.
302	APC alarm: nth-axis over time	nth–axis (n=1 – 2) APC overtime error. Failure in data transmission. Possible causes include a faulty APC, cable, or servo module.
303	APC alarm: nth-axis framing	nth–axis (n=1 – 2) APC framing error. Failure in data transmission. Possible causes include a faulty APC, cable, or servo module.
304	APC alarm: nth-axis parity	nth–axis (n=1 – 2) APC parity error. Failure in data transmission. Possible causes include a faulty APC, cable, or servo module.
305	APC alarm: nth-axis pulse error	nth–axis (n=1 – 2) APC pulse error alarm. APC alarm.APC or cable may be faulty.
306	APC alarm: nth–axis battery voltage 0	nth–axis (n=1 – 2) APC battery voltage has decreased to a low level so that the data cannot be held. APC alarm. Battery or cable may be faulty.
307	APC alarm: nth-axis battery low 1	nth-axis $(n=1 - 2)$ axis APC battery voltage reaches a level where the battery must be renewed. APC alarm. Replace the battery.
308	APC alarm: nth-axis battery low 2	nth–axis (n=1 – 2) APC battery voltage has reached a level where the battery must be renewed (including when power is OFF). APC alarm .Replace battery.
309	APC alarm: nth-axis Ern impossible	An attempt was made to return to the reference position without rotat- ing the motor. First rotate the motor through at least one turn, then turn the power off, before returning to the reference position.

4) Serial pulse coder (SPC) alarms

When either of the following alarms is issued, a possible cause is a faulty serial pulse coder or cable.

Number	Message	Contents
350	SPC ALARM: n AXIS PULSE COD- ER	The n axis (axis 1–2) pulse coder has a fault. Refer to diagnosis display No. 202 for details.
351	SPC ALARM: n AXIS COMMUNICA- TION	n axis (axis 1–2) serial pulse coder communication error (data trans- mission fault) Refer to diagnosis display No. 203 for details.

• The details of serial pulse coder alarm No.350

The details of serial pulse coder alarm No. 350 (pulse coder alarm) are displayed in the diagnosis display (No. 202 or 204) as shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
202		CSA	BLA	PHA	RCA	BZA	СКА	SPH

- **CSA** : The serial pulse coder is defective. Replace it.
- **BLA** : The battery voltage is low. Replace the batteries. This alarm has nothing to do with alarm 350 (serial pulse coder alarm).
- **SPH** : The serial pulse coder or feedback cable is defective. Replace the serial pulse coder or cable.
- **RCA**: The serial pulse coder is defective. Replace it.

BZA : The pulse coder was supplied with power for the first time. Make sure that the batteries are connected. Turn the power off, then turn it on again and perform a reference

position return. This alarm has nothing to do with alarm 350 (serial pulse coder alarm).

- CKA: The serial pulse coder is defective. Replace it.
- **PHA** : The serial pulse coder or feedback cable is defective. Replace the serial pulse coder or cable.

	#7	#6	#5	#4	#3	#2	#1	#0
204		OFS	MCC	LDA	PMS			

- **OFS** : A current conversion error has occured in the digital servo.
- MCC: A magnetic contactor contact in the servo amplifier has welded.
- LDA : The LED indicates that serial pulse coder C is defective
- **PMS** : A feedback pulse error has occured because the feedback cable is defective.

The details of serial pulse coder alarm No. 351 (communication alarm) are displayed in the diagnosis display (No. 203) as shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
203	DTE	CRC	STB	PRM				

DTE : The serial pulse coder encountered a communication error. The pulse coder, feedbak cable, or feedback receiver circuit is defective. Replace the pulse coder, feedback cable, base PCB, or servo module.

The servo interface type (A or B) is incorrect.

- **CRC**: The serial pulse coder encountered a communication error. The pulse coder, feedback cable, or feedback receiver circuit is defective. Replace the pulse coder, feedback cable, base PCB, or servo module.
- **STB** : The serial pulse coder encountered a communication error. The pulse coder, feedback cable, or feedback receiver circuit is defective.

Replace the pulse coder, feedback cable, base PCB, or servo module.

PRM: An invalid parameter was found. Alarm 417 (invalid servo parameter) is also issued.

• The details of serial pulse coder alarm No.351

5) Servo alarms

Number	Message	Contents
400	SERVO ALARM: n–th AXIS OVERLOAD	The n–th axis (axis 1–2) overload signal is on. Refer to diagnosis display No. 201 for details.
401	SERVO ALARM: n-th AXIS VRDY OFF	 The n-th (axis 1 or 2) servo amplifier ready signal (DRDY) went off. Check the servo amplifier. This alarm may occur if a servo amplifier is shared by several NC units, or if a two-axis servo amplifier is used in a dual Power Mate-D system. Set NOFVY (bit 2 of parameter No. 1803).
404	SERVO ALARM: n-th AXIS VRDY ON	Even though the n-th axis (axis 1-2) READY signal (*MCON) went off, the servo amplifier READY signal (*DRDY) is still on. Or, when the power was turned on, *DRDY went on even though *MCON was off.
405	SERVO ALARM: (ZERO POINT RETURN FAULT)	Position control system fault. Due to an NC or servo system fault in the reference position return, there is the possibility that reference position return could not be executed correctly. Try again from the manual reference position return.
409	SERVO ALARM: n–th AXIS TORQUE ALM	An abnormal servo motor load was detected.
410	SERVO ALARM: n–th AXIS – EXCESS ERROR	The position deviation value when the n–th axis (axis 1–6) stops is larger than the set value. Note) Limit value must be set to parameter No.1829 for each axis.
411	SERVO ALARM: n–th AXIS – EXCESS ERROR	The position deviation value when the n–th axis (axis 1–6) moves is larger than the set value. Note) Limit value must be set to parameter No.1828 for each axis.
413	SERVO ALARM: n–th AXIS – LSI OVERFLOW	The contents of the error register for the n–th axis (axis 1–6) and be- yond the range of -2^{31} to 2^{31} . This error usually occurs as the result of an improperly set parameters.
414	SERVO ALARM: n-th AXIS - DETECTION RELATED ERROR	N–th axis (axis 1–6) digital servo system fault. Refer to diagnosis display No. 200 and No.204 for details.
415	SERVO ALARM: n–th AXIS – EXCESS SHIFT	A speed higher than 511875 units/s was attempted to be set in the n -th axis (axis 1–6). This error occurs as the result of improperly set CMR.
416	SERVO ALARM: n–th AXIS – DISCONNECTION	Position detection system fault in the n–th axis (axis 1–6) pulse coder (disconnection alarm). Refer to diagnosis display No. 201 for details.
417	SERVO ALARM: nth AXIS - PARAMETER INCORRECT	 This alarm occurs when the n-th axis (axis 1-6) is in one of the conditions listed below. (Digital servo system alarm) 1) The value set in Parameter No. 2020 (motor form) is out of the specified limit. 2) A proper value (111 or -111) is not set in parameter No.2022 (motor revolution direction). 3) Illegal data (a value below 0, etc.) was set in parameter No. 2023 (number of speed feedback pulses per motor revolution). 4) Illegal data (a value below 0, etc.) was set in parameter No. 2024 (number of position feedback pulses per motor revolution). 5) Parameters No. 2084 and No. 2085 (flexible field gear rate) have not been set. 6) A value outside the limit of {1 to the number of control axes} or a non-continuous value (Parameter 1023 (servo axis number) contains a value out of the range from 1 to the number of axes, or an isolated value (for example, 3 not prceded by 2).was set in parameter No. 1023 (servo axisnumber).

• Details of servo alarm No.414

The details of servo alarm No. 414 are displayed in the diagnosis display (No. 200) as shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
200	OVL	LV	OVC	HCAL	HVAL	DCAL	FBAL	OFAL

OFAL	:	An overfloy	w alarm	is	being	generated.
	•	1 111 0 / 01110	·· mmini	10	comp	Sonoracoa.

- FBAL : A disconnection alarm is being generated.
 - (No relation to alarm No. 414)
- **DCAL** : A regenerative discharge circuit alarm is being generated.
- **HVA** : A overvoltage alarm is being generated.
- HCAL: An abnormal current alarm is being generated.
- **OVC** : A overcurrent alarm is being generated.
- **LV** : A low voltage alarm is being generated.
- **OVL** : An overload alarm is being generated. (No relation to alram No. 414)

The details of servo alarms No. 400 and No. 416 are displayed in the diagnosis display (No. 201) as shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
201	ALD							

When servo alarm No. 400 is being generated :

- ALD 1 : Motor overheating
 - 0 : Amplifier overheating

When servo alarm No. 416 is being generated :

- **ALD** 1 : Built–in pulse coder disconnection (hardware)
 - 0 : Pulse coder is not connected due to software.

6) Over travel alarms

If this alarm occurs, move the machine manually in the direction opposite to that in which it was moving when the alarm occurred, then reset the alarm.

Number	Message	Contents
500	OVER TRAVEL : +n	Exceeded the n-th axis (axis 1-2) + side stored stroke limit I. (Parameter No.1320)
501	OVER TRAVEL :n	Exceeded the n-th axis (axis 1-2) - side stored stroke limit I. (Parameter No.1321)

7) Overheat alarms

Number	Message	Contents
700	OVERHEAT: CONTROL UNIT	Control unit overheat Check that the fan motor operates normally, and clean the air filter.
701	OVERHEAT: FAN MOTOR	The fan motor at the top of the control unit has malfunctioned. Check the operation of the fan motor. If the fan motor has stopped, replace the fan or power supply PCB.

8) System alarms

(These alarms cannot be reset with reset key.)

Number	Message	Contents
900	ROM PARITY	ROM parity error Replace the ROM.
910	DRAM PARITY: (LOW)	ROM parity error in DRAM on the base PCB Replace the base PCB.
911	DRAM PARITY: (HIGH)	ROM parity error in DRAM on the base PCB Replace the base PCB.

Number	Message	Contents
912	SRAM PARITY: (LOW)	ROM parity error in RAM for which a backup battery is used. Clear the memory or replace the base PCB or memory module. After this operation, reset all data including the parameters.
913	SRAM PARITY: (HIGH)	ROM parity error in RAM for which a backup battery is used. Clear the memory or replace the base PCB or memory module. After this operation, reset all data including the parameters.
920	SERVO ALARM (1/2 AXIS)	Servo alarm (1st or 2nd axis). A watchdog alarm or a local RAM par- ity error of the servo occured. Replace the servo control module on the main CPU board.
921	SERVO ALARM (3/4 AXIS)	Servo alarm (3rd or 4th axis). A watchdog alarm or a RAM parity error in the servo module occurred. Replace the servo control module on the main CPU board.
922	SERVO ALARM (5/6 AXIS)	Servo alarm (5th or 6th axis). A watchdog alarm or a RAM parity error in the servo module occurred. Replace the servo control module on the main CPU board.
924	SERVO MODULE SETTING ERROR	The servo module is not installed. Check that the servo module or servo interface module on the base PCB is mounted securely.
930	CPU INTERRUPUT	CPU error The base PCB, memory module, or CPU module is faulty.
950	PMC SYSTEM ALARM	Fault occurred in the PMC. The base PCB or PMC module may be faulty.
951	PMC–PA WATCH DOG ALARM	Fault occurred in the PMC–PA3 module (watchdog alarm). Defective base printed–circuit board or PMC control module
970	NMI OCCURRED IN BOC	A RAM parity error or NMI occurred in the PMC–PA3 module. It is likely that the base printed–circuit board or PMC module is defective.
971	NMI OCCURRED IN SLC	An alarm occurred in the FANUC I/O link master function. Check the connection between the controller and the I/O unit or I/O card. Also check whether the I/O unit and I/O card are supplied with power and whether the interface module or the I/O card is faulty. Or, check the PMC module. This alarm is issued when the power to another Power Mate connected to the FANUC I/O link is turned off, or when a system alarm is issued on another Power Mate. In this case, the unit does not indicate a failure.
973	NON MASK INTERRUPT	NMI occurred for an unknown reason. Or, a communication error oc- curred in the FANUC I/O link slave function. This alarm is issued when the power to another Power Mate con- nected to the FANUC I/O link is turned off, or when a system alarm is issued on another Power Mate. In this case, the unit does not indi- cate a failure.
980	SYNC ERROR	The ITP period of the master became asynchronous with that of the slave. Replace the base printed–circuit board.

9) ALARM OF M-NET

Number	Message	Contents
5051	M–NET CODE ERROR	Abnormal character received (other than code used for transmission).
5052	M–NET ETX ERROR	Abnormal ETX code.
5053	M-NET CONNECT TIMEOUT	Connection time monitoring error (parameter No. 175).
5054	M-NET RECEIVE TIMEOUT	Polling time monitoring error (parameter No. 176).
5055	M-NET PRT/FRM ERROR	Vertical parity or framing error.
5056	M-NET OVERRUN ERROR	Overrun error is detected.
5057	M-NET TRANSFER TIMEOUT	Transmission timeout error (parameter No. 178).
5058	M-NET ROM PARITY ERROR	ROM parity error is detected.
5059	M-NET BOARD SYSTEM ERROR	Unjust interruption is occured.

10) MEMORY CARD ALARM

Number	Message	Contents and solution
5101	MEMORY CARD NOT CONNECTED	No memory card is inserted. Insert a memory card before attempting input/output.
5102	MEMORY CARD WRITE PROTECTED	The memory card is write–protected. Write–enable the memory card before attempting to write data to it.
5103	MEMORY CARD DATA ERROR	(During restoration) The memory card contains invalid data. (During saving) Data cannot be written to the memory card. The memory card may be defective. Use another memory card.
5104	EMERGENCY STOP RELEASE	The emergency stop state was released during input/output to or from the memory card. Place the system in emergency stop state, then retry input/output.
5106	MEMORY CARD SIZE ERROR	The capacity of the memory card is less than the size of the data to be saved. Use a memory card having a capacity greater than the size of the data to be saved.
5107	MEMORY CARD DATA TYPE ILLEGAL	The data stored on the memory card is not supported by the system. Retry using a memory card containing data that is compatible with the system.
5109	MEMORY CARD BATTERY ALARM	A PMC communication error occurred during input/output to or from the memory card. Retry input/output.

11) MULTI-PATH ALARM

Number	Message	Contents and solution
5160	ILLEGAL COMMAND IN THE MULTI PATH	The multi-path command format is invalid. Correct the program.
5161	ILLEGAL AXIS SELECT	1 An axis is duplicated in paths.
		2 The setting of parameter 8010 is invalid.
5162	FEEDRATE IS ZERO IN THE MULTI PATH	For setting cutting feed in multi-path mode, use the F command.
5163	ILLEGAL WAIT M CODE COMMAND	The wait M code command format is invalid. Correct the program.

12) ALARM

Number	Message	Contents	Counter plan	Reference
1000 to 1999	A message created by the user or machine tool builder, using the PMC alarm message function, is dis- played. NOTE) On the DPL/MDI, only the number is displayed.	Alarm generated by the user or machine tool builder using the PMC	Apply appropriate countermeasures as explained in the manual provided by the machine tool builder.	Manual provided by machine tool builder
3000 to 3200	A message created by the user or machine tool builder, using a custom macro, is displayed. NOTE) On the DPL/MDI, only the number is displayed.	Alarm generated by the user or machine tool builder, using a custom macro	Apply appropriate countermeasures as explained in the manual provided by the machine tool builder.	Manual provided by machine tool builder
3000 to 3099	P/S ALARM	Alarm generated by the user or machine tool builder, using the PMC alarm display function	Manual provided by machine tool builder	Manual provided by machine tool builder
5010	END OF RECORD	EOR was read with- out specifying a pro- gram end command.		
5150	PARAM. (NO. 1011) SETTING ERROR	The number of con- trolled axes set in parameter 1011 is invalid. Change the parameter setting.		

13) Alarm messages (PMC)

This list contains alarms which do not occur in the Power Mate-H.

Message	Contents and solution
ALARM NOTHING	Normal status
ER00 PROGRAM DATA ERROR(ROM)	The ladder program is not written correctly. (solution) Write the ladder program again.
ER03 PROGRAM SIZE ERROR(OPTION)	The size of ladder program exceeds the option specification size.(solution)Please increase the option specification size.Or, reduce the size of ladder program.
ER04 PMC TYPE UNMATCH	The PMC model setting of the ladder program is not corresponding to an actual model. (solution) Please change the PMC model setting by the offline programmer.
ER05 PMC MODULE TYPE	The module type of the PMC engine is not correct.
ERROR	(solution) Please exchange the module of PMC engine for a correct one.
ER07 NO OPTION (LADDER STEP)	There is no step number option of LADDER.
ER17 PROGRAM PARITY	A parity error occurred in RAM containing a ladder program. (solution) Please edit the sequence program once on PMC. Check the operation. Still the error occurs, exchange the RAM.
ER18 PROGRAM DATA ERROR BY I/O	Transferring the ladder program from offline programmer was interrupted by the power off etc. (solution) Please clear the ladder program and transfer the ladder program again.
ER19 LADDER DATA ERROR	Editing the LADDER was interrupted by the power off or by the switch to the CNC screen by the function key etc. (solution) Please edit LADDER once on PMC. Or, please input LADDER again.
ER20 SYMBOL/COMMENT DATA ERROR	Editing the symbol and comment was interrupted by the power off or by the switch to the CNC screen by the function key etc. (solution) Please edit symbol and comment once on PMC. Or, please input symbol and comment again.

Message	Contents and solution			
ER21 MESSAGE DATA ERROR	Editing the message data was interrupted by the power off or the switch to the CNC screen by the function key etc. (solution) Please edit message data once on PMC. Or, please input message data again.			
ER22 PROGRAM NOTHING	There is no sequence program			
ER23 PLEASE TURN OFF POW- ER	There is a change in setting LADDER MAX AREA SIZE etc.(solution)Please restart the system to make the change effective.			
ER32 NO I/O DEVICE	Any DI/DO unit of I/O Unit or the connection unit etc. is not connected. (solution) When I/O Link is used: Please confirm whether the DI/DO units turning on. Or please confirm the connection of the cable.			
ER33 SLC ERROR	The LSI for I/O Link is defective.(solution)Please exchange the module of PMC engine.			
ER34 SLC ERROR(xx)	The communication with the DI/DO units of the xx group failed.(solution)Please confirm the connection of the cable connected to the DI/DO units of the xx group.Please confirm whether the DI/DO units turned on earlier than Power Mate. Or, please exchange the module of PMC engine on the DI/DO units of the xx group			
ER35 TOO MUCH OUTPUT DATA IN GROUP(xx)	The number of the output data in the xx group exceeded the max. The data, which ex- ceed 32 bytes, become ineffective. (solution) Please refer to the following for the number of the data for each group. "FANUC I/O Unit–MODEL A connecting and maintenance manual" (B–61813E) "FANUC I/O Unit–MODEL B connecting manual"(B–62163E)			
ER36 TOO MUCH INPUT DATA IN GROUP(xx)	The number of the input data in the xx group exceeded the max. The data, which exceed32 bytes, become ineffective.(solution)Please refer to the following for the number of the data for each group."FANUC I/O Unit-MODEL A connecting and maintenance manual"(B-61813E)"FANUC I/O Unit-MODEL B connecting manual"(B-62163E)			
ER38 MAX SETTING OUTPUT DATA OVER(xx)	The assignment data for a group exceeds 128 bytes.(The assignment data of output side of xx group or later become ineffective.)(solution)Please reduce the assignment data to 128 bytes or less for the number of the output data of each group.			
ER39 MAX SETTING INPUT DATA OVER(xx)	 The assignment data for a group exceeds 128 bytes. (The assignment data of input side of xx group or later become infective.) (Solution) Please reduce the assignment data to 128 bytes or less for the number of the input data of each goup. 			
WN01 LADDER MAX SIZE ERROR	The MAX LADDER AREA SIZE in the system parameter is illegal. (solution) Set the correct value to MAX LADDER AREA SIZE and restart the system.			
WN03 ABORT NC-WINDOW/ EXIN	 LADDER was stopped while CNC and PMC were communicating. The functional instruction WINDR, WINDW, EXIN, DISPB, and etc. may not work normally. (solution) When restarting the system, this alarm will be released. Execute the sequence program(Press RUN key) after confirming whether there is a problem in LADDER or not. 			
WN07 LADDER SP ERROR (STACK)	When functional instruction CALL(SUB65) or CALLU(SUB66) was executed, the stack of the LADDER overflowed. (solution) Please reduce the nesting of the subprogram to 8 or less.			

*When ER00 to ER23 occur, sequence program is not available.

Alarm messages (For EDIT)

Message	Contents and solution
ADDRESS BIT NOTHING	The address of the relay/coil is not set.
FUNCTION NOT FOUND	There is no functional instruction of the input number.
COM FUNCTION MISSING	The funcitonal instruction COM (SUB9) is not correctly dealt with. Correspondence of COM and COME (SUB29) is incorrect. Or, the number of coil controlled by COM is specified by the model which the number cannot be specified.
EDIT BUFFER OVER	There in no empty area of the buffer for the editing. (solution) Please reduce NET under editing.
END FUNCTION MISSING	Functional instruction END1,END2,END3 and END do not exist. Or, there are error net in END1,END2,END3,END. Or, order of END1,END2,END3, and END is not correct.
ERROR NET FOUND	There is an error net.
ILLEGAL FUNCTION NO.	The wrong number of the functional instruction is searched.
FUNCTION LINE ILLEGAL	The functional instruction is not correctly connected.
HORIZONTAL LINE ILLEGAL	The horizontal line of the net is not connected.
ILLEGAL NET CLEARED	Because the power had been turn off while editing LADDER, some net under editing was cleared.
ILLEGAL OPERATION	Operation is not correct. The value is not specified and only INPUT key was pushed. The address data is not correctly inputted. Because the space to display the instruction on screen is not enough, the functional instruction cannot be made.
SYMBOL UNDEFINED	The symbol which was inputted is not defined.
INPUT INVALID	There is an incorrect input data. Non–numerical value was inputted with COPY, INSLIN,C–UP,C–DOWN etc. The input address was specified for write coil. An illegal character was specified for the data table.
NET TOO LARGE	The input net is larger than the editing buffer. (solution) Please reduce the net under editing.
JUMP FUNCTION MISSING	The functional instruction JMP(SUB10) is not correctly dealt with. Correspondence of JMP and JMPE(SUB30) is incorrect. The number of coil to jump is specified by the model which the number of coil cannot specified. (It is possible to specify the coil number only on PMC–RB/RC.)
LADDER BROKEN	LADDER is broken.
LADDER ILLEGAL	There is an incorrect LADDER.
OBJECT BUFFER OVER	The sequence program area was filled. (solution) Please reduce the LADDER.
PARAMETER NOTHING	There is no parameter of the functional instruction.
PLEASE COMPLETE NET	The error net was found in LADDER. (solution) After correcting the error net, please continue operating.
PLEASE KEY IN SUB NO.	Please input the number of the functional instruction. (solution) If you do not input the functional instruction, please push soft key "FUNC" again.
RELAY COIL FORBIT	There is an unnecessary relay or coil.
RELAY OR COIL NOTHING	The relay or the coil does not suffice.
PLEASE CLEAR ALL	It is impossible to recover the sequence program. (solution) Please clear the all data.
SYMBOL DATA DUPLICATE	The same symbol name is defined in other place.
COMMENT DATA OVERFLOW	The comment data area was filled. (solution) Please reduce the number of the commnet.

Message	Contents and solution		
SYMBOL DATA OVERFLOW	The symbol data area was filled. (solution) Please reduce the number of the symbol.		
VERTICAL LINE ILLEGAL	There is an incorrect vertical line of the net.		
MESSAGE DATA OVERFLOW	The message data area was filled. (solution) Please reduce the number of the message.		
1ST LEVEL EXECUTE TIME OVER	The 1st level of LADDER is too large to complete execution in time. (solution) Please reduce the 1st level of LADDER.		

C LIST OF MAINTENANCE PARTS

C.1 MAINTENANCE PARTS

C.1 MAINTENANCE PARTS

Maintenance Parts (Consumable)

Consumables here refer to the parts which are not reused after replacement. Rank : A > B > C

Name	Drawing number	Vender	Remarks	Rank
Fan motor	A90L-0001-0385	SANYO		А
Battery	A98L-0031-0006	SANYO		А
Fuse	A60L-0001-0046#5.0R	DAITO	5. 0A Contorol unit	В
	A60L-0001-0175#3.2R	DAITO	3. 2A CRT/ MDI, I/O card	В
	A60L-0001-0290#LM50	DAITO	5.0A I/O card	В
	A60L-0001-0290#LM10	DAITO	1. 0A LCD	В
key board	A86L-0001-0171#SM2	FUJITSU	A02B-0166-C001	В
	A86L-0001-0171#SM2R	FUJITSU	A02B-0166-C201#R	В
	A86L-0001-0171#SM2S	FUJITSU	A02B-0120-C201#S	В
	A20B-1003-0170	FANUC	A02B-0168-C010 to C013 A02B-0118-C030 to C033 A02B-0118-C130#R to C133#R A02B-0118-C130#S to C133#S	В
	A16B-2600-0070	FANUC	A02B-0211-C020#R, #S	В
Key sheet	A98L-0001-0741		A02B-0168-C010 to C013 A02B-0118-C030 to C033	В
	A98L-0001-0741#R		A02B-0118-C130#R to C133#R	В
	A98L-0005-0022	FUJI POLY-	A02B-0118-C130#S to C133#S	В
	A98L-0005-0035#PMGE1	MERTECH	A02B-0211-C020#R	В
	A98L-0005-0035#PMGS1]	A02B-0211-C020#S	В
	A98L-0005-0036#PMGE1]	A02B-0211-C020#R LED	В
	A98L-0005-0036#PMGS1	1	A02B-0211-C020#S LED	В
Plastic case	A230-0476-T004	FANUC		С

Name	Drawing number	Vender	Remarks	Rank
Power supply P.C.B	A20B-1004-0960	FANUC		В
Base P.C.B	A20B-2100-0020	FANUC	Max.4axes	В
	A20B-2100-0021	FANUC	Max.6axes macro executer, C language executer	В
Built-in I/O card	A20B-2001-0902	FANUC	DI:32 DO:24 (Source type)	В
I/O Link– II card	A20B-2100-0040	FANUC	Drawing 0041 is compatible with	В
	A20B-2100-0041	FANUC	drawing 0040.	В
Genius card	A20B-8100-0060	FANUC		В
Profibus card1	A20B-2100-0120	FANUC		В
Profibus card2	A20B-8001-0500	FANUC		В

Name		Drawing number	Vender	Remarks	Rank
Memory module	With POS,HDI	A20B-2902-0300	FANUC	External pulse input, with following control	В
	Without POS,HDI	A20B-2902-0301	FANUC		В
	With POS	A20B-2902-0302	FANUC	External pulse input	
	For C language macro	A20B-2902-0450	FANUC	Memory increase, external pulse input	В
CRT control n	nodule	A20B-2901-0480	FANUC		В
Touch panel o	control module	A20B-2902-0470	FANUC		В
HSSB module	Э	A20B-2902-0540	FANUC		В
Servo module)	A20B-2902-0290	FANUC		В
Analog servo	module	A20B-2902-0510	FANUC		В
PMC control r	module	A20B-2901-0660	FANUC		В
CRT control F	P.C.B.	A20B-2000-0840	FANUC		В
		A20B-2100-0061	FANUC	Simple graphic 32 screen	В
		A16B-2100-0060	FANUC	Simple graphic 64 screen	В
I/O card D		A16B-2202-0733	FANUC	DI:48DO:32 (Source type)	В
I/O card E		A16B-2202-0732	FANUC	DI:96DO:64 (Source type)	В
DPL/MDI P.C.B.		A20B-8000-0141	FANUC		В
DPL/MDI P.C.B.		A20B-8000-0490	FANUC	Long direction type	В
DPL/MDI P.C.B.		A20B-8001-0310	FANUC	Dust protected type	В
DPL/MDI Switch circuit		A16B-2600-0080	FANUC		В
Handy operator's panel control P.C.B.		A20B-2002-0200	FANUC		В
HSSB adapte	er P.C.B.	A20B-8001-0510	FANUC		В
Touch panel a	adapter P.C.B.	A20B-8001-0680	FANUC		В
CRT/MDI Uni	t	A02B-0166-C001	FANUC		В
		A02B-0166-C201#R	FANUC	For CE marking	В
		A02B-0166-C201#S	FANUC	For CE marking	В
CRT/MDI Uni	t	A02B-0166-C221#R	FANUC	Graphic 32 screen	В
(Picture displa	ay)	A02B-0166-C221#S	FANUC	Graphic 32 screen	В
		A02B-0166-C222#R	FANUC	Graphic 64 screen	В
		A02B-0166-C222#S	FANUC	Graphic 64 screen	В
LCD/MDI unit		A02B-0166-C261#R	FANUC		В
		A02B-0166-C261#S	FANUC		В
Separate type CRT		A02B-0120-C111	FANUC		В
Separata type PDP		A02B-0120-C113	FANUC	200VAC input	В
		A02B-0200-C100	200-C100 FANUC 24VDC input For CE marking		В
Separate type	e MDI unit	A02B-0166-C010	FANUC		В
		A02B-0166-C210#R	66-C210#R FANUC For CE marking		В
		A02B-0166-C210#S	FANUC	For CE marking	В

Maintenance Parts (Parts to be repaired by us)

N	ame	Drawing number	Vender	Remarks	Rank
Separate type	MDI unit	A02B-0166-C231#R	FANUC	Graphic 32 screen	В
(Picture display)		A02B-0166-C231#S	FANUC	Graphic 32 screen	В
		A02B-0166-C232#R	FANUC	Graphic 64 screen	В
		A02B-0166-C232#S	FANUC	Graphic 64 screen	В
Separate type	LCD unit	A02B-0166-C251	FANUC		В
CRT display device		A61L-0001-0093	MATSUSHITA	Usable unit A02B-0166-C001 A02B-0166-C201#R A02B-0166-C201#S A02B-0120-C111	В
Plasma displa	y device	A61L-0001-0116	FUJITSU	Usable unit A02B-0120-C113	В
		A61L-0001-0116#S	FUJITSU	Usable unit A02B-0200-C100	В
LCD disply device		A61L-0001-0142	HITACHI	Usable unit A02B-0166-C251	В
Handy operator's panel		A02B-0211-020#R	FANUC		В
		A02B-0211-020#S	FANUC		В
LCD		A61L-0001-0119	EPSON	Usable unit A02B-0211-C020#R, #S	В
HSSB adapte	r	A02B-0211-C220	FANUC		В
Touch panel a	dapter	A02B-0166-C0240	FANUC		В
DPL/MDI	FANUC,Table mount	A02B-0168-C010	FANUC		В
	FANUC,Wall mount	A02B-0168-C011	FANUC		В
	GEFanuc,Table mount	A02B-0168-C012	FANUC		В
	GEFanuc,Wall mount	A02B-0168-C013	FANUC		В

Name		Drawing number	Vender	Remarks	Compatibility	Rank
	FANUC, Table mount	A02B-0118-C030	FANUC		A02B-0118-C131, C132, C133	В
Long direction	FANUC, Wall mount	A02B-0118-C031	FANUC		A02B-0118-C130, C132, C133	В
type DPL/MDI	GEFANUC, Table mount	A02B-0118-C032	FANUC		A02B-0118-C130, C131, C133	В
	GEFANUC, Wall mount	A02B-0118-C033	FANUC		A02B-0118-C130, C131, C132	В

N	ame	Drawing number	Vender	Remarks	Compatibility	Rank
	FANUC, Table mount	A02B-0118-C130#R	FANUC	For CE marking	A02B-0118-C131#R, C132#R, C133#R	В
		A02B-0118-C130#S	FANUC	For CE marking	A02B-0118-C131#S, C132#S, C133#S	В
	FANUC, Wall mount	A02B-0118-C131#R	FANUC	For CE marking	A02B-0118-C130#R, C132#R, C133#R	В
Dust protected		A02B-0118-C131#S	FANUC	For CE marking	A02B-0118-C130#S, C132#S, C133#S	В
type DPL/MDI	GEFANUC, Table mount	A02B-0118-C132#R	FANUC	For CE marking	A02B-0118-C130#R, C131#R, C133#R	В
		A02B-0118-C132#S	FANUC	For CE marking	A02B-0118-C130#S, C131#S, C133#S	В
	GEFANUC, Wall mount	A02B-0118-C133#R	FANUC	For CE marking	A02B-0118-C130#R, C131#R, C132#R	В
		A02B-0118-C133#S	FANUC	For CE marking	A02B-0118-C130#S, C131#S, C132#S	В
LCD		A61L-0001-0110#A	HITACHI	Usable uint A02B-0168-C010 to C A02B-0118-C030 to C A02B-0118-C130#R t A02B-0118-C130#S t	C013 C033 o C133#R o C133#S	В

MAINTENANCE AND INPUT/OUTPUT OF MEMORY CARD IN BOOT SYSTEM

- D.1 OVERVIEW
- D.2 SCREEN CONFIGURATION AND OPERATING PROCEDURE
- D.3 ERROR MESSAGES AND REQUIRED ACTIONS

D.1 OVERVIEW

The boot system load the system software (flash memory \rightarrow DRAM), then starts it so that software can be executed.

The boot system provides the following maintenance functions for the Power Mate:

(1) Registering a file in flash memory

- Reads a file from a memory card, in MS–DOS format conforming to JEIDA V4.1, into flash memory.
- (2) Checking a file (series and edition) in flash memory
- (3) Deleting a file from flash memory
- (4) Batch saving and restoration of files of parameters and programs backed up by battery (SRAM area), to and from a memory card
- (5) Saving a file in flash memory to a memory card
- (6) Formatting of a memory card
- (7) Deleting a file from a memory card

This manual describes the activation of the boot system, as well as the screen displays and operation for the functions listed above.

CAUTION

Memory cards can be used as an input/output device for the Power Mate. Before attempting to insert or remove a memory card, however, ensure that the power is turned off.

For the boot system, SRAM memory cards (only those specified by FANUC) and flash memory cards can be used. To store data for an extended period, use a flash memory card.

NOTE

Use an Intel Series 2 flash memory card. (Recommended: 4MB)

D.1.1 Starting The Boot System

In ordinary system activation, the boot system automatically transfers files from flash memory to DRAM in the background.

The user is not aware of this operation. However, the boot system must be operated manually, from menu screen, when maintenance is to be carried out or when the flash memory does not contain a required file.

1 In system maintenance, for example, to replace a file in memory Operation : Turn the power on by simultaneously pressing the two CRT/MDI soft keys at the right end.



Operation : Turn the power on by simultaneously pressing the o and

• DPL keys.

Hold down the two keys until the boot system screen appears.

2 When the flash memory does not contain a file required to start the Power Mate

Immediately after the Power Mate is turned on, the boot system starts transferring files from flash memory to DRAM. If, for some reason, a file required to start the CNC (NC basic) is not in flash memory or has been destroyed, the boot system is automatically started.

D.1.2 System Files and User Files	The boot system organizes files in flash memory into two main groups : system files and user files. These two file types have the following characteristics :
System files	CNC and servo control software provided by FANUC
• User files	PMC sequence program (ladder), P–CODE macro program, and other user–created files

D.2 SCREEN CONFIGURATION AND OPERATING PROCEDURE

• MAIN MENU screen (CRT/MDI)

When the boot system is first started, the MAIN MENU screen is displayed. This screen is described below :

- (1)SYSTEM MONITOR MAIN MENU 881A-01 (2)1. SYSTEM DATA LOADING 2. SYSTEM DATA CHECK (3) SYSTEM DATA DELETE (4)3. (5) 4. SYSTEM DATA SAVE 5. SRAM DATA BACKUP (6) 6. MEMORY CARD FILE DELETE (7)(8)7. MEMORY CARD FORMAT 9. END (9) *** MESSAGE *** SELECT MENU AND HIT SELECT KEY. (10)[SELECT][YES][NO][UP][DOWN]
- 1 : Screen title. The series and edition of the boot system appear at the right end.
- 2 : Function for writing data to flash memory.
- 3 : Function for checking the edition of a file in ROM.
- 4 : Function for deleting a file from flash memory.
- 5 : Function for making a backup copy of the data stored on the memory card.
- 6 : Function for making a backup copy of the data in SRAM.
- 7 : Function for deleting a file from a memory card.
- 8 : Function for formatting a memory card.
- 9 : Function for terminating the boot system and starting the Power Mate.
- 10 : Condensed guidance or error message

Press the **[UP]** or **[DOWN]** soft key to select the desired function. After positioning the cursor to the desired function, press the **[SELECT]** soft key. Before executing a function, the system my request confirmation from the operator by having him/her press the **[YES]** or **[NO]** soft key.



Operating procedure (CRT/MDI)

Basic operation (CRT/MDI)

D. MAINTENANCE AND INPUT/OUTPUT OF MEMORY CARD IN BOOT SYSTEM APP

MAIN MENU screen
 (DPL/MDI)

SYSTEM MONITOR 881A-01

When the above BOOT SYSTEM screen is displayed, pressing the key on the DPL displays the following screens, in the order shown.



Operation (DPL/MDI)

When the screen for the function to be selected is displayed, press the *INPUT* key on the DPL.

D.2.1 System Data Loading Screen

- Description
- Screen configuration (CRT/MDI)

This screen is used to read a system or user file from a memory card into flash memory.

(1)	SYSTEM DATA LOADING	1/1
(2)	FILE DIRECTORY 8880E10. ROM 8880E11. ROM	
(3)	END	
(4)	*** MESSAGE *** SELECT FILE AND HIT SELECT KEY.	
. /	[SELECT][YES][NO][UP][DOWN]
)

- (1): Screen title. The page number (n) and total number of pages (m) are displayed, in n/m format, at the right end.
- (2): Files on the memory card
- (3): Option for returning to previous menu Message
- (4): Message
- 1 Position the cursor to the file to be read from the memory card and written to flash memory. Then, press the **[SELECT]** soft key.

A single page can list up to eight file names. If the memory card contains nine or more files, the remaining files are displayed on another page.

To display the next page, press the \triangleright soft key.

To display the previous page, press the \bigcirc soft key. The END option is displayed on the last page.

The END option is displayed on the last page.

2 After a file has been selected, the system asks whether that file is to be loaded.

```
*** MESSAGE ***
LOADING OK ? HIT YES OR NO.
```

• Operating procedure (CRT/MDI)

3 To start loading, press the [YES] soft key. To cancel, press the [NO] key.

```
*** MESSAGE ***
LOADING FROM MEMORY CARD.
```

4 When loading terminates normally, the system displays the following message. Press the **[SELECT]** soft key. If an error occurs, see D.3



Selecting SYSTEM DATA LOADING displays the file selection screen, shown below. Pressing the \checkmark or \uparrow key on the DPL displays the names of the files in the memory card. Once the name of the file to be loaded appears, pressing the $\square PUT$ key starts loading of that file.



: File selection screen

During loading, the following screen is displayed:

: The name of the file being loaded is displayed and LOADING blinks.

Once loading has been completed, the file selection screen is displayed again. To end the operation, press the \boxed{INPUT} key once *END appears on the screen. The initial screen is displayed. Pressing the \boxed{CAN} key also causes the initial screen to be displayed.

Others

Operation (DPL/MDI)

1 Counter display while a file is being loaded (CRT/MDI only)

While a file is being loaded, the address of the data currently being accessed is displayed.



- (1): Number of 128-KB management unit in flash memory
- (2): Relative address within the management unit
- 2 File name in flash memory

The boot systme identifies a file in flash memory by the first four characters of the file name. If the name of the file to be read from the memory card and the name of a file already present in flash memory begin with the same four characters, delete the latter from flash memory. Then, load the desired file. The following table lists the names and contents of files.

Note that these file names may be changed without notice.

— 278 —

File name	Contents	File type
NC BASIC	Basic	System file
DG SERVO	Servo	System file
PCD****	P–CODE macro file/ OMM	User file
CEX ****	C–language executor	User file
PMC - PA	Ladder software	User file

 \Box : A numeric character, *: An alphabetic character

- 3 During SYSTEM DATA LOADING, if a file having the specified file name already exists in flash memory, that file is overwritten by the file existing in the memory card. Note that system files cannot be deleted, but that they can be overwritten.
- 4 During SYSTEM DATA LOADING operation, the 128K and 256K macro executors have different file names (PCD 128K, PCD56K) and thus can be loaded into flash memory at the same time. If they are loaded at the same time, however, the operation may be erroneous. Before attempting to load a file, delete any unnecessary files using SYSTEM DATA DELETE.

D.2.2 System Data Check Screen

- Description
- Screen configuration (CRT/MDI)

This screen is used to list files in flash memory, together with the corresponding numbers of 128–KB management units in each file and the series and edition of the software.

```
(1)
     SYSTEM DATA CHECK
                                              1/1
     FILE DIRECTORY
       1 NC BASIC
(2)
                    (10)
       2 DG SERVO
                    (1)
      3 PMC PA
                    (1)
       4 PCD 128K
                    (1)
      END
(3)
     *** MESSAGE ***
     SELECT FILE AND HIT SELECT KEY.
(4)
     [ SELECT ][ YES ][ NO ][ UP
                                       ][
                                            DOWN
                                                  ]
```

- (1): Screen title
- (2): Names of files in flash memory The number of management units constituting each file appears in parentheses to the right of the file name. For file name See D.2.1 others (2).
- (3): Returning to the previous menu
- (4): Message

- Operating procedure (CRT/MDI)
- 1 Select the file whose details are required. For example, select "1 NC BASIC (8)."
- 2 The numbers of management units in the selected file are listed, together with the series and edition of the software in each management unit. After checking the listed data, select the **[SELECT]** soft key to return to the file selection screen.



Operation (DPL/MDI)
 Selecting SYSTEM DATA CHECK displays the file information screen, shown below. Pressing the I or I key on the DPL displays other file information.



: File information screen The number of control units used by the file (1 unit = 128 KB) is indicated in parentheses.

When a file name is displayed, pressing the I^{INPUT} key displays detailed information for that file, including the series, ROM number, edition, and internal control number (up to 16).



To end the operation, press the $x \to x$ key once *END appears on the screen.

The file information screen is displayed. Pressing the CAN key also displays the file information screen.

To return from the file information screen to the initial screen, press the key once *END appears on the screen. The initial screen is

displayed. Pressing the $\|CAN\|$ key also displays the initial screen.
Others

APPENDIX D. MAINTENANCE AND INPUT/OUTPUT OF MEMORY CARD IN BOOT SYSTEM

Parity information for the system file and user file

The NC BASIC, DG SERVO, and other system files in flash memory contain parity information in each management unit. If the file name field or parity field on the check screen contains a non–ASC II character or an "@", the flash ROM may have been destroyed or a damaged file may have been read. Re–read the data from the memory card. The PMC–PA, PCD 128K, and other user files do not contain parity

information in each management unit. A non–ASCII character or an "@" may appear in the series/edition information. In this case, it does not indicate that the file has been damaged.

D.2.3 System Data Delete Screen

- Description
- Screen configuration (CRT/MDI)

This screen is used to delete a user file from flash memory.

	CUCTEM DATA DELETE	1 / 1	
(1)	SISTEM DATA DELETE	1/1	
	FILE DIRECTORY		
(2)	1 NC BASIC (10)		
(-)	2 DG SERVO (1)		
	3 PMC PA (1)		
	4 PCD 128K (1)		
(3)	END		
(0)			
	*** MESSAGE ***		
(4)	SELECT FILE AND HIT SELECT KEY.		
(.,	[SELECT][YES][NO][UP][DOWN]	
'			

- (1): Screen title
- (2): Names of files in flash memory The number of management units constituting each file appears in parentheses to the right of the file name.
- (3): Returning to the previous menu
- (4): Message

- Operating procedure (CRT/MDI)
- 1 Position the cursor to the name of the file to be deleted. Press the **[SELECT]** soft key.
- 2 The system displays the following confirmation message :

```
*** MESSAGE ***
DELETE OK ? HIT YES OR NO.
```

3 To start the deletion, press the [YES] key. To cancel, press [NO].

```
*** MESSAGE ***
DELETING ROM FILE IN FLASH MEMORY.
```

4 When deletion terminates normally, the system displays the following message. Press the **[SELECT]** key.

```
*** MESSAGE ***
DELETING COMPLETE. HIT SELECT KEY.
```

Operation (DPL/MDI)
 Selecting SYSTEM DATA DELETE displays the file selection screen, shown below. Pressing the I or I key on the DPL displays the names of the files in flash memory. Once the name of the file to be deleted appears, pressing the INPUT key deletes that file.



: File selection screen The number of control units used by the file (1 unit = 128 KB) is indicated

During deletion, the following screen is displayed:

: The name of the file being deleted is displayed and DELETE blinks.

Once deletion has been completed, the file selection screen is displayed again. To end the operation, press the \boxed{INPUT} key once *END appears on the screen. The initial screen is displayed. Pressing the \boxed{CAN} key also displays the initial screen.

1 System files and user files on SYSTEM DATA DELETE screen The SYSTEM DATA DELETE screen guards against system files being accidentally deleted by the operator. User files, however, are not protected. Protected system files can be overwritten from the SYSTEM DATA LOADING screen.

• Others

D.2.4 System Data Save Screen

- Description
- Screen configuration (CRT/MDI)

This screen is used to write a user file in flash memory to a memory card. Only user files can be saved from flash memory to a memory card. System files cannot be saved.



- (1): Screen title
- (2): Names of files in flash memory The number of management units constituting each file appears in parentheses to the right of the file name.
- (3): Returning to the previous menu
- (4): Message

- Operating procedure (CRT/MDI)
- 1 Position the cursor to the name of the file to be deleted. Press the [SELECT] soft key.
- 2 The system displays the following confirmation message :

*** MESSAGE *** SAVE OK ? HIT YES OR NO.

3 To start saving, press the **[YES]** key. To cancel, press **[NO]**.

```
*** MESSAGE ***
WRITING FLASH ROM FILE TO MEMORY CARD.
SAVE FILE NAME : PMC_PA.000
```

4 When saving terminates normally, the system displays the following message. Press the **[SELECT]** key. The names of files written to the memory card are listed. Check the file names by, for example, making a note of the list.

```
*** MESSAGE ***
FILE SAVE COMPELETE. HIT SELECT KEY.
SAVE FILE NAME : PMC_PA.000
```

Operation (DPL/MDI)
 Selecting SYSTEM DATA SAVE displays the file selection screen, shown below. Pressing the I or I key on the DPL displays the names of the files in flash memory. Once the name of the file to be saved appears, pressing the INPUT key saves that file.

: File selection screen The number of control units used by the file (1 unit = 128 KB) is indicated in parentheses.

During saving, the following screen is displayed:



: The name of the file being saved is displayed and SAVE blinks.

Once saving has been completed, the file selection screen is displayed again. To end the operation, press the $x \in x$ key once *END appears on

the screen. The initial screen is displayed. Pressing the CAN key also displays the initial screen.

• Others

1 System files and user files on SYSTEM DATA SAVE screen

The SYSTEM DATA SAVE function provides a safeguard against free copying of the system files.

User files, however, are not protected.

2 Names of saved files

Files saved from flash memory to a memory card have the following names :

Flash memory		Memory card
PMC–PA PCD 128K	\rightarrow \rightarrow	PMC_PA. XXX PCD_128K.XXX

XXX corresponds to the file extension of MS–DOS format files. A number from 000 to 031 is specified for XXX. For example, if the PMC–PA file in flash memory is saved to a memory card that does not yet contain any PMC–PA. * files, the saved file is named PMC–PA.000. If, however, that file is saved to a memory card that already contains a file named PMC–PA.000, the saved file is named PMC–PA.001. As files are added, the extension is incremented up to a maximum of PMC–PA.031. Any no–longer used numbers in the sequence of the extension numbers are used in as sending order. If two or more files having identical names but different extension numbers are normally saved to the memory card, check the file names displayed subsequently.

D.2.5 Sram Data Backup Screen

- Description
- Screen configuration (CRT/MDI)

This screen is used to collectively save and restore parameters, programs, and other data, retained after the Power Mate's power is turned off, to and from a memory card.

Select "4 SRAM DATA BACKUP" on the SYSTEM MONITOR MAIN MENU screen. The following screen is displayed.

	/	
(1)	SRAM DATA BACKUP	
	[BOARD:MAIN]	
(2)	1. SRAM BACKUP (CNC \rightarrow MEMORY CARD)	
	2. RESTORE SRAM (MEMORY CARD \rightarrow CNC)	
(3)	END	
(4)	SRAM SIZE : 256kB (BASIC)	
(5)	FILE NAME : SRAM256k.000	
(6)	*** MESSAGE *** SELECT MENU AND HIT SELECT KEY. [SELECT][YES][NO][UP][DOWN]]
1		

- (1): Screen title
- (2): Menu
- (3): Returning to the previous menu
- (4): Size of SRAM mounted on the Power Mate
- (5): File name
- (6): Message

• Operating procedure (CRT/MDI)

[Backing up data]

1 Select "1. SRAM BACKUP." The following confirmation message is displayed. Press **[YES]** to start backup.

```
*** MESSAGE ***
BACKUP SRAM DATA OK ? HIT YES OR NO.
```

2 The name of the file being written to the memory card is displayed in the FILE NAME: field. The time required for writing depends on the amount of free space on the memory card.

Normally, writting SRAM BASIC (256KB) should take about one minutes.



3 Upon terminating normally, the system displays the following message. Press the [SELECT] soft key.

```
*** MESSAGE ***
SRAM BACKUP COMPLETE. HIT SELECT KEY.
```

[Restoring the data]

1 Select "2. RESTORE SRAM." The system displays the following message. Press the **[YES]** key.

```
*** MESSAGE ***
RESTORE SRAM DATA OK ? HIT YES OR NO.
```

2 The system displays the following message during restoration.

```
*** MESSAGE ***
RESTORE SRAM DATA FROM MEMORY CARD.
```

3 Upon terminating normally, the system displays the following message. Press the [SELECT] soft key.

```
*** MESSAGE ***
RESTORE COMPLETE. HIT SELECT KEY.
```

— 286 —

Operation (DPL/MDI)

Selecting FILE DATA BACKUP/RESTORE displays the selection screen, shown below. Select BACKUP or RESTORE by pressing the vertex or vertex by the saves or restores the file

data.

BACKUP : Save data into the backup file.

RESTORE : Restore data from the backup file.



: The file data is saved into the memory card.

During saving or restoration, the following screen is displayed:



: The name of the file being saved or restored is displayed and BACKUP blinks.

Once saving or restoration has been completed, the selection screen is displayed again. To end the operation, press the $\boxed{\text{INPUT}}$ key once *END appears on the screen. The initial screen is displayed. Pressing the $\boxed{\text{CAN}}$ key also displays the initial screen.

Others

1 Name of backup file

The name of the backup file written to the memory card by the SRAM backup function is SRAM 256K.xxx.

CAUTION

When the absolute pulse coder is used, after this function is used to restore data, determine whether the position displayed by the Power Mate deviates from the actual position. If any deviation is detected, reset the reference point.

D.2.6 Memory Card File Delete Screen

- Description
- Screen configuration (CRT/MDI)

 Operating procedure (CRT/MDI) This screen is used to delete a file from a memory card.



- (1): Screen title. The current page number (n) and the total number of pages (m) are displayed, in n/m format, at the right end.
- (2): Files on the memory card
- (3): Option for returning to the previous menu
- (4): Message
- 1 Press the **[SELECT]** key to select the name of the file to be deleted from the memory card.
- 2 The system displays the following confirmation message. Press the **[YES]** key.

*** MESSAGE *** DELETE OK ? HIT YES OR NO.

3 When deletion is completed correctly, following message is displayed. Press the **[SELECT]** key.

```
*** MESSAGE ***
DELETE COMPLETE. HIT SELECT KEY.
```

• Operation (DPL/MDI)

Selecting MEMORY CARD FILE DELETE displays the file selection screen, shown below. Pressing the or key on the DPL displays the names of the files stored on the memory card. Once the name of the file to be deleted appears, pressing the wey deletes that file.

Others

MEMORY DELETE
*BASIC. DAT

: File selection screen

During deletion, the following screen is displayed:

BASIC.DAT DELETE : The name of the file being deleted is displayed and DELETE blinks.

Once deletion has been completed, the file selection screen is displayed again. To end the operation, press the \square key. The initial screen is displayed.

- 1 When the memory card contains nine or more files Display the desired page, following the procedure given in the description of the SYSTEM DATA LOADING screen.
- 2 For a flash memory card, the deletion of one file is impossible.

D.2.7 Memory Card Format Function

- Description
- Operating procedure (CRT/MDI)

This function is used to format a memory card. Memory cards must be formatted before they can be used for the first time or before they can be re–used after their data has been destroyed or lost because of, for example, battery failure.

- From the SYSTEM MONITOR MAIN MENU screen, select "7. MEMORY CARD FORMAT."
- 2 The system displays the following confirmation message. Press the **[YES]** key.

*** MESSAGE *** MEMORY CARD FORMAT OK ? HIT YES OR NO.

3 The system displays the following message during formatting :

```
*** MESSAGE ***
FORMATTING MEMORY CARD.
```

4 When a card has been formatted normally, the system display the following message.

Press the **[SELECT]** key.

```
*** MESSAGE ***
FORMAT COMPLETE. HIT SELECT KEY.
```

Operation (DPL/MDI) Selecting MEMORY CARD FORMAT displays the confirmation screen, shown below. Pressing the rever key starts formatting. To cancel formatting, press the CAN key. The initial screen is displayed again. CARD FORMAT OK? PUSH INP OR CAN. Card formatting, the following screen is displayed:



Once formatting has been completed, the initial screen is displayed again.

D.2.8 Load Basic System Function • Description

 Operating procedure (CRT/MDI) The function is used to terminate the boot system and activate the Power Mate.

From the MAIN MENU screen, select "9. END." The system displays the "ARE YOU SURE? HIT YES OR NO" message. To terminate the boot system and activate the Power Mate, press the **[YES]** soft key. Pressing the **[NO]** key cancels this operation.

```
*** MESSAGE ***
ARE YOU SURE ? HIT YES OR NO.
[ SELECT ][ YES ][ NO ][ UP ][ DOWN ]
```

1 After pressing the [YES] soft key

The system checks the NC BASIC system file in the flash ROM. The system displays the following message :



When the NC BASIC system file is found to be normal, the system sends the system file to DRAM and starts the NC BASIC SYSTEM. During LOADING, the system blinks the following message.

*:	** MESSA	AGE	*** BASTO	τO	DPAM					
_	HOADII		DADIC	10	DIAN					_
	SELECT][YES][NO][UP][DOWN	נ ע

If the contents of the NC BASIC SYSTEM file are found to have been damaged or destroyed, the system returns to the processing selection state, in exactly the same way as when the **[NO]** soft key is pressed.

2 If the **[NO]** soft key is pressed, the system returns to the processing selection state as shown below :

```
*** MESSAGE ***
SELECT MENU AND HIT [SELECT] KEY.
[ SELECT ][ YES ][ NO ][ UP ][ DOWN ]
```

• Operation (DPL/MDI)

Selecting SYSTEM MONITOR EXIT displays the confirmation screen, shown below. Pressing the *INPUT* key loads the basic system from flash memory into DRAM. To cancel loading, press the *CAN* key. The initial screen is displayed again.



: Confirmation screen "PUSH INP OR CAN." blinks.

During loading, the following screens are displayed, in the order shown:



Once loading has been completed, the series and edition are displayed, then the Power Mate–H is started.

D.3 ERROR MESSAGES AND REQUIRED ACTIONS

The following table lists and explains error messages in alphabetical order.

	Message	Description and required action
D	DELETE ERROR. HIT SELECT KEY. (ERROR–014)	An attempt to delete a file from flash memory was unsuccessful or files of memory card cannot be deleted. Retry the deletion. If the second attempt also fails, the flash memory may have been damaged or destroyed. Replace the memory module.
	DEVICE ERROR (CNC x) (ERROR–012)	An attempt to write data to flash memory was unsuccessful. Retry the write operation off power and restart the system. If the second attempt also fails, the flash memory may have been damaged or destroyed. Repalce the flash memory module.
F	FILE NOT FOUND IN FLASH ROM. HIT SELECT KEY. (ERROR–029)	Files do not appear on the flash memory. After writting in flash memory, the flash memory may be destroyed. Change the memory module.
	FILE SAVE ERROR. HIT SELECT KEY. (ERROR–015)	An attempt to write a file to a memory card was unsuccessful. Check that the memory card is not damaged. Note) Check that the memory card's battery is not exhusted, that its circuitry has not been damaged, and that it is securely inserted into its slot.
	FLASH MEMORY NO SPACE (ERROR–004)	There is insufficient free flash memory to store the selected file. Delete any unnecessary files from flash memory.
	FORMAT ERROR. HIT SELECT KEY (ERROR–025)	Format of memory card is unsuccessful.
I	ILLEGAL FORMAT FILE (ERROR–003)	The selected file cannot be read into flash memory. The selected file or the header information for flash memory may have been damaged or destroyed.
	IN CORRECT PASSWORD. HIT SELECT KEY. (ERROR–017)	Password is not correct. Input correct password.
L	LOADING ERROR. HIT SELECT KEY. (ERROR–013)	An error occurred while loading data into flash memory. Do not touch the memory card while loading data.

	Message	Description and required action
М	MAX EXTENSION OVER. HIT SELECT KEY. (ERROR–022)	The extension number added to a file name exceeds 031. Delete any unnecessary backup files from the memory card.
	MEMORY CARD BATTERY ALARM. HIT SELECT. (ERROR–002)	The memory card's battery is exhausted. Replace the battery.
	MEMORY CARD FULL. HIT SELECT KEY. (ERROR–021)	The memory card is full. Delete any unnecessary files from the memory card. Alternatively, replace the memory card with another card having sufficient free space.
	MEMORY CARD MOUNT ERROR. HIT SELECT KEY (ERROR–005)	The memory card could not be accessed. Check that the memory card is normal. The memory card may not be correct format . Format correctly.
	MEMORY CARD NOT EXIST. HIT SELECT KEY. (ERROR–001)	The memory card is not inserted into its slot. Check that the memory card is pushed fully home.
	MEMORY CARD PROTEC- TED.HIT SELECT KEY. (ERROR–016)	Although writing to the memory card was selected, the write inhibit switch is set. Disable the write inhibit switch.
	MEMORY CARD TYPE RESET ERROR. HIT SELECT KEY. (ERROR–018)	Access to the memory card has failed. Check whether the memory card is defective.
	MEMORY CARD WRITE ERROR. HIT SELECT KEY. (ERROR–020)	Write to memory card is failed. Check whether the memory card is normal.
Ρ	PROTECT FILE.	An attempt was made to delete the system data. System data cannot be deleted.
S	SRAM DATA BACKUP ERROR. HIT SELECT KEY. (ERROR–023)	An attempt to write a backup file to a memory card failed. Check that the memory card is normal.
	SRAM DATA RESTORE ERROR. HIT SELECT KEY. (ERROR–027)	Reading of the backup data from the memory card failed. The files stored on the memory card are erroneous. Check whether the memory card is defective.
	SRAM 256K.*NOT FOUND (ERROR–026)	The memory card does not contain system data file SRAM256K. Use a memory card containing SRAM256K.

(): Message for DPL/MDI

DATA INPUT/OUTPUT TO AND FROM A MEMORY CARD

- **E.1 OVERVIEW**
- **E.2 FUNCTION DESCRIPTION**
- **E.3 OPERATION**
- E.4 MEMORY CARD WRITE PROTECT SWITCH

E.1 OVERVIEW

Data stored in memory of the Power Mate can be output to a single memory card at one time. Moreover, programs, parameters, variables, PMC data can be input to the CNC.

Use the flash type memory card specified by FANUC.

Data backup may be able to execute as execution of boot system.

See D.2.5 SRAM DATA BACKUP.

NOTE

Those files that are collectively backed up by performing this operation are incompatible with those that are backed up in the boot system, as described in Subsection D.2.5, "SRAM Data Backup Screen."

E.2 FUNCTION DESCRIPTION

E.2.1 Conditions for Enabling This Function

Before this function can be enabled, the Power Mate and a memory card to be used must meet the conditions explained following.

- Conditions of the Power Mate
- (1) For input processing, EDIT or MDI mode must be set. To enable output processing, EDIT mode must be set.
- (2) The Power Mate must be placed in the emergency stop state.
- (3) The program display screen must be selected.
- (4) To input data, setting parameter parameter write> must be set to 1. (For the DPL/MDI, <PWE> must be set to 1.)
- Conditions of the memory card
- (1) Use following memory card. Flash 256KB, 512KB, 1MB, and 4MB.
- (2) To output data, the write protect switch must be set off.
- (3) The memory card must have attribute information.
 *This function cannot be used with memory cards having no attribute information. So, use memory cards version 4.0 or later.

E.2.2 Output to a Memory Card

The contents of the entire memory area of the Power Mate are output to a memory card. The size of the output data is recorded in the memory card. If the capacity of the memory card is smaller than the memory size of the Power Mate, alarm 5106 is issued. The Power Mate memory cannot be divided in order to be output to two or more memory cards.

Data in two or more Power Mate units cannot be output to one memory card. For input/output processing with a memory card in the boot system described in Appendix D, data in two or more Power Mate units can be output to one memory card.

E.2.3 Input from a Memory Card

- Inputting all data
- (1) With the CRT/MDI

 $\mathsf{M} \mid \rightarrow [\mathsf{READ}] \rightarrow [\mathsf{EXEC}]$

(2) With the DPL/MDI



NOTE

"All data" includes NC programs, parameters, variables, tool compensation data, PMC data, and operation history data. (Ladders, macro executors, and C executors are not included.)

- Inputting data individually
- (1) With the CRT/MDI



(2) With the DPL/MDI



- n1 : Program
- n2 : Parameter
- n3 : Variable, tool length compensation data
- n4 : Be sure to set 0
- n5 : PMC data
- *n6: Operation history data
- *n7: Be sure to set 0

Specifying 1 causes the corresponding data to be read. Specifying 0 causes the corresponding data to be skipped.

(Example) When variable number and program are read.



E. DATA INPUT/OUTPUT TO AND FROM A MEMORY CARD

APPENDIX

E.3 OPERATION

E.3.1 Outputting Data to a Memory Card	 Data stored in Power Mate memory can be output to a memory card by following the procedure below. (1) Select the EDIT mode. (2) Place the system in the emergency stop state. (3) Press the <prgrm> display button to display the program display screen.</prgrm> (4) Insert the memory card in the CNC. (5) Enter address <m>.</m> (6) Select the [OPRT], [→], and [PUNCH] soft keys, then press [EXEC]. (When the DPL/MDI is used, press the write key.) All data in the Power Mate memory is then output.
E.3.2 Inputting Data from a	Data can be input from a memory card to Power Mate memory by following the procedure below.
Memory Card	Inputting all data
	(1) Select the EDIT or MDI mode.
	(2) Place the system in the emergency stop state.
	(3) For both paths, set setting parameter [parameter write enable] to 1.(When the DPL/MDI is used, set [PWE] to 1.)
	 (4) Press the <prgrm> display boutton to display the program display screen.</prgrm>
	(5) Insert the memory card in the Power Mate.
	(6) Enter address <m>.</m>
	(7) Select the [OPRT] [\rightarrow] and [READ] soft keys, then press [EXEC]. (When the DPL/MDI is used, press the READ key.)
	All data is then read into the CNC memory.
	Inputting specific data
	(1) Select the EDIT or MDI mode.
	(2) Place the system in the emergency stop state.
	(3) Set setting parameter [parameter write] to 1.(When the DPL/MDI is used, set [PWE] to 1.)
	(4) Press the <prgrm> display button to display the program display screen.</prgrm>
	(5) Insert the memory card in the Power Mate.
	(6) Enter address <m>.</m>
	 (7) Specify the types of data to be input by using numeric characters in the form <n7n6n5n4n3n2n1>.</n7n6n5n4n3n2n1> n1 : Program

- n2 : Parameter
- n3 : Variable, tool length compensation data
- n4: Be sure to set 0
- n5 : PMC data
- n6 : Operation history data
- n7: Be sure to set 0

Specifying 1 causes the corresponding data to be read. Specifying 0 causes the corresponding data to be skipped.

(8) Select [OPRT], $[\rightarrow]$ and [READ], then press [EXEC]. (When the DPL/MDI is used, press the READ key.)

The specified data is then read into the Power Mate memory.

E.4 MEMORY CARD WRITE PROTECT SWITCH

The write protect switch is used to protect the data recorded on the card. Important data can be kept safely by setting the write protect switch as shown in the figure below. The switch prevents data from being inadvertently rewritten.



MEMORY CARD OPERATOR'S MANUAL

- F.1 OUTLINE
- F.2 ADVICE FOR USE
- F.3 NAMES AND FUNCTION OF MEMORY COMPONENTS
- F.4 OPERATING OF MEMORY CARD
- F.5 BATTERY CHANGE
- F.6 SPECIFICATIONS OF MEMORY CARDS THAT ARE NOT ALLOWED TO BE USED

F.1 OUTLINE

FANUC–specified flash memory card and the SRAM memory card can be used as a data exchanging media for CNC unit, and are based on following standards.

•JEIDA "IC Memory Card Guideline Ver. 4.0"

•PCMCIA "PC Card Standard R.2.0"

The memory card is easy to use and a data exchanging media which can be input and output data with high speed, and you should take care of operation for the memory card.

This manual describes operating procedure and advice for the memory card.

Some software of CNC unit may restrict a kind of useful memory card, input/output file function.

For detail, refer to the manual of each CNC unit.

FANUC-specified memory cards are listed	below.
---	--------

		Fujitsu Ltd.	MB98A80813-20-G-S	
	256KB	Fuji Electro- chemical Co., Ltd.	SC-9027-22H14	
		Fujitsu Ltd.	MB98A80913-20-G-S	
Flash memory card	h 512KB nory	Fuji Electro- chemical Co., Ltd.	SC-9027-42H14	Appendix E
		Fujitsu Ltd.	MB98A81013-20-G-S	
	1MB	Fuji Electro- chemical Co., Ltd.	SC-9027-82H14	
	2MB	Intel	IMC002FLSA	Appendix D
	4MB	Intel	IMC004FLSA	Appendix E
SRAM	1MB	Fujitsu Ltd.	MB98A91023-20	Appendix D
card	2MB	Fujitsu Ltd.	MB98A91123-20	

F.2 ADVICE FOR USE

F.2.1 SRAM Memory Card

(1) The SRAM memory card needs the battery for data backup, but does not include the battery when you get it.

Please insert the battery, according to "F.5 Change Battery".

- (2) The SRAM memory card, data of memory card will be lost when the battery life is over, and please copy data of the memory card into a floppy disk.
- (3) The SRAM memory card has a battery voltage detecting function. And when the SRAM memory card which has low voltage battery is connected to CNC unit, the alarm message is displayed on CNC unit. But the battery voltage detecting function cannot operate without a battery.

NOTE

The SRAM memory card cannot be used to back up data.

F.3 NAMES AND FUNCTION OF MEMORY COMPONENTS



	Name	Function				
1	Write Protect Switch	The memory card can be protected from writing data into the memory card by setting of the write protect switch.				
		Non Write Protect Write protect				
2	Battery Case	Incase of the SRAM memory card, the battery case				
		The flash memory card has no battery case.				

F.4 OPERATING OF MEMORY CARD

F.4.1 Connection of Memory Card

- (1) Insert the memory card in the direction shown in the figure through the memory card insertion slot.
- (2) The memory card cannot be inserted with wrong side, because the memory card has insertion guides.

Take care the direction of the memory card.



(1) For the read/write operation, refer to the Addendix D or E.

F.4.2 Operation

F.4.3 Disconnection of Memory Card (1) Pull the memory card out in the direction shown in the figure.



F. MEMORY CARD OPERATOR'S MANUAL

APPENDIX

F.5 BATTERY CHANGE

Procedure of Battery

F.5.1

F.5.3

Change

Battery

F.5.2 Battery Life

The battery life is as follows.

But the battery life in the table is only reference data, because the battery life is changeable by the change of ambient temperature.

CR2325 or equivalent battery can be used for the SRAM memory card.

Drawing Number	Part's Number	Battery Life
A87L-0001-0150#512K	MB98A90923-20	about 6 months
A87L–0001–0150#1M	MB98A91023-20	about 1 year
A87L-0001-0150#2M	MB98A91123-20	about 6 months

(1) Pull the battery case out with pushing projection.

(2) Change the battery.

"+" mark of the battery must be set to "+" mark of the battery case.



(3) Put the battery case back in the memory card, and make sure read/write operation.



F.6 SPECIFICATIONS OF MEMORY CARDS THAT ARE NOT ALLOWED TO BE USED

Among those memory cards that are compliant with the PC Card Standard, those which are operational at 3.3 V cannot be used.

- Memory cards which are operational at 3.3 V
 - \rightarrow This type of memory card cannot be inserted physically.
- Memory cards which are operational at 3.3 or 5 V (automatic voltage selection)
 - → This type of memory card can be inserted physically, but must not be used because an electrical failure of the memory card itself or CNC control unit may result.

G NOTATION OF MDI KEYS

FANUC Power Mate–MODEL H has two types of MDI keypads : English type and Symbolic type.

The table below shows correspondence between English keys and Symbolic keys.

This manual uses English type in the text.

Therefore when a user uses Symbolic type MDI keypads and encounters an English key in the text, please refer to the correspondence table shown below.

MDI keys for CRT

Name	English key	Symbolic key		
CANCEL key	CAN			
POSITION key	POS			
PROGRAM key	PROG			
OFFSET/ SETTING key	OFFSET SETTING			
CUSTOM key	CUSTOM			
SYSTEM key	SYSTEM	\bigcirc		
MESSAGE key	MESSAGE	?		
GRAPH key	GRAPH			
CNC/MMC key				
SHIFT key	SHIFT	Û		
INPUT key	INPUT	$\overline{\mathbf{r}}$		
ALTER key	ALTER			
INSERT key	INSERT			

Name	English key	Symbolic key	
DELETE key	DELETE		
PAGE UP key	† PAGE		
PAGE DOWN key	PAGE		
HELP key	HELP		
RESET key	RESET		
CUSTOM/ GRAPH key	CUSTOM GRAPH		

MDI keys for DPL

Name	English key	Symbolic key
POSITION key	POS	
PROGRAM key	PRGRM	
MENU/VAR key	MENU VAR	
INSERT key	INSRT	
DELETE key	DELET	
ALTER key	ALTER	
INPUT key	INPUT	$\widehat{ \ }$
DIAGNOSE/PARAMETER key	DGNOS PARAM	
OPERATION/ALARM key	OPR ALARM	2
READ key	READ	
WRITE key	WRITE	
CANCEL key	CAN	

[Numbers]

7.2-inch Monochrome LCD Adjustment, 104

[A]

Action Againts Noise, 48

Address, 127

Address List, 156

Adjusting Reference Position (Dog Method), 177

Adjusting the Color Liquid Crystal Display and Plasma Display, 103

Adjusting the Plasma Display, 103

Advice for Use, 303

Alarm 300 (Request for Reference Position Return), 213

- Alarm 301 to 305 (Absolute Pulse Coder is Faulty), 214
- Alarm 306 to 308 (Absolute Pulse Coder Battery is Low), 215

Alarm 350 (Serial Pulse Coder is Abnormal), 219

Alarm 351 (Serial Pulse Coder is Abnormal), 220

Alarm 400 (Overload), 221

Alarm 401 (*DRDY Signal Turned OFF), 223

Alarm 404 and 405 (*DRDY Signal Turned on, Reference Position Return Abnormal), 225

- Alarm 410 (Excessive Position Error Amount During Stop), 226
- Alarm 411 (Excessive Position Error During Move), 227
- Alarm 414 (Digital Servo System is Abnormal), 229

Alarm 416 (Disconnection Alarm), 230

Alarm 417 (Digital Servo System is Abnormal), 231

Alarm 700 (Overheat at Control Side), 232

Alarm 85 to 87 (Reader/Puncher Interface Alarm), 205

Alarm 90 (Reference Position Return is Abnormal), 210

- Alarm 900 (ROM Parity Error), 233
- Alarm 912 to 913 (Sram Parity), 235

Alarm 920 to 922 (Watch Dog or RAM Parity), 236

Alarm 924 (Servo Module Mounting Error), 238

Alarm 930 (CPU Error), 238

Alarm 950 (PMC System Alarm), 239

Alarm 970 (NMI Alarm in PMC Module), 240

Alarm 971 (NMI Alarm in SLC), 241

Alarm 973 (NMI Alarm by Unknown Cause), 242

Alarm History Screen, 21 Alarm List, 253 Associated Parameters, 180 Automatic Operation Cannot be Done, 195

[B]

Basic Unit, 79 Battery, 306 Battery Change, 306 Battery Life, 306 Battery of Controller, 74 Built–in Debug Function, 127

[C]

Clearing Alarm History, 21 Conditions for Enabling This Function, 296 Configuration Display of Software, 17 Confirming the Parameters Required for Data input/ Output, 111 Connection of Memory Card, 305 Connector and Signal Name, 73 Contens Displayed (DPL/MDI), 27 Contents Displayed (Common), 25 Control Unit PC Board, 79 Corrective Action for Failures, 183 CRT/MDI, 17 CRT/MDI Unit, 55 CRT/MDI, DPL/MDI PC Board, 81 CRT/MDI, DPL/MDI Unit, 80 Cycle Start LED Signal has Turned OFF, 201

[D]

Data Input/Output to and from a Memory Card, 294 Detachable LCD/MDI Interface, 67 Digital Servo, 169 Disconnection of Memory Card, 305 Display and Operation, 1 Display Method, 19, 22, 129 Display of Special Alarms, 21 Displaying Diagnostic Page, 25 Displaying of CRT/MDI, 25 Displaying of DPL/MDI, 25 Displaying Servo Tuning Screen, 174 Dogless Reference Position Setting, 179 DPL/MDI, 15, 18 DPL/MDI Interface, 65

[E]

Editing Ladder Mnemonics, 143 Editing the Sequence Program (Edit), 143 Environmental Requirement, 47 Error List, 153 Error Messages (for Ladder Mnemonics Editing), 148 Error Messages and Required Actions, 292 Execution Period of PMC, 128 External Pulse Input Function (Single phase input type) Cannot be used, 193 External Pulse Input Interface, 60

[F]

Function Description, 296 Function Keys and Soft Keys, 2 Fuse of Controller, 73 Fuses, 250

[G]

General of Interface, 125

[H]

Handy Operator's Panel Interface, 68 Hardware, 44 hardware Configuration, 248 Help Funciton, 22 How to Replace the Batteries, 82 How to Replace the Modules, 88

[I]

I/O Link, 62 I/O Unit Model A, 247 Initial Setting Servo Parameters, 170 Input and Output of Data, 107 Input from a Memory Card, 297 Input/Output Ladder/PMC- parameter by DPL/MDI, 150 Inputting CNC Parameters, 117 Inputting Custom Macro Variable Values, 120 Inputting Data from a Memory Card, 298 Inputting Part Programs, 122 Inputting PMC Ladder, 123 Inputting PMC Parameters, 119 Inputting Tool Compensation Amount, 121 Inputting/Outputting Data, 111 Insertion, 88 Installation, 47 Inter-Machine Connection, 55 Interface Between NC and PMC, 124 Investigating the Conditions under which Failure Occurred, 183

[J]

Jog Operation Cannot be Done, 190

[L]

LED Display of Control Unit, 72 LED display of I/O Link Connection Unit, 78 Led Display/Setting and Module Configuration of Unit, 72 LED Indication, 249 List of Maintenance Parts, 267 List of Operations (CRT/MDI), 38 List of Operations (DPL/MDI), 41 List of PC Board and Unit, 79 List of Signals by Each Mode, 154 Load Basic System Function, 290 Location of Modules and Internal PC Boards, 76

[M]

- Maintenance and Input/Output of Memory Card In Boot System, 272 Maintenance of Heat Pipe Type Heat Exchanger, 94
- Maintenance Parts, 268

Memory Card File Delete Screen, 288

Memory Card Format Function, 289

Memory Card Operator's Manual, 301

Memory Card Write Protect Switch, 300 Module, 79 Module Configuration Screen, 20

[N]

Names and Function of Memory Components, 304 No Manual Operation nor Automatic Operation Can be Executed, 186 No Signal Change in FANUC I/O Link Master, 243 Notation of MDI Keys, 309

[0]

On–line Debugging Function, 151 Operating of Memory Card, 305 Operation, 179, 298, 305 Operation History, 30 Operation on the CRT/MDI, 129 Operation on the DPL/MDI, 140 Output Data to a Memory Card, 298 Output to a Memory Card, 298 Output to a Memory Card, 296 Outputting CNC Parameters, 112 Outputting Custom Macro Variable Values, 114 Outputting Ladder Programs, 116 Outputting Part Program, 115 Outputting PMC Parameters, 113 Outputting Tool Compensation Amount, 114

[P]

Parameter Setting, 174 PMCDGN Screen, 131 PMCLAD Screen, 130 PMCRAM Screen, 135 Power Cannot be Turned ON, 185 Power Capacity, 48 Power Mate Status Display, 29 Procedure of Battery Change, 306

[R]

Reader/Puncher Interface, 59 Reference Position Deviates, 209 Removing, 88

Removing a printed Circuit Board, 251

Replace the Battery for Memory Back Up, 82

- Replacing Batteries for Absolute Pulse Coder (β Series Servo Amp Module/Built–in Type Battery), 85
- Replacing Batteries for Absolute Pulse Coder (Separate Battery Case), 86
- Replacing Batteries for Absolute Pulse Coder (Servo Amplifier Built–in Type Battery/Servo Amplifier α Series), 84

Replacing Printed Circuit Board and Unit, 90

Replacing the DRL/MDI Switcher Fuses, 101

Replacing the Fuse, 97

Replacing the Lcd Baklight, 106

Replacing the LCD Fuse, 102

Rotary Switch MTSW, 75

Rotary Switch RSW, 74

[S]

Screen Configuration and Operating Procedure, 275

Screen Display, 21, 30

Selectingthe PMC Programmer Menu, 142

Servo Interface, 64

Servo Tuning Screen, 174

Setting and Displaying System Parameters (System Param), 142

Setting Parameters for Input/Output, 108

Setting the Input Signal or Output Signal to be Recorded in the Operation History, 33

Signal and Symbol Correspondence Table, 164

Soft Keys, 2

Software Configuration Screen, 19

Specification, 126

Specification of PMC, 126

Specifications of Memory Cards that are not Allowed to be Used, 308

Sram Data Backup Screen, 285

SRAM Memory Card, 303

Starting and Stopping the Sequence Program (Run/ Stop), 148

Starting The Boot System, 273

Storing the Sequence Program into Flash Eeprom (I/O), 149

System Configuration, 248

System Configuration Screen, 19

System Data Check Screen, 279

System Data Delete Screen, 281 System Data Loading Screen, 277 System Data Save Screen, 283 System Files and User Files, 274 System Reserve Area of Internal Relay, 128

[T]

The Base Printed Circuit Boards, 90 The CRT Control Printed Circuit Board, 92 The CRT Display, 93 The CRT/MDI Control PCB Fuse, 98 The Fan Motor, 92 The I/O Card Fuses, 99 The I/O Unit–MODEL A Fuses, 100 The MDI Keyboard, 92 The Power Mate Controller Fuse, 97 The Power Supply Printed Circuit Boards and Sub PC Board, 91 Total Connection Diagram, 45 Touch Panel Interface, 71 Troubleshooting, 181

[W]

When Manipulation is not Possible with the CRT/ $MDI,\,203$

(B-62685EN)					Contents
E MANUAL					Date
ITENANC					Edition
FANUC Power Mate-MODEL H MAIN		 Addition contents related to DPL/MDI Correction of errors 	 All pages are rewritten 		Contents
		Dec., '97	Apr., '96	May, '95	Date
		03	02	6	Edition

Revision Record
- No part of this manual may be reproduced in any form.
- All specifications and designs are subject to change without notice.