

# **GE Fanuc Automation**

**Computer Numerical Control Products** 

Series 15 / 150 – Model B

Maintenance Manual

GFZ-62075E/04

May 1998

# Warnings, Cautions, and Notes as Used in this Publication

## Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

#### Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

©Copyright 1998 GE Fanuc Automation North America, Inc. All Rights Reserved.

# SAFETY PRECAUTIONS

This section describes the safety precautions related to the use of CNC units. It is essential that these precautions be observed by users to ensure the safe operation of machines equipped with a CNC unit (all descriptions in this section assume this configuration).

CNC maintenance involves various dangers. CNC maintenance must be undertaken only by a qualified technician.

Users must also observe the safety precautions related to the machine, as described in the relevant manual supplied by the machine tool builder.

Before checking the operation of the machine, take time to become familiar with the manuals provided by the machine tool builder and FANUC.

#### Contents

1.	DEFINITION OF WARNING, CAUTION, AND NOTE s-2
2.	WARNINGS RELATED TO CHECK OPERATION
3.	WARNINGS RELATED TO REPLACEMENT s–5
4.	WARNINGS RELATED TO PARAMETERS s-6
5.	WARNINGS AND NOTES RELATED TO DAILY MAINTENANCE s-7

# **DEFINITION OF WARNING, CAUTION, AND NOTE**

This manual includes safety precautions for protecting the maintenance personnel (herein referred to as the user) and preventing damage to the machine. Precautions are classified into Warnings and Cautions according to their bearing on safety. Also, supplementary information is described as a Note. Read the Warning, Caution, and Note thoroughly before attempting to use the machine.

## WARNING

Applied when there is a danger of the user being injured or when there is a damage of both the user being injured and the equipment being damaged if the approved procedure is not observed.

# CAUTION

Applied when there is a danger of the equipment being damaged, if the approved procedure is not observed.

#### NOTE

The Note is used to indicate supplementary information other than Warning and Caution.

Q Read this manual carefully, and store it in a safe place.

# WARNINGS RELATED TO CHECK OPERATION

## WARNING

- 1. When checking the operation of the machine with the cover removed
  - (1) The user's clothing could become caught in the spindle or other components, thus presenting a danger of injury. When checking the operation, stand away from the machine to ensure that your clothing does not become tangled in the spindle or other components.
  - (2) When checking the operation, perform idle operation without workpiece. When a workpiece is mounted in the machine, a malfunction could cause the workpiece to be dropped or destroy the tool tip, possibly scattering fragments throughout the area. This presents a serious danger of injury. Therefore, stand in a safe location when checking the operation.
- 2. When checking the machine operation with the power magnetics cabinet door opened
  - (1) The power magnetics cabinet has a high–voltage section (carrying a ▲ mark). Never touch the high–voltage section. The high–voltage section presents a severe risk of electric shock. Before starting any check of the operation, confirm that the cover is mounted on the high–voltage section. When the high–voltage section itself must be checked, note that touching a terminal presents a severe danger of electric shock.
  - (2) Within the power magnetics cabinet, internal units present potentially injurious corners and projections. Be careful when working inside the power magnetics cabinet.
- **3.** Never attempt to machine a workpiece without first checking the operation of the machine. Before starting a production run, ensure that the machine is operating correctly by performing a trial run using, for example, the single block, feedrate override, or machine lock function or by operating the machine with neither a tool nor workpiece mounted. Failure to confirm the correct operation of the machine may result in the machine behaving unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.
- **4.** Before operating the machine, thoroughly check the entered data. Operating the machine with incorrectly specified data may result in the machine behaving unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.

#### WARNING

- **5.** Ensure that the specified feedrate is appropriate for the intended operation. Generally, for each machine, there is a maximum allowable feedrate. The appropriate feedrate varies with the intended operation. Refer to the manual provided with the machine to determine the maximum allowable feedrate. If a machine is run at other than the correct speed, it may behave unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.
- **6.** When using a tool compensation function, thoroughly check the direction and amount of compensation.

Operating the machine with incorrectly specified data may result in the machine behaving unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.

# WARNINGS RELATED TO REPLACEMENT

## WARNING

- **1.** Always turn off the power to the CNC and the main power to the power magnetics cabinet. If only the power to the CNC is turned off, power may continue to be supplied to the serve section. In such a case, replacing a unit may damage the unit, while also presenting a danger of electric shock.
- **2.** When a heavy unit is to be replaced, the task must be undertaken by two persons. If the replacement is attempted by only one person, the replacement unit could slip and fall, possibly causing injury.
- **3.** After the power is turned off, the servo amplifier and spindle amplifier may retain voltages for a while, such that there is a danger of electric shock even while the amplifier is turned off. Allow at least twenty minutes after turning off the power for these residual voltages to dissipate.
- **4.** When replacing a unit, ensure that the new unit has the same parameter and other settings as the old unit. (For details, refer to the manual provided with the machine.) Otherwise, unpredictable machine movement could damage the workpiece or the machine itself, and present a danger of injury.

# WARNINGS RELATED TO PARAMETERS

## WARNING

- **1.** When machining a workpiece for the first time after modifying a parameter, close the machine cover. Never use the automatic operation function immediately after such a modification. Instead, confirm normal machine operation by using functions such as the single block function, feedrate override function, and machine lock function, or by operating the machine without mounting a tool and workpiece. If the machine is used before confirming that it operates normally, the machine may move unpredictably, possibly damaging the machine or workpiece, and presenting a risk of injury.
- **2.** The CNC and PMC parameters are set to their optimal values, so that those parameters usually need not be modified. When a parameter must be modified for some reason, ensure that you fully understand the function of that parameter before attempting to modify it. If a parameter is set incorrectly, the machine may move unpredictably, possibly damaging the machine or workpiece, and presenting a risk of injury.

# WARNINGS AND NOTES RELATED TO DAILY MAINTENANCE

#### WARNING

#### 1. Memory backup battery replacement

When replacing the memory backup batteries, keep the power to the machine (CNC) turned on, and apply an emergency stop to the machine. Because this work is performed with the power on and the cabinet open, only those personnel who have received approved safety and maintenance training may perform this work.

When replacing the batteries, be careful not to touch the high–voltage circuits (marked ▲ and fitted with an insulating cover).

Touching the uncovered high-voltage circuits presents an extremely dangerous electric shock hazard.

## NOTE

The CNC uses batteries to preserve the contents of its memory, because it must retain data such as programs, offsets, and parameters even while external power is not applied.

If the battery voltage drops, a low battery voltage alarm is displayed on the machine operator's panel or CRT screen.

When a low battery voltage alarm is displayed, replace the batteries within a week. Otherwise, the contents of the CNC's memory will be lost.

To replace the battery, see the procedure described in Section 2.8 of this manual.

#### WARNING

#### 2. Absolute pulse coder battery replacement

When replacing the memory backup batteries, keep the power to the machine (CNC) turned on, and apply an emergency stop to the machine. Because this work is performed with the power on and the cabinet open, only those personnel who have received approved safety and maintenance training may perform this work.

When replacing the batteries, be careful not to touch the high–voltage circuits (marked ▲ and fitted with an insulating cover).

Touching the uncovered high-voltage circuits presents an extremely dangerous electric shock hazard.

## NOTE

The absolute pulse coder uses batteries to preserve its absolute position.

If the battery voltage drops, a low battery voltage alarm is displayed on the machine operator's panel or CRT screen.

When a low battery voltage alarm is displayed, replace the batteries within a week. Otherwise, the absolute position data held by the pulse coder will be lost.

To replace the battery, see the procedure described in Section 2.8 of this manual.

### WARNING

#### 3. Fuse replacement

Before replacing a blown fuse, however, it is necessary to locate and remove the cause of the blown fuse.

For this reason, only those personnel who have received approved safety and maintenance training may perform this work.

When replacing a fuse with the cabinet open, be careful not to touch the high–voltage circuits (marked  $\blacktriangle$  and fitted with an insulating cover).

Touching an uncovered high-voltage circuit presents an extremely dangerous electric shock hazard.

# **Table of Contents**

SAFETY	PREC	AUTIONS s–1
PREFACE	Ξ	p–1
1. OPERA		OF MDI PANEL 1
1.1	OPF	RATION OF MDI PANEL
	1.1.1	Screen Transition Chart
1.2	DIS	PLAYING SYSTEM CONFIGURATIONS
	1.2.1	Displaying Method
	1.2.2	Software Information
	1.2.3	Slot Information
	1.2.4	Module Information
1.3	ALA	ARM HISTORY DISPLAY
	1.3.1	Display Method
	1.3.2	Alarm History Screen
	1.3.3	Display Format of History Data
	1.3.4	Restrictions
1.4	HEI	P FUNCTION
	1.4.1	General
	1.4.2	Operation
1.5	DIA	GNOSIS FUNCTION
	1.5.1	Displaying the Diagnosis Screen
	1.5.2	Displaying the Status when it Appears that a Command is not being Executed
1.6	NC	STATUS DISPLAY
1.7	WAY	VEFORM DIAGNOSIS FUNCTION
	1.7.1	Display of Wave Diagnosis (Graph) Screen
	1.7.2	Setting the Waveform Diagnosis Parameters
	1.7.3	Starting or Terminating Data Sampling
	174	Waveform Display 34
	175	Editing a Displayed Waveform 34
	176	Erasing a Displayed Waveform 34
18	OPF	RATING MONITOR SCREEN 35
1.0	181	Display Method 35
19	INT	FRNAL POSITION COMPENSATION DATA DISPLAY FUNCTION 36
1.9	191	Display Method
	192	Display Data 36
1 1(	) OPF	ERATION HISTORY 41
1110	1 10 1	Display Method 41
	1.10.2	Soft Key Operation 41
	1.10.3	Select DI/DO Screen 44
	1 10 4	Related Parameters 45
1.11	I OPE	ERATION LIST
2. HARDI	NARF	51
	~	
2.1	STR	UCTURE
2.2	OU'	ILINE OF HARDWARE         53
2.3	TOT	AL CONNECTION

2.4	INT	ER–MACHINE CONNECTION	. 68
	2.4.1	CRT/MDI Unit	. 68
	2.4.2	Reader/Puncher Interface	. 71
	2.4.3	Manual Pulse Generator	. 72
	2.4.4	I/O Link	. 73
	2.4.5	Servo Interface	. 76
	2.4.6	Connections by Type of Detectors	. 77
	2.4.7	Combining Serial Spindle and Analog Spindle	. 79
	2.4.8	Connection to $\alpha$ Serial Spindle Amplifier	. 80
	2.4.9	Connection to Analog Spindle Amplifier	. 81
	2.4.10	Remote Buffer Interface	. 82
	2.4.11	High-speed DI Signal Interface	. 84
	2.4.12	Environmental Requirement	. 85
	2.4.13	Power Capacity	. 86
	2.4.14	Action Against Noise	. 86
2.5	LIGI	HTING OF ALARM LEDS ON PCBS	. 92
	2.5.1	Configuration of the Power Supply Unit	. 92
	2.5.2	Configuration of the CPU Board (MAIN–B)	. 96
	2.5.3	Configuration of the Main CPU Board (MAIN–A)	100
	2.5.4	Configuration of the Upgraded Main CPU Board (MAIN-C)	104
	2.5.5	Configuration of the High-speed Multiaxis Main CPU Board (MAX MAIN-A)	107
	2.5.6	Configuration of the Level Up Multiaxis Main CPU Board (MAX MAIN–C)	111
	2.5.7	Configuration of the PMC–NA Board	115
	2.5.8	Configuration of the PMC–NA Board with or without the Conversational Function	118
	2.5.9	Configuration of the PMC–NB Board with or without the Conversational Function	122
	2.5.10	Configuration of the PMC–NB/NB2 Board with or without the Conversational Function	126
	2.5.11	Configuration of the Axis CPU Board (ACPU)	130
	2.5.12	Configuration of the Multiaxis Buffer Board	133
	2.5.13	Configuration of the RISC Board	134
	2.5.14	Configuration of the RISC Board	137
	2.5.15	Configuration of the Sub–CPU Board (SUB–A)	140
	2.5.16	Configuration of the Standard Multiaxis Sub–CPU Board (MAX SUB–B)	143
	2.5.17	Configuration of the Upgraded Sub–CPU Board (SUB–C)	146
	2.5.18	Configuration of Additional Axis (ADAX) Board	149
	2.5.19	Configuration of the Option 1 Board	152
	2.5.20	OSI Ethernet Board Configuration (10 Base 2)	156
	2.5.21	OSI Ethernet Board Configuration (10 Base 5)	158
	2.5.22	Alarm LED Display (Red) in the Event of an Error	160
	2.5.23	Alarm LED (Red) Display in the Event of an Error Occurring	
		in the Connection Unit/Operator's Panel Connection Unit	161
2.6	LIST	Γ OF THE PCBS AND UNITS	163
	2.6.1	Control Unit Rack	163
	2.6.2	Power Supply Unit	164
	2.6.3	Control Unit PCB	164
	2.6.4	Back Panel PCB	165
	2.6.5	Module (For Main CPU Board)	166
	2.6.6	Module (For PMC/Conversational Board)	167
	2.6.7	Module (For Sub CPU Board, Additional Axis Board, or Axis CPU Board)	168
	2.6.8	Module (For RISC Board)	168

	2.6	5.9	Module (Option 1 Board)	169
	2.6	5.10	Module (OSI Ethernet Board)	169
	2.6	5.11	Display Unit	170
	2.6	5.12	External Control Unit (Except I/O Unit)	173
	2.7	HOW	V TO REPLACE THE MODULES	176
	2.7	7.1	Removing	176
	2.7	7.2	Insertion	176
	2.8	HOW	V TO REPLACE THE BATTERIES	177
	2.8	8.1	Replace the Battery for Memory Back Up	177
	2.8	3.2	Replacing Batteries for Separate Absolute Pulse Coder	178
	2.9	HOW	V TO REPLACE FAN MOTOR	179
	2.10	FUSI	E REPLACEMENT IN POWER SUPPLY UNIT	181
	2.11	MAI	NTENANCE OF HEAT PIPE TYPE HEAT EXCHANGER	182
	2.12	ADЛ	USTING THE LIQUID–CRYSTAL DISPLAYS	185
	2.1	2.1	9.5″ LCD	185
	2.1	2.2	10" LCD	185
	2.1	2.3	10" PDP	186
	2.1	2.4	9" PDP	186
	2.13	REPI	LACING THE FUSES OF THE LIQUID–CRYSTAL DISPLAYS	187
	2.1	3.1	9.5" LCD, 10.4" LCD (Graphic Function Built–in Type or for MMC–IV)	187
	2.1	3.2	10" LCD	187
	2.14	REPI	LACING THE LCD BACKLIGHT	188
	2.15	HOW	V TO REPLACE THE CRT DISPLAY	189
	2.16	HOW	V TO REPLACE THE MDI KEYBOARD	190
	2.17	HOW	V TO REPLACE THE CARD CAGE IN THE CONTROL UNIT	191
	2.18	HAN	IDLING MEMORY CARDS	192
	2.1	8.1	Overview	192
	2.1	8.2	Notes on Use	192
	2.1	8.3	Names and Functions of the Components	193
	2.1	8.4	Using Memory Cards	194
	2.1	8.5	Replacing the Battery	195
3. INP	UT AI	ND O	OUTPUT OF DATA	196
	3.1	SET	TING THE PARAMETERS REQUIRED FOR INPUT/OUTPUT	197
	3.2	DAT	A INPUT/OUTPUT	200
	3.2	2.1	Checking the Parameters Required for Data Input/Output	200
	3.2	2.2	Data Output	208
	3.2	2.2.1	CNC parameter output	208
	3.2	2.2.2	Outputting PMC parameter	208
	3.2	2.2.3	Pitch error compensation data output	212
	3.2	2.2.4	Custom macro variable value output	212
	3.2	2.2.5	Tool offset data output	213
	3.2	2.2.6	Part program output	213
	3.2	2.3	Data Input	214
	3.2	2.3.1	CNC parameter input	214
	3.2	2.3.2	Inputting CNC parameter	214
	3.2	2.3.3	Inputting PMC data	216

	3.2	.3.4	Pitch error compensation data input	218
	3.2	.3.5	Custom macro variable value input	218
	3.2	.3.6	Tool offset data input	219
	3.2	.3.7	Part program registration	220
	3.2	.4	15–MFB Data Input/Output	222
	3.2	.4.1	Conversational data input/output	222
	3.2	.4.2	Conversational data input	222
	3.2	.4.3	Conversational data output	223
4. IN1	<b>TERFA</b>	CE E	BETWEEN NC AND PMC	224
	4.1	GEN	ERAL OF INTERFACE	225
	4.2	SPE	CIFICATION OF PMC	226
	4.2	.1	Specification	226
	4.2	.2	Address	227
	4.2	.3	Built-in Debug Function	228
	4.2	.4	System Reserve Area in Internal Relay	228
	4.2	.5	Execution Period of PMC	229
	4.3	PMC	SYSTEM CONFIGURATION	230
	4.4	PMC	SCREEN	231
	4.4	.1	Display Method	231
	4.4	.2	PMCLAD Screen	233
	4.4	.3	PMCDGN Screen	237
	4.4	.4	PMCRAM Screen	245
	4.5	SIGN	VAL AND SYMBOL CORRESPONDENCE TABLE	253
5. TR	OUBL	ESH	OOTING	270
5. TR	<b>OUBL</b> 5.1	ESH COR	OOTING	233 270
5. TR	<b>OUBL</b> 5.1 5.1	ESH COR .1	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred	270 271 271
5. TR	5.1 5.1 5.2	ESH COR .1 POW	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred //ER CANNOT BE TURNED ON	270 271 271 273
5. TR	<b>OUBL</b> 5.1 5.2 5.3	ESH COR .1 POW NO I	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred /ER CANNOT BE TURNED ON	270 271 271 273 276
5. TR	<b>OUBL</b> I 5.1 5.2 5.3 5.4	ESH COR .1 POW NO I JOG	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred RE CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE	270 271 271 273 276 281
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5	ESH COR .1 POW NO N JOG HAN	OOTING RECTIVE ACTION FOR FAILURES	270 271 271 273 276 281 285
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6	ESH COR .1 POW NO N JOG HAN AUT	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred /ER CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE DDLE OPERATION CANNOT BE DONE OMATIC OPERATION CANNOT BE DONE	270 271 271 273 273 276 281 285 288
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7	ESH COR .1 POW NO I JOG HAN AUT CYC	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred VER CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE DLE OPERATION CANNOT BE DONE OMATIC OPERATION CANNOT BE DONE CHE START LED SIGNAL HAS TURNED OFF	270           271           273           276           281           285           288           295
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8	ESH COR .1 POW NO N JOG HAN AUT CYC NOT	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred /ER CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE DDLE OPERATION CANNOT BE DONE OMATIC OPERATION CANNOT BE DONE COMATIC OPERATION CANNOT BE DONE CILE START LED SIGNAL HAS TURNED OFF HING IS DISPLAYED ON CRT	270          271          271          273          276          281          285          285          295          297
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred /ER CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE DULE OPERATION CANNOT BE DONE OMATIC OPERATION CANNOT BE DONE LE START LED SIGNAL HAS TURNED OFF HING IS DISPLAYED ON CRT O5 TO SR874 (RELATED TO READER/PUNCH INTERFACE)	270            271            271            273            273            276            281            285            288            297            297            298
5. TR	5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10	ESH COR .1 POW NO N JOG HAN AUT CYC NOT SR80 REF	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred /ER CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE DDLE OPERATION CANNOT BE DONE COMATIC OPERATION CANNOT BE DONE CLE START LED SIGNAL HAS TURNED OFF HING IS DISPLAYED ON CRT D5 TO SR874 (RELATED TO READER/PUNCH INTERFACE) ERENCE POSITION DEVIATES	270           271           271           271           271           271           273           276           281           285           288           295           297           298           310
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred /ER CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE DOPERATION CANNOT BE DONE COMATIC OPERATION COM SI STALLED COMATIC OPERATION COM SI STALLED COMATIC OPERATION CANNOT BE DONE COMATIC OPERATION DEVIATES COM SINCH COM SI STALLED COM SINCH COM	270           271           271           271           273           273           276           281           285           285           285           285           285           285           295           297           298           310           311
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA	OOTING RECTIVE ACTION FOR FAILURES Investigating the Conditions under which Failure Occurred /ER CANNOT BE TURNED ON MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED OPERATION CANNOT BE DONE DLE OPERATION CANNOT BE DONE COMATIC OPERATION CANNOT BE DONE CLE START LED SIGNAL HAS TURNED OFF HING IS DISPLAYED ON CRT D5 TO SR874 (RELATED TO READER/PUNCH INTERFACE) ERENCE POSITION DEVIATES (0) (GRID SYNCHRONOUS IS FAILED) RM OT32 (NEED ZRN (ABS PDR))	270           271           271           271           271           273           276           281           285           285           285           285           295           297           298           310           311           314
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA	<b>OOTING</b> RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         /ER CANNOT BE TURNED ON         MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         OMATIC OPERATION CANNOT BE DONE         'E START LED SIGNAL HAS TURNED OFF         'HING IS DISPLAYED ON CRT         'D5 TO SR874 (RELATED TO READER/PUNCH INTERFACE)         ERENCE POSITION DEVIATES         '00 (GRID SYNCHRONOUS IS FAILED)         RM OT32 (NEED ZRN (ABS PDR))         RM SV101 (DATA ERROR (ABS PCDR))	270           271           271           271           271           271           271           271           271           271           271           271           271           271           273           273           275           285           295           297           298           310           311           314           315
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA	<b>OOTING</b> RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         /ER CANNOT BE TURNED ON         MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         OMATIC OPERATION CANNOT BE DONE         'CMATIC OPERATION CANNOT BE DONE         'DE START LED SIGNAL HAS TURNED OFF         'HING IS DISPLAYED ON CRT         'D5 TO SR874 (RELATED TO READER/PUNCH INTERFACE)         ERENCE POSITION DEVIATES         'O' (GRID SYNCHRONOUS IS FAILED)         RM OT32 (NEED ZRN (ABS PDR))         RM SV101 (DATA ERROR (ABS PCDR))         RM OT34 (BATTERY ZERO (ABS PCDR))	270            271            271            271            273            273            273            276            285            285            285            295            297            298            310
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14 5.15	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA ALA	<b>OOTING</b> RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         /ER CANNOT BE TURNED ON         MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         OMATIC OPERATION CANNOT BE DONE         OMATIC OPERATION CANNOT BE DONE         OMATIC OPERATION CANNOT BE DONE         'DLE START LED SIGNAL HAS TURNED OFF         'HING IS DISPLAYED ON CRT         'D5 TO SR874 (RELATED TO READER/PUNCH INTERFACE)         ERENCE POSITION DEVIATES         '00 (GRID SYNCHRONOUS IS FAILED)         RM OT32 (NEED ZRN (ABS PDR))         RM SV101 (DATA ERROR (ABS PCDR))         RM OT34 (BATTERY ZERO (ABS PCDR))         RM SV110 (PULSE CODER ALARM1 (SERIAL))	270           271           271           271           271           271           271           271           271           271           271           271           271           271           273           273           275           285           295           297           298           310           311           314           315           316           317
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14 5.15 5.16	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA ALA ALA	<b>OOTING</b> RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         /ER CANNOT BE TURNED ON         /MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         'OMATIC OPERATION CANNOT BE DONE         'HING IS DISPLAYED ON CRT         'ST TO SR874 (RELATED TO READER/PUNCH INTERFACE)         ERENCE POSITION DEVIATES         'O' (GRID SYNCHRONOUS IS FAILED)         'RM OT32 (NEED ZRN (ABS PDR))         'RM SV101 (DATA ERROR (ABS PCDR))         'RM S	270           271           271           271           271           271           271           271           271           271           271           271           271           271           271           273           275           285           285           285           285           285           295           297           298           310           311           314           315           316           317           317
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14 5.15 5.16 5.17	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA ALA ALA	<b>OOTING</b> RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         /ER CANNOT BE TURNED ON         MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         'OMATIC OPERATION CANNOT BE DONE         'ON START LED SIGNAL HAS TURNED OFF         'HING IS DISPLAYED ON CRT         'S TO SR874 (RELATED TO READER/PUNCH INTERFACE)         ERENCE POSITION DEVIATES         '0 (GRID SYNCHRONOUS IS FAILED)         'RM OT32 (NEED ZRN (ABS PDR))         'RM SV101 (DATA ERROR (ABS PCDR))         'RM S	270            271            271            273            273            273            276            285            285            285            297            297            310            311            314            316            317            318
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14 5.15 5.16 5.17 5.18	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA ALA ALA ALA	<b>OOTING</b> RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         /ER CANNOT BE TURNED ON         MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         'OMATIC OPERATION CANNOT BE DONE         'OBSTART LED SIGNAL HAS TURNED OFF         'HING IS DISPLAYED ON CRT         'D'S TO SR874 (RELATED TO READER/PUNCH INTERFACE)         ERENCE POSITION DEVIATES         'O' (GRID SYNCHRONOUS IS FAILED)         RM OT32 (NEED ZRN (ABS PDR))         RM SV101 (DATA ERROR (ABS PCDR))         RM OT34 (BATTERY ZERO (ABS PCDR))         RM SV110 (PULSE CODER ALARM1 (SERIAL))         RM SV114 (ABNORMAL REV DATA)         RM SV115 (ABNORMAL COMMUNICATION (SERIAL PCDR))         RM SV23 (SV OVER LOAD)	270           271           271           271           271           271           271           271           271           271           271           271           271           271           273           273           275           285           295           297           298           310           311           314           315           316           317           318           319
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14 5.15 5.16 5.17 5.18 5.19	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA ALA ALA ALA ALA	<b>OOTING</b> RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         VER CANNOT BE TURNED ON         MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         OMATIC OPERATION CANNOT BE DONE         OMATIC OPERATION CANNOT BE DONE         'EL START LED SIGNAL HAS TURNED OFF         'HING IS DISPLAYED ON CRT         'D5 TO SR874 (RELATED TO READER/PUNCH INTERFACE)         ERENCE POSITION DEVIATES         '00 (GRID SYNCHRONOUS IS FAILED)         RM OT32 (NEED ZRN (ABS PDR))         RM SV101 (DATA ERROR (ABS PCDR))         RM SV110 (PULSE CODER ALARM1 (SERIAL))         RM SV114 (ABNORMAL REV DATA)         RM SV115 (ABNORMAL COMMUNICATION (SERIAL PCDR))         RM SV23 (SV OVER LOAD)         RM 700 (OVERHEAT AT CONTROL SIDE)	270          271          271          271          271          273          273          273          276          285          285          285          295          297          298          310          311          311
5. TR	<b>OUBL</b> 5.1 5.2 5.3 5.4 5.5 5.6 5.7 5.8 5.9 5.10 5.11 5.12 5.13 5.14 5.15 5.16 5.17 5.18 5.19 5.20	ESH COR .1 POW NO I JOG HAN AUT CYC NOT SR80 REF PS20 ALA ALA ALA ALA ALA ALA ALA	OOTING         RECTIVE ACTION FOR FAILURES         Investigating the Conditions under which Failure Occurred         /ER CANNOT BE TURNED ON         MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED         OPERATION CANNOT BE DONE         IDLE OPERATION CANNOT BE DONE         'OMATIC OPERATION CANNOT BE DONE         'ONATIC OPERATION CANNOT BE DONE         'BONG SIGNAL HAS TURNED OFF         'HING IS DISPLAYED ON CRT         'BONG SIGNAL HAS TURNED OFF         'HING SUPPLAYED (DETECTION (ABS PCDR))         'RM SV110 (DULSE CODER ALARM1 (SERIAL))         'RM SV110 (PULSE CODER ALARM1 (SERIAL))         'RM SV114 (ABNORMAL REV DATA)         'RM SV1	270          271          271          273          273          276          276          285          285          288          297          310          311          314          315          316          317          318          321          322

# APPENDIX

A. MAINTER	NANCE PARTS	329
A.1	MAINTENANCE PARTS FOR THE FANUC Series 15–B	330
B. BOOT S	YSTEM	335
B.1	OVERVIEW	336
B.1	.1.1 Power-up Processing Sequence Display	336
B.1	1.2 Starting the Boot System	337
B.1	1.3   System File and User File	338
B.1	1.4 Memory Cards for Use with the Boot System	340
B.2	SCREEN CONFIGURATION AND OPERATING PROCEDURE	341
B.2	2.1 SYSTEM DATA LOADING Screen	342
B.2	2.2 SYSTEM DATA CHECK Screen	344
B.2	2.3 SYSTEM DATA SAVE Screen	347
B.2	2.4 SRAM DATA BACKUP Screen	348
B.2	2.5 MEMORY CARD FORMAT Function	353
B.2	2.6 LOAD BASIC SYSTEM	354
B.3	ERROR MESSAGES AND REQUIRED COUNTERMEASURES	355
B.4	SYSTEM ALARMS AND REQUIRED COUNTERMEASURES	357
C. ERROR	CODE TABLE	363
C.1	ALARM LIST (CNC)	364
C.2	ALARM LIST (PMC)	383
C.3	PMC ERRORS	388
D. WARNIN	IG MESSAGE LIST	395

#### PREFACE

# Description of this manual

This manual is organized as described below.

#### 1. CRT/MDI display and operation

This chapter covers those items, displayed on the screen, that are related to maintenance. A list of all supported operations is also provided at the end of this chapter.

#### 2. Hardware

This chapter covers hardware–related items, including the hardware configuration, connection, and NC status indicated on printed circuit boards. A list of all units is also provided as well as an explanation of how to replace each unit.

#### 3. Data input/output

This chapter describes the input/output of data, including programs, parameters, and tool compensation data, aswell as the input/output procedures for conversational data.

#### 4. Interface between the NC and PMC

This chapter describes the PMC specifications, the system configuration, and the signals used by the PMC.

#### 5. Trouble shooting

This chapter describes the procedures to be followed in the event of certain problems occurring, for example, if the power cannot be turned on or if manual operation cannot be performed. Countermeasures to be applied in the event of alarms being output are also described.

#### APPENDIX

The appendix consists of a list of all alarms, a list of maintenance parts, and boot system.

This manual does not provide a parameter list. If necessary, refer to the separate PARAMETER MANUAL (B-62560E).

The maintenance of the servo unit, spindle motor, and amplifier is not covered by this manual. For information related to the maintenance of these units, refer to the relevant manuals.

This manual describes all optional functions. Refer to the manual provided by the machine tool builder for details of any options with which the installed machine tool is provided.

Depending on the model, some functions described in this manual may not be available. For details, refer to the relevant descriptions.

#### Applicable models

This manual can be used with the following models. The abbreviated names may be used.

Product Name Abbreviations			าร
FANUC Series 15–TB	15–TB	15–T 15–M	
FANUC Series 15–TFB	15–TFB		
FANUC Series 15TED-MODEL B-4 (*1)	15TED		
FANUC Series 15TEE-MODEL B-4 (*1)	15TEE		
FANUC Series 15TEF-MODEL B-4 (*1)	15TEF		
FANUC Series 15–MB	15–MB		Series 15
FANUC Series 15–MFB	15–MFB		
FANUC Series 15MEK-MODEL B-4 (*1)	15MEK		
FANUC Series 15MEL-MODEL B-4 (*1)	15MEL		
FANUC Series 15–TTB	15–TTB	15 TT	
FANUC Series 15–TTFB	15–TTFB	15-11	
FANUC Series 150–TB	150–TB	150–T	
FANUC Series 150-TTB	150–TTB	150–TT	Series 150
FANUC Series 150–MB	150–MB	150–M	

(\*1) With 15TED, 15TEE, and 15TEF, some options are not available. Moreover, the following PC boards cannot be used:

- Sub–CPU board
- RISC board
- OSI ethernet board

(\*2) The MMC board can be used only with the Series 150.

#### Series of CNC

Product Name	Series		
FANUC Series 15–TB			
FANUC Series 15–TFB			
FANUC Series 15TED-MODEL B-4		T series	
FANUC Series 15TEE-MODEL B-4			
FANUC Series 15TEF-MODEL B-4			For Lathe
FANUC Series 150–TB			
FANUC Series 15–TTB			
FANUC Series 15–TTFB	TT series		
FANUC Series 150–TTB			
FANUC Series 15–MB			
FANUC Series 15–MFB	M series		
FANUC Series 15MEK–MODEL B–4			For Machining center
FANUC Series 15MEL-MODEL B-4			
FANUC Series 150–MB			

#### B-62075E/04

#### Manuals related to Series 15/150–MODEL B

Manuals related to FANUC Series 15/150–MODEL B are as follows. This manual is marked with an asterisk (\*).

#### List of manuals related to Series 15/150-MODEL B

Manual Name	Specification Number	
FANUC Series 15–TB/TFB/TTB/TTFB DESCRIPTIONS	B-62072E	
FANUC Series 15/150–MODEL B For Machining Center DESCRIPTIONS	B-62082E	
FANUC Series 15/150–MODEL B CONNECTION MANUAL	B-62073E	
FANUC Series 15/150–MODEL B CONNECTION MANUAL (BMI Interface)	B-62073E-1	
FANUC Series 15–MODEL B For Lathe OPERATOR'S MANUAL (Programming)	B-62554E	
FANUC Series 15–MODEL B For Lathe OPERATOR'S MANUAL (Operation)	B-62554E-1	
FANUC Series 15/150–MODEL B For Machining Center OPERATOR'S MANUAL (Programming)	B-62564E	
FANUC Series 15/150–MODEL B For Machining Center OPERATOR'S MANUAL (Operation)	B-62564E-1	
FANUC Series 15/150–MODEL B PARAMETER MANUAL	B-62560E	
FANUC Series 15/150–MODEL B MAINTENANCE MANUAL	B-62075E	*
FANUC Series 15–MODEL B DESCRIPTIONS (Supplement for Remote Buffer)	B-62072E-1	
FANUC Series 15–MODEL B PROGRAMMING MANUAL (Macro Compiler / Macro Executer)	B-62073E-2	
PMC		
FANUC PMC-MODEL N/NA PROGRAMMING MANUAL (Ladder Language)	B-61013E	
FANUC PMC-MODEL NB/NB2 PROGRAMMING MANUAL (Ladder Language)	B-61863E	
FANUC PMC–MODEL N/NA PROGRAMMING MANUAL (C Language)	B-61013E-2	
FANUC PMC-MODEL NB PROGRAMMING MANUAL (C Language)	B-61863E-1	
FANUC PMC–MODEL N/NA PROGRAMMING MANUAL (C Language – Tool Management Library)	B-61013E-4	
Conversational Automatic Programming Function		
CONVERSATIONAL AUTOMATIC PROGRAMMING FUNCTION FOR MACHINING CENTER (Series 15–MF/MFB) PROGRAMMING MANUAL	B-61263E	
CONVERSATIONAL AUTOMATIC PROGRAMMING FUNCTION FOR MACHINING CENTER (Series 15–MF/MFB) OPERATOR'S MANUAL	B–61264E	
CONVERSATIONAL AUTOMATIC PROGRAMMING FUNCTION FOR LATHE (Series 15–TF/TTF/TFB/TTFB) OPERATOR'S MANUAL	B-61234E	
CONVERSATIONAL AUTOMATIC PROGRAMMING FUNCTION II FOR LATHE (Series 15–TFB/TTFB) OPERATOR'S MANUAL	B-61804E-2	
Tracing / Digitizing	1	
FANUC Series 15–MB DESCRIPTIONS (Supplement for Tracing / Digitizing)	B-62472E	
FANUC Series 15–MB CONNECTION MANUAL (Supplement for Tracing / Digitizing)	B-62473E	
FANUC Series 15–MB OPERATOR'S MANUAL (Supplement for Tracing / Digitizing)	B-62474E	
Gas, Laser Plasma Cutting Machine		
FANUC Series 15–MB DESCRIPTIONS (FOR GAS, LASER PLASMA CUTTING MACHINE)	B-62082EN-1	
Multi-Teaching Function		
FANUC Series 15–MB CONNECTION MANUAL (Multi–Teaching Function)	B-62083E-1	
Multiple-axis and Multiple-path Control Function		
FANUC Series 15–TTB OPERATOR'S MANUAL (Supplement Explanations for Multiple–axis and Multiple–path Control Function)	B-62074E-1	

# OPERATION OF MDI PANEL

This chapter describes how to display and operate each screen, and so forth.

1.1	OPERATION OF MDI PANEL 2
1.2	DISPLAYING SYSTEM CONFIGURATIONS
1.3	ALARM HISTORY DISPLAY 13
1.4	HELP FUNCTION 15
1.5	DIAGNOSIS FUNCTION 19
1.6	NC STATUS DISPLAY 28
1.7	WAVEFORM DIAGNOSIS FUNCTION 30
1.8	OPERATING MONITOR SCREEN 35
1.9	INTERNAL POSITION COMPENSATION DATA
	DISPLAY FUNCTION
1.10	OPERATION HISTORY 41
1.11	OPERATION LIST

## 1.1 OPERATION OF MDI PANEL

1.1.1 Screen Transition Chart







Screens included in PRG_CHK
PROGRAM CHECK SCREEN PROGRAM (LAST BLOCK) PROGRAM (CURRENT BLOCK) PROGRAM (CURRENT BLOCK) PROGRAM (CURRENT BLOCK)
COMMAND SCREEN
[CUT_CMF][TLC_OFS][CAN_CYL][ROTATON][3DM_CNV]
CUTTER     TOOL     CANNED     COORDI-     3-DIMENSION-       COM-     LENGTH     CYCLE     NATE SYS-     AL COORDI-       PENSA-     COM-     SCREEN     SCREEN     TEM ROTA-     NATE SYSTEM       TION     PENSATION     SCREEN     SCREEN     SCREEN     SCREEN
INTERNAL POSITION COMPENSATION DATA DISPLAY
[PRG_MRR][SCALING][3DM_OFS][ ][CHPTER]
$\bigcirc$ $\bigcirc$ $\bigcirc$
PROGRAM MIRROR SCREEN SCREEN SCREEN SCREEN SCREEN SCREEN

Screens indluded in SETTING	
SETTING	
SETTING SCREEN	
SETTING (INPUT/ OUTPU) UTPU) (INPUT/ OUTPU) SETTING (GENER- AL) PANEL) SETTING (MACRO VARI- ABLE)	
SETTING SCREEN	
TOOL LIFE MANAGE- MENT	
SETTING SCREEN	
[ TIMER ] [ ] [RS232C ] [ ] [CHAPTER]     Image: Setting (TIMER)     Setting (TIMER)     Setting (Setting RS-232-C)	

Screens included in SERVICE
SERVICE SCREEN
PARAME- TER SCREEN SCREEN DIAGNO- SIS SCREEN DIAGNO- DIAGNO- DIAGNO- DIAGNO- DISPLAY
SERVICE SCREEN
[ ][SYSTEM][ ][WAV- ][CHAPTER]
SYSTEM STRUC- TURE SCREEN
SERVICE SCREEN
[ ][SERVO][SPINDLE][HPCC ][CHAPTER]
SERVO SETTING AND AD- JUSTING SCREEN SCREEN SCREEN

Screens included in MESSAGE
MESSAGE
MESSAGE SCREEN
[ALARM][OPERATOR][ ][ ][CHAPTER]
ALARM SCREEN DERATOR MESSAGE SCREEN





#### 1.2 DISPLAYING SYSTEM CONFIGURATIONS

The software and hardware configuration of the CNC unit can be displayed on the CRT display. This feature allows you to easily obtain hardware or software information necessary, for example, when maintaining the CNC.

### 1.2.1 Displaying Method

(1) Press the service key or [SERVICE] soft key to display screens such as parameter screens.

(2) Press the [SYSTEM] soft key.

(3) Press the page keys (  $\bigcap_{PAGE} PAGE$  ) to switch the screen.

### 1.2.2 Software Information

			)
	SYSTEM CONFIG	(SOFTWARE)	01234 N12345
	CNC SYSTEM ID	: SERIES /	EDITION
	<u>FI5M9A (I)</u>	: <u>AABI (2</u> )	<u>    0001 (3)</u>
	ASSEMBLY	EDITION DR.	AM SIZE
	BASIC (4)	0001 (5)	8MBYTE (6)
	OPTION A1	0001	
	OPTION A2	0001	
	OPTION A3	0001 MACH	IINE NAME
	OPTION A4	<u>AB</u>	CDEFGHIJ (7)
	BASIC (SUB)	0001	
	OPTION S1		
	MEM *** STOP **	*** *** *** 01 :	23:45 LSK
	SYSTEM		CHAPTER+
•			/

- (1) CNC system ID
- (2) CNC control software series
- (3) CNC control software general edition
- (4) Assemblies providing CNC control software
- (5) Edition of each assembly
  - (A dash indicates that the assembly is not used.)
- (6) DRAM size of CNC
- (7) Machine name
  - (displayed only when set in parameter No.2390 to 2399)

SYSTEM CONFIG (	SOFTW	ARE)	012	34 N12345	
SOFTWARE KIND	:	SERIES	/	EDITION	
HELP MESSAGE ()	<u>L)</u> :	AH00 (2	)/	0001 (3)	
SYSTEM BOOT	:	6014	/	0005	
DIGITAL SERVO	:	9060	/	0005	
SERIAL SPDL #1	:	9A20	/	0008	
SERIAL SPDL #2	:	9A20	/	0008	
PMC - NA	:	4046	/	0005	
GRAPHIC	:	6001	/	0003	
RMT BUF / DNC1	:	609A	/	0004	
MEM *** STOP *** SYSTEM	** ***	*** 01	: 23	: 45 LSK CHAPTER	+

- (1) Software type
- (2) Software series
- (3) Software edition



(2) Type of printed-circuit board

\_\_\_\_\_10 \_\_\_\_

(3) ID numb	ber
<u>XXXX</u> : X	X
	<ul> <li>Module ID XX3F : Remote buffer mode</li> <li>(See Section XX45 : Graphic CPU board</li> <li>2.6 for details.)XX62 : Main CPU board (high–speed)</li> <li>XX63 : Additional axis/sub–CPU board</li> <li>XX6B : PMC–NB board</li> <li>XX6C : FAPT/IAP CPU board</li> <li>XX71 : Main CPU board (standard)</li> <li>XX74 : ROM cassette adapter</li> <li>XX77 : PMC–NA board</li> </ul>
	Software ID 37 : CNC CPU 39 : NON CPU SUB 3A : SUB CPU 3C : RMT–BUF/DNC1 3D : PMC–NA CPU 40 : Graphic CPU 41 : ROM cassette adapter 42 : PMC–NB CPU 44 : DNC1 #2 45 : FAPT CPU 4C : TC CPU 4D : IAP CPU

(4) Series and edition of software (displayed only for modules featuring a CPU)

#### 1.2.4 Module Information

	SYSTEM CONFIG (SLOT) 01234 N12345
(1)	CMC MAIN CPU BOARD
	MODULE Remark
(2)	PROGRAM MEMORY (FROM) : 6MBYTE3.
	MAIN MEMORY (DRAM) : 4MBYTE
	MAIN MEMORY (SRAM) : TYPE A
	TAPE MEMORY (FILE) : 512KBYTE
	PERIPHERAL MODULE :
	CHARACTER CONTROL : 9"CRT
	SPINDLE CONTROL : SERIAL, HI-DI
	SERVO CONTROL 1/2 : DIGITAL
	SERVO CONTROL 3/4 : DIGITAL
	MEM *** STOP **** *** *** 01 : 23 : 45 LSK
	SYSTEM CHAPTER+

(1) Name of printed-circuit board

Module information is displayed for the following printed–circuit boards (if mounted):

- 1 CNC main CPU board
- 3 Additional axis board 1
- 5 PMC–NA CPU board
- 7 Graphic CPU board
- 9 DNC1 CPU board
- 11 RISC CPU board
- 13 MMC–II graphic CPU board
- 15 Axis CPU board (multiaxis)

- 2 CNC sub–CPU board
- 4 Additional axis board 2
- 6 PMC–NB CPU board
- 8 Remote buffer/DNC2 board
- 10 CAP/FAPT CPU board
- 12 MMC-II main CPU board
- 14 MMC-III main CPU board

(2) Module name

The names of the modules mounted on the printed-circuit board, if any, are displayed.

(3) Module type

The type of each module is displayed if there are two or more types of a certain module, such as types having different capacities. A dash is displayed for those modules for which there is only a single type.

## 1.3 ALARM HISTORY DISPLAY

#### 1.3.1 Display Method

(1) Press the [HISTRY] soft key.

(2) Press the [ALM\_HIS] soft key. Then, the alarm history screen appears.

(3) Other screens can be displayed by using the page keys



### 1.3.2 Alarm History Screen

/		
	ALARM HISTORY 00000 N00001	
	SW000 PARAMETER ENABLE SWITCH ON	
	96/08/26 12:35:26	
	OT007 X + OVERTRAVEL(HARD)	
	96/08/27 08:40:18	
	0T008 X - OVERTRAVEL(HARD)	
	96/08/27 08:40:18	
	PW000 POWER MUST BE OFF	
	96/08/27 08:45:32	
	MC001	
	96/08/28 09:20:50	
	MDI *** STOP **** *** *** 00:00:00 ***	
	CHAPTER	
5		/

1.3.3 Display Format of History Data

#### History data items are displayed as follows: OT 007 X + overtravel (hard limit) Message text Axis for which the alarm occurred Alarm number Alarm type

On the 14–inch CRT display, the date and time of alarm occurrence and alarm history data are displayed in this order on a line. On the 9–inch CRT display, the date and time of alarm occurrence is displayed over two lines under the alarm history data.

#### NOTE

- 1 No message text is displayed for EX and MC alarms.
- 2 When the values of parameter 1020 and 1021 are different from those when an alarm occurred, no correct axis data is not displayed.

1.3.4 Restrictions	(1) The operation history function does not collect history data items while the OPERATION HISTORY screen is being displayed.
	(2) While the OPERATION HISTORY screen is being displayed, the operation history function does not collect history data items even when the OPERATION HISTORY screen is changed to the PMC screen. This is because it is still assumed that the OPERATION HISTORY screen is being displayed.
	(3) Approx. 2040 <mdi> key history data items can be recorded in memory as history data. When memory is full, older data items are deleted first.</mdi>
	(4) Specify the correct date and time on the setting screen.
	(5) The number of signal addresses specified on the SELECT DI/DO screen affects the processing speed during automatic operation. Specify only the required signal addresses.

#### — 14 —

# 1.4 HELP FUNCTION

1.4.1 General	The help function displays detailed information about the alarm state of the CNC unit and soft key operations in a window on the CRT screen.		
1.4.2 Operation			
<ul> <li>Displaying and clearing the help window</li> </ul>	While the CNC screen is displayed, press the $HELP$ key $(SHIFT + EOB)$ to		
	display the help window. To clear the help window, press the $HELP$ key		
	again or select "9.CLOSE HELP WINDOW" from the help initial menu. (The help window cannot be called from the PMC screen, MMC screen, or conversational macro screen.)		
<ul> <li>Help initial menu</li> </ul>	To display the help initial menu, press the $HELP$ key while no alarm is		
	being issued.		
	HELP INITIAL MENU		
	I.ALARM 2.SOFT KEY		
	9.CLOSE HELP WINDOW		
	HELP ROM SER.:AH00 EDT:01		



(SELECT BY CURSOR & PUSH INPUT KEY)

#### Alarm help

Select "1.ALARM" from the help initial menu to display alarm help information (alarm selection/alarm details).



Fig. 1.4.2 (b) Sample alarm selection display (14-inch CRT)



Fig. 1.4.2 (c) Sample detailed alarm display (14-inch CRT)
#### Soft key help

Select "2.SOFT KEY" from the help initial menu to display soft key help information (soft key selection/soft key details).

SOFTKEY	SELECT:	ION		
NO.1 POSITI ON	NO.2 PROGRA M	NO.3 OFFSET	NO.4 PRGRAM CHECK	NO.5 SETTIN G
NO.6 SERVIC E	NO.7 MESSAG E	NO.8 GRAPHI C	NO.9	NO.10 CHAPTE R
KEY STA	ATUS :	FUNCTION	I SELECT	ION
REVER CURR	SE DISPI ENTLY SE	AYED KEY	IS FUNCTION	

Fig. 1.4.2 (d) Sample soft key selection display (14-inch CRT)



Fig. 1.4.2 (e) Sample detailed soft key display (14-inch CRT)

# • Using the help function in the alarm state

Press the HELP key when the CNC is placed in the alarm state. Then, help information (alarm details/alarm list) relating to the currently issued alarm is displayed.



Fig. 1.4.2 (f) Sample detailed alarm display (14–inch CRT) in the alarm state

1.ALARM	
CURRENT ALARM LIST	
<b>PS010</b> OT008	
-(select by cursor & push input key) $\Box$	



## 1.5 DIAGNOSIS FUNCTION

## 1.5.1

Displaying the Diagnosis Screen

(2) Press the [DIAGNOS] soft key. Then, the diagnosis screen is displayed.

(1) Press the SERVICE

key.

### 1.5.2 Displaying the Status when it Appears that a Command is not being Executed

 Displaying the status of the PMC interface signals

The status of the interface signals (F and G) between the PMC and CNC can be displayed as the CNC internal status. The following table lists the correspondence between the numbers of this diagnostic data and address numbers (F000 and after and G000 and after).

	Output from the CNC (G000 and after)	Input to the CNC (F000 and after)
For the BMI interface	Diagnostic numbers 0 and after	Diagnostic numbers 200 and after
For the FS3/6 inter- face	Diagnostic numbers 400 and after	Diagnostic numbers 500 and after

For example, data passed to the PMC through address G010 by the CNC is displayed as diagnostic data with number 10 (for the BMI interface) or number 410 (for the FS3/6 interface). For the interface signals, see Sec.4.5.

For details of each signal, refer to the corresponding interface connection manual.

#### • Displaying the status when it appears that a command is not being executed

Number	Bit	Display	Internal status when 1 is displayed
1000	0	INPOSITION CHECK	The position is being checked.
	1	FEED RATE OVERRIDE	The feedrate override is 0%.
	2	JOG FEED OVERRIDE	The jog feedrate override is 0%.
	3	INT./START LOCK ON	The start lock or interlock is on.
	4	SPEED ARRIVAL CHECK	The CNC is waiting for the speed–attained signal to be turned on.
	5	WAIT REVOLUTION	The CNC is waiting for the signal indicating that the spindle rotates once during threading.
	6	STOP POSITION CODER	The CNC is waiting for the position coder to rotate dur- ing spindle feed per rotation.
	7	FOREGROUND READING	The CNC is reading the tape in the foreground.
1001	0	BACKGROUND READING	The CNC is reading the tape in the background.

#### Displaying the start disable status

The details of the start disable status are displayed.

If a bit is on, correct the error and start the machine.

When the operator starts the machine, the bit is cleared. Only one of the following bits is on at the same time. If there are two or more causes, only the bit corresponding to the last cause is on.

	#15	#14	#13	#12	#11	#10	#9	#8
1005								
	#7	#6	#5	#4	#3	#2	#1	#0
1006								

The bits indicate the following status when 1 is displayed for them:

- #0 The automatic operation stop signal (\*SP) is low.
- **#1** An alarm occurred.
- **#2** The SRN or BRN signal is on.
- **#3** An attempt was made to execute the same program in the background.
- **#4** The device is not ready in the tape mode.
- **#5** MDI execution data remains.
- **#6** The tool retraction signal (TRESC) is on. Alternatively, the machine is not at the position when the tool retraction signal was input.
- **#7** The status does not permit the program to be executed in reverse.
- **#8** The status of a DI or DO signal is invalid for a manual numerical command.(Note1)
- **#9** The status of a DI or DO signal is invalid for repositioning.(Note2)

- **#10** Other than the above(Note3)
- **#11** Not used.

#### NOTE

- The DO DEN or IPEN signal is high. Constant surface speed control is being executed. The status of the DI HEAD1/2 signal is invalid in the MDI mode. (Only for the Series 15–TT)
- 2 The DO OP signal is low for return operation.The DI MLK signal is on.The DO STL signal is on.
- 3 The system enters the start lock state during tracing.A tool is being retracted in the hobbing machine.On the bed grinder, an alarm is issued or the DI MLK signal is on.

The axis to be retracted in the jog mode is at a position at which starting is disabled.

• Displaying the type of an alarm

The type of the alarm issued is displayed.

When the alarm status is released, the corresponding bit is set to 0.

	#15	#14	#13	#12	#11	#10	#9	#8
1007								
	#7	#6	#5	#4	#3	#2	#1	#0
1008								

Each bit indicates an alarm type when 1 is displayed for the bit as follows:

- **#0** Background P/S alarm
- #1 Foreground P/S alarm
- #2 Overheating
- **#3** Sub–CPU error
- #4 Excessive synchronous error
- **#5** Parameter writing switch on
- #6 Overtravel/external data input/output error
- **#7** PMC error
- **#8** External alarm message
- **#9** Not used.
- #10 Serious P/S
- #11 Not used.
- **#12** Servo alarm
- #13 I/O error
- **#14** Input of a parameter requiring power disconnection
- **#15** System error

 Displaying the warning status The warning status is displayed. When the warning status is released, the bit is set to 0.

	#7	#6	#5	#4	#3	#2	#1	#0
1009								

A bit indicates the following status when 1 is displayed for it.

- **#0** The system is in the warning state.
- **#1 to #7** Not used.
- **Displaying the reset** The reset status and the status of input signals related to feed hold are displayed.

	#7	#6	#5	#4	#3	#2	#1	#0
1010					RST	ERS	RRW	ESP

The bits indicate the following status when 1 is displayed for them:

- **ESP** The emergency stop status is indicated.
- **RRW** The reset and rewind signal is on.
- **ERS** The external reset signal is on.
- **RST** The reset key is pressed.
- Displaying the details of a TH alarm

#### The details of a TH alarm are displayed.

Number	Display	Description
1100	POSITION (CHARACTER) F	Location of the character for which a TH alarm is issued indicated as the number of characters from the beginning of the block (TH alarm in the foreground)
1101	BIT PATTERN (CHARACTER) F	Read code of the character for which a TH alarm is issued with a bit pattern (TH alarm in the foreground)
1110	POSITION (CHARACTER) B	Location of the character for which a TH alarm is issued indicated as the number of characters from the beginning of the block (TH alarm in the background)
1111	BIT PATTERN (CHARACTER) B	Read code of the character for which a TH alarm is issued with a bit pattern (TH alarm in the background)

The positional deviation of each axis is displayed.

Number	Display	Description
3000	X SERVO ERROR	Positional deviation along the X–axis in the detection unit
	Y SERVO ERROR	Positional deviation along the Y–axis in the detection unit
	Z SERVO ERROR	Positional deviation along the Z–axis in the detection unit
	:	
	:	

# • Displaying servo control information

#### Servo control information is displayed.

••••••••	
3010 to 3023	Servo control information for axis 1
3030 to 3043	Servo control information for axis 2
3050 to 3063	Servo control information for axis 3
3070 to 3083	Servo control information for axis 4
3090 to 3103	Servo control information for axis 5
3110 to 3123	Servo control information for axis 6
3130 to 3143	Servo control information for axis 7
3150 to 3163	Servo control information for axis 8
3170 to 3183	Servo control information for axis 9
3190 to 3203	Servo control information for axis 10
3210 to 3223	Servo control information for axis 11
3230 to 3243	Servo control information for axis 12
3250 to 3263	Servo control information for axis 13
3270 to 3283	Servo control information for axis 14
3290 to 3303	Servo control information for axis 15

 Checking a disconnection or overload alarm If a message indicating an overload alarm (SV 023) or disconnection alarm (SV 015) appears on the screen, check the diagnostic data to see if the data indicates an overload or disconnection alarm. The number of the diagnostic data is 3014 for axis 1, 3034 for axis 2, 3054 for axis 3, and the start number + 4 for other axes.

3024 OVL LVAL OVC	HCAL	HVAL	DCAL	FBAL	OFAL

When an overload alarm is issued: #7 = 1

When a disconnection alarm is issued: #1 = 1

Then check the diagnostic data to determine the cause of the alarm. The number of the diagnostic data is 3015 for axis 1, 3035 for axis 2, 3055 for axis 3, and the start number + 5 for other axes.

Check bits 7 and 4 at the address to determine the cause of the alarm by consulting the following table.

	#7	#6	#5	#4	#3	#2	#1	#0	
3025	ALDF			EXPC					
		Cause of the alarm				7 bit ALDF	4 bit EXPC		
	Ν	Motor overheated					1	0	
	A	Amplifier overheated					0	0	
	C	Disconnected built-in pulse coder (hard)						1	0
	C	Disconnected separate pulse coder (hard)						1	1
	Disconnected pulse coder (soft)					0	0		

#### Example

When a disconnection alarm (SV 015) is issued for axis 1, assume that the diagnostic data of Nos. 3014 and 3015 is as follows:

No. 3014: 00000010

No. 3015: 10110100

FBAL (bit 1) of diagnostic data No. 3014 is set to 1.

Both ALDF (bit 7) and EXPC (bit 4) of diagnostic data No. 3015 are set to 1. The diagnostic data indicates that the cause of the alarm is a disconnected separate pulse coder (hard).

Details of digital servo alarms

	#7	#6	#5	#4	#3	#2	#1	#0
3024	OVL	LVAL	OVC	HCAL	HVAL	DCAL	FBAL	OFAL

Symbol	Description
OFAL	LSI OVERFLOW An overflow alarm occurred in the digital servo.
FBAL	PULCO DISCONNECTION A disconnected pulse coder alarm occurred.
DCAL	EXCESS I FROM MOTOR A regenerative discharge circuit alarm occurred in the servo am- plifier. (LED DC on the servo amplifier is on.)
HVAL	EXCESS V TO MOTOR An overvoltage alarm occurred in the servo amplifier. (LED HV on the servo amplifier is on.)
HCAL	ABNORMAL CURRENT IN SERVO An abnormal current alarm occurred in the servo amplifier. (LED HC on the servo amplifier is on.)
OVC	EXCESS CURRENT IN SERVO An overcurrent (overload) alarm occurred in the servo amplifier.
LVAL	POWER V TOO LOW An insufficient voltage alarm occurred in the servo amplifier. (LED LV on the servo amplifier is on.)
OVL	SV OVERLOAD An overload alarm occurred in the servo motor or amplifier. When this alarm occurs in the servo amplifier, the servo amplifi- er, separate discharge unit, or power transformer is overheated. (LED OH on the servo amplifier is on.)

#### Checking an absolute–position detection alarm

If an alarm is detected at power-on when the absolute position is detected optionally, the message SV101 DATA ERROR (ABS PCDR) or OT032 NEED ZRN (ABS PCDR) appears. The cause of the alarm is indicated in the diagnostic data.

If the alarm message SV101 DATA ERROR (ABS PCDR) or OT032 NEED ZRN (ABS PCDR) appears on the screen, the cause of the alarm is indicated in the diagnostic data. The number of the diagnostic data is 3018 for axis 1, 3038 for axis 2, 3058 for axis 3, and the start number + 8 for other axes.

	#7	#6	#5	#4	#3	#2	#1	#0
3028	APMVAL	APPER	APFER	APTER	APCER	APBATZ	APPLSM	APNZRN

Symbol	Description (Action to be taken)
APNZRN	Absolute–position detection is not correlated with the reference position. (Action: Correlate absolute–position detection with the reference position.)
APPLSM	A pulse error alarm occurred. (Action: Correlate the absolute–position detection with the reference position.)
APBATZ	The voltage of the battery of the absolute pulse coder is 0. (Action: Replace the battery and correlate absolute–position detection with the reference position.)
APCER	A communication error occurred during data transmission. (Action: Replace the pulse coder.)
APTER	A time–out error occurred during data transmission. (Action: Replace the pulse coder.)
APFER	A framing error occurred during data transmission. (Action: Replace the pulse coder.)
APPER	A parity error occurred during data transmission. (Action: Replace the pulse coder.)
APMVAL	An excessive motor displacement alarm occurred. This alarm occurs if the machine moves by more than 24,000 pulses in the detection unit at power–on. (Action: Take appropriate action for the machine so that it does not move at power–on.)
Diagnosis	

No.	Description
4100	Amount of shift in the coordinate system by manual operation
4101	Amount of shift in the coordinate system by a manual interrupt using a function such as the simultaneous automatic/manual function
4102	Amount of offset in the coordinate system by workpiece coordi- nate system setting using the G92 command
4103	Amount of offset in the coordinate system by local coordinate system setting using the G52 command
4104	Amount of shift in the coordinate system in the machine lock state

#### • Coordinate related data

(1) Amount of shift in the coordinate system by manual operation

The amount of shift when the manual absolute signal based on manual operation along each axis is indicated.

Diagnosis No.	Display	Meaning of display data
4100	MANUAL SHIFT	Indicates the amount of shift in the coordinate system by manual operation along the X–axis. Indicates the amount of shift in the coordinate system by manual operation along the Y–axis. Indicates the amount of shift in the coordinate system by manual operation along the Z–axis.

(2) Amount of shift in the coordinate system by a manual interrupt using a function such as the simultaneous automatic/manual function

The amount of intervention by a manual interrupt along each axis is indicated.

Diagnosis No. Display		Meaning of display data			
4101	MANUAL SHIFT	Indicates the amount of manual interrupt using a function such as the simultaneous automatic/ manual function along the X–axis. Indicates the amount of manual interrupt using a function such as the simultaneous automatic/ manual function along the Y–axis. Indicates the amount of manual interrupt using a function such as the simultaneous automatic/ manual function along the Z–axis.			

(3) Amount of offset in the coordinate system by workpiece coordinate system setting using the G92 command

The amount of offset in the coordinate system with the G92 command along each axis is indicated.

Diagnosis No.	Display	Meaning of display data
4102	G92 OFFSET	Indicates, in input units, the amount of offset using the G92 command along the X-axis. Indicates, in input units, the amount of offset using the G92 command along the Y-axis. Indicates, in input units, the amount of offset using the G92 command along the Z-axis.

\_\_\_\_\_ 26 \_\_\_\_

(4) Amount of offset in the coordinate system by local coordinate system setting using the G52 command

The amount of offset in the coordinate system with the G52 command along each axis is indicated.

Diagnosis No.	Display	Meaning of display data
4103	G52 OFFSET	Indicates, in input units, the amount of offset using the G52 command along the X-axis. Indicates, in input units, the amount of offset using the G52 command along the Y-axis. Indicates, in input units, the amount of offset using the G52 command along the Z-axis.

(5) Amount of shift in the coordinate system in the machine lock state

The amount of shift along each axis in the coordinate system by using a move command in the machine lock state is indicated.

Diagnosis No.	Display	Meaning of display data
4104	MCN LOCK SHIFT	Indicates, in input units, the amount of shift in the machine lock state along the X–axis. Indicates, in input units, the amount of shift in the machine lock state along the Y–axis. Indicates, in input units, the amount of shift in the machine lock state along the Z–axis.

#### \_\_\_\_ 27 \_\_\_\_

## 1.6 NC STATUS DISPLAY



(1) Automatic operation mode selection (MEM, MDI, TAPE, EDIT, or \*\*\*\*)

This field displays the automatic operation mode currently selected. When no automatic operation mode is selected, \*\*\*\* is displayed.

(2) Manual operation mode selection (JOG, HND, INC, AGJ, J+REF, or \*\*\*)

This field displays the manual operation mode currently selected. When no manual operation mode is selected, \*\*\*\* is displayed.

(3) Automatic operation status

(RESET, STOP, HOLD, STRT, MSTR, or SRCH)

This field displays the status of automatic operation.

- RSET : Reset is in progress.
- STOP : Automatic operation is stopped.
- HOLD : Automatic operation is suspended.
- STRT : Automatic operation is started.
- MSTR : Execution of a manual numeric command is started.
- NSRC : Sequence number search is in progress.
- (4) Program editing status

(READ, PNCH, VRFY, SRCH, COND, EDIT, or \*\*\*\*)

This field displays the status of program editing.

- READ : Registration is in progress.
- PNCH : Punch-out is in progress.
- VRFY : Verification is in progress.
- SRCH : Search is in progress.
- COND : Memory arrangement is in progress.
- EDIT : An editing operation (such as insertion or alteration) is in progress.
- \*\*\*\* : No editing operation is in progress,

(5) Axis movement/dwell status (MTN, DWL, or \*\*\*)

This field displays MTN during movement along an axis, and displays DWL when the machine is dwelling. This field displays \*\*\* in other cases.

(6) M/S/T/B function status (FIN or \*\*\*)

This field displays FIN when a miscellaneous function such as M, S, T, and B is being performed (that is, when the system is waiting for a completion signal from the PMC). In other cases, this field displays \*\*\*.

(5)' (6)' Emergency stop status (EMG)

If an emergency stop occurs, the display of (5) and (6) disappears and the character string —EMG– is displayed in reverse, instead.

(7) Current time display

This field displays the current time in hours, minutes, and seconds. Example)

16:52:13 (Fifty-two minutes and thirteen seconds after four o'clock in the afternoon)

(8) Status of writing into nonvolatile memory (@ or space)

This field displays @ when data is being written into nonvolatile memory.

(9) Alarm status and label skip status (ALM, BAT, WRN, LSK, or \*\*\*)

ALM blinks in reverse when an alarm has occurred.

WRN blinks when a warning message appears on the CRT screen.

This field displays BAT when the voltage of the battery for the absolute–position detector or nonvolatile memory for storing parameters, tool compensation data, and part programs is low. This display disappears after the battery is replaced and the alarm is reset.

This field displays LSK when none of these statuses are present, and the tape reader is placed in the label skip status. In other cases, this field displays \*\*\*.

## 1.7 WAVEFORM DIAGNOSIS FUNCTION

## 1.7.1 Display of Wave Diagnosis (Graph) Screen

(1) Press the [SERVICE] soft key or key.

(2) Press the [WAVE DIAGNS] soft key. Then, the WAVE DIAGNOSIS (GRAPH) screen is displayed.



## 1.7.2 Setting the Waveform Diagnosis Parameters

While the WAVE DIAGNOSIS (GRAPH) screen is displayed, press the [PARAMETER] soft key. Then, the WAVE DIAGNOSIS (PARAMETER) screen is displayed.

WAVE DIAGNOSIS	(PARAMETER)	0000000	00000111 NN	N00000000000333
CONDITION TRIGGER DELAY TIME	= = X010. = 100	0 DI/ .1 )0	'DO =	X001.1 X001.2 X001.3
TIME RANGE (25,50,100, ZERO SIFT	= 200,400, =	0 800MS) 0		X001.4
(WAVE 1) DATA KIND DATA RANGE DATA COLOR WAVE COLOR	= = = 100	(WA 0 DA1 1 DA1 0 DA1 1 WAN	AVE 2) TA KIND TA RANGE TA COLOR VE COLOR	= 1 = 2 = 1000 = 2
INPUT	MEM **	** STOP **	** *** *** 03:	14:18 LSK SET CHAPTE ND R

(1) One-shot type waveform diagnosis

The collection of data is started according to a set start condition, and data changes are displayed graphically.

#### (a) CONDITION

Enter one of the following settings in the CONDITION field on the WAVE DIAGNOSIS (PARAMETER) screen.

- 0: Starts sampling data the moment the [TRACE] key is pressed.
- 1 : Starts sampling data when the trigger signal rises after the [TRACE] key is pressed.
- 2 : Starts sampling data when the trigger signal falls after the [TRACE] key is pressed.

#### NOTE

When no trigger signal is specified, 1 and 2 are assumed to be 0.

#### (b) TRIGGER

Enter the PMC address and bit number corresponding to a trigger signal in the TRIGGER field on the WAVE DIAGNOSIS (PARAMETER) screen.

Valid data range : G000.0 to G511.7, F000.0 to F319.7, Y000.0 to Y127.7, and X000.0 to X127.7

#### (c) TIME RANGE

Enter 25, 50, 100, 200, 400, or 800 in the TIME RANGE field on the WAVE DIAGNOSIS (PARAMETER) screen. The sampling time is specified as 0.5, 1.0, 2.0, 4.0, 8.0, or 16.0 s.

The sampling time determines not only sampling conditions, but also graph display conditions.

#### (d) DATA KIND

5: Actual speed

Select the type of waveform to be traced and enter your choice in the DATA TYPE field on the WAVE DIAGNOSIS (PARAMETER) screen.

- 0: Servo error (pulses, detection units)
- 1 : Number of servo pulses to be generated

(pulses, command units)

- 2 : Servo torque
  - (pulses, detection units)

(%)

6 : Value of the electric current command for the servo

	(%)
7: Data during heat simulation	(%)
9: Composite speed for all axes	(mm/min or rpm)
10: Spindle speed	(rpm)

11: Load meter for a spindle (%)

#### NOTE

The servo torque and the value of the electric current command are represented as percentages of the corresponding settings in parameter 1979. Spindle speed refers to the speed of a digital spindle only.

#### (e) AXIS ASSIGN

Enter one of the following settings in the AXIS ASSIGN field on the WAVE DIAGNOSIS (PARAMETER) screen.

[When 1 to 7 is specified as the waveform type]

1 to (the number of controlled axes): Servo axis number

[When 9 is specified as the waveform type]

1 or 2: For the Series 15–MB/15–TB, specify 1 only. For the Series 15–TTB, specify 1 on the head 1 side, and specify 2 on the head 2 side.

[When 10 or 11 is specified as the waveform type]

1 or 2: Spindle amplifier number

(f) DI/DO

Enter the PMC address and bit number of the external input/output signal to be traced in the DI/DO field on the WAVE DIAGNOSIS (PARAMETER) screen.

Valid data range :	G000.0 to G511.7,	F000.0 to F319.7,
-	Y000.0 to Y127.7,	and X000.0 to X127.7

#### (g) DATA RANGE

Enter the value per graduation on the vertical axis of the graph (0 to 524287) in the DATA RANGE field on the WAVE DIAGNOSIS (PARAMETER) screen.

#### (h) ZERO SHIFT

Enter the value for the zero point (-10000 to +10000) in the ZERO SHIFT field on the WAVE DIAGNOSIS (PARAMETER) screen.

#### (i) WAVE COLOR

Enter one of the following settings in the WAVE COLOR field on the WAVE DIAGNOSIS (PARAMETER) screen.

1: Red, 2: Green, 3: Yellow, 4: Blue, 5: Purple, 6: Light blue, 7: White

#### (2) Waveform diagnosis of servo-alarm type

#### (a) CONDITION

Enter one of the following settings in the CONDITION field on the WAVE DIAGNOSIS (PARAMETER) screen.

- 100 : Starts sampling data and fetching it into the ring buffer the moment the [TRACE] key is pressed and terminates the sampling when a servo alarm occurs.
- 101 : Starts sampling data and fetching it into the ring buffer the moment the [TRACE] key is pressed and terminates the sampling when a servo alarm occurs or when the trigger signal rises.
- 102 : Starts sampling data and fetching it into the ring buffer the moment the [TRACE] key is pressed and terminates the sampling when a servo alarm occurs or when the trigger signal falls.

#### (b) TRIGGER

Enter the PMC address and bit number corresponding to the trigger signal specified in the TRIGGER field on the WAVE DIAGNOSIS (PARAMETER) screen.

Valid data range : G000.0 to G511.7, F000.0 to F319.7, Y000.0 to Y127.7, and X000.0 to X127.7

#### (c) DELAY TIME

Enter the time (0 to 32000 ms) in the DELAY TIME field on the WAVE DIAGNOSIS (PARAMETER) screen. This setting specifies how long actual termination of tracing is delayed since the tracing termination condition is satisfied.

(d) DATA KIND

Select the types of waveforms to be traced from the following and enter the settings in parameters 4640, 4641, 4645, and 4646 on the WAVE DIAGNOSIS (PARAMETER) screen.

For details, see the later description of parameters.

- 0 : Servo error (pulses, detection units)
- 1 : Number of servo pulses to be generated (pulse,command units)
- 2 : Servo torque (%)
- 5 : Actual speed (pulses, detection units)
- 6 : Value of the electric current command for the servo

(pulses, detection units)

(%)

7 : Data during heat simulation

#### NOTE

The servo torque and the value of the electric current command are represented as percentages of the corresponding settings in parameter 1979.

#### (e) AXIS ASSIGN

Enter one of the following settings in the AXIS ASSIGN field on the WAVE DIAGNOSIS (PARAMETER) screen.

1 to (the number of controlled axes): Servo axis number

#### (f) DATA RANGE

Enter the value per graduation on the vertical axis of the graph (0 to 524287) in the DATA RANGE field on the WAVE DIAGNOSIS (PARAMETER) screen.

#### (g)ZERO SHIFT

Enter the value for the zero point (-10000 to +10000) in the ZERO SHIFT field on the WAVE DIAGNOSIS (PARAMETER) screen.

(h) WAVE COLOR

Enter one of the following settings in the WAVE COLOR field on the WAVE DIAGNOSIS (PARAMETER) screen.

1: Red, 2: Green, 3: Yellow, 4: Blue, 5: Purple, 6: Light blue, 7: White

1.7.3 Starting or Terminating Data Sampling	<ol> <li>(1) Starting data sampling Press the [TRACE] key. The system enters the sampling–enabled state (trace mode).</li> <li>(2) Terminating data sampling Press the [STOP] key. When data is being sampled, data sampling is terminated.</li> </ol>
1.7.4 Waveform Display	As soon as data is sampled, it is displayed in the form of a graph on the WAVE DIAGNOSIS (GRAPH) screen. For servo–alarm types, the date and time at the end of data sampling are displayed at the top of the screen.
1.7.5 Editing a Displayed	The waveform representing the sampled data can be edited using the following operations to make it easier to view.
Waveform	(1) Specifying the waveform type (only for the servo-alarm type)
	To display data items sampled with the servo-alarm waveform diagnosis function, specify the waveform type specified in parameters 4640 and 4641 as the type of the 1st waveform and the waveform type specified in parameters 4645 and 4646 as the type of the 2nd waveform.
	(2) Specifying the display range of the vertical axis
	To enlarge or reduce the display range of the vertical axis, enter a value per graduation in the DATA RANGE field on the WAVE DIAGNOSIS (PARAMETER) screen.
	(3) Specifying the display range of the horizontal axis
	To enlarge or reduce the display range of the horizontal axis, enter a time per graduation in the TIME RANGE field on the WAVE DIAGNOSIS (PARAMETER) screen.
	(4) Specifying the value of the zero point
	To move the display range for the vertical axis up or down, enter the desired value of the zero point in the ZERO SHIFT field on the WAVE DIAGNOSIS (PARAMETER) screen.
	(5) Moving the zero point
	press the [SHIFT] key on the WAVE DIAGNOSIS (PARAMETER) screen. The WAVE DIAGNOSIS (GRAPH) screen is displayed. To move the position of the zero point in the graph up and down, press the [WAVE 1 $\uparrow$ ], [WAVE 1 $\downarrow$ ], [WAVE 2 $\uparrow$ ], and [WAVE 2 $\downarrow$ ] keys on the screen.
1./.b	to erase the waveform being displayed, press the [EKASE] key on the

Erasing a Displayed Waveform To erase the waveform being displayed, press the [ERASE] key on the WAVE DIAGNOSIS (PARAMETER) screen. Once a waveform is erased, it cannot be displayed again.

## 1.8 OPERATING MONITOR SCREEN

## 1.8.1 Display Method

- 1. Press the  $\langle PRG-CHK \rangle$  soft key or |P-CHECK| key.
- 2. Press the <OPE.MNTR> key.

1		
	OPERATING MONITOR 01234	NØØØØØ
	(ABSOLUTE) (FEEDRATE/SPINDLE/T X 123.456 CMD.F: 2000. 1 Y 234.567 ACT.F: 0(MM/ Z 345.678	00L) 00.00% MIN)
	CMD.S: 4000 ACT.S: 0(RPM	100%
	(LOAD METER) T: 12 S======= 150% (TIMER) PARTS:	58
	X=         7% UPERHTING:         6H 4           Y=         17% CUTTING :         5H 1           Z==         25% FREE :         0H 2	211 395 1M 035 0M 025
	MDI *** STRT **** *** FIN *** LSK POSITON PROGRAM OFFSET <b>PRG_CHK C</b> H	*** APTER+

#### NOTE

- Set the numbers of the axes whose load is to be displayed in parameter Nos. 2231 to 2333. Set the rated load of the motor corresponding to each load meter in parameter Nos. 2234 to 2237. When the applied load reaches the rated load, the load meter indicates 100%.
- 2 Load meter data is displayed using a bar graph and percentages. The range of the bar graph is 0% to 200%. 100% is indicated by a change in color on the 14" screen or a change in brightness on the 9" CRT screen.
- 3 The 14" CRT screen displays a graph indicating the fluctuations in load over one minute. One screen displays the fluctuations for one load meter. The cursor keys  $<\uparrow>$  and  $<\downarrow>$  can be used to select the load meter for which this type of graph is to be displayed.

OPERATING MONI	TOR	00123	N00000
(ABSOLUTE) × 123.456 Y 234.567 Z 345.679	(FEEDRATE/SPINDLE/ CMD.F: 2008. ACT.F: 0(MM CMD.S: 4000 ACT.S: 0(RP	TOOL) (x108%) 100,08% MIN) 2- 108% M)	
(LOAD METER) S X = Y = Z	T: 0 = 102% 8% 33%	1-	
(TIMER) PARTS OPERATING TIM CUTTING TIME FREE PURPOSE	: 68 E: 9H 26M 48S : 5H 18M 14S : 8H 28M 82S	2	329 (SEC) 60
POSITI PROCE		MDI *** STRT ****	PHI OHPTE

1.9 INTERNAL POSITION COMPENSATION DATA DISPLAY FUNCTION	The function for displaying internal position compensation data displays the data used in the CNC for each function while the following functions are executed: Cutter compensation Tool length compensation Drilling canned cycle Coordinate rotation Three–dimensional coordinate conversion Programmable mirror image Scaling Three–dimensional tool compensation
1.9.1 Display Method	<ul> <li>(1)Press the [PRG_CHK] soft key or the [P–CHECK] key on the MDI panel.</li> <li>(2)Press the [POS_DAT] soft key. Then, the internal position compensation data display screen is displayed.</li> </ul>

## 1.9.2 Display Data

• Cutter compensation screen

POSITION DATA					001	~ ~	
					OUT	00	N00000
CUTTER COMPENSATION ON/OFF	(REL	ATIVE)	(	DIST	TO GO)		
	х	0.000		х	0.000		
	Y	0.000		Y	0.000		
OFFSET VECTOR	Z	0.000		Z	0.000		
	U	0.000		U	0.000		
X 100.000	V	0.000		V	0.000		
Y 200.000	W	0.000		W	0.000		
	(G/D	/H)	(M)	(T)			
	G91	G54	M02				
	G01	G80					
	G17	G64					
	G41 D 0	G49 H 0		(1	5): 0		
	(F)	0	(ACI	.F)	0		
	(S)		(ACI	.s)	0		
	MDI***5	STOP***	* */*	*/* 0	2:47:55	LSK	:
CUTTER TL LEN CANNED ROTAT	I 3-DIM	PRGMBL	SCALIN	3-DIM		CHAI	PT
CMPENS OFFSET CYCLE ON	CNVSON	MIRROR	G	OFFSE	т	ER	
	1	1 1		I	1	1	

#### [ON/OFF]

Displays ON in the cutter compensation mode and OFF in other modes.

#### [OFFSET VECTOR]

Displays the cutter compensation vector created for each block.

#### Tool length compensation screen

CUTI	TER COMPENS	ATION		(REL	ATIVE	)	(DIST	TO G	0)		
	01	I/OFF									
				Х	0.00	a	X	0.0	000		
				Y	0.00	a	Y	0.0	000		
OFFS	SET VECTOR			Z	0.00	o	Z	0.0	000		
				U	0.00	D	U	0.0	000		
Х	100.000			V	0.00	O	V	0.0	000		
Y	200.000			W	0.00	a	W	0.0	000		
Z	300.000			(G/D	/H)	(M)	( T	)			
U	0.000										
V	0.000			G91	G54	M02	2				
W	0.000			G01	G80						
				G17	G64						
				G40	G43			(L):	0		
				DU	H U						
				(F)		0 ()	ACT.F)		0		
				(S)		(.	ACT.S)		0		
				MDI***8	STOP**	** *	/* */*	02:47	7:55 LS	ιK	
ſ	CUTTER TL LE	IN CANNED	ROTATI	3-DTM	PRGMB	L SCA	LTN 3-D	тм	CH	APT	
	CMPENS OFFSI	T CYCLE	ON	CNVSON	MIRRO	RG	OFF	SET	ER		

#### [ON/OFF]

Displays ON in the tool length compensation mode and OFF in other modes.

#### [OFFSET VECTOR]

Displays the tool length compensation vector created for each block. Remark)

Tool length compensation can be applied for any axis according to parameter setting and therefore data for all axes are displayed.

#### • Canned cycle screen

POS	ITION	DATA						0	01	00	N00000
CANNE	D CYCLE	N/OFF		(R	ELATI	VE)		(DIST	то	GO)	
	0.				X Y	0.000		X Y	0	.000	
INTIA	L POINT	NUMBER (	OF REPE	TITIONS	Z U	0.00	00	U	z 0	0.0	000
Ζ	0.000	L(CMD) L(ACT)	20 1		V W	0.000		V W	0	.000	
POINT	R	CUT-IN	VALUE		(G/D/	H) (	M )	(T)			
Z -2	200.000				G91 G01	G54 G76	M02				
POINT	Z	SHIFT '	VALUE		G17 G40	G64 G49			(L):		0
Z -2	200.000	X	10.000	D 0	н 0	0 (100					
		1	20.000	(F) (S)		(AC1	I.F) T.S)		0		
_			M	IDI***S	TOP**	** */*	*/*	02:47	:55	LSK	
CI	JTTER TL L MPENS OFFS	EN CANNEI ET CYCLE	OROTATI ON	3-DIM CNVSON	PRGMBI MIRROF	G SCALIN	0FFS	em Bet		CHAI ER	PT

#### [ON/OFF]

Displays ON in the drilling canned cycle mode and OFF in other modes.

#### [INITIAL POINT]

Displays the absolute position of the initial point.

#### [POINT R]

Displays the absolute position of point R.

#### [POIN Z]

Displays the absolute position of point Z.

[NUMBER OF REPETITIONS]

Displays the specified value and current value of the number of repetitions.

[CUT IN VALUE] Displays the depth of cut for G73 and G83.[SHIFT VALUE] Displays the shift for G76 and G87.

 Coordinate rotation screen

							```
POSITION DATA					001	00	N00000
COORDINATE SYSTEM ROTATION ON/OFF	(REL	ATIVE)		(DIST	TO GO)		
	х	0.000		х	0.000		
	Y	0.000		Y	0.000		
ROTATION CENTER	Z	0.000		Z	0.000		
	U	0.000		U	0.000		
X 100.000	V	0.000		V	0.000		
Y 200.000	W	0.000		W	0.000		
	(G/D	/H)	(M)	(T)			
ANGLE OF ROTATION							
	G91	G54	M02				
90.00000	G01	G80					
	G17	G64					
	G40	G49			(L): 0		
	D 0	н 0					
	(				0		
	(F)	L.	) (A)	CT.F)	0		
	(5)		(A(	CI.S)	U		
M	DI***S	STOP***	* * /	* */*	02:47:55	LSF	c
CUTTER TL LEN CANNED ROTATI	3-DIM	PRGMBL	SCAL	IN 3-D3	M	CHA	PT
CMPENS OFFSET CYCLE ON	INVSON	MIRROR	G	OFFS	SET	ER	
					1		
×							

#### [ON/OFF]

Displays ON in the coordinate rotation mod and OFF in other modes. [ROTATION CENTER]

Displays the absolute position of the center of coordinate rotation.

#### [ANGLE OF ROTATION]

Displays the angle of coordinate rotation.

 Three–dimensional coordinate conversion screen

POSITION DATA	O0100 N00000
3-DIMENSIONAL COORDINATE CONVERSION	(RELATIVE) (DIST TO GO)
ON/OFF	
	X 0.000 X 0.000
	Y 0.000 Y 0.000
ROTATION CENTER	Z 0.000 Z 0.000
(FIRST) (SECOND)	U 0.000 U 0.000
X 1.000 X -1.000	V 0.000 V 0.000
Y 2.000 Y -2.000	W 0.000 W 0.000
Z 3.000 Z -3.000	(G/D/H) (M) (T)
DIRECTION OF CENTER AXIS OF POTATION	G91 G54 M02
(FIRST) (SECOND)	G01 G80
X 1.000 X -1.000	G17 G64
Y 2.000 Y -2.000	G40 G49 (L): 0
Z 3.000 Z -3.000	D O H O
ROTATION ANGLE	(F) 0 (ACT.F) 0
(FIRST) (SECOND)	(S) (ACT.S) 0
30.00000 -30.00000	
MDT * * * 9770	D**** */* */* 02.47.55 T.CK
MBI 510	/ / / 02:4/:55 LSR
CUTTER TI. LEN CANNED ROTATI 3-DIM D	POMBI, SCALIN 3-DIM CHADT
CMPENS OFFSET CYCLE ON CNVSON M	IRROR G OFFSET ER

#### [ON/OFF]

Displays ON in the three–dimensional coordinate conversion mode and OFF in other modes.

#### [ROTATION CENTER]

Displays the absolute position of the rotation center for three–dimensional coordinate conversion.

#### [DIRECTION OF CENTER AXIS OF ROTATION]

Displays the direction of the rotation center axis for three–dimensional coordinate conversion

#### [ROTATION ANGLE]

Displays the rotation angle for three-dimensional coordinate conversion.

• Programmable mirror image screen

PROGRAMMABLE MIRROR IMAGE ON/OFF         (RELATIVE)         (DIST TO GO)           X         0.000         X         0.000           MIRROR CENTER         Z         0.000         Y         0.000           X         100.000         Y         0.000         Y         0.000           X         100.000         V         0.000         U         0.000           X         100.000         V         0.000         V         0.000           X         200.000         W         0.000         V         0.000           Z         300.000         (G/D/H)         (M)         (T)         U           U         G91         G54         M02         G01         G40         G40	POSITION DATA			00100	N00000
X         0.000         X         0.000           MIRROR CENTER         Z         0.000         Z         0.000           X         100.000         V         0.000         U         0.000           X         100.000         V         0.000         U         0.000           X         100.000         V         0.000         U         0.000           X         200.000         W         0.000         W         0.000           Y         200.000         W         0.000         W         0.000           Y         0.000         W         0.000         W         0.000           U         G91         G54         M02         G64         G40         G49         (L):         0           U         G91         G64         G64         (L):         0         0         U         0         U         0         U         0         U         0         U         0         U         U         U         U         U         U         U         U         U         U         U         U         U         U         U         U         U         U         U         U	PROGRAMMABLE MIRROR IMAGE ON/OFF	(RELATIVE)	(DIST	TO GO)	
Y         0.000         Y         0.000           MIRROR CENTER         Z         0.000         U         0.000           X         100.000         V         0.000         U         0.000           X         100.000         V         0.000         V         0.000           X         200.000         W         0.000         V         0.000           Z         300.000         (G/D/H)         (M)         (T)           U         G91         G54         M02           W         G01         G80         G17         G64           G40         G49         (L):         0         D           D         0         H0           MIRROR           CUTTER         TL LER         CANNED         ROTATI         3-DIM         PROMEL         SCALIN         3-DIM         CHAPT           CMPENS         OFFSET         CYCLE         ON         ANROR         G         OFFSET         CHAPT		X 0.000	х	0.000	
MIRROR CENTER         Z         0.000         Z         0.000           X         100.000         V         0.000         U         0.000           X         200.000         W         0.000         W         0.000           Y         200.000         W         0.000         W         0.000           Y         200.000         W         0.000         W         0.000           U         (G/D/H)         (M)         (T)         U           U         G91         G54         M02           G01         G80         G17         G64           G40         G49         (L):         0           D         0         H         0           (S)         (ACT.F)         0           (S)         (ACT.S)         0		Y 0.000	Y	0.000	
U 0.000 U 0.000 X 100.000 V 0.000 V 0.000 Z 300.000 G(D/H) (M) (T) U V G91 G54 M02 G01 G80 G17 G64 G40 G49 (L): 0 D 0 H 0 (F) 0 (ACT.F) 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LER CANNED ROTATI GNUSON MIRROR G OFFSET CHAPT CMPENS OFFSET CYCLE ON GROUND SCALIN 3-DIM CHAPT CMPENS OFFSET CYCLE ON GROUND SCALIN 3-DIM CHAPT CMPENS OFFSET CYCLE ON GROUND SCALIN 3-DIM CHAPT	MIRROR CENTER	Z 0.000	Z	0.000	
X 100.000 V 0.000 V 0.000 Y 200.000 W 0.000 W 0.000 Z 300.000 (G/D/H) (M) (T) U V W G91 G54 M02 G01 G80 G17 G64 G40 G49 (L): 0 D 0 H 0 (F) 0 (ACT.F) 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LER CANNED ROTATI 3-DIM PROMEL SCALIN 3-DIM CHAPT CMPENS OFFSET CYCLE ON DRATE SCALIN 3-DIM OFFSET ER		U 0.000	Ū	0.000	
Y 200.000 W 0.000 W 0.000 Z 300.000 (G/D/H) (M) (T) U V G91 G54 M02 G01 G80 G17 G64 G40 G49 (L): 0 D 0 H 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LEN CANNED ROTATI GNUSON MIRROR G OFFSET CHAPT ER	X 100.000	V 0.000	v	0 000	
2 300.000 (G/D/H) (M) (T) U V W G91 G54 M02 G17 G64 G40 G49 (L): 0 D 0 H 0 (F) 0 (ACT.F) 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LEN CANNED ROTATI 3-DIM PROMEL SCALIN 3-DIM CHAPT CMPENS OFFSET CYCLE ON CNVSON MIRROR G OFFSET ER	Y 200.000	W 0.000	Ŵ	0.000	
U V W G91 G54 M02 G01 G80 G17 G64 G40 G49 (L): 0 (F) 0 (ACT.F) 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LEN CANNED ROTATI 3-DIM PROMEL SCALIN 3-DIM OFFSET CHAPT CMPENS OFFSET CYCLE ON CNVSON MIRROR G OFFSET ER	Z 300.000	(G/D/H)	(M) (T)		
V         G91         G54         M02           G01         G80         G17         G64           G40         G49         (L):         0           D         0 H         0         (L):         0           (F)         0         (ACT.F)         0         (S)         (ACT.S)         0           MDI***STOP**** */* */* 02:47:55 LSK           CUTTER TL LEN CANNED ROTATI         3-DIM         PROMEL SCALIN         3-DIM         CHAPT           CMPENS OFFSET         CYCLE         ON         GNINCON MIRROR         G         OFFSET         ER	П	( = / = / == /	()		
W G01 G80 G17 G64 G17 G64 G19 (L): 0 (F) 0 (ACT.F) 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LEN CANNED ROTATI 3-DIM PROMEL SCALIN 3-DIM CHAPT CMPENS OFFSET CYCLE ON CNVSON MIRROR G OFFSET ER	v	G91 G54	M02		
G17       G64         G40       G49       (L):       0         (F)       0       (ACT.F)       0         (S)       (ACT.S)       0         MDI***STOP**** */* */* 02:47:55 LSK         CUTTER TL LEN CANNED ROTATI         3-DIM       PRGMEL SCALIN       3-DIM         CMPENS       OFFSET       CHAPT         CNVSON       MIRROR       G       OFFSET	Ŵ	G01 G80			
G40         G49         (L):         0           D         0         H         0         (ACT.F)         0           (S)         (ACT.S)         0         0         0         0           MDI***STOP**** */* */* 02:47:55         LSK           CUTTER         TL LEN         CANNED         ROTATI         3-DIM         PROMEL         SCALIN         3-DIM         CHAPT           CMPENS         OFFSET         CYCLE         ON         MIRROR         G         OFFSET         ER		G17 G64			
D 0 H 0 (F) 0 (ACT.F) 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LEN CANNED ROTATI GMPENS OFFSET CYCLE ON GROMEL SCALIN 3-DIM OFFSET ER		G40 G49	(1	L): 0	
(F) 0 (ACT.F) 0 (S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LEN CANNED ROTATI CMPENS OFFSET CYCLE ON GROMEL SCALIN 3-DIM OFFSET ER		D O H O		, .	
(S) (ACT.S) 0 MDI***STOP**** */* */* 02:47:55 LSK CUTTER TL LEN CANNED ROTATI GMPENS OFFSET CYCLE ON GROMEL SCALIN 3-DIM OFFSET ER		(F) 0	(ACT.F)	0	
MDI***STOP**** */* */* 02:47:55 LSK		(S)	(ACT.S)	0	
MDI***STOP**** */* */* 02:47:55 LSK					
CUTTER TL LEN CANNED ROTATI 3-DIM PRGMEL SCALIN 3-DIM CHAPT CMPENS OFFSET CYCLE ON CNVSON MIRROR G OFFSET ER		MDI***STOP***	* */* */* 0	2:47:55 LSI	c.
CMPENS OFFSET CYCLE ON CNVSON MIRROR G OFFSET ER	CUTTER TI LENI CANNER ROTAT	T 2-DTM DRCMRT	CONTINU 2-DT		NDT.
	CMPENS OFFSET CYCLE ON	CNVSON MIRROR	G OFFSI	ET ER	<sup>1</sup>
	Le s'he ser le ser les				

#### [ON/OFF]

Displays ON in the programmable mirror image mode and OFF in other modes.

#### [MIRROR CENTER]

Displays the absolute position of the mirror axis.

Remark)

Nothing is displayed for axes along which no mirror axis exists. When 0 is displayed, it means that the mirror axis exists at coordinate 0.

#### • Scaling screen

1										
	POSITION	DATA						0010	00	N00000
	SCALING	V/OFF		(REL	ATIVE		(DIST	TO GO)		
	0.			x	0 000		x	0 000		
				Y	0.000		Y	0.000		
3	SCALING CENTER	SCALIN	FACTOR	z	0.000	)	Z	0.000		
				U	0.000	)	U	0.000		
	0.000	X 2.0	0000	v	0.000	)	v	0.000		
1	0.000	Y 2.0	0000	W	0.000	)	W	0.000		
5	0.000	Z 2.0	0000	(G/D	/H)	(M)	(T)			
1	J 0.000	U 1.0	0000							
1	7 0.000	V 1.0	0000	G91	G54	M02				
1	0.000	W 1.0	0000	G01	G80					
				G17	G64					
				G40	G49		(1	L): 0		
				DU	H U					
				(12)		0 (3)	(TT E)	0		
				(S)		( A	CT.S)	0		
				(0)		(11)	01.07	0		
			M	DI***S	TOP**	** */	* */* 0	2:47:55	LSK	
	CUTTER TL LI	EN CANNEL	ON ON	3-DIM	PRGMBI	SCAL.	IN 3-DIM	T I	CHA.	PT
	CHE ENS OF ES.	EI CICLE	014	CIAA 2014	MIRCOR	13	OFF SE	1	1216	

#### [ON/OFF]

Displays ON in the scaling mode and OFF in other modes.

#### [SCALING CENTER]

Displays the absolute position of the scaling center.

#### [SCALE FACTOR]

Displays the scale factor for each axis.

• Three-dimensional tool compensation screen

POSITION DATA			00100	N0000
THREE-DIMENSIONAL TOOL OFFSET ON/OFF	(RELATIVE)	(DIST T	0 G0)	
	X 0.000	х	0.000	
OBECHER MECHOD	Y 0.000	Y	0.000	
OFFSET VECTOR	Z 0.000	Z II	0.000	
x 1.000	v 0.000	v	0.000	
Y 2.000	W 0.000	w	0.000	
Z 3.000	(G/D/H) (M)	(T)		
	G91 G54 M02			
	G01 G80			
	G17 G64			
	G41 G49 D 0 H 0	(L	): 0	
	(F) 0 (P	ACT.F)	0	
	(S) (P	ACT.S)	0	
М	DI***STOP**** */	/* */* 02	:47:55 LSP	c
CUTTER TI. LEN CANNED ROTATI	3-DTM PROMBL SCAL	T.TN 3-DTM	CH2	DT
CMPENS OFFSET CYCLE ON	CNVSON MIRROR G	OFFSET	E ER	

#### [ON/OFF]

Displays ON in the three–dimensional tool compensation mode and OFF in other modes.

#### [OFFSET VECTOR]

Displays the three–dimensional tool compensaion vector created for each block.

1.10.1

## 1.10 OPERATION HISTORY

**Display Method** 

This function always collects history data for keys pressed by the NC operator and the states of signals set by the NC operator. In addition, this function enables the operator to monitor history data when necessary.

Press the [HISTRY] soft key. Then, the OPERATION HISTORY screen is displayed. Smaller numbers represent older data.

*							
OPEF	ATION HI	STOR	Y	0	0001 N000	001	
NO.	DATA	NO.	DATA	NO.	DATA	NO.	DATA
01	PW 000	11	5	21	G003.3↓	31	G
02	96/08/25	12	[SOFT 5]	22	G003.4↑	32	9
03	08:40:00	13	1	23	[SOFT 2]	33	0
04	<reset></reset>	14	0	24	0	34	Х
05	G003.5↓	15	0	25	0	35	4
06	G003.3↑	16	0	26	0	36	5
07	[SOFT 6]	17	[SOFT 1]	27	0	37	б
08	2	18	<reset></reset>	28	1	38	
09	2	19	96/08/25	29	[SOFT 2]	39	F
10	0	20	08:41:36	30	;	40	1
			MDI***STOP**	** ***	*** 00:00:00	* * *	
TO	P LAST SEAR	CH PUNC	н			CHAP-	
10.						TER	
	1 1			1			· /

## 1.10.2 Soft Key Operation

#### (1)TOP

Displays the first page of history data, which starts with oldest history data item.

#### (2)LAST

Displays the last page of history data, which ends with the newest history data item.

#### (3) SEARCH

By selecting the SEARCH key from the operation selection keys, the search operation described below can be performed.

- (a) Signal data item
  - (i) Press the [DIDO] key.
  - (ii) Use one of the following search methods:
    - 1. Enter a signal type (X, Y, G, or F), address, decimal point (.), and bit number.

#### ExampleG3.5

When the entered signal type, address, and bit number agree with those of a history data item, that history data item is found.

2. Enter a signal type (X, Y, G, or F) and address. **Example**G3

When the entered signal type and address agree with those of a history data item, that history data item is found.

3. Enter a signal type (X, Y, G, or F).

#### **Example**G

When the entered signal type agrees with that of a history data item, that history data item is found.

- (b) Alarm data item
  - (i) Press the [ALARM] key.
  - (ii) Use one of the following search methods:
    - 1. Enter an alarm type and alarm number with keys.

#### ExampleOT7

When the entered alarm type and alarm number agree with those of a history data item, that history data item is found.

2. Enter an alarm type with keys.

#### ExampleOT

When the entered alarm type agrees with that of a history data item, that history data item is found.

- (c) Time data
  - (i) Press the [TIME] key.
  - (ii) Use the following search method.

Enter month/date/hour/minute with keys. Less significant data can be omitted as shown in the example below.

Example Month/date/hour/minute: 08/26/13/24

Month/date/hour: 08/26/13 Month/date: 08/26 Month: 08

#### NOTE

Enter the month, date, hour, and minute with two digits each.

After the above operations do the following:

To search for a history data item forward from the currently displayed history data (toward newer history data), press the [FW\_SRCH] soft key.

To search for a history data item backward from the currently displayed history data (toward older history data), press the [BW\_SRCH] soft key.

#### NOTE

Searching forward for a history data item terminates at the most recent history data item (last data item). Searching backward for a history data item terminates at the oldest history data item (first data item). If the specified history data item is not found, a warning is issued.

When the specified history data item is found during searching, the page of history data items that contains the specified history data item is displayed. The line number of the specified history data item is displayed in reverse video. Subsequently, this history data item is used as the (search pointer) during searching. When searching has not yet been performed, the oldest history data item (first data) is used as the search pointer. The search pointer is also used during partial punching–out.

— 42 —

Once history data has been searched for, the search pointer is kept until the power is turned off. When the memory for history data items becomes full, the first data in the history is automatically used as the search pointer.

(4) Outputting history data

History data can be output to the host computer via the RS–232–C interface.

- (a) Press the [PUNCH] soft key (one of the operation selection keys) on the OPERATION HISTORY screen.
- (b) The following punching–out can be performed:
  - (i) Complete punch-out

Press the [ALL] soft key, then press the [EXEC] soft key. All history data items are output.

- (ii) Partial punch-out
  - 1. Before starting partial punch–out, use the search function to determine the reference points for starting and ending partial punch–out. The search pointer is used as (reference history data item) for partial punch–out.
  - 2. Specify the number of display lines of history data items to output.
    - **Example1** To output 100 history data items forward from the reference history data item, press the [PART] soft key, enter 100, then press the [EXEC] soft key.
    - **Example2** To output 100 history data items backward from the reference history data item, press the [PART] soft key, enter –100, then press the [EXEC] soft key.
    - **Example3** To output all history data items forward from the reference history data item, press the [PART] soft key, enter 9999, then press the [EXEC] soft key.
    - **Example4** To output all history data items backward from the reference history data item, press the [PART] soft key, enter –9999, then press the [EXEC] soft key.

#### NOTE

- 1 History data items are always output in the foreground.
- 2 The valid data range for partial punching is –9999 to 9999 excluding 0. 9999 and –9999 have the meanings described in the above examples.

When the number of history data items is less than the absolute value of the value entered, the entered numeric value is handled as if it were 9999 or –9999.

(c) History data ite	ems are output in ASCII code in the following
format.	
(i) MDI key	
Example	When the [A] key is pressed [MDI] key pushed A LF
(ii) DI/DO	
Example1	When the state of G003.5 changes from off to on DI/DO changed G3.5_ON LF
Example2	When different signals with the same address are changed at the same time DI/DO changed F0.6_ONF0.1_OFF LF
(iii) Alarm	
Example	When the alarm, "PW000 TURN OFF THE POWER" occurs
(iv) Time	Alarin: 1 w0 at 92/8/30 23:17:30 LI
(IV) Time	At 22.17.56 on August 20, 1006
Example1	'96/8/30 23:17:56 LF
Example2	When the power is turned on '96/8/30 23:17:56 Power On LF
(d) Communication	protocol
Refer to the ca Method for the Operator's Man	use where the NC sends data in "Transmission RS–232–C Interface" in the FANUC Series 15–B ual (Operation).
(5) Erasing history data	a
(a) Press the [OPE_	HIS] soft key (one of the chapter selection keys).
(b) Press the [ERAS	SE] soft key (one of the operation selection keys).
(c) Press the [EXEC	C] soft key (one of the operation instruction keys).
When the [EXE press the [CAN	C] soft key is pressed by mistake during selection, CEL] soft key.
When operation erased is recorde	history data is erased, the date and time it was ed at the beginning of new history data.

## 1.10.3 Select DI/DO Screen

Select the [DIDO SELECT] key. Then, the DI/DO SELECT screen is displayed.

(						
	DI/DC	) SELECT			00001 N	10001
	NO.	ADDRESS	SIGNAL	NO.	ADDRESS	SIGNAL
	01	X000	00001000	11	G000	00000001
	02	X004	10000000	12	G004	00000010
	03	X008	00001100	13	G008	00000011
	04	X009	00111000	14	G003	01011100
	05	X012	00001111	15	G043	00100001
	06	Y000	01000000	16	F000	01100010
	07	Y004	00110000	17		* * * * * * * *
	08	Y007	00011100	18		* * * * * * * *
	09	Y008	00011100	19		* * * * * * * *
	10	Y010	00011100	20	F020	10101010
	MDT *	* * 9700	* * * * *	* *	* * * 00	.00.00 * * *
	MDI	310P			000	
	CLEAR	ALL_C	LR ON:I		OFF:0	CHAPTER +

#### - 44 -----

Specifying data

- 1. Press the cursor keys or to move the cursor to the position to enter data.
- 2. Enter a signal type (X, Y, G, or F) and address, then press the [INPUT] soft key.

Example Y4([INPUT] key)

Valid data range: G0 to G511, F0 to F319, X0 to X127, or Y0 to Y127

- 3. Specify signal address Y004 in the ADDRESS column, then set the SIGNAL column to the initial value (00000000).
- 4. The operation selection keys have the following functions:
  - (i) CLEAR

When the [CLEAR] soft key and the [EXEC] soft key are pressed, the signal data at the cursor is deleted. The contents of the signal field is changed to \*\*\*\*\*\*\*\*, and the address field is cleared. When the [CLEAR] soft key is pressed by mistake, press the [CANCEL] key.

(ii) ALL\_CLR

When the [ALL\_CLR] soft key and the [EXEC] soft key are pressed, all specified data items are deleted. When the [ALL\_CLR] soft key is pressed by mistake, press the [CANCEL] key.

(iii) ON:1

Press this soft key to set all bits of the data item at the cursor to 1.

(iv) OFF:0

Press this soft key to set all bits of the data item at the cursor to 0.

(v) INPUT

This soft key is used to enter a signal address. It is also used to enter the value of the signal after a signal address is entered.

#### NOTE

Changes in signals cannot be deleted unless they continue for longer than 16ms.

1.10.4	
Related	Parameters

Parameter No. 0013#5:	Specifies whether to display DI/DO
	history information.
Parameter No. 0013#4:	Specifies whether to display MDI key
	operation history information.
Parameter No. 0015#4:	Specifies whether to display the
	deletion key.
Parameter No. 0015#3:	Specifies whether to display the
	OPERATION HISTORY screen.

Classifi- cation	Function	Data protecion key	PWE =1 (DATA No. 8000)	Mode selection	Function key	
Clear	Tool offset Value	KEY 1		Power ON	OFFSET	Operation menu key $\rightarrow$ [ALL–CLR] $\rightarrow$ [ALL], [WEAR], or [GEOMETRY]
Data In- put From Tape	One Program Input (program number not changed)	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [READ] $\rightarrow$ [1–PRGRM] $\rightarrow$ [NEW]
	One Program Input (program number changed or added)	KEY 3		EDIT	PRGRM	Operation menu key → [READ] → [(PROG#)] → Program number → [EXEC]
	Add Program	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [READ] $\rightarrow$ [1–PRGRM] ] $\rightarrow$ [ADD]
	Registration of all programs	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [READ] $\rightarrow$ [ALL]
	Pitch Error Com- pensation amount		0	Emergen- cy SW. ON.	SERVICE	$[PITCHH] \rightarrow [READ]$
Data In- put From MDI	Parameter		0	MDI or Emergen- cy switch ON.	SERVICE	$ \begin{array}{c} [\text{ON:1}] \\ [\text{PARAM}] \rightarrow [\text{INP-No.]} \rightarrow & [\text{OFF:0}] \\ \text{Data No.} \rightarrow [\text{EXEC}] \rightarrow & [\text{INPUT}] \\ [+\text{INPUT}] \end{array} $
	Offset Value	KEY 1			OFFSET	Operation menu key → [INPUT] (Absolute input) [+INPUT] (Incremental input) → Offset value → [EXEC]
	Setting Data	KEY 2		MDI	SETTING	Operation menu key $\rightarrow$ [HANDY] (Setting relating to I/O) [GENERAL] (Settable parameter) $\rightarrow$ [1 : ON] [0 : OFF] $\rightarrow$ Data $\rightarrow$ [EXEC] [(VALUE)]

Classifi- cation	Function	Data protecion key	PWE =1 (DATA No. 8000)	Mode selection	Function key	
Output	Parameter, Pitch er- ror compensation data			EDIT	SERVICE	$\begin{array}{c} [ALL]\\ \mbox{Operation menu key} \rightarrow [\mbox{PUNCH}] \rightarrow [\mbox{PARAM}]\\ [\mbox{PITCH}] \end{array}$
	Offset Value			EDIT	OFFSET	Operation menu key $\rightarrow$ [PUNCH] $\rightarrow$ [TOOL]
	All Program	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [PUNCH] $\rightarrow$ [ALL]
	One Program	KEY 3		EDIT	PRGRM	Operation menu key → [PUNCH] → [THIS] or [PUNCH] → [(PROG#)] → Program number → [EXEC]
Search	Program No. Search (Programs in memory)	KEY 3		EDIT or MEMORY	PRGRM	Operation menu key $\rightarrow$ [FW–SRCH] $\rightarrow$ [(PROG#)] $\rightarrow$ Program number $\rightarrow$ [EXEC]
	Sequence No. Search (Sequence No. in memory)	KEY 3		EDIT or MEMORY	PRGRM	Operation menu key $\rightarrow$ [FW–SRCH] $\rightarrow$ [(SEQ#)] $\rightarrow$ Sequence number $\rightarrow$ [EXEC]
	Sequence No. Search (Sequence Nos. on tape)			TAPE	PRGRM	[CHAPTER] → [TEXT] Operation menu key → [FW–SRCH] → [(SEQ#)] → Sequence num→ [EXEC]
	Word Search (Words in memory)	KEY 3		EDIT	PRGRM	$\begin{array}{l} [CHAPTER] \rightarrow (TEXT] \rightarrow Operation \\ menu \ key \rightarrow [FW-SRCH] \ or \ [BW-SRCH] \\ [(WORD)] \rightarrow Word \ to \ be \ searched \ \rightarrow [EXEC] \end{array}$
	Address Search (Addresses in memory)	KEY 3		EDIT	PRGRM	$\begin{array}{l} [CHAPTER] \rightarrow [TEXT] \rightarrow Operation \\ menu \ key \rightarrow [FW\text{-}SRCH] \ or \ [BW\text{-}SRCH] \\ [(WORD)] \rightarrow Word \ to \ be \ searched \ \rightarrow [EXEC] \end{array}$

Classifi- cation	Function		Data protecion key	PWE =1 (DATA No. 8000)	Mode selection	Function key	
Program Editing	Deletion of all Programs		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [DELETE] $\rightarrow$ [PROGRAM] $\rightarrow$ [ALL] $\rightarrow$ [EXEC]
	Deletion of a Pro- gram	Currently dis- played program	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [DELETE] $\rightarrow$ [PROGRAM] $\rightarrow$ [THIS]
		Disig- nated program	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [DELETE] $\rightarrow$ [PROGRAM] $\rightarrow$ [(PROG#)] $\rightarrow$ Program number $\rightarrow$ [EXEC]
	Deletion of words, from cursor posi- tioned to designated word		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [DELETE] $\rightarrow$ [ $\sim$ (WORD)] $\rightarrow$ Word $\rightarrow$ [EXEC]
	Deletion of words from cursor position to EOB		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [DELETE] $\rightarrow$ [ $\sim$ EOB]
	Deletion of one word		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [DLT $\rightarrow$ WRD] or [DELETE] $\rightarrow$ [WORD]
	Alternation of a word		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [ALTER] [(WORD)] $\rightarrow$ Word to changed $\rightarrow$ [EXEC]
	Insertion of a word		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [INSERT] [(WORD)] $\rightarrow$ Word to changed $\rightarrow$ [EXEC]
	All Program Memory Arrangement		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [CONDENS] $\rightarrow$ [ALL]
	Currently Selected Program Memory Arrangement		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [CONDENS] $\rightarrow$ [THIS]
	Designated Program Memory Arrange- ment		KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [CONDENS] [(PROG#)] $\rightarrow$ Program number $\rightarrow$ [EXEC]
Compari- son	Comparise grams in N with those	on all Pro- Memory on tape			EDIT	PRGRM	Operation menu key $\rightarrow$ [VERIFY] $\rightarrow$ [ALL]
	Comparison one Program in Memory with that on tape				EDIT	PRGRM	Operation menu key $\rightarrow$ [VERIFY] $\rightarrow$ [1–PRGRM]
	Comparise Current Po	on from osition			EDIT	PRGRM	Operation menu key $\rightarrow$ [VERIFY] $\rightarrow$ [HERE]

Classifi- cation	Function	Data protecion key	PWE =1 (DATA No. 8000)	Mode selection	Function key	
I/O to or from	File head search			EDIT	PRGRM	Operation menu key $\rightarrow$ [SERCHFILE] $\rightarrow$ [TOP] $\rightarrow$ [EXEC]
FANUC cassette						Operation menu key $\rightarrow$ [SERCHFILE] $\rightarrow$ [(FILE#)] $\rightarrow$ [EXEC]
						Operation menu key $\rightarrow$ [SERCHFILE] $\rightarrow$ [(FILE NAME)] $\rightarrow$ [EXEC]
	File deletion			EDIT	PRGRM	Operation menu key $\rightarrow$ [DELFILE] $\rightarrow$ [(FILE#)] $\rightarrow$ N[File name] $\rightarrow$ [EXEC]
						Operation menu key $\rightarrow$ [DELFILE] $\rightarrow$ [(FILE NAME)] $\rightarrow$ N[File name] $\rightarrow$ [EXEC]
						Operation menu key $\rightarrow$ [DELFILE] $\rightarrow$ [ALL] $\rightarrow$ [EXEC]
	Program registration	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [READ] $\rightarrow$ [(FILE#)] $\rightarrow$ N[File No.] $\rightarrow$ [EXEC]
						Operation menu key → [READ] → [(PROG#)] → O[Program No.] → [EXEC]
						Operation menu key $\rightarrow$ [READ] $\rightarrow$ [(FILE NAME)] $\rightarrow$ [File name] $\rightarrow$ [EXEC]
	Output of all pro- grams	KEY 3		EDIT	PRGRM	Operation menu key $\rightarrow$ [PUNCH] $\rightarrow$ [ALL]
	Output of one pro- gram	KEY 3		EDIT	PRGRM	$\begin{array}{l} \mbox{Operation menu key} \rightarrow [\mbox{PUNCH}] \rightarrow [\mbox{THIS}] \mbox{ or } \\ [\mbox{PUNCH}] \rightarrow [(\mbox{PROG}\#)] \\ \mbox{O}[\mbox{Program No.}] \rightarrow [\mbox{EXEC}] \end{array}$
						Operation menu key $\rightarrow$ [PUNCH] $\rightarrow$ [(FILE NAME)] "[File name] $\rightarrow$ [EXEC]
						Oeration menu key $\rightarrow$ [PUNCH] $\rightarrow$ [(FILE#)] $\rightarrow$ N[File No.] $\rightarrow$ [EXEC]
	Change of file name			EDIT	PRGRM	Operation menu key $\rightarrow$ [RENAME] $\rightarrow$ [(FILE#)] $\rightarrow$ N[File No.] $\rightarrow$ "[File name] $\rightarrow$ [EXEC]

Classifi- cation	Function	Data protecion key	PWE =1 (DATA No. 8000)	Mode selection	Function key	
Manual operation	Manual refererence position return			JOG		Set the reference position return switch to ON. $\rightarrow$ Set the +X, -X, +Y, and -Y switches to ON. $\rightarrow$ The reference position return completion lamp lights.
	Jog feed			JOG		Set the +X, -X, +Y, and -Y switches to ON. $\rightarrow$ Specify the feedrate using the jog feedrate dial. $\rightarrow$ Press the rapid traverse button to perform rapid tra- verse.
	Incremental feed			INC		Specify the travel using the travel selection switch. $\rightarrow$ Set the +X, $-X$ , +Y, and $-Y$ switches to ON. $\rightarrow$ Press the rapid traverse button to perform rapid tra- verse $\rightarrow$ During rapid traverse, rapid traverse over- ride is enabled.
	Manual handle feed			HANDLE		Select the axis to move, using the axis selection switch. $\rightarrow$ Turn the handle. $\rightarrow$ Specify the magnification using the handle magnification switch.
Graphic function	Parameter setting				GRAPH- IC	[GRAPH PARAM]
	Tool path				GRAPH-	Selection of graphic screen
						[GRAPH]
						Graphic start/end
						Automatic or manual operation
						Erasing graphic screen
						[ERASE]
						Magnification
						[ENLARGE]
Help function	Displaying INITIAL MENU screen				SHIFT + HELP	
	Displaying ALARM HELP screen				SHIFT + HELP	[1 ALARM]" Scroll to the required screen by using the <pageup> or <pagedown> key, enter the num- ber, then press the <input/> key to display the screen.</pagedown></pageup>
	Displaying ALARM HELP screen when alarm occured			Alarm status	SHIFT + HELP	The alarm help screen is displayed. Press the <pa- GEUP&gt; or <pagedown> key to display other in- formation. Press the <input/> key to display all alarms.</pagedown></pa- 
	Displaying SOFT KEY HELP screen				SHIFT + HELP	[2.SOFT KEY] " Scroll to the desired screen by press- ing the <pageup> or <pagedown> key.</pagedown></pageup>
Display- ing DIAG- NOSTIC screen					SERVICE	[DGNOS] 1. Page change keys 2. Number of the diagnostic data

# 2 HARDWARE

This chapter describes the overall configuration of the CNC control section, the interconnections between the units, the functions of the PC boards, and the functions of the modules on the PC boards.

2.1	STRUCTURE	52
2.2	OUTLINE OF HARDWARE	53
2.3	TOTAL CONNECTION	56
2.4	INTER-MACHINE CONNECTION	68
2.5	LIGHTING OF ALARM LEDS ON PCBS	92
2.6	LIST OF THE PCBS AND UNITS	163
2.7	HOW TO REPLACE THE MODULES	176
2.8	HOW TO REPLACE THE BATTERIES	177
2.9	HOW TO REPLACE FAN MOTOR	179
2.10	FUSE REPLACEMENT IN POWER SUPPLY UNIT	181
2.11	MAINTENANCE OF HEAT PIPE TYPE	
	HEAT EXCHANGER	182
2.12	ADJUSTING THE LIQUID–CRYSTAL DISPLAYS	185
2.13	REPLACING THE FUSES OF THE	
	LIQUID–CRYSTAL DISPLAYS	187
2.14	REPLACING THE LCD BACKLIGHT	188
2.15	HOW TO REPLACE THE CRT DISPLAY	189
2.16	HOW TO REPLACE THE MDI KEYBOARD	190
2.17	HOW TO REPLACE THE CARD CAGE IN THE	
	CONTROL UNIT	191
2.18	HANDLING MEMORY CARDS	192

## 2.1 STRUCTURE



\_\_\_\_\_ 52 \_\_\_\_
# 2.2 OUTLINE OF HARDWARE



Fig. 2.2 (a) Control unit configuration of Series 15/150-B

## NOTE

With the Series 15MEK/MEL/TED/TEE/TEF/TEF–B–4, the SUB CPU, RISC, and OSI Ethernet boards cannot be used. (The MMC board can be used only with the Series 150–B.)



Fig. 2.2 (b) Control unit configuration of Series 15/150-B (Multiple axis)

#### NOTE

With the Series 15MEK/MEL/TED/TEE/TEF/TEF–B–4, the SUB CPU, RISC, and OSI Ethernet boards cannot be used. (The MMC board can be used only with the Series 150–B.)



Fig. 2.2 (c) Configuration of Series 15/150-B additional locker used with multiaxis machines

## NOTE

More than one axis CPU board may be used, depending on the system configuration.

# 2.3 TOTAL CONNECTION

# Connection diagram for Series 15–TB/TTB/MB/TFB/TTFB/MFB/MEK/MEL/ TED/TEE/TEF, Series 150–TB/MB/TTB (in case of serial spindle)





#### NOTE



# Connection diagram for Series 15–TB/TTB/MB/TFB/TTFB/MFB/MEK/MEL/ TED/TEE/TEF, Series 150–TB/MB/TTB (in case of analog spindle)



## NOTE

# Connection diagram for Series 15–MB (incase of multiple axis)

## Control unit



## NOTE

#### Additional cabinet (in case of serial spindle interface)



#### NOTE

## Additional cabinet (in case of analog spindle interface)



#### NOTE

# Connection diagram for Series 15–TB/TTB/MB/MEL/TEE (in case of graphic function bult–in type LCD/MDI unit)





## NOTE

# Connection diagram for MMC-II



## NOTE

- 1 The above diagram shows the connections between the MMC–II and peripheral devices. For details of the other connections, see 4.1, 4.2, and 4.3.
- 2 The MMC–II CPU (A02B–0120–J202), which requires three RS–232C channels, uses JD6 as an RS–232C port.
- 3 The MMC board can be used only with the Series 150–B.

# **Connection diagram for MMC-III**



#### NOTE

- 1 The above diagram shows the connections between the MMC–III and peripheral devices. For details of the other connections, see 4.1, 4.2, and 4.3.
- 2 Used for application download only.
- 3 The MMC board can be used only with the Series 150-B.

Connection diagram for MMC-IV



#### NOTE

MMC-IV can be used only with the Series 150-B.

# 2.4 INTER-MACHINE CONNECTION

# 2.4.1 CRT/MDI Unit

• Connection of Series 15–B



• Graphic function built-in type 10.4" LCD/MDI unit



# • Terminal arrangement on the display power supply

(For details, including connector information, refer to the "FANUC Series 15/150–MODEL B CONNECTION MANUAL (B–62073E)."

14" CRT/MDI, 9	" color CRT/MDI,	9" PDP/MDI	(200V type)
----------------	------------------	------------	-------------

CP2	or CP3	CP2	or CP1
1	200A	1	200A
2	200B	2	200B
3	0V	3	0V

## 9" monochrome CRT/MDI



# 9.5"LCD/MDI, Graphic function built–in type 10.4"LCD, 10.4"LCD for MMC–IV

CP5	;	CPS	5
1	+24V	1	+24V
2	0V	2	0V
3		3	

# 9"PDP/MDI (+24V type)



#### • Cable connection



# 2.4.2 Reader/Puncher Interface

Connection



#### Cable connection



# 2.4.3 Manual Pulse Generator

Connection



### Cable connection



 Voltage drop by cable length Restrict voltage drop by cable to less than 0.2V in accordance with +5V/0V.

Voltage drop V =  $\frac{A \times R \times 2L}{m}$ 

Where A : manual pulse generator's current (0.1A)

- R : Registance per cable length
- L : Cable length
- m : No. of cables

When cable A66L–0001–0286 is used for one unit of manual pulse generator, registance is  $0.0394\Omega/m$  and 3 cables are used. Therefore, cable length can be extended up to 50 m according to the following equation:

$$L = \frac{V \times m}{2A \times R} = \frac{0.2 \times 3}{2 \times 0.1 \times 0.0394} = 76.75[m]$$

# 2.4.4

# I/O Link

Connection



2. HARDWARE

• Cable connection within group



## NOTE

Connect +5V when optical I/O link adapter is used. Do not connect when metal cable is used. When metal cable is used, cable length between units is extended by 10 m. When optical I/O link adapter is used, cable length between units is extended by 200m.  Connection between bases (with I/O unit–A)



• Cable connection in the terminator



# 2.4.5 Servo Interface

Connection



Connection to α series servo amplifier



## NOTE

- 1 Not used for  $\alpha$  series amplifier.
- 2 Suffix n in signal name is an axis number 1 to 8.

 Connection of serial pulse coder



# NOTE

Be sure to note voltage drop by cable resistance.

# 2.4.6 Connections by Type of Detectors

• Built-in pulse coder



(n: 1 to 8. However, the sub-board is used when n = 4 to 8.)

# • Separate type pulse coder,Linear scale



(n: 1 to 8. However, the sub-board is used when n = 4 to 8.)

	Cable for connecting between the main	When a built–in pulse coder is used	When a separate pulse coder or linear scale is used		
	CPU board to the servo amplifier		Feedback cable connected to the motor	Cable connected to the separate pulse coder	
1st axis	AMP1	ENC1	ENC1	SCALE1	
2nd axis	AMP2	ENC2	ENC2	SCALE2	
3rd axis	AMP3	ENC3	ENC3	SCALE3	
4th axis	AMP4	ENC4	ENC4	SCALE4	

# 2.4.7 Combining Serial Spindle and Analog Spindle

• Only serial spindle is used



• Only analog spindle is used



# 2.4.8 Connection to $\alpha$ Serial Spindle Amplifier



# 2.4.9 Connection to Analog Spindle Amplifier



# 2.4.10 Remote Buffer Interface

Connection



# • Example of cable connection



# NOTE

- 1 Connect RS when CS is not used.
- 2 Connect as follows when protocol A or extended protocol A is used:
  - a) Connect to ER when DR is not used.
  - b) Always connect CD to ER

# • Example of RS-422 cable



# NOTE

Be sure to use the twisted pair cable. Note that pin arrangement of \*DM signal on NC side is not regular to escape from damage due to wrong connection.

# 2.4.11 High–speed DI Signal Interface

• Connection diagram



# • Connection details



# 2.4.12 Environmental Requirement

The peripheral units, such as the control unit and CRT/MDI, have been designed on the assumption that they are housed in closed cabinets. In this manual "cabinet" refers to the following:

- (1)Cabinet manufactured by the machine tool builder for housing the control unit or peripheral units;
- (2) Cabinet for housing the flexible turnkey system provided by FANUC:
- (3) Operation pendant, manufactured by the machine tool builder, for housing the CRT/MDI unit or operator's panel ;
- (4) Equivalent to the above.

The environmental conditions when installing these cabinets shall conform to the following table.

Ambient temperature	Operating Ambient temperature outside the cabinet: +0 °C to +45°C
	Ambient temperature inside the cabinet: 0°C to +55°C (+5°C to +50°C for MMC–IV) Storage or transportation -20°C to +60°C
Temperature change rate	Allowable temperature change rate $\leq 1.1^{\circ}$ C per minute
Humidity	Relative humidity: 30% to 95% (no condensation)
Altitude	No more than 2000 m above sea level
Vibration	Operating: 0.5 G or less
Atmosphere	Environment outside the cabinet: Special consideration is required when cabinets are used in an environment exposed to relatively high levels of contaminants (dust, coolant, organic solvent, acid, corro- sive gas, salt, and so forth).
	Environment inside the cabinet: Ensure that the equipment housed in the cabinet is ex- posed to those contaminants described above.
	Radiation fins, fans, and so forth outside the cabinet: Ensure that these components are not directly exposed to coolant, lubricant, or chips.
lonizing radiation and non–ionizing radiation	When a cabinet is used in an environment exposed to radiation (microwaves, ultraviolet rays, laser beams, X rays, and so forth), take protective measures.

2.4.13 Power Capacity	The power capaci the specification r power capacity of section.	ty of the CNC control unit, which in the equired for the power supply, is obtain the control section and the power capa	is section means led by adding the acity of the serve
	Power capacity of the control	When the control unit has four slots or less, and power supply AI is used.	0.4KVA
	Section	When the control unit has six or more slots, or power supply BI is used.	1KVA
		When the multiple axis is used.	2KVA
	Power capacity of the servo section	Depends on servo motor type.	

2.4.14 Action Against Noise	The CNC has been steadily reduced in size using surface-mount and custom LS1 technologies for electronic components. The CNC also is designed to be protected from external noise. However, it is difficult to measure the level and frequency of noise quantitatively, and noise has many uncertain factors. It is important to prevent both noise from being generated and generated noise from being introduced into the CNC. This precaution improves the stability of the CNC machine tool system. The CNC component units are often installed close to the parts generating noise in the power magnetics cabinet. Possible noise sources into the CNC are capacitive coupling, electromagnetic induction, and ground loops. When designing the power magnetics cabinet, guard against noise in the machine as described in the following:

# • Separating signal lines

The cables used for the CNC machine tool are classified as listed in the following table :

Bind the cables in each group as described in the action column.

Group	Signal line	Action	
А	Primary AC power line	Bind the cables in group A sep	
	Secondary AC power line	and C or cover group A with an electromagnetic shield (Caution	
	AC/DC power lines (containing the power lines for the servo and spindle motors)	2).	
	AC/DC solenoid	with the solenoid and relay.	
	AC/DC relay		
В	DC solenoid (24VDC)	Connect diodes with DC solenoid	
	DC relay (24 VDC)	Bind the cables in group B sepa-	
	DI/DO cable between the CNC and power magnetics cabinet	B with an electromagnetic shield. Separate group B as far from group C as possible	
	DI/DO cable between the CNC and machine	It is more desirable to cover group B with the shield.	
С	Cable between the CNC and servo amplifier	Bind the cables in group C sep rately from group A or cover grou C with an electromagnetic shiel	
	Cable for position and velocity feedback	Separate group C as far from group B as possible	
	Cable between the CNC and spindle amplifier	Be sure to perform shield proces-	
	Cable for the position coder	Sing	
	Cable for the manual pulse gener- ator		
	Cable between the CRT and MDI		
	RS232C and RS422 interface cables		
	Cable for the battery		
	Other cables to be covered with the shield		

# CAUTION

- 1 The groups must be 10 cm or more apart from one another when binding the cables in each group.
- 2 The electromagnetic shield refers to shielding between groups with grounded steel plates.

Ground

The following ground systems are provided for the CNC machined tool:

- 1. Signal ground system (SG) The signal ground (SG) supplies the reference voltage (0V) of the electrical signal system to the machine.
- 2. Frame ground system (FG)

The frame ground system (FG) is used for safety, and suppressing external and internal noises. In the frame ground system, the frames and cases of the units, panels, and shields for the interface cables between the units are connected.

3. System ground system

The system ground system is used to connect the frame ground systems connected between devices or units with the ground.



Notes on connecting the ground systems

- Connect the signal gournd with the frame ground (FG) at only one place in the CNC control unit.
- The grounding resistance of the system gorund shall be 100 ohms or less (class 3 grounding).
- The system ground cable must have enough cross-sectional area to safely carry the accidental current flow into the system gound when an accident such as a short circuit occurs.
  - (Generally, it must have the cross-sectional area of the AC power cable or more.)
- Use the cable containing the AC power wire and the system gound wire so that power is supplied with the ground wire connected.
• Connecting the signal ground (SG) of the control unit



Connect the 0 V line of the electronic circuit in the control unit with the ground plate of the cabinet via the signal ground (SG) terminal. The SG terminal is located on the printed circuit board at the rear of the control unit.

#### Noise suppressor

The AC/DC solenoid and relay are used in the power magnetics cabinet. A high pulse voltage is caused by coil inductance when these devices are turned on or off.

This pulse voltage induced through the cable causes the electronic circuits to be disturbed.

To reduce the pulse voltage, use a spark killer for an AC device or a diode for a DC device.

Notes on selecting the spark killer

Use a spark killer consisting of a resistor and capacitor in series. This type of spark killer is called a CR spark killer.

(A varistor is useful in clamping the peak voltage of the pulse voltage, but cannot suppress the sudden rise of the pulse voltage. FANUC therefore recommends a CR spark killer.)

The reference capacitance and resistance of the spark killer shall conform to the following based on the current (1(A)) and DC resistance of the stationary coil :

1) Resistance (R):Equivalent to DC resistance of the coil

2) Capacitance (C): 
$$\frac{I^2}{10} \sim \frac{I^2}{20}$$
 (µF)





# • Cable clamp and shield processing

The CNC cables that required shielding should be clamped by the method shown below. This cable clamp treatment is for both cable support and proper grounding of the shield. To insure stable CNC system operation, follow this cable clamp method.

Partially peel out the sheath and expose the shield. Push and clamp by the plate metal fittings for clamp at the part. Metal fittings for clamp are attached to the control unit. The ground plate must be made by the machine tool builder, and set as follows:



Use a cable of the appropriate length. A cable that is longer than necessary is undesirable because immunity to noise is likely to degrade and the cable may induce noise on another cable. If the excess length of cable is coiled, increased inductance will result. Such an increased inductance may induce a very high voltage when a signal is turned on or off, and could cause a failure or noise–based malfunction.

# 2.5 LIGHTING OF ALARM LEDS ON PCBS

If an alarm condition occurs, an alarm message is usually displayed on the CRT screen. The state of the PCB when the alarm occurred is indicated by the LEDs on the front panel of each control unit PCBs, as shown below.

When a system alarm occurs, the alarm message displayed on the screen, together with the LED indications on each PCB, help you to determine the cause. Record the LED indications for each PCB to enable rapid recovery of the system.



Fig. 2.5 LED display for the printed circuit boards in the control unit

# 2.5.1 Configuration of the Power Supply Unit

Name	Code	Remarks
	A16B-1212-0471	Conventional type
Power supply unit Al	A16B-1212-0901	CE marking compatible type
	A16B-1212-0531	Conventional type
Power supply unit BI	A16B-1212-0871	CE marking compatible type

### • LED display

PIL (Green)	This LED is lit when the input AC power voltage is supplied to CP1.
ALM (Red)	This LED is lit when overcurrent, overvoltage, or low voltage occurs in direct current output voltage.

• Disposition of Connector, etc.



# • Fuse

### List of fuses (Conventional type)

Power supply	Ordering drawing number	Symbol	Rating	Specification	Application
AI	A02B-0120-K102	F1	7.5A	A60L-0001-0245#GP75	For a 200–VAC input power supply
		F2	7.5A	A60L-0001-0245#GP75	For a 200–VAC input power supply
		F3	3.2A	A60L-0001-0075#3.2	24–V indicator, main CPU, +24V for optional PC boards
		F4	5AS	A60L-0001-0046#5.0	Protection of the machine– side +24E line from external failures
		F5	0.3A	A60L-0001-0290#LM03	Inside the power supply unit
BI	A02B-0120-K103	F1	10A	A60L-0001-0245#GP100	For a 200–VAC input power supply
		F2	10A	A60L-0001-0245#GP100	For a 200–VAC input power supply
		F3	5A	A60L-0001-0075#5.0	24–V indicator, main CPU, +24V for optional PC boards
		F4	5AS	A60L-0001-0046#5.0	Protection of the machine– side +24E line from external failures
		F5	0.3A	A60L-0001-0290#LM03	Inside the power supply unit

# List of fuses (CE Marking compatible type)

Power supply	Ordering drawing number	Symbol	Rating	Specification	Application
AI	A02B-0200-K100	F1	7.5A	A60L–0001–0245#GP75	For the 200–VAC input power supply
		F3	3.2A	A60L-0001-0075#3.2	24–V indicator, main CPU, +24V for optional PC boards
		F4	5AS	A60L-0001-0046#5.0	Protection of the machine– side +24E line from external failures
BI	A02B-0200-K101	F1	7.5A	A60L-0001-0245#GP100	For the 200–VAC input power supply
		F3	5A	A60L-0001-0075#5.0	24–V indicator, main CPU, +24V for optional PC boards
		F4	5AS	A60L-0001-0046#5.0	Protection of the machine– side +24E line from external failures

### • Battery

Ordering drawing number	Specification	Remarks
A02B-0120-K106	A98L-0031-0007	Battery for conventional power supply
A02B-0200-K103	A98L-0031-0012	Battery for power supply com- patible with CE marking

### • Block diagram



Fig. 2.5.1 Power unit block diagram

• Adjustment

No adjustment is needed.

# 2.5.2 Configuration of the CPU Board (MAIN–B)

(1) Parts layout

Drawing number: A16B-2201-0320



No.	Module name	Function outline
1	SRAM module	Part programs strage, RAM for parameter
2	Servo control module	3rd and 4th servo control
3	Servo control module	1st and 2nd servo control
4	Servo interface module	3rd and 4th amplifier, pulse coder interface
5	Servo interface module	1st and 2nd amplifier, pulse coder interface
6	DRAM module	RAM for CNC system
7	FLASH ROM module	FLASH-EPROM for CNC system
8	Spindle control module	System clear, battery backup control, spindle control, HDI interface etc
9	Peripheral module	MDI, MPG, RS–232C, etc System timer, system clock, calendar clock
10	CRT control module	CRT display control

#### WARNING

means the module connected power supply for battery backup. If the module are taken away carelessly, the backup are lost.

### NOTE

If a peripheral module is replaced, the time indicator may be disabled. In such a case, turn off the CNC. Then, turn on the CNC while holding down both the - key and 2 key on the MDI keyboard. Keep the two keys held down until the position screen is displayed. Then, the time indicator will resume normal operation.



### NOTE

- 1 When the module of analog spindle is built in as a module of spindle control, the series interface is not there.
- 2 When a serial spindle module is mounted as the spindle control module, an analog spindle interface is not used.

(3) Adjustment

No adjustment is needed.

(4) LED display

 $\Box$  : off  $\blacksquare$  : Lit  $\bigstar$  : Flashing

1. LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS	Power-off
2	STATUS	Initial state immediately after power-on
3	STATUS	Beginning of activation of the CNC software
4	STATUS	End of CNC local RAM test
5	STATUS	End of CNC local RAM clear
6	STATUS	FROM test in progress
7	STATUS	End of key initialization. Logical slot setting is completed.
8	STATUS	End of CRT initialization. The CRT is ready for use.
9	STATUS	Waiting for the completion of setting of the PC boards connected to the FANUC bus (1)
10	STATUS	IPL monitoring in progress
11	STATUS	End of IPL
12	STATUS	Waiting for the setting of *SYSFAIL
13	STATUS	Waiting for the completion of setting of the PC boards connected to the FANUC bus (2)
14	STATUS .	Waiting for the completion of initialization of the servo
15	STATUS	Normal state. The power-on sequence is ended.

2. LED display when an error occurs (STATUS LED)

No.	LED di	isplay	NC status
1	STATUS	*	An error (1) occurred in the DRAM module of the CNC.
2	STATUS		An error occurred in the file SRAM.
3	STATUS	**□□	An error (2) occurred in the DRAM module of the CNC.
4	STATUS		The CRT control module is not supported by the installed CNC software.
5	STATUS	★□★□	The main CPU board is not supported by the installed CNC software.
6	STATUS		An illegal PC board is installed in a slot of the FA- NUC bus. Two or more identical PC boards are installed when only one is permitted.
7	STATUS	***□	A system error (stack overflow) occurred.
8	STATUS		An illegal module is installed in the flash ROM module.
9	STATUS	★□□★	A flash ROM file configuration error (CNC area) occurred.
10	STATUS	□★□★	A flash ROM file configuration error (PMC area) occurred.
16	STATUS		A system error (NMI to the CNC CPU) occurred.

# 3. LED display (STATUS LED) when an error occurs

No.	LED display	NC status
1	ALARM ∎□□	Battery voltage for backup decreases.
2	ALARM	SYSFAIL (A fault occured on some modules of F–BUS)
3	ALARM	SERVO ALARM
4	ALARM	SYSEMG (NMI occured on some modules of F–BUS.)
5	ALARM ∎□■	ABC ALARM (Parity alarm on FILE SRAM, A fault of peripheral bus)
6	ALARM	Parity alarm occured on DRAM area

# 2.5.3 Configuration of the Main CPU Board (MAIN–A)

(1) Parts layout

Drawing number: A16B-2201-0300



No.	Module name	Function outline
1	CRT control module	CRT disdplay control
2	SRAM module	Part program strage, RAM for parameter
3	Servo control module	3rd and 4th sevo control
4	Servo control module	1st and 2nd servo control
5	Servo interface module	3rd and 4th amplifier, pulse coder interface
6	Servo interface module	1st and 2nd amplifier, pulse coder interface
7	High-speed SRAM module	High-speed RAM for CNC system
8	DRAM module	RAM for CNC system
9	FLASH ROM module	FLASH–EPROM for CNC system
10	Spindle control module	System clear, battery backup control, spindle control, HDI interface etc
11	Peripheral module	MDI, MPG, RS–232C, etc interface System timer, system clock, calendar clock

#### WARNING

means the module connected power supply for battery backup. If the module are taken away carelessly, the backup are lost.

### NOTE

If a peripheral module is replaced, the time indicator may be disabled. In such a case, turn off the CNC. Then, turn on the CNC while holding down both the - key and 2 key on the MDI keyboard. Keep the two keys held down until the position screen is displayed. Then, the time indicator will resume normal operation.



### (2) Block diagram

#### NOTE

- 1 When the module of analog spindle is built in as module of spindle control, the serial spindle interface is not there.
- 2 When a serial spindle module is mounted as the spindle control module, an analog spindle interface is not used.

(3) Adjustment

No adjustment is needed.

(4) LED display

 $\Box$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED display	NC status
1	STATUS DDD	Power-off
2	STATUS	Initial state immediately after power-on
3	STATUS	Beginning of activation of the CNC software
4	STATUS DDD	End of CNC local RAM test
5	STATUS	End of CNC local RAM clear
6	STATUS	FROM test in progress
7	STATUS ∎□■□	End of key initialization. Logical slot setting is completed.
8	STATUS	End of CRT initialization. The CRT is ready for use.
9	STATUS	Waiting for the completion of setting of the PC boards connected to the FANUC bus (1)
10	STATUS 🗆	IPL monitoring in progress
11	STATUS	End of IPL
12	STATUS	Waiting for the setting of *SYSFAIL
13	STATUS 🗆	Waiting for the completion of setting of the PC boards connected to the FANUC bus (2)
14	STATUS D	Waiting for the completion of initialization of the servo
15	STATUS	Normal state. The power-on sequence is ended.

2. LED display when an error occurs (STATUS LED)

No.	LED di	isplay	NC status
1	STATUS	*	An error (1) occurred in the high–speed SRAM or DRAM module of the CNC.
2	STATUS		An error occurred in the file SRAM.
3	STATUS	**□□	An error (2) occurred in the high–speed SRAM or DRAM module of the CNC.
4	STATUS		The CRT control module is not supported by the installed CNC software.
5	STATUS	★□★□	The main CPU board is not supported by the installed CNC software.
6	STATUS	□★★□	An illegal PC board is installed in a slot of the FA- NUC bus. Two or more identical PC boards are installed when only one is permitted.
7	STATUS	***□	A system error (stack overflow) occurred.
8	STATUS		An illegal module is installed in the flash ROM module.
9	STATUS	★□□★	A flash ROM file configuration error (CNC area) occurred.
10	STATUS	□★□★	A flash ROM file configuration error (PMC area) occurred.
16	STATUS		A system error (NMI to the CNC CPU) occurred.

# 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM ■□□	The voltage of the backup battery has fallen below the specified minimum level.
2	ALARM	SYSFAIL (fault in a module on the F-bus) occurred.
3	ALARM	A servo alarm occurred.
4	ALARM □□■	SYSEMG (NMI in a module on the F–bus) occurred.
5	ALARM ∎□■	An ABC alarm (parity alarm in the file SRAM, fault in the peripheral bus, SUB bus, or FANUC bus) occurred.
6	ALARM	A parity alarm occurred in the DRAM module.
7	ALARM	A parity alarm occurred in the high-speed SRAM module.

# 2.5.4 Configuration of the Upgraded Main CPU Board (MAIN–C)

(1) Parts layout

Drawing number: A16B-3200-0060



No.	Module name	Function outline
1	CRT control module	CRT display control
2	SRAM module	Part program storage, RAM for parameters
3	Servo control module	Third–axis and fourth–axis servo control
4	Servo control module	First-axis and second-axis servo control
5	Servo interface module	Third–axis and fourth–axis amplifier, pulse coder interface
6	Servo interface module	First–axis and second–axis amplifier, pulse coder interface
7	DRAM module	RAM for CNC system
8	Flash ROM module	Flash EPROM for CNC system
9	Spindle control module	System clear, battery backup, spindle control, HDI interface, etc.

### WARNING

Power for the battery backup is supplied to the module in the shaded box. If the module is disconnected, all data will be lost.

(2) Block diagram

See Subsec.2.5.2

(3) Adjustment

No adjustment is needed.

(4) LED display

 $\square$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED d	isplay	NC status
1	STATUS		Power-off
2	STATUS		Initial state immediately after power-on
3	STATUS		Beginning of activation of the CNC software
4	STATUS		End of CNC local RAM test
5	STATUS		End of CNC local RAM clear
6	STATUS		FROM test in progress
7	STATUS		End of key initialization. Logical slot setting is completed.
8	STATUS		End of CRT initialization. The CRT is ready for use.
9	STATUS		Waiting for the completion of setting of the PC boards connected to the FANUC bus (1)
10	STATUS		IPL monitoring in progress
11	STATUS		End of IPL
12	STATUS		Waiting for the setting of *SYSFAIL
13	STATUS		Waiting for the completion of setting of the PC boards connected to the FANUC bus (2)
14	STATUS		Waiting for the completion of initialization of the servo
15	STATUS		Normal state. The power-on sequence is ended.

2. LED display when an error occurs (STATUS LED)

No.	LED display		NC status
1	STATUS	*	An error (1) occurred in the DRAM module of the CNC.
2	STATUS		An error occurred in the file SRAM.
3	STATUS	★★□□	An error (2) occurred in the DRAM module of the CNC.
4	STATUS		The CRT control module is not supported by the installed CNC software.
5	STATUS	★□★□	The main CPU board is not supported by the installed CNC software.
6	STATUS		An illegal PC board is installed in a slot of the FA- NUC bus. Two or more identical PC boards are installed when only one is permitted.
7	STATUS	***□	A system error (stack overflow) occurred.
8	STATUS		An illegal module is installed in the flash ROM module.
9	STATUS	★□□★	A flash ROM file configuration error (CNC area) occurred.
10	STATUS		A flash ROM file configuration error (PMC area) occurred.
16	STATUS		A system error (NMI to the CNC CPU) occurred.

# 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM ■□□	The voltage of the backup battery has fallen below the specified minimum level.
2	ALARM □■□	SYSFAIL (fault in a module on the F–bus) occurred.
3	ALARM	A servo alarm occurred.
4	ALARM □□■	SYSEMG (NMI in a module on the F–bus) occurred.
5	ALARM ∎□■	An ABC alarm (parity alarm in the file SRAM, fault in the peripheral bus or FANUC bus) occurred.
6	ALARM	A parity alarm occurred in the DRAM module.
7	ALARM	A parity alarm occurred in the shared RAM on the SUB board.

# 2.5.5 Configuration of the High–speed Multiaxis Main CPU Board (MAX MAIN–A)



(1) Parts layout

Drawing number: A16B-2201-0340

No.	Module name	Function outline
1	CRT control module	CRT display control
2	SRAM module	Part program storage, RAM for parameters
3	Peripheral module	Interface such as MDI, MPG, and RS–232C, system timer, system clock, calendar clock
4	High–speed SRAM module	High-speed RAM for CNC system
5	DRAM module	RAM for CNC system
6	FLASH ROM module	FLASH EPROM for CNC system

### WARNING

Power for the battery backup is supplied to the module in the shaded box. If the module is disconnected, all data will be lost.

### NOTE

If a peripheral module is replaced, the time indicator may be disabled. In such a case, turn off the CNC. Then, turn on the CNC while holding down both the  $\boxed{-}$  key and  $\boxed{2}$  key on the MDI keyboard. Keep the two keys held down until the position screen is displayed. Then, the time indicator will resume normal operation.



(3) Adjustment

No adjustment is needed.

\_\_\_\_ 108 \_\_\_\_

(4) LED display

□ :Not lit ■ :Lit ★ :Blinking STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED dis	splay	NC status
1	STATUS		Power-off
2	STATUS		Initial state immediately after power-on
3	STATUS		Beginning of activation of the CNC software
4	STATUS		End of CNC local RAM test
5	STATUS		End of CNC local RAM clear
6	STATUS		FROM test in progress
7	STATUS		End of key initialization. Logical slot setting is completed.
8	STATUS		End of CRT initialization. The CRT is ready for use.
9	STATUS		Waiting for the completion of setting of the PC boards connected to the FANUC bus (1)
10	STATUS		IPL monitoring in progress
11	STATUS		End of IPL
12	STATUS		Waiting for the setting of *SYSFAIL
13	STATUS		Waiting for the completion of setting of the PC boards connected to the FANUC bus (2)
14	STATUS		Waiting for the completion of initialization of the servo
15	STATUS		Normal state. The power-on sequence is ended.

2. LED display when an error occurs (STATUS	LED)
---------------------------------------------	------

No.	LED display		NC status
1	STATUS	*	An error (1) occurred in the high–speed SRAM or DRAM module of the CNC.
2	STATUS		An error occurred in the file SRAM.
3	STATUS	★★□□	An error (2) occurred in the high–speed SRAM or DRAM module of the CNC.
4	STATUS		The CRT control module is not supported by the installed CNC software.
5	STATUS	★□★□	The main CPU board is not supported by the installed CNC software.
6	STATUS		An illegal PC board is installed in a slot of the FA- NUC bus. Two or more identical PC boards are installed when only one is permitted.
7	STATUS	***□	A system error (stack overflow) occurred.
8	STATUS		An illegal module is installed in the flash ROM module.
9	STATUS	★□□★	A flash ROM file configuration error (CNC area) occurred.
10	STATUS	□★□★	A flash ROM file configuration error (PMC area) occurred.
16	STATUS		A system error (NMI to the CNC CPU) occurred.

# 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM ∎□□	The voltage of the backup battery has fallen below the specified minimum level.
2	ALARM	SYSFAIL (fault in a module on the F-bus) occurred.
3	ALARM ■■□	SYSEMG occurred in an additional shelf. (An NMI occurred in a module mounted on the F–bus of the additional shelf side.)
4	ALARM □□■	SYSEMG (NMI in a module on the F–bus) occurred.
5	ALARM	An ABC alarm (parity alarm in the file SRAM, fault in the peripheral bus, SUB bus, multiaxis bus, or FANUC bus) occurred.
6	ALARM	A parity alarm occurred in the DRAM module.
7	ALARM	A parity alarm occurred in the high-speed SRAM module.

# 2.5.6 Configuration of the Level Up Multiaxis Main CPU Board (MAX MAIN–C)



(1) Parts layout

Drawing number: A16B-2202-0640

No.	Module name	Function outline
1	CRT control module	CRT display control
2	SRAM module	Part program storage, RAM for parameters
3	DRAM module	RAM for CNC system
4	FLASH ROM module	FLASH EPROM for CNC system

### WARNING

Power for the battery backup is supplied to the module in the shaded box. If the module is disconnected, all data will be lost.

— 111 —

### NOTE

If a peripheral module is replaced, the time indicator may be disabled. In such a case, turn off the CNC. Then, turn on the CNC while holding down both the  $\boxed{-}$  key and  $\boxed{2}$  key on the MDI keyboard. Keep the two keys held down until the position screen is displayed. Then, the time indicator will resume normal operation.



(3) Adjustment

No adjustment is needed.

(4) LED display

□ :Not lit ■ :Lit ★ :Blinking STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED dis	splay	NC status
1	STATUS		Power-off
2	STATUS		Initial state immediately after power-on
3	STATUS		Beginning of activation of the CNC software
4	STATUS		End of CNC local RAM test
5	STATUS		End of CNC local RAM clear
6	STATUS		FROM test in progress
7	STATUS		End of key initialization. Logical slot setting is completed.
8	STATUS		End of CRT initialization. The CRT is ready for use.
9	STATUS		Waiting for the completion of setting of the PC boards connected to the FANUC bus (1)
10	STATUS		IPL monitoring in progress
11	STATUS		End of IPL
12	STATUS		Waiting for the setting of *SYSFAIL
13	STATUS		Waiting for the completion of setting of the PC boards connected to the FANUC bus (2)
14	STATUS		Waiting for the completion of initialization of the servo
15	STATUS		Normal state. The power-on sequence is ended.

2.	LED display	when an error occurs	(STATUS LED)
----	-------------	----------------------	--------------

No.	LED display		NC status
1	STATUS	*	An error (1) occurred in the high–speed SRAM or DRAM module of the CNC.
2	STATUS		An error occurred in the file SRAM.
3	STATUS	★★□□	An error (2) occurred in the high–speed SRAM or DRAM module of the CNC.
4	STATUS		The CRT control module is not supported by the installed CNC software.
5	STATUS	★□★□	The main CPU board is not supported by the installed CNC software.
6	STATUS	□★★□	An illegal PC board is installed in a slot of the FA- NUC bus. Two or more identical PC boards are installed when only one is permitted.
7	STATUS	***□	A system error (stack overflow) occurred.
8	STATUS		An illegal module is installed in the flash ROM module.
9	STATUS	*□□*	A flash ROM file configuration error (CNC area) occurred.
10	STATUS		A flash ROM file configuration error (PMC area) occurred.
16	STATUS		A system error (NMI to the CNC CPU) occurred.

# 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM ∎□□	The voltage of the backup battery has fallen below the specified minimum level.
2	ALARM	SYSFAIL (fault in a module on the F-bus) occurred.
3	ALARM ■■□	SYSEMG occurred in an additional shelf. (An NMI occurred in a module mounted on the F–bus of the additional shelf side.)
4	ALARM □□■	SYSEMG (NMI in a module on the F–bus) occurred.
5	ALARM	An ABC alarm (parity alarm in the file SRAM, fault in the peripheral bus, SUB bus, multiaxis bus, or FANUC bus) occurred.
6	ALARM	A parity alarm occurred in the DRAM module.
7	ALARM	A parity alarm occurred in the high-speed SRAM module.

# 2.5.7 Configuration of the PMC–NA Board

(1) Parts layout

Drawing number: A16B–2201–0371

(PMC-NA board without conversational function)



No.	Module name	Function outline
1	PMC CPU module	CPU module for PMC–NA
2	PMC engine module	PMC operation control, I/O Link control
3	DRAM module	Work RAM for PMC-NA
4	FLASH ROM module	FLASH EPROM



(2) Block diagram

(3) Adjustment

No adjustment is needed.

(4) LED display

Of the STATUS LEDs provided at the top on the front edge of the PMC–NA board, only two are valid as shown on the right:

### Legend

 $\Box$ :Not lit  $\blacksquare$ : Lit  $\bigstar$ :Blinking  $\diamondsuit$ :Irrelevant

 $\star\star$  represents that the two LEDs blink simultaneously.

 $\star$  represents that the two LEDs blink alternately.



# (a) STATUS LED display for the PMC–NA function

# 1. STATUS LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS DDDD	Power-off
2	STATUS	Initial state immediately after power-on or the state in which the PMC CPU is not operating
3	STATUS	Initial state. PMC initialization is in progress.
4	STATUS ∎□□□	Initial state PMC ROM parity check, transfer of a Ladder or PASCAL program to DRAM in progress, SLC ini- tialization in progress (IPL is completed in the CNC and the NC ready status is awaited.)
5	STATUS DODD	Normal state

# 2. STATUS LED display when an error occurs

No.	LED display		NC status
1	STATUS	★★□□	An error occurred in another PC board.
2	STATUS		An error occurred during transfer from or to DI/DO. The DRAM module to be installed on the main CPU is defective.
3	STATUS	★■□□	A RAM parity error occurred in the PMC engine module (upon accessing the BOC).
4	STATUS		A RAM parity error occurred in the PMC engine module or PMC DRAM module (upon accessing the CPU).
5	STATUS	*	A failure (BUS ERR, ADDR ERR, ILL INST, ZERO DIV, etc.) occurred in the PMC function. The PMC ROM is defective.

# (b) ALARM LED display

No.	LED display	NC status
1	ALARM	The PMC CPU asserts SYSFAIL.
2	ALARM	The PMC CPU is in the stop state.
3	ALARM	An error (SLC error) occurred during data transfer to or from DI/DO.
4	ALARM	A RAM (RAM on the PMC engine module or PMC DRAM module) parity error occurred in the PMC.

#### 2.5.8 (1) Parts layout Configuration of the PMC–NA Board with or without the Conversational Function (1) Parts layout (1) Parts layout Drawing numbers : A16B–2201–0390 (PMC–NA board with conversational function) A16B–2201–0391 (PMC–NA board without conversational function)



No.	Module name	Function outline
1	Conversational CPU module	CPU module for the conversational function
2	SRAM module	Sub-memory for the conversational function
3	DRAM module	Work DRAM for the conversational function
4	ROM module	System ROM for the conversational function
5	PMC engine module	PMC operation control, I/O Link control
6	DRAM module	Work RAM for PMC-NA

### WARNING

Power for the battery backup is supplied to the module in the shaded box. If the module is disconnected, all data will be lost.





(3) Adjustment

No adjustment is needed.

(4) LED display

The STATUS LEDs at the top of the front of the PMC–NA board having the conversational function are used for independent functions, as shown on the right.

#### Legend

 $\Box$ :Not lit  $\blacksquare$ : Lit  $\bigstar \gtrsim$ :Blinking  $\blacklozenge$ :Irrelevant

 $\star\star$  represents that the two LEDs blink simultaneously.

 $\star$  represents that the two LEDs blink alternately.



— 119 —

(a) LED display for the PMC–NA function

1. STATUS LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS	Power-off
2	STATUS ■■♦♦	Initial state immediately after power-on or the state in which the PMC CPU is not operating
3	STATUS □∎♦♦	Initial state. PMC initialization is in progress.
4	STATUS ∎□◆◆	Initial state PMC ROM parity check, transfer of a Ladder or PASCAL program to DRAM in progress, SLC ini- tialization in progress (IPL is completed in the CNC and the NC ready status is awaited.)
5	STATUS □□♦♦	Normal state

2. STATUS LED display for the PMC–NA function upon the occurrence of an error

No.	LED display		NC status
1	STATUS	** <b>◆</b> ◆	An error occurred in another PC board.
2	STATUS	■★♦♦	An error occurred during transfer to or from DI/DO. Alternatively, the DRAM module on the main CPU board is defective.
3	STATUS	★■♦♦	A RAM parity error occurred in the PMC engine module (upon accessing the BOC).
4	STATUS	□★♦♦	A RAM parity error occurred in the PMC engine module or PMC DRAM module (upon accessing the CPU).
5	STATUS	★☆◆◆	A failure (BUS ERR, ADDR ERR, ILL INST, ZERO DIV, etc.) occurred in the PMC function. The PMC ROM is defective.

(b) STATUS LED display for the conversational function (15–TFB, 15–TTFB, 15–MFB, 15TEF)

1. STATUS LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS DDDD	Power-off
2	STATUS ♦♦□■	Waiting for initialization of the main CPU (waiting for ID setting)
3	STATUS 🔶	Initialized state
4	STATUS 🔶 🗆	Normal state

2. STATUS LED display for the conversational function upon the occurrence of an error (15–TFB, 15TTFB, 15TEF)

No.	LED display		NC status
1	STATUS ★	***	An error occurred in another PC board.
2	STATUS ★	★□◆	A RAM parity error occurred on the PC board for the conversational function.
3	STATUS 🔶	<b>◆★</b> ☆	A defective ROM module was detected on the PC board for the conversational function.
4	STATUS 🔶	•	The CPU for the conversational function performed illegal processing.

3. STATUS LED display for the conversational function when an error occurs (15–MFB)

No.	LED display		NC status
1	STATUS	<b>**</b> **	An error occurred in another PC board or the CPU for the conversational function.

#### (c) ALARM LED display

No.	LED display	NC status
1	ALARM ∎□□	The CPU for the conversational function asserts SYSFAIL.
2	ALARM	The PMC CPU asserts SYSFAIL.
3	ALARM	The PMC CPU is in the stop state.
4	ALARM	An error (SLC error) occurred during data transfer to or from DI/DO.
5	ALARM	A RAM (RAM on the PMC engine module or PMC DRAM module) parity error occurred in the PMC.

#### 2.5.9 (1) Parts layout **Configuration of the** Drawing numbers : A16B-2201-0810 (PMC-NB board with conversational function) PMC-NB Board with or without the conversational function) Conversational

Function

A16B-2201-0811 (PMC-NB board without A16B-2201-0381 (PMC-NB board without conversational function)



No.	Module name	Function outline
1	Conversational CPU module	CPU module for conversational function
2	DRAM module	Work RAM for conversational function
3	ROM module	System ROM for conversational function
4	SRAM module	Sub-memory for conversational function
5	ROM module	System ROM for PMC–NB
6	PMC CPU module	CPU module for PMC–NB
7	PMC engine module	PMC operation control, I/O Link control
8	SRAM module	Work RAM for PMC–NB
9	FLASH ROM module	FLASH EPROM

### WARNING

Power for battery backup is supplied to the module in the shaded box. If the module is disconnected, all data will be lost.





(3) Adjustment

No adjustment is needed.

(4) LED display

The STATUS LEDs at the top of the front of the PMC–NB board having the conversational function are used for independent functions, as shown on the right.

Legend

 $\Box$ :Not lit  $\blacksquare$ : Lit  $\Rightarrow \bigstar$ :Blinking  $\blacklozenge$ :Irrelevant

 $\star\star$  represents that the two LEDs blink simultaneously.

 $\star$  represents that the two LEDs blink alternately.



# (a) LED display for the PMC–NB function

1.STATUS LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS	Power-off
2	STATUS ■■♦♦	Initial state immediately after power-on or the state in which the PMC CPU is not operating
3	STATUS □∎♦◆	Initial state. PMC initialization is in progress.
4	STATUS ∎□♦♦	Initial state PMC ROM parity check, transfer of a Ladder or PASCAL program to DRAM in progress, SLC ini- tialization in progress (IPL is completed in the CNC and the NC ready status is awaited.)
5	STATUS □□♦♦	Normal state

2. STATUS LED display for the PMC–NB function when an error occurs

No.	LED display	NC status
1	STATUS ★★♦♦	An error occurred in another PC board.
2	STATUS ■★◆◆	An error occurred during transfer to or from DI/DO. The DRAM module module on the main CPU board is defective. The PMC system ROM module is defective.
3	STATUS ★■◆◆	A RAM parity error occurred in the PMC engine module (during access to the PMC).
4	STATUS □★♦♦	A RAM parity error occurred in the PMC engine module or PMC SRAM module (during access to the CPU).
5	STATUS ★☆◆◆	A failure (BUS ERR, INVALID OPCODE, etc.) occurred in the PMC function. The PMC ROM is defective.
(b) STATUS LED display for the conversational function (15–TFB, 15–TTFB, 15–MFB, 15TEF)

1. STATUS LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS	Power-off
2	STATUS ♦♦□■	Waiting for initialization of the main CPU (waiting for ID setting)
3	STATUS 🔶	Initialized state
4	STATUS ••□□	Normal state

# 2. STATUS LED display for the conversational function when an error occurs (15–TBF, 15–TTFB, 15TEF)

No.	LED display	NC status
1	STATUS ♦♦★★	An error occurred in another PC board.
2	STATUS ♦♦□★	A RAM parity error occurred on the PC board for the conversational function.
3	STATUS ♦♦★☆	A defective ROM module was detected on the PC board for the conversational function.
4	STATUS ♦♦∎□	The CPU for the conversational function performed illegal processing.

3. STATUS LED display for the conversational function when an error occurs (15–MFB)

No.	LED d	isplay	NC status
1	STATUS	<b>**</b> **	An error occurred in another PC board or the CPU for the conversational function.

#### (c) ALARM LED display

No.	LED display	NC status
1	ALARM ■□□	The CPU for the conversational function asserts SYSFAIL.
2	ALARM	The PMC CPU asserts SYSFAIL.
3	ALARM	The PMC CPU is in the stop state.
4	ALARM	An error (SLC error) occurred during data transfer to or from DI/DO.
5	ALARM	A RAM (RAM on the PMC engine module or PMC SRAM module) parity error occurred in the PMC.

# 2.5.10 Configuration of the PMC–NB/NB2 Board with or without the Conversational Function

• Parts layout



No.	Module name	Function outline
1	ROM module	System ROM for conversational function
2	Conversational CPU module	CPU module for conversational function
3	Memory module (DRAM/SRAM)	Work memory for conversational function + Sub–memory for conversational function (TFB/TTFB)
4	DRAM module	Work memory for PMC CPU
5	PMC engine module	PMC operation control, I/D Link control

# WARNING

The shaded module ( ) is connected to a power supply for battery backup. If that power supply is disconnected, the backup data may be lost. The memory module uses battery backup with 15–TFB, 15–TTFB, and 15TEF only.

# • Block diagram



(1) Adjustment

No adjustment is needed.

(2) LED display

The STATUS LEDs at the top of the front of the PMC–NB board having the conversational function are used for independent functions, as shown on the right.

Legend

- $\Box$ :Not lit  $\blacksquare$ : Lit  $\Rightarrow \bigstar$ :Blinking  $\blacklozenge$ : Irrelevant
- $\star\star$  represents that the two LEDs blink simultaneously.
- $\star$  represents that the two LEDs blink alternately.



# (a) LED display for the PMC–NB function

1.STATUS LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS	Power-off
2	STATUS ■■♦♦	Initial state immediately after power-on or the state in which the PMC CPU is not operating
3	STATUS □∎♦◆	Initial state. PMC initialization is in progress.
4	STATUS ∎□♦♦	Initial state PMC ROM parity check, transfer of a Ladder or PASCAL program to DRAM in progress, SLC ini- tialization in progress (IPL is completed in the CNC and the NC ready status is awaited.)
5	STATUS □□♦♦	Normal state

2. STATUS LED display for the PMC–NB function when an error occurs

No.	LED display	NC status
1	STATUS ★★♦♦	An error occurred in another PC board.
2	STATUS ■★◆◆	An error occurred during transfer to or from DI/DO. The DRAM module module on the main CPU board is defective. The PMC system ROM module is defective.
3	STATUS ★■◆◆	A RAM parity error occurred in the PMC engine module (during access to the PMP).
4	STATUS □★♦♦	A RAM parity error occurred in the PMC engine module or PMC DRAM (during access to the CPU).(Note)
5	STATUS ★☆◆◆	A failure (BUS ERR, INVALID OPCODE, etc.) occurred in the PMC function. The PMC ROM is defective.

(b) STATUS LED display for the conversational function (15–TFB, 15–TTFB, 15–MFB, 15TEF)

No.	LED display	NC status
1	STATUS DDDD	Power-off
2	STATUS ♦♦□■	Waiting for initialization of the main CPU (waiting for ID setting)
3	STATUS 🔶	Initialized state
4	STATUS ♦♦□□	Normal state

1. STATUS LED display transition when the power is turned on

2. STATUS LED display for the conversational function when an error occurs (15–TFB, 15–TTFB, 15TEF)

No.	LED display	NC status
1	STATUS ♦♦★★	An error occurred in another PC board.
2	STATUS ♦♦□★	A RAM parity error occurred on the PC board for the conversational function.
3	STATUS ♦♦★☆	A defective ROM module was detected on the PC board for the conversational function.
4	STATUS ♦♦∎□	The CPU for the conversational function performed illegal processing.

3. STATUS LED display for the conversational function when an error occurs (15–MFB)

No.	LED display	NC status
1	STATUS ♦♦★★	An error occurred in another PC board or the CPU for the conversational function.

#### (c) ALARM LED display

No.	LED display	NC status
1	ALARM ■□□	The CPU for the conversational function asserts SYSFAIL.
2	ALARM	The PMC CPU asserts SYSFAIL.
3	ALARM	The PMC CPU is in the stop state.
4	ALARM	An error occurred in data transfer to or from DI/ DO. (SLC ERROR)
5	ALARM	A DRAM parity error occurred on the PMC side (Note).
6	ALARM	A RAM parity error occurred in RAM of the PMC engine module.

#### NOTE

DRAM is mounted on the PMC–NB/NB2 board and DRAM module.

# 2.5.11 Configuration of the Axis CPU Board (ACPU)

(1) Parts layout

Drawing number: A16B-2201-0360



No.	Module name	Function outline
1	Servo control module	Third-axis and fourth-axis servo control
2	Servo control module	First-axis and second-axis servo control
3	Servo interface module	Third–axis and fourth–axis amplifier, pulse coder interface
4	Servo interface module	First–axis and second–axis amplifier, pulse coder interface
5	DRAM module	RAM for the axis CPU system
6	Error motion check module	First-axis and second-axis error motion check interface
7	Error motion check module	Third-axis and Fourth-axis error motion check interface
8	Spindle control module	Spindle control, reference point proximity signal interface

# (2) Block diagram



(3) Adjustment

No adjustment is needed.

(4) LED display

 $\Box$ :Not lit  $\blacksquare$ :Lit  $\bigstar$ :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED display	NC status
1	STATUS	Power-off
2	STATUS	State in which the axis CPU is not started
3	STATUS	Beginning of the activation of the axis CPU software
4	STATUS	End of the axis CPU local RAM test
5	STATUS	End of the axis CPU local RAM clear
6	STATUS	Waiting for a response from the main CPU (1)
7	STATUS	Waiting for a response from the main CPU (2)
8	STATUS	Waiting for a response from the main CPU (3)
9	STATUS	Waiting for a response from the digital servo
10	STATUS	Waiting for a response from the main CPU (4)
15	STATUS	Normal state. The power–on sequence is ended.

2. LED display when an error occurs (STATUS LED)

No.	LED display	NC status
1	STATUS *	An error occurred in the DRAM of the axis CPU.
2	STATUS □★□□	An unsupported component is installed in the DRAM of the axis CPU.
3	STATUS □★★□	A logical slot setting error occurred.
16	STATUS	A system error occurred.

3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
2	ALARM	SYSFAIL (fault in a module on the F–BUS) occurred.
3	ALARM	A servo alarm occurred.
4	ALARM	SYSEMG (NMI in a module on the F–BUS) occurred.
5	ALARM ∎□■	A bus error occurred (F–BUS, servo, spindle module).
6	ALARM	A parity alarm occurred in the DRAM module.



(2) Block diagram



(3) Adjustment

No adjustment is needed.

(4) LED display

 $\square$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

- 1.2. The STATUS LEDs (green LEDs) on this PC board have no meaning.
- 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM	SYSFAIL occurred in the axis shelf. (A fault occurred in a module of the axis shelf.)
2	ALARM	SYSEMG occurred in the axis shelf. (An NMI occurred in a module of the axis shelf.)
3	ALARM	A bus error occurred during write access from the main shelf.
4	ALARM	A bus error occurred in the F-bus of the axis shelf.



No.	Module name	Function outline
1	SRAM module	For SHARED RAM
2	ROM module	Memory for RISC CPU

# NOTE

RISC board can not be used in Series 15MEK/MEL/TED/TEE/TEF-B-4.



(3) Adjustment

No adjustment is needed.

(4) LED display

 $\square$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display when the power is turned on (Nos.1 to 8) and during operation (Nos. 9 to 12) (STATUS LED)

No.	LED di	splay	NC status
1	STATUS		Power-off
2	STATUS		Immediately after power-on or the state in which the RISC CPU is not started
3	STATUS		DRAM or SHARED RAM test in progress (If an error is detected during the test, this LED display is held and not changed.)
4	STATUS		ROM test in progress (If an error is detected during the test, this LED display is held and not changed.)
5	STATUS		Waiting for the processing by the CNC (1)
6	STATUS		Waiting for the processing by the CNC (2)
7	STATUS		Waiting for the processing by the CNC (3)
8	STATUS		Waiting for the processing by the CNC (4)
9	STATUS	$\Box\Box\Box\star$	Waiting for RISC mode
10	STATUS	□★□★	Waiting for the input of an NC statement
11	STATUS		Executing a command in RISC mode
12	STATUS	*	Resetting
13	STATUS	*□**	Override 0 upon acceleration/deceleration before interpolation (waiting for an override change)

2. LED display when an error occurs (STATUS LED)

No.	LED display	NC status
1	STATUS	An error occurred during test of the DRAM or SRAM module (shared RAM) on the RISC board.
2	STATUS	An error occurred during test of the ROM module.
3	STATUS 🗆	A synchronization signal cannot be detected from the main CPU.
4	STATUS	An error occurred during access to the F–bus. (The module ID cannot be read correctly.)
5	STATUS	A system error occurred.

3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM	The RISC CPU is not started.
2	ALARM	A parity alarm occurred in the SRAM module.
3	ALARM	A parity alarm occurred in the DRAM on the RISC board.

# 2.5.14 Configuration of the RISC Board

(1) Parts layout

Drawing number: A16B-3200-0150/0313 and on



No.	Module name	Function outline
1	ROM module	Memory for RISC CPU

# NOTE

RISC board can not be used in Series 15MEK/MEL/TED/TEE/TEF-B-4.

# (2) Block diagram



- (3) Adjustment
  - No adjustment is needed.

# (4) LED display

- (a) LED1
  - $\square$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display when the power is turned on (Nos.1 to 8) and during operation (Nos. 9 to 12) (STATUS LED)

No.	LED di	isplay	NC status
1	STATUS		Power-off
2	STATUS		Immediately after power-on or the state in which the RISC CPU is not started
3	STATUS		DRAM or SHARED RAM test in progress (If an error is detected during the test, this LED display is held and not changed.)
4	STATUS		ROM test in progress (If an error is detected during the test, this LED display is held and not changed.)
5	STATUS		Waiting for the processing by the CNC (1)
6	STATUS		Waiting for the processing by the CNC (2)
7	STATUS		Waiting for the processing by the CNC (3)
8	STATUS		Waiting for the processing by the CNC (4)
9	STATUS	$\Box\Box\Box\star$	Waiting for RISC mode
10	STATUS	□★□★	Waiting for the input of an NC statement
11	STATUS		Executing a command in RISC mode
12	STATUS	*	Resetting
13	STATUS	*□**	Override 0 upon acceleration/deceleration before interpolation (waiting for an override change)

2. LED display when an error occurs (STATUS LED)

No.	LED display	NC status
1	STATUS DDD	An error occurred during test of the DRAM or SRAM module (shared RAM) on the RISC board.
2	STATUS	An error occurred during test of the ROM module.
3	STATUS 🗆	A synchronization signal cannot be detected from the main CPU.
4	STATUS	An error occurred during access to the F–bus. (The module ID cannot be read correctly.)
5	STATUS	A system error occurred.

3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM	The RISC CPU is not started.
2	ALARM	A parity alarm occurred in the SRAM.
3	ALARM	A parity alarm occurred in the DRAM on the RISC board.

#### (b) LED2

4. LED2 (LV ALM) display

No.	LED display	NC status
1	LV ALM ■(Red)	The output voltage of the 3.3V power supply exceeded the specified range.

### • Fuse F21

This fuse may blow if the 3.3V power supply or a 3.3V device suffers a serious failure.

# 2.5.15 Configuration of the Sub–CPU Board (SUB–A)



(1) Parts layout

Drawing number: A16B-2201-0310

No.	Module name	Function outline
1	SRAM module	For SHARED RAM
2	Servo control module	7th and 8th servo control
3	Servo control module	5th and 6th servo contorl
4	Servo interface module	7th and 8th amplifier, pulse coder interface
5	Servo interface module	5th and 6th amplifier, pulse coder interface
6	High-speed SRAM module	High–speed RAM for sub.system
7	DRAM module	RAM for sub.system
8	2nd spindle control module	2nd spindle control, HDI interface etc
9	Analog IN & Serial communication module	Input of analog, RS-232C, RS-422 interface

#### (2) Block diagram



# NOTE

- 1 When the module of analog spindle is built in as a module of spindle control, the serial spindle interface is not there.
- 2 When a serial spindle module is mounted as the spindle control module, an analog spindle interface is not used.

(3) Adjustment

No adjustment is needed.

(4) LED display

 $\Box$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED display		NC status
1	STATUS		Power-off
2	STATUS		Initial state immediately after power-on
3	STATUS		State in which the sub–CPU software is to be activated
4	STATUS [		Beginning of the activation of the sub–CPU soft- ware
5	STATUS		Beginning of the sub-CPU local RAM test
6	STATUS		End of the sub-CPU local RAM test
7	STATUS		End of initialization of a custom LSI chip
8	STATUS [		Beginning of the internal processing of the sub–CPU
9	STATUS		Waiting for the processing by the main CPU (1)
10	STATUS [		Waiting for the processing by the main CPU (2)
11	STATUS		Normal state. The power–on sequence has en- ded.

#### 2. LED display when an error occurs (STATUS LED)

No.	LED di	splay	NC status
1	STATUS	★□★★	An error occurred in the local RAM of the sub–CPU.
16	STATUS		A system error occurred.

#### 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM	The sub–CPU is not started.
2	ALARM	SYSFAIL (fault in a module on the F-bus) occurred.
3	ALARM	A servo alarm occurred.
4	ALARM	SYSEMG (NMI in a module on the F–bus) occurred.
5	ALARM ∎□■	An ABC alarm (parity alarm in shared RAM, fault in the peripheral bus, SUB bus, FANUC bus) oc- curred.
6	ALARM	A parity alarm occurred in the DRAM module.
7	ALARM	A parity alarm occurred in the high-speed SRAM module.

— 142 —

# 2.5.16 Configuration of the Standard Multiaxis Sub–CPU Board (MAX SUB–B)



(1) Parts layout

Drawing number: A16B-2201-0331

No.	Module name	Function outline
1	SRAM module	For SHARED RAM
2	Analog IN and serial communication module	Analog input, RS-232C and RS-422 interface
3	DRAM module	RAM for subsystem





(3) Adjustment

No adjustment is needed.

(4) LED display

 $\square$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED display		NC status
1	STATUS		Power-off
2	STATUS		Initial state immediately after power-on
3	STATUS		State in which the sub–CPU software is to be activated
4	STATUS		Beginning of the activation of the sub–CPU soft- ware
5	STATUS		Beginning of the sub–CPU local RAM test
6	STATUS		End of the sub–CPU local RAM test
7	STATUS		End of initialization of a custom LSI chip
8	STATUS		Beginning of sub–CPU's internal processing
9	STATUS		Waiting for the processing by the main CPU (1)
10	STATUS		Waiting for the processing by the main CPU (2)
11	STATUS		Normal state. The power-on sequence is ended

— 144 —

2. LED display when an error occurs (STATUS LED)

No.	LED d	isplay	NC status
1	STATUS	★□★★	An error occurred in the local RAM of the sub- CPU.
2	STATUS		A system error occurred.

# 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM	SYSFAIL (fault in a module on the F-bus) occurred.
2	ALARM	A servo alarm occurred.
3	ALARM □□■	SYSEMG (NMI in a module on the F–bus) occurred.
4	ALARM ∎□■	An ABC alarm (parity alarm in the shared RAM, fault in the peripheral bus, SUB bus, FANUC bus) occurred.
5	ALARM	A parity alarm occurred in the DRAM module.

# 2.5.17 Configuration of the Upgraded Sub–CPU Board (SUB–C)

(1) Parts layout

Drawing number: A16B-2202-0571



No.	Module name	Function outline
1	Analog IN & serial communication module	Analog input, RS-232C and RS-422 interface
2	Second spindle control module	Second spindle control, HDI interface, etc.
3	Servo control module	Seventh-axis and eighth-axis servo control
4	Servo control module	Fifth–axis and sixth–axis servo control
5	Servo interface module	Seventh–axis and eighth–axis servo amplifier, pulse coder interface
6	Servo interface module	Fifth–axis and sixth–axis servo amplifier, pulse coder interface
7	DRAM module	RAM for subsystem

#### (2) Block diagram



# NOTE

- 1 If the analog spindle module is mounted as the spindle control module, the serial spindle interface is not included.
- 2 If the serial spindle module is mounted as the spindle control module, the analog spindle interface is not included.

(3) Adjustment

No adjustment is needed.

(4) LED display

 $\Box$  :Not lit  $\blacksquare$  :Lit  $\bigstar$  :Blinking

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED display		NC status
1	STATUS		Power-off
2	STATUS		Initial state immediately after power-on
3	STATUS		State in which the sub–CPU software is to be activated
4	STATUS		Beginning of the activation of the sub–CPU soft- ware
5	STATUS		Beginning of the sub–CPU local RAM test
6	STATUS		End of the sub–CPU local RAM test
7	STATUS		End of initialization of a custom LSI chip
8	STATUS		Beginning of the sub–CPU's internal processing
9	STATUS		Waiting for the processing by the main CPU (1)
10	STATUS		Waiting for the processing by the main CPU (2)
11	STATUS		Normal state. The power-on sequence has en- ded.

2. LED display when an error occurs (STATUS LED)

No.	LED display	NC status
1	STATUS ★□★★	An error occurred in the local RAM of the sub- CPU.
16	STATUS	A system error occurred.

#### 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM ∎□□	The sub–CPU has not started.
2	ALARM	SYSFAIL (fault in a module on the F–bus) occurred.
3	ALARM	A servo alarm occurred.
4	ALARM	SYSEMG (NMI in a module on the F–bus) occurred.
5	ALARM	An ABC alarm (fault in the peripheral bus, FANUC bus) occurred.
6	ALARM	A parity alarm occurred in the DRAM module.
7	ALARM	A parity alarm occurred in the SRAM mounted on the sub–CPU.

# 2.5.18 Configuration of Additional Axis (ADAX) Board

(1) Parts layout

Drawing number : A16B–2201–0311



No.	Module name	Function outline
1	Servo control module	7th and 8th servo control
2	Servo control module	5th and 6th servo control
3	Servo interface module	7th and 8th amplifier, pulse coder interface
4	Servo interface module	5th and 6th amplifier, pulse coder interface
5	2nd spindle control module	2nd spindle control, HDI interface etc
6	Analog IN & serial communications module	Input of Analog, RS–232C, RS–422 interface

#### (2) Block diagram



# NOTE

- 1 When the module of analog spindle is built in as a module of spindle control, the serial spindle interface is not there.
- 2 When a serial spindle module is mounted as the spindle control module, an analog spindle interface is not used.

(3) Adjustment

No adjustment is needed.

(4) LED display

 $\Box$ :Off  $\blacksquare$ :Lit  $\bigstar$ :Flashing

The STATUS LEDs are green and the ALARM LEDs are red.

LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM	Not used
2	ALARM	SYSFAIL (A fault occured on some modules of F–BUS.)
3	ALARM	SERVO ALARM
4	ALARM	SYSEMG (NMI occred on some modules of F–BUS.)
5	ALARM	ABC ALARM (A fault of peripheral bus)
6	ALARM	Not used
7	ALARM	Not used

#### NOTE

All the STATUS LED is always off

2.5.19	(1) Parts layout
Configuration of the Option 1 Board	(Remote buffer communication function + Graphic function)
	: A16B-2200-0911
	(DNC1 communication function+Graphic function RAM added)
	: A16B–2200–0912 (Graphic function)
	: A16B-2200-0913
	(Remote buffer communication function)
	: A16B-2200-0914
	(DNC1 communication function)
	: A16B-2200-0915
	(Remote buffer communication function+Graphic
	function RAM added)
	: A16B-2200-0916
	(DNC1 communication function+Graphic function RAM added)
	$\cdot $ A 16B 2200 0917
	(Graphic function RAM added)
	: A16B-2200-0918
	(Remote buffer communication function+Graphic
	function RAM added)
	: A16B-2200-0919
	(*Graphic function RAM added)
	Connector Connector
	name <u>No.</u> Description
CPU	
	R232–1 JD5C RS–232–C serial port
	R422–1 JD6A RS–422 serial port
Communicatio	
function ROM	



— 152 —

No.	Module name	Function outline
1	Graphic CPU module	Graphic display control CPU
2	Graphic engine module	Graphic display control circuit (No.2) Add in casee of CAP II of FS15–TT.
3	Graphic engine module	Graphic display control circuit (No.1)
4	CRT control module	Character display contorl circuit for 9" CRT Character display contorl circuit for 10.4" LCD Character display contorl circuit for 14" CRT
5	Communication control module	Serial communication control, DMA control





(3) Adjustment

No adjustment is needed.

#### (4) LED display

The STATUS LEDs in the front upper section of the option board are used for two independent functions as shown in the figure on the below.

 $\Box$ :Off  $\blacksquare$ :Lit  $\bigstar$  :Flashing  $\blacklozenge$ :Don't care

 $\star\star$  means both of LED are flashing at the same time.

 $\star$  means both of LED are flashing alternately.



(a) LED display of graphic display function

1. LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS	Startup status immediately after the power is turned on.
2	STATUS□■♦♦ ALARM □□□	Waiting for setting each processor of ID in the system.
3	STATUS∎□♦♦ ALARM □□□	Waiting for initialization of each processor in the system.
4	STATUS□□◆◆ ALARM □□□	The initialization of graphic display function is completed and on executing.

2. LED display when an error occurs

No.	LED display	NC status
1	STATUS∎□♦♦ ALARM ∎□□	ROM parity error occurs. Change graphic ROM.
2	STATUS∎□♦♦ ALARM ∎□□	RAM parity error occurs. Change option 1 board.
3	STATUS□★♦♦ ALARM ■□□	Command error occurs. Change option 1 board.
4	STATUS★★♦♦ ALARM ■□□	NMI from other boards. Check LED display of other boards.
5	STATUS★□♦♦ ALARM ■□□	Bus error (Wrong memory access) occurs. Change option 1 board.
6	STATUS★☆◆◆ ALARM ■□□	Division error occurs. Change option 1 board.
7	STATUS∎★♦♦ ALARM ∎□□	Incorrect interruption occurs. Change option 1 board.

(b) Communication function (Display of remote buffer)

1. LED display transition when the power is turned on

No.	LED display	NC status
1	STATUS	Startup status immediately after power is turned on or remote buffer CPU is not executing.
2	STATUS♦♦□□ ALARM ♦□□	Initialization of remote buffer is beginning.
3	STATUS♦♦■□ ALARM ♦□□	Initialization of remote buffer is completed and status of waiting for command from CNC.
4	STATUS♦♦□■ ALARM ♦□□	Command is executed.
5	STATUS♦ <b>◆■■</b> ALARM ◆□□	On closing (After closing, back to the status of No.3)

# 2. LED display when an error occurs

No.	LED display	NC status
1	STATUS♦♦★□ ALARM ♦□□	ROM parity alarm occurred.
2	STATUS♦♦□★ ALARM ♦□□	RAM error of test
3	STATUS♦♦★☆ ALARM ♦□□	A fault occurred in the remote buffer. (BUS ERROR, illegal interruption etc)
4	STATUS♦♦★★ ALARM ♦□□	NMI from other boards
5	STATUS♦♦♦♦ ALARM ♦□■	Parity alarm occurred on the work RAM of remote buffer.





No.	Module name	Function outline
1	DRAM module	Work RAM
2	F–ROM module	System ROM for ethernet

# NOTE

The OSI Ethernet board cannot be used with the Series 15MEK/MEL/TED/TEF/TEF-B-4.

#### (2) Block diagram



# (3) Adjustment

No adjustment is needed.

(4) LED display

 $\Box$  : Off  $\blacksquare$  : Lit  $\bigstar$  : Flashing

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED display	NC status
1	ALARM	Power-off
2	ALARM	Initial state immediately after power-on
3	ALARM □□★★	During self-diagnosis
4	ALARM	Normal state. The power on sequence is ended.

2. LED display when an error occurs (STATUS LED)

No.	LED display	NC status
1	ALARM □◊◊◊	An error occurred on the Ethernet board.
2	ALARM ∎□□★	Connection to the network failed.

#### 3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM ∎□□	SYSFAIL state (occurred on the board)
2	ALARM	Watchdog alarm
3	ALARM	A parity error occurred in the DRAM area.

# 2.5.21(1) Parts layoutOSI Ethernet BoardDrawing number : A16B-2201-0570Configuration<br/>(10 Base 5)Herein Constant



No.	Module name	Function outline
1	DRAM module	Work RAM
2	F–ROM module	System ROM for ethernet

# NOTE

The OSI Ethernet board cannot be used with the Series 15MEK/MEL/TED/TEF/TEF-B-4.

#### (2) Block diagram



(3) Adjustment

No adjustment is needed.

- (4) LED display
  - $\Box$  : Off  $\blacksquare$  : Lit  $\bigstar$  : Flashing

STATUS LEDs are green. ALARM LEDs are red.

1. LED display transition when the power is turned on (STATUS LED)

No.	LED display	NC status
1	ALARM	Power-off
2	ALARM	Initial state immediately after power-on
3	ALARM □□★★	During self-diagnosis
4	ALARM ■□□□	Normal state. The power on sequence is ended.

2. LED display when an error occurs (STATUS LED)

No.	LED display	NC status
1	ALARM □◊◊◊	An error occurred on the Ethernet board.
2	ALARM ∎□□★	Connection to the network failed.

3. LED display when an error occurs (ALARM LED)

No.	LED display	NC status
1	ALARM ∎□□	SYSFAIL state (occurred on the board)
2	ALARM	Watchdog alarm
3	ALARM	A parity error occurred in the DRAM area.

# 2.5.22 Alarm LED Display (Red) in the Event of an Error

With the Series 15–B, if an error occurs on a PC board other than the main board or sub–board, the red LED on the main board or sub–board may light.

The tables below list the ALARM LED statuses when an error occurs on the main board or on a sub-board:

ALARM LED display when an error occurs (when the main CPU is MAIN–A or MAIN–B)

Main board	Sub–board	Description
SYSEMG.	□□■ SYSEMG.	An NMI error occurred on the PMC, remote buff- er, or a PC board other than the main board or sub-board on the F-bus. The power supply unit supplies a lower-than- normal voltage.
SERVO ALARM	□■□ SYSFAIL	An error occurred in the servo module on the main board. The software detected an error on a PC board on the F–bus.
SYSEMG.	SERVO ALARM	An error occurred in the servo module of the sub-board.

ALARM LED display when an error occurs (when the main CPU is MAIN–C)

	Main board	Sub–board	Description
	SYSFAIL	□■□ SYSFAIL	The software detected an error on a PC board on the F–bus.
	SYSEMG.	□□■ SYSEMG.	An NMI error occurred on the PMC, remote buff- er, or a PC board other than main board or sub- board on the F-bus. The power supply unit supplies a lower-than- normal voltage.
	SERVO ALARM	□■□ SYSFAIL	An error occurred in the servo module on the main board.
or	SYSFAIL SYSEMG.	SERVO ALARM	An error occurred in the servo module on the sub-board.

ALARM LED display when an error occurs (when the main CPU is MAIN–A, –C)

Main board	Sub–board	Description
SYSFAIL	□∎□ SYSFAIL	A software–detected error occurred on a PC board on the F–bus (including the F–bus on the additional shelf side).
SYSEMG.	□□■ SYSEMG.	On the main shelf side, an NMI error occurred on the PMC, remote buffer, or a PC board on the F–bus other than the main board and sub–board. The voltage being supplied from the power sup- ply unit dropped.
ADD SHELF SYSEMG.	□∎□ SYSFAIL	An NMI error occurred on a PC board on the additional shelf side. The voltage being supplied from the power supply on the additional shelf side dropped.
### 2.5.23

Alarm LED (Red) Display in the Event of an Error Occurring in the Connection Unit/Operator's Panel Connection Unit

• Alarm LED on the connection unit



LED2 Off: Normal

On: Alarm state (Communication with the CNC is stopped.)

• Alarm LED on the operator's panel connection unit



ALARM Off: Normal

On : Alarm state (Communication with the CNC is stopped.)

 Alarm LED on the operator's panel connection unit (source output type)

A16B-2202-0730	
A16B-2202-0731	
CP1 OALARM	
DAL7	

#### ALARM Off: Normal

On : Alarm state (Communication with the CNC is stopped.)

The operator's panel connection unit (source output type) has a function for issuing an alarm upon detecting an excessive current that may flow through the output driver element as a result of such as DO grounding.

If an alarm state is detected, the CNC is placed in the system alarm state, and the LED corresponding to the DO causing that alarm is turned on. (See the table below.)

By using setting pin CP1 on the board, the CNC can be prevented from being placed in the system alarm state due to an output driver alarm.

DAL1	Off: Normal
	On : An error occurred in DO output Yq+0.0 to Yq+0.7.
DAL2	Off: Normal
	On : An error occurred in DO output Yq+1.0 to Yq+1.7.
DAL3	Off: Normal
	On : An error occurred in DO output $Yq+2.0$ to $Yq+2.7$ .
DAL4	Off: Normal
	On : An error occurred in DO output $Yq+3.0$ to $Yq+3.7$ .
DAL5	Off: Normal
	On : An error occurred in DO output $Yq+4.0$ to $Yq+4.7$ .
DAL6	Off: Normal
	On : An error occurred in DO output $Yq+5.0$ to $Yq+5.7$ .
DAL7	Off: Normal
	On : An error occurred in DO output $Yq+6.0$ to $Yq+6.7$ .
DAL8	Off: Normal
	On : An error occurred in DO output $Yq+7.0$ to $Yq+7.7$ .
A systen	n alarm caused by one of the above alarms is indicated as follows:
"SLC	C ERROR aa(bb)" Example: "SLC ERROR 03(01)"
(aa:	$XXXXXX11  Bits \ 0 \ and \ 1 \ are \ set \ to \ 1. \ The \ other \ bits \ are$
unde	fined.)
(bb:	XXXXXXX1 Bit 0 is set to 1. The other bits are undefined.)
Setting of	of setting pin CP1
Open	: An alarm is reported to the CNC.
~	

Connected : No alarm is reported to the CNC.

## 2.6 LIST OF THE PCBS AND UNITS

### 2.6.1 Control Unit Rack

Name		Drawing No.		Remarks	
	3–SLOT	A02B-0162-C001			
	4–SLOT	A02B-0162-C002		Standard	
	6–SLOT	A02B-0162-C003		Standard	
	8–SLOT	A02B-0162-C004	FANUC name plate		
		A02B-0240-C004		E Version	
	6–SLOT	A02B-0162-C008		Response to	
	8–SLOT	A02B-0162-C009		MMC-IV	Without sub BUS
	3–SLOT	A02B-0162-C011			Without sub. Doo
	4–SLOT	A02B-0162-C012		Chandard	
	6–SLOT	A02B-0162-C013	GE Fanuc name plate	Standard	
	8–SLOT	A02B-0162-C014			
Control unit		A02B-0240-C014		E Version	
rack	6–SLOT	A02B-0162-C018		Response to	
	8–SLOT	A02B-0162-C019		MMC-IV	
	4–SLOT	A02B-0162-C022			
	6–SLOT	A02B-0162-C023		Standard	
	8–SLOT	A02B-0162-C024	FANUC name plate		
	6–SLOT	A02B-0162-C028		Response to	
	8–SLOT	A02B-0162-C029		MMC-IV	With Sub BUS
	4–SLOT	A02B-0162-C032			
	6–SLOT	A02B-0162-C033		Standard	
	8-SLOT	A02B-0162-C034	GE Fanuc name plate		
	6-SLOT	A02B-0162-C038		Response to	
	8-SLOT	A02B-0162-C039		MMC-IV	

## 2.6.2 Power Supply Unit

Name		Drawing No.	Remarks
Power supply unit	AI	A16B–1212–0471 A16B–1212–0901	Conventional type CE marking compatible type
	BI	A16B–1212–0531 A16B–1212–0871	Conventional type CE marking compatible type

### 2.6.3 Control Unit PCB

	Name	Drawing No.	Remarks	Module ID
Main CPU	Standard MAIN–B	A16B-2201-0320		
board	High-speed MAIN-A	A16B-2201-0300		
	MAIN-C	A16B-3200-0060	Level up	
	MAIN-C	A16B-3200-0240	This board can not be used in Se- ries 15MEK/MEL/TED/TEE/TEF.	
	High-speed MAX-MAIN-A	A16B-2201-0340	For multi axis control, synchronous control, and malfunction control	
	MAX-MAIN-C	A16B-2202-0640	For multi axis control, synchronous control, and malfunction control	
PMC/ Conversational	Without conversational CPU for PMC–NA	A16B-2201-0371 A16B-2201-0391		77
board	Without conversational CPU for PMC–NB	A16B–2201–0381 A16B–2201–0811		6B
	Without conversational CPU for PMC–NB/NB2	A16B-2201-0851		9D
	With conversational CPU for PMC–NA	A16B-2201-0390		77/6D
	With conversational CPU for PMC–NB	A16B-2201-0810		7B/6D
	With conversational CPU for PMC–NB/NB2	A16B-2201-0850		9D/6D
Additional axis b	oard	A16B-2201-0311		63
Axis CPU board		A16B-2201-0360		7A
Buffer board		A16B-2201-0351		68
Sub CPU board	Standard MAX SUB–B	A16B-2201-0331	For multi axis control, synchronous Control, and malfunction control	73
	High-speed SUB-A	A16B-2201-0310		63
	SUB-C	A16B-2202-0571		A1

	Name	Drawing No.	Rei	narks	Module ID
Option 1 board	Graphic + Remote buffer	A16B-2200-0910	Increase of	For 10"LCD,	45/3F
	Graphic + DNC1	A16B-2200-0911	graphic CPU	9"graphic, or	45/3F
	Graphic	A16B-2200-0912			45
	Graphic	A16B-2200-0917	Graphic CPU		45
	Graphic + Remote buffer	A16B-2200-0915	RAM (standard)		45/3F
	Graphic + Remote buffer	A16B-2200-0918	Increase of	For 9.5"LCD,	45/3F
	Graphic + DNC1	A16B-2200-0916	graphic CPU	8.4"LCD, MMC–	45/3F
	Graphic	A16B-2200-0919		(analog)	45
	Remote buffer	A16B-2200-0913		·	3F
	DNC1	A16B-2200-0914			3F
RISC board		A16B-2201-0710			7F
		A16B-3200-0150	This board can n Series 15MEK/M	ot be used in EL/TED/TEE/TEF.	AF
ROM cassette a	dapter	A20B-2000-0760			74
OSI ethernet board		A16B-2201-0570	10 BASE 5 This board can not be used in Series 15MEK/MEL/TED/TEE/TEF.		6F
		A16B-2201-0571	10 BASE 5 This board can n Series 15MEK/M	ot be used in EL/TED/TEE/TEF.	6F

### 2.6.4 Back Panel PCB

Name		Drawing No.	Remarks
	3–SLOT	A20B-2000-0900	Standard
	4–SLOT	A20B-2000-0710	
	6-SLOT	A20B-2000-0720	
	8–SLOT	A20B-2000-0730	
Back plane	8–SLOT	A20B-2002-0430	for Series 15MEK/MEL/TED/ TEE/TEF-B-4
	6–SLOT	A20B-2001-0651	Response to MMC–IV
	8–SLOT	A20B-2001-0661	
	Sub bus	A20B-1005-0270	

### 2.6.5 Module (For Main CPU Board)

Name		Drawing No.	Remarks
Spindle control	Serial spindle + High–speed skip	A20B-2900-0672	
	Analog spindle + High–speed skip	A20B-2900-0770	
Peripheral modu	lle	A20B-2900-0660	
FLASH ROM	8MB	A20B-2902-0375*	Note that, for those modules marked with *, the correspond-
	6MB	A20B-2900-0810	ing software is required.
	4MB	A20B-2900-0811	
	4MB	A20B-2902-0374*	
	2MB	A20B-2900-0812	
DRAM module	4MB	A20B-2900-0651	
	2MB	A20B-2900-0800	
	6MB	A20B-2901-0940	For MAIN-C
	4MB	A20B-2901-0941	
	2MB	A20B-2901-0942	
High-speed SR/	AM module	A20B-2900-0641	
SRAM module	2MB	A20B-2900-0682	
	1MB	A20B-2900-0680	
	512KB	A20B-2900-0681	
	256KB	A20B-2900-0700	
	128KB	A20B-2900-0701	
	64KB	A20B-2900-0711	
Servo control mo	odule	A20B-2901-0340	Used for servo software series 9060 and 9061 (no restric- tion on the edition)
		A20B-2902-0400	Used for servo software series 9060/edition R or later. Used for servo software series 9061/edition B or later.
		A20B-2902-0180	Used for servo software series 9070
		A20B-2902-0420	Used for servo software series 9070 and 9080
Servo interface module		A20B-2900-0830 A20B-2901-0360 A20B-2902-0440	
CRT control mod	dule	A20B-2900-0691	9" CRT control
		A20B-2902-0520	Used for an intelligent terminal and graphic function built-in 10.4" LCD

### 2.6.6 Module (For PMC/ Conversational Board)

Name		Drawing No.	Remarks
	PMC-NA	A20B-2900-0780	
PMC CPU	PMC-NB	A20B-2901-0581	
		A20B 2000 0700	
PMC engine	PIVIC-NA	A20B-2900-0790	
	PMC-NB	A20B-2901-0660	
PMC control	PMC–NB	A20B-2901-0960	
module	PMC–NB2	A20B-2902-0250	
	2MB	A20B-2900-0653	
	512KB	A20B-2900-0803	
DRAM module	1M/512K	A20B-2902-0192	Only for PMC–NB/NB2
	512K/512K	A20B-9202-0193	
	–/512K	A20B-2902-0194	
SRAM module	1.25MB	A20B-2901-0400	Only for PMC–NB
	512KB	A20B-2901-0402	
Conversational module	CPU	A20B-2901-0390	
	1MB	A20B-2900-0290	
EPROM module	768KB	A20B-2900-0291	
	512KB	A20B-2900-0292	
	1MB	A20B-2900-0550	
DRAM module	512KB	A20B-2900-0551	
	128KB	A20B-2900-0555	
SRAM module	512KB	A20B-2900-0541	
SRAM/DRAM module	512K/512K	A20B-2901-0413	Only for PMC–NB/NB2

### 2.6.7 Module (For Sub CPU Board, Additional Axis Board, or Axis CPU Board)

Name		Drawing No.	Remarks
Spindle control module	Analog spindle + High–speed skip	A20B-2900-0770	
	Serial spindle + High–speed skip	A20B-2900-0672	
Analog input & serial comm	unication module	A20B-2900-0721	Serial communication is each one channel of RS–422 or RS–232C
Servo control module		A20B-2901-0340	Used for servo software series 9060 and 9061 (no restriction on the edition)
		A20B-2902-0400	Used for servo software series 9060/edition R or later. Used for servo software series 9061/edition B or later.
		A20B-2902-0180	Used for servo software series 9070
Servo interface module		A20B–2901–0360 A20B–2900–0830	
DRAM module	2MB	A20B-2900-0800	
	1MB	A20B-2900-0802	
	2MB	A20B-2901-0942	For SUB–C
High–speed SRAM module		A20B-2900-0641	
SRAM module	512KB	A20B-2900-0681	
	256KB	A20B-2900-0700	
Error motion check module		A20B-2900-0830	

### 2.6.8 Module (For RISC Board)

Nam	е	Drawing No.	Remarks
SRAM module	512KB	A20B-2900-0541	
ROM module	512KB	A20B-2900-0292	

### 2.6.9 Module (Option 1 Board)

New		Description No.	Demerler
Name		Drawing No.	Remarks
	14"CRT	A20B-2901-0370	Standard
		A20B-2902-0278	
	10″LCD 10″PDP	A20B-2901-0372	
CRT Control	9.5″LCD	A20B-2902-0272	
module	9″CRT 9″PDP	A20B-2901-0371	
	14"CRT	A20B-2901-0373	MMC-III
	10"LCD	A20B-2901-0375	
	MMC-IV	A20B-2902-0275	MMC-IV
Communication control module		A20B-2900-0361	
Graphic control module		A20B-2900-0311	
Graphic CPU m	odule	A20B-2900-0350	

### NOTE

When a graphic function built–in 10.4" LCD is used, the graphic function of the option 1 board is not used.

### 2.6.10 Module (OSI Ethernet Board)

Name	Drawing No.	Remarks
DRAM module	A20B-2901-0254	
F–ROM module	A20B-2900-0481	

## 2.6.11 Display Unit

N	lame		Drawing No.	Remarks
	Monochrome	Э,	A02B-0162-C041	
	vertical type		A02B-0162-C044	
			A02B-0163-C244	CE marking, English MDI
			A02B-0163-C444	CE marking, Symbolic MDI
	Monochrome	э,	A02B-0162-C042	
	horizontal ty	pe	A02B-0162-C045	
9 CKT/MDI			A02B-0163-C245	CE marking, English MDI
			A02B-0163-C445	CE marking, Symbolic MDI
	Color,		A02B-0162-C051	
	vertical type		A02B-0162-C054	
	Color,		A02B-0162-C052	
	norizontai ty	pe	A02B-0162-C055	
	Mono- chrome	М	A02B-0162-C101	
			A02B-0163-C301	CE marking, English MDI
9"small			A02B-0162-C102	
CRT/MDI		Т	A02B-0163-C302	CE marking, English MDI
	Color	М	A02B-0162-C103	
		Т	A02B-0162-C104	
	Monochrome	Э,	A02B-0162-C062	
		pe	A02B-0162-C065	
9"PDP/MDI			A02B-0163-C265	CE marking, English MDI
			A02B-0163-C465	CE marking, Symbolic MDI
	Mono-		A02B-0162-C105	
9"small	chrome	M	A02B-0163-C305	CE marking, English MDI
PDP/MDI			A02B-0162-C106	
	-		A02B-0163-C306	CE marking, English MDI

Name		Drawing No.	Remarks
	Color,	A02B-0162-C131	
		A02B-0163-C331	CE marking, English MDI
		A02B-0162-C141	MMC-IV
		A02B-0163-C341	MMC–IV, CE marking, English MDI
		A02B-0162-C133	15–TFB, 15–TTFB, 15TEF
9.5″LCD/		A02B-0163-C333	15–TFB, 15–TTFB, 15TEF, CE marking, English MDI
MDI	Color,	A02B-0162-C132	
	horizontal type	A02B-0163-C332	CE marking, English MDI
		A02B-0162-C142	MMC-IV
		A02B-0163-C342	MMC–IV, CE marking, English MDI
		A02B-0162-C132	15–TFB, 15–TTFB, 15TEF
		A02B-0163-C332	15–TFB, 15–TTFB, 15TEF, CE marking, English MDI
	Color,	A02B-0162-C071	
10"LCD/	vertical type	A02B-0162-C073	15–TFB, 15–TTFB, 15TEF
MDI	Color,	A02B-0162-C072	
nonzontai typ		A02B-0162-C074	15–TFB, 15–TTFB, 15TEF
	Color, vertical type	A02B-0163-C371	CE marking, graphic function bult–in
10.4″LCD/		A02B-0163-C571	CE marking, graphic function bult–in Symbolic MDI
MDI		A02B-0163-C381	CE marking, for MMC–IV
		A02B-0163-C581	CE marking, for MMC–IV Symbolic MDI

1	lame	Drawing No.	Remarks
	Color, horizontal type	A02B-0163-C372	CE marking, graphic function bult-in
10.4"LCD/		A02B-0163-C572	CE marking, graphic function bult–in Symbolic MDI
MDI		A02B-0163-C382	CE marking, for MMC–IV
		A02B-0163-C582	CE marking, for MMC–IV Symbolic MDI
10"PDP/	Monochrome, vertical type	A02B-0162-C081	
MDI	Monochrome, horizontal type	A02B-0162-C082	
	Color,	A02B-0162-C091	
	vertical type	A02B-0162-C093	15–TFB, 15–TTFB, 15TEF
		A02B-0162-C121	MMC-IV
		A02B-0163-C321	CE marking, English MDI*
14″CRT/		A02B-0163-C323	CE marking, English MDI, 15–TFB, 15–TTFB, 15TEF
		A02B-0163-C523	CE marking, Symbolic MDI, 15–TFB, 15–TTFB, 15TEF
	Color,	A02B-0162-C092	
	horizontal type	A02B-0162-C094	15–TFB, 15–TTFB, 15TEF
		A02B-0162-C122	MMC-IV
		A02B-0163-C322	CE marking, English MDI*
		A02B-0163-C324	CE marking, English MDI, 15–TFB, 15–TTFB, 15TEF
		A02B-0163-C522	CE marking, Symbolic MDI
Separate	Monochrome	A02B-0162-C046	
type CRT	Color	A02B-0162-C056	
Separate	Monochrome	A02B-0162-C066	
type PDP		A02B-0163-C268	CE marking

Name		Drawing No.	Remarks	
Separate type 10.4″LCD unit	Color	A02B-0222-C150	CE marking, graphic function bult–in	
Separate type 9.5″LCD unit	Monochrome	A02B-0222-C110	CE marking	

\* : Shared by 15–MB, 15–MFB, 15–TB, 15–TTB, 15MEL 15TEE and MMC–IV

### 2.6.12 External Control Unit (Except I/O Unit)

N	lame	Drawing No.	Remarks
Separate type	e MDI unit	A02B-0162-C111	
		A02B-0162-C112	
		A02B-0163-C312	CE marking, English MDI
		A02B-0163-C313	CE marking, Symbolic MDI
		A02B-0163-C316	CE marking, for separate type LCD, vertical type, English MDI*
		A02B-0163-C317	CE marking, for separate type LCD, horizontal type, English MDI*
		A02B-0163-C318	CE marking, for separate type LCD, vertical type, English MDI*
		A02B-0163-C319	CE marking, for separate type LCD, horizontal type, English MDI*
Connection u	init 1	A20B-1005-0310	DI/DO 96/64
Connection u	init 2	A20B-1003-0200	DI/DO 96/64
	DI/DO 64/32	A16B-2200-0661	Sink type
Operator's		A16B-2202-0731	Source type
panel con- nection unit	DI/DO 96/64	A16B-2200-0660	Sink type
		A16B-2202-0730	Source type
Optical I/O Li	nk adaptor	A13B-0154-B001	
Input unit for multiple axis system		A14B-0076-B402	

Name		Drawing No.			Ren	narks		
Basic unit	ABU10A	A03B-0807-J001	It's possible to mount up to 10 modules.					
	ABU10B	A03B-0807-J004						
Basic unit	ABU05A	A03B-0807-J002	002 It's possible to mount up to 5 modules.					
	ABU05B	A03B-0807-J003						
Interface	AIF01A	A03B-0807-J011						
module	AIF01B	A03B-0807-J012	For slave					
	AIF02C	A03B-0807-J013						
Digital input module		Drawing No.	Туре	Point	Voltage	Porar- ity	Resp onse	Connection
∗1.When	AID32A1	A03B-0807-J101	Non-in	32	24VDC	Both	20ms	Connector A
level, it will be	AID32B1	A03B-0807-J102	type DC	32	24VDC	Both	2ms	Connector A
considered to turn - on. (0V common)	AID32H1	A03B-0807-J111	Input	32	24VDC	Both	2ms: 8 20ms: 8	Connector A
∗2.When Input is Hi	AID16C	A03B-0807-J103	–J103 Inslation type DC input –	16	24VDC	<sup>*</sup> 1 NEG	20ms	Terminal block
level, it will be considered to turn on.	AID16D	A03B-0807-J104		16	24VDC	*2 POS	20ms	Terminal block
(24V common)	/ common) AID16K A03B-0807-J113	16	24VDC	<sup>*</sup> 1 NEG	2ms	Terminal block		
	AID16L	A03B-0807-J114		16	24VDC	*2 POS	2ms	Terminal block
	AID32E1	A03B-0807-J105	Inslation	32	24VDC	Both	20ms	Connector A
	AID32E2	A03B-0807-J110	input	32	24VDC	Both	20ms	Connector B
	AID32F1	A03B-0807-J106		32	24VDC	Both	2ms	Connector A
	AID32F2	A03B-0807-J109	]	32	24VDC	Both	2ms	Connector B
	AID16G	A03B-0807-J107	AC input	16	100 –115VAC	ON OFF	30ms 45ms	Terminal block

### I/O Unit-MODEL A

Name		Drawing No.	No. Remarks					
Digital output modul	е	Drawing No.	Туре	point	Voltage	Porar- ity	Resp once	Connection
•3.When turning on, output becomes Lo	AOD32A1	A03B-0807-J162	Non – inslation type DC output	32	5 -24VDC	<sup>*</sup> 3 NEG	0.3A	Connection A
(0V common)	AOD08C	A03B-0807-J151	Inslation type DC	8	12 -24VDC	·3 NEG	2A	Terminal block
*4.vvnen turning on output	AOD08D	A03B-0807-J152	σαιραί	8		⁺4 POS	2A	Terminal block
becomes Lo level. (24V common)	AOD16C	A03B-0807-J153		16		·3 NEG	0.5A	Terminal block
	AOD16D	A03B-0807-J154		16		·4 POS	0.5A	Terminal block
	AOD32C1	A03B-0807-J155		32		·3 NEG	0.3A	Connector A
	AOD32D1	A03B-0807-J156		32		<sup>*</sup> 4 POS	0.3A	Connector A
	AOD32D2	A03B-0807-J167		32		<sup>*</sup> 4 POS	0.3A	Connector B
	AOA05E	A03B-0807-J157	AC output	5	100 –230VAC		2A	Terminal block
	AOA08E	A03B-0807-J158		8			1A	Terminal block
	AOA12F	A03B-0807-J159		12	100 -115VAC		0.5A	Terminal block
	AOR08G	A03B-0807-J160	Relay output	8	250VAC /30VDC		4A	Terminal block
	AOR16G	A03B-0807-J161		16			2A	Terminal block
	AOR16H2	A03B-0807-J165		16	30VDC		2A	Connector B
Analog input module	AAD04A	A03B-0807-J051	Analog inpu	t 4 chanı	nels			
Analog output module	ADA02A	A03B-0807-J052	Analog outp	ut 2 chai	nnels			
High–speed counter module	ACT01A	A03B-0807-J052	Pulse input 1 channel					

I/O	Unit-MODEL	Α
I/O	Unit MODLL	11

## 2.7 HOW TO REPLACE THE MODULES

2.7.1 Removing (1) Pull the latches of the module socket outwards. (Fig.(a))(2) Pull out the module upward. (Fig.(b))

### 2.7.2 Insertion

### Procedure for insetion of the module

- (1) Insert the new module board diagonally with B-SIDE outward (Fig.b)
- (2) While pushing on the upper edge of the module board, raise it until it is locked (Fig.(c)).



### 2.8 HOW TO REPLACE THE BATTERIES

### 2.8.1

Replace the Battery for Memory Back Up (1) Use the following lithium batteries:

When the power supply unit is A02B–0162–H101 or –H102: Ordering drawing number A98L–0031–0007 When the power supply unit is A02B–0162–H107 or –H108: Ordering drawing number A98L–0031–0012

(2) Trun on the 15–B

(3) Remove the battery case from the front panel of the power supply unit. The case can be removed easily by holding the top and bottom of it and pulling.



Fig. 2.8.1 (a) Replacing the battery (1)

(4) Remove the connector from the battery.



Fig. 2.8.1 (b) Replacing the battery (2)

(5) Replace the battery and reconnect the connector.

(6) Install the battery case.

(7) Turn off the Series 15–B

### 2.8.2 Replacing Batteries for Separate Absolute Pulse Coder

#### Procedure for replacing the batteries for absolute pulse coder

- **1** Prepare 4 commercially available dry cell batteries
- 2 Turn on CNC power. If the batteries are replaced with the power off, absolute position of the machine is lost.
- **3** Loosen the screws of battery case lid and remove the lid. Consult with the MTB's manual for where the battery case is installed.
- 4 Replace the batteries in the case. Take care to place the batteries facing in the correct direction. (Insert the batteries as shown in the diagram with 2 facing one way and 2 the other.)



- 5 Having exchanged the batteries put the lid back on.
- 6 Turn off the power once, then turn it to on.
- 7 A battery alarm may be generated, but execute power off and on.
- 8 Procedure completes.

## 2.9 HOW TO REPLACE FAN MOTOR

#### Fan ordering information

	Ordering code	Number of units required
For 2–slot rack	A90L-0001-0378	For 1–slot rack
For 1-slot rack	A90L-0001-0385#A	For 2–slot rack

#### Procedure for replacing the fan motor

- 1 Remove the control section printed circuit board underneath the fan to be replaced.
- 2 There is a backplane inside the slot. The fan motor cable is connected to the backplane. Grasp the left and right side of the cable connector attached to the backplane and remove it.
- **3** Open the upper lid of the control section rack. Insert a philips head screwdriver into the hole at the center front of the lid. The latch holding the cover in place can be released by prying with the screwdriver in the direction shown in (3) of following figure.
- 4 Open the lid sufficiently and remove the fan motor. Since the fan itself is not screwed into the rack, it can be easily removed.
- 5 Install the new fan motor. Guide the fan motor cable through the hole and into the rack.
- 6 Close the lid until the latch locks.
- 7 Attach the fan motor cable to the connector on the back plane. At this time, affix the middle portion of the cable to the hooks at the back of the rack.
- 8 Insert the removed control section printed circuit board.



Fig. 2.9 Fan motor replacement

### 2.10 FUSE REPLACEMENT IN POWER SUPPLY UNIT

When a fuse blows in the power supply unit of the CNC, find and correct the cause of the failure and replace the fuse.

Each fuse has a small window in which a white mark appears when the fuse has blown.

Fig. 1 shows the fuse mounting diagram, and table 1 shows the fuse lists. (For the fuse specifications, see Section 2.5.1.)



Fig. 2.10 (a) Mounting positions of fuses in the power supply unit (Power supply unit of CE marking compatible type)



Fig. 2.10 (b) Mounting positions of fuses in the power supply unit (Power supply unit of conventional type)

### 2.11 MAINTENANCE OF HEAT PIPE TYPE HEAT EXCHANGER

It is necessary to regulary clean the heat transformer, because the heat transformation ability will be reduced by the accumulation of dust. The frequency of the cleaning needed differs according to the installation environment and therefore should be determined by your own judgment accordint to the degree of dirt.

#### Air filter cleaning and replacement method

- **1** When cleaning and replacing the filter, be sure to cut off the fan's electric power source.
- 2 Detach the filter cover and take out the filter inside.



3 Protect the filter from silting due to dust by blowing air on both sides.



- 4 When dirt is conspicuous, press wash with a neutral detergent, rinse with fresh water, and the washing, allow to dry naturally. When replacing with the same product.
- **5** Insert the filter in the cover, align the flange in the groove, and install by pressing. Confirm that the cover will not come loose even if it is pulled.

#### **Cleaning heat exchanger**

- 1 When cleaning, be sure to cut off the fan power source.
- 2 Take out the external fan unit from the heat exchanger main unit.



#### Method of cleaning fan unit

1 Wipe the dirt, condensation, etc., which has accumulated on the fan motor and fan installation case with a dry cloth, etc. When the condensation, etc. has accumulated and the dirt is difficult to remove, soak a cloth in neutral detergent, lightry squeze it and wipe away the dirt.

However, take care not to allow the detergent to enter the electrical sections such as the internal rotor of the fan motor.



#### Method of cleaning heat exchanger fan

1 Detach the heat exchanger format the unit and either blow off with air, wipe off with a dry cloth, or brush the accumulated dirt, condensation, etc.



1 Detach the internal fan unit, the terminal unit, and the cable from the main unit.



- **2** Using a neutral detergent, remove the dirt from the main unit fan section by brushing. At this time, take care not to bend the fin of the element.
- **3** After cleaning, dry well.

#### Method of installation after cleaning

After completing cleaning of the fan unit and heat transformer.

- **1** Install the terminal unit and cable in the original position.
- 2 Install the fan unit in the original position. At this time, do not forget to connect the fan power cable and the earth cable.

2.12.1

Other

2.12.2

10" LCD

9.5" LCD

### 2.12 ADJUSTING THE LIQUID–CRYSTAL DISPLAYS

The liquid–crystal displays have controls for fine adjustment of the video signal. These are required to adjust any horizontal dot shift and/or flicker of the screen caused by a slight mismatch between the NC and the cable being used.

9.5" color liquid–crystal display (rear)

O SW1	<u>000</u> TM1	

- Adjusting for flicker (TM1)
- Horizontal shift of the screen display (SW1)

If any flicker is observed, switch TM1 to the other setting. Usually, selecting one of the two settings will eliminate any flicker.

- 1 The display screen can be shifted horizontally one dot at a time.
- 2 Set SW1 so that all information to be displayed appears on the screen. There is only one optimal position. The liquid–crystal display is factory–set to the optimal position, so that the user should not have to make any change.

Never change any of the other settings or controls.

10" color liquid–crystal display (rear)



- Adjusting for flicker (TM1)
- Horizontal shift of the screen display (SW1)
- Other

- 1 By change the setting until the flicker is eliminated.
- 2 If each of several settings eliminates the flicker, select that setting which best corresponds to the midpoint.

Example: If no flicker occurs with settings [1] through [6], select [4].

- 1 The display screen can be shifted horizontally one dot at a time.
- 2 Set SW1 so that all information to be displayed appears on the screen. There is only one optimal position. The liquid–crystal display is factory–set to the optimal position, so that the user should not have to make any change.
- Never change any of the other settings or controls.
- Never change the settings of the graphic function built–in 10.4" LCD.
- Never change the settings of the 10.4" LCD (for MMC–IV).

2.12.3 10″ PDP	10" plasma display (rear)
	Power supply
<ul> <li>Adjusting for flicker (SW2)</li> </ul>	<ol> <li>Change the setting until the flicker is eliminated.</li> <li>If each of several settings eliminates the flicker, select that setting which best corresponds to the midpoint. Example: If no flicker occurs with settings [1] through [6], select [4].</li> </ol>
<ul> <li>Horizontal shift of the screen display (SW1)</li> </ul>	<ol> <li>The display screen can be shifted horizontally one dot at a time.</li> <li>Set SW1 so that all information to be displayed appears on the screen. There is only one optimal position. The plasma display is factory-set to the optimal position, so that the user should not have to make any change.</li> </ol>
• Other	Never change any of the other settings or controls.
2.12.4 9″ PDP	9" plasma display (rear)
<ul> <li>Adjusting for flicker (SW1)</li> </ul>	<ol> <li>Change the setting until the flicker is eliminated.</li> <li>If each of several settings eliminates the flicker, select that setting which best corresponds to the midpoint. Example: If no flicker occurs with settings [1] through [6], select [4].</li> </ol>
<ul> <li>Horizontal shift of the screen display (SW2)</li> </ul>	<ol> <li>The display screen can be shifted horizontally one dot at a time.</li> <li>Set SW2 so that all information to be displayed appears on the screen. There is only one optimal position. The plasma display is factory-set to the optimal position, so that the user should not have to make any change.</li> </ol>
• Other	Never change any of the other settings or controls.

### 2.13 REPLACING THE FUSES OF THE LIQUID-CRYSTAL DISPLAYS

This section describes the locations of the fuses of the liquid–crystal displays, as well as how to replace them.



### 2.14 REPLACING THE LCD BACKLIGHT

The LCD backlight must be replaced periodically. Replace the unit in which the LCD backlight is mounted.

The LCD backlight has a life of about 10,000 hours (5,000 hours guaranteed). (During its lifetime, the backlight should maintain a brightness exceeding 50% of that when new.)

Upon reaching the end of its service life, the LCD backlight unit must be replaced. The unit can be replaced either by the user or by a FANUC service engineer.

### 2.15 HOW TO REPLACE THE CRT DISPLAY

#### Procedure for replacing the CRT display

- 1 Disconnect the CRT unit power cable and the video signal cable.
- 2 When replacing a 9" monochrome CRT, remove the chloridized veneer cover and the four screws from the front of the CRT unit.
- 3 When replacing a 9" color CRT, remove the four screws in the front of the CRT unit.
- 4 When replacing a 14" color CRT, remove the two screws from the bottom of the CRT unit and pull it towards you.
- **5** Install the new CRT unit.
- 6 Reconnect the CRT power supply cable and video signal cable to their original positions.



Fig. 2.15 Replacing the CRT display

### 2.16 HOW TO REPLACE THE MDI KEYBOARD

#### Procedure for replacing the MDI keyboard

- 1 The small printed circuit board at the rear of the MDI keyboard can be seen from the back of the CRT/MDI control unit. There is a flat cable, coming from the soft keyboard, attached to this printed circuit board. Disconnect this cable.
- 2 Remove the cable attached to the power on/off button.
- **3** Remove the M3 screws from the front panel attached to the sheet metal panel of the CRT/MDI unit.
- 4 The keyboard is located in between the front panel and the sheet metal panel. The keyboard can now be removed (there are no screws holding the keyboard).
- 5 Insert the new keyboard into the front panel. Screw the front panel onto the sheet metal panel.
- 6 Reattach the power on/off cable and flat cable removed in steps (1) and (2) to their original positions.



Fig. 2.16 MDI keyboard replacement

### 2.17 HOW TO REPLACE THE CARD CAGE IN THE CONTROL UNIT

Procedure for replacing the control unit

- **1** Turn off the power supply and disconnect all the attached cables.
- 2 Unscrew and remove the screws holding the lower portion of the rack.
- **3** The screw holes in the upper portion of the rack are made for slide–off removal. Loosen the screws and remove the rack by lifting it up and away.
- 4 Temporarily position the new rack by guiding the screws through the holes in the upper portion of the rack.
- **5** Insert the screws for affixing the lower portion of the rack, then sufficiently tighten all the screws holding the rack.
- 6 Reconnect the cables to their original positions.



Fig. 2.17 Replacement of the control section rack

— 191 —

### 2.18 HANDLING MEMORY CARDS

2.18.1 Overview	<ul> <li>As data exchange media, the CNC supports the use of two types of memory cards, flash memory cards and SRAM memory cards, that conform to the following standards:</li> <li>JEIDA "IC Memory Card Guideline Ver.4.0"</li> <li>PCMCIA "PC Card Standard R.2.0"</li> </ul>	
	A memory card is a user-friendly data exchange medium allowing high-speed input/output. Memory cards must, however, be handled with care.	
	The sections below provide notes on using memory cards and describe the method of using memory cards.	
	Note that a flash memory card, when used with PMC–NA, can be used only with the Boot menu.	
2.18.2 Notes on Use		
<ul> <li>Flash memory card</li> </ul>	(1) It is recommended that a flash memory card be backed up to a floppy disk to guard against the data on the flash memory card being destroyed or lost as a result of an accident.	
<ul> <li>SRAM Memory Card</li> </ul>	(1) An SRAM memory card requires a backup battery. SRAM memory cards are sold with no battery installed, however. Install a battery as explained in Section 2.18.5.	
	(2) The data stored on an SRAM memory card will be lost when the installed battery fails. Therefore, always back up the data stored on an SRAM memory card.	
	(3) SRAM memory cards are provided with a battery voltage detection function. If an SRAM memory card with a weak battery is connected to the CNC, the CNC displays an alarm. Note, however, that if a battery is not installed in the SRAM memory card, the battery voltage detection function will be disabled.	

### 2.18.3 Names and Functions of the Components



	Name	Function		
1	Write protect switch	Writing to the memory card can be disabled by setting the write protect switch accordingly.         Writing is enabled.         Writing is disabled.		
2	Battery case	An SRAM memory card has a battery case for housing the battery used for data backup. Flash memory cards have no battery case.		

## 2.18.4 Using Memory Cards

- Inserting a memory card
- (1)Carefully insert a memory card into the memory card slot, in the direction shown below.
- (2) A memory card has an insertion guide; it cannot be inserted in other than the correct orientation. When inserting a memory card, however, check its orientation.



- Operation
- Removing a memory card
- (1)For details of the write and read operations, refer to the relevant operator's manual.
- (1) Pull out the memory card in the direction shown below.



### 2.18.5 Replacing the Battery

- Battery
- Battery life

A BR2325 or equivalent battery is used.

The lives of batteries are listed below. Note that the life of a battery depends on its environment, including the ambient temperature. So, the values given should be used for reference only.

(Ambient temperature: 20°C)

Drawing number	Manufacturer model	Battery life
A87L-0001-0150#256K	MB98A90823-20	About 1 year
A87L-0001-0150#512K	MB98A90923-20	About 6 months
A87L-0001-0150#1M	MB98A91023-20	About 1 year
A87L-0001-0150#2M	MB98A91123–20	About 6 months

#### • Replacing the battery

(1) While holding down the locking clip, pull out the battery case.



(2) Replace the battery with a new one.

Align the + mark of the new battery with the + mark on the battery case.



(3) Reinstall the battery case, then check that the battery operates normally.





# INPUT AND OUTPUT OF DATA

This chapter describes the methods of inputting/outputting various types of data, required settings, and so forth.

3.1	1 SETTING THE PARAMETERS REQUIRED FOR		
	INPUT/OUTPUT	197	
3.2	DATA INPUT/OUTPUT	200	
# 3.1 SETTING THE PARAMETERS REQUIRED FOR INPUT/OUTPUT

Falallet	
Procedure	1 Enable parameter writing.
	(1) Set the MDI mode or emergency stop state.
	(2) When the MDI mode is selected instead of the emergency stop state, switch memory protection key KEY2 to ON.
	(3) Display the general setting screen.
	1) Press the $setting$ key.
	2) Press the $\bigcirc$ function menu key.
	3) Press the [CHAPTER] soft key.
	4) Press the [GENERAL] soft key.
	The general setting screen can also be displayed by pressing the
	setting key several times.
	(4) Set bit 0 of setting data No. 8000 to 1.
	1) Key in 8000, then press the [INP–NO.] soft key.
	2) Press <b>1</b> and $\begin{bmatrix} INPUT\\INSERT \end{bmatrix}$ .
	Then, the "SW000 parameter write switch on" alarm is issued.
	2 Display the parameter screen.
	(1) Press the service key.
	(2) Press the $\bigcirc$ function menu key.
	(3) Press the [CHAPTER] soft key.
	(4) Press the [PARAM] soft key.
	The parameter screen can also be displayed by pressing the service key
	several times.
	3 Set parameters.
	Press the b operation menu key. Then, the operation menu shown below
	(1) INP_NO: Searches for a parameter number
	Example: $Parameter number \rightarrow INP-NO.$
	(2) ON : 1: Sets the value where the cursor is positioned to 1 (only for bit parameter).
	(3) OFF : 0: Sets the value where the cursor is positioned to 0 (only for bit parameters).

- (4)+INPUT: Adds an input value to the data at the cursor position so that the sum is entered at the cursor position (parameters other than bit parameters).
- (5) INPUT: Enters an input value at the cursor position.
- (6) READ: Enters parameters from the reader/punch interface.
- (7) PUNCH: Outputs parameters to the reader/punch interface.
- 4 Ending parameter writing

After terminating parameter write operation, return bit 0 of setting data No. 8000 to 0 by using the same procedure as described in Item 1 above. Then, press RESET to release the SW000 alarm.

5 Simple setting methods

(1) Bit–by–bit setting

The cursor can be resized to the one-bit size by pressing the cursor keys  $\frown$  and  $\frown$ , thus enabling bit-by-bit setting (only for bit parameters).

(2) Successive data setting starting at the cursor position

Data items can be successively entered by inserting  $\begin{bmatrix} EOB \\ HELP \end{bmatrix}$  between adjacent data items.



(3) Repeatedly setting the same data

The same data item can be set repeatedly by using the  $0_{\pm}$  key.



# **3.2 DATA INPUT/OUTPUT** The main CPU board stores the data indicated below. While the control unit is operating normally, output the data to an I/O device beforehand. (1) CNC parameters (2) PMC parameters (3) Pitch error compensation data (4) Custom macro variable values

(5) Tool offset data

(6) Part programs (machining programs, custom macros)

# 3.2.1 Checking the Parameters Required for Data Input/Output

Correlation diagrams for parameters related to reader/punch interfaces are given below.

Parameters related to the reader/punch interface

The correlation diagrams of the parameters related to the reader/punch interface are given below.

1) Main CPU board + Option 1 board (with communication functions)



- Channel 1 : JD5A of the main CPU board
- Channel 2 : JD5B of the main CPU board
- Channel 10 : JD5C (RS-232-C) or JD6A (RS-422) of OP1. Only one of the two can be used. Which is used is specified with bit 0 of parameter No. 5000.

2) Main CPU board + Additional axis board (SUB, ADAX)



- Channel 1 : JD5A of the main CPU board
- Channel 2 : JD5B of the main CPU board
- Channel 3 : JD5J of the sub-board
- Channel 13 : JD6D of the sub-board
- 3) Main CPU board + Sub–board (additional axis) + Option 1 board (with communication functions)



Channel 1	: JD5A of the main CPU board		
Channel 2	JD5B of the main CPU board		
Channel 3	JD5J of the sub-board		
Channel 13	: JD6D of the sub–board		
Channel 10	: JD5C or JD6A of OP1.		
	Only one of the two can be used.		
	Which is used is specified with bit 0 of parameter		
	No. 5000.		
Connector for	or RS–232–C : JD5A, JD5B, JD5C, JD5J		
Connector for	or RS–422 : JD6A, JD6D		

#### NOTE

The option 1 board contains a remote buffer.

Each reader/punch unit is temporarily assigned device numbers 1 to 6.

When you have four reader/punch units, for example, assign device numbers 1 to 4 to them.

Set the specifications of the assigned reader/punch units in parameter Nos. 5110 to 5162. Set the device numbers of the reader/punch units connected to channels 1, 2, 3, and 13 in parameter Nos. 5001, 5002, 5003, and 5013.

Set the specifications of the host computer connected to the remote buffer in parameter Nos. 5071 to 5084. A parameter that specifies which reader/punch unit is connected to channel 10 is not provided because the remote buffer is always connected to channel 10.

Parameter Nos. 0020 to 0023 select which channels are used as input/output units for foreground/background. These parameters are normally set on a dedicated screen called the SETTING HANDY screen.



0020

Interface No. of input device for foreground

#### [Setting input]

[Data type] Byte

Assignment of input device numbers for foreground

- 0: Reader connected to JD5A of main CPU board
- 1 : Reader connected to JD5A of main CPU board (Settings 0 and 1 are identical.)
- 2: Reader connected to JD5B of main CPU board
- 3: Reader connected to JD5J of the subboard
- 4 : DNC1
- 9 : PMC
- 10: Remote buffer
- 13: Reader connected to JD6D of the subboard
- 15: MMC DNC operation interface
- 16: MMC upload/download interface

Perform system reset after setting this parameter.

#### 0021

Interface No. of output device for foreground

#### [Setting input]

[Data type] Byte

Assignment of output device numbers for foreground

- 1: Punch connected to JD5A of main CPU board
- 2: Punch connected to JD5B of main CPU board
- 3: Punch connected to JD5J of the subboard
- 4 : DNC1
- 9 : PMC
- 10: Remote buffer
- 13: Punch connected to JD6D of the subboard
- 15: MMC DNC operation interface
- 16: MMC upload/download interface

Perform system reset after setting this parameter.

0022 Interface No. of input device for background

#### [Setting input]

#### [Data type] Byte

Assignment of input device numbers for background

- 0: Reader connected to JD5A of main CPU board
- 1 : Reader connected to JD5A of main CPU board (Settings 0 and 1 are identical.)
- 2: Reader connected to JD5B of main CPU board
- 3: Reader connected to JD5J of the subboard
- 4 : DNC1
- 9 : PMC
- 10: Remote buffer
- 13: Reader connected to JD6D of the subboard
- 16: MMC upload/download interface

Perform system reset after setting this parameter.

0023

Interface No. of output device for background

#### [Setting input]

#### [Data type] Byte

Assignment of output device numbers for background

- 1: Punch connected to JD5A of main CPU board
- 2: Punch connected to JD5B of main CPU board
- 3: Punch connected to JD5J of the subboard
- 4 : DNC1
- 9 : PMC
- 10: Remote buffer
- 13: Punch connected to JD6D of the subboard
- 15: MMC DNC operation interface
- 16: MMC upload/download interface

Perform system reset after setting this parameter.

5001	Device number of reader/punch unit connected to JD5A of MAIN
5002	Device number of reader/punch unit connected to JD5B of MAIN
5003	Device number of reader/punch unit connected to JD5J of additional axis board

#### [Setting input]

[Data type] Byte

[Valid data range] 1 to 6

Set the device numbers of the reader/punch units connected to connectors CD4A, CD4B, and CD4.

Set the code numbers of the reader/punch units corresponding to device numbers 1 to 6 in parameter Nos. 5100 to 5162.

5013 Device number of reader/punch unit connected to JD6D of additional axis board				
[Setting input]				
[Data type]	Byte			
[Valid data range]	1 to 6			
Set the device number of the reader/punch unit connected to the RS-422 interface.				
Set the code numbers of the reader/punch units corresponding to device numbers 1 to 6 in parameter Nos. 5110 to 5162.				
5110	Code number of reader/punch unit corresponding to device number 1			
[Setting input]				
[Data type]	Byte			
[Valid data range]	1 to 8			
	Set the code number of reader/punch unit corresponding to device number 1.			

The table below gives the correspondence between code numbers and specifications of reader/punch units.

Spec. number	Reader/puncher device specifications
1	Control codes (DC1–DC4) are used. A punch outputs a feed. Tape reader
2	Control codes (DC1–DC4) are not used. A punch outputs a feed.
3	Control codes (DC1–DC4) are used. A punch does not output a feed.
4	Control codes (DC1–DC4) are not used. A punch does not output a feed.
5	Portable tape reader
6	PPR, Handy File (Local mode)
7	FANUC cassette
8	Floppy cassette, PROGRAM FILE Mate, Handy File (Remote mode)

Be sure to set 5 to use the rewinding function with the RS–232–C interface.

5111

Number of stop bits of reader/punch unit corresponding to device number 1

[Setting input]

[Data type] Byte

[Valid data range] 1 to 2

Set the number of stop bits of reader/punch unit corresponding to device number 1.

5112

Baud rate of reader/punch unit corresponding to device number 1

#### [Setting input]

[Data type] Byte

[Valid data range] 1 to 12

Set the baud rate of the reader/punch unit corresponding to device number 1.

The table below gives the correspondence between the specified numbers and baud rate.

Specified number	Baud rate	Specified number	Baud rate
1	50	7	600
2	100	8	1200
3	110	9	2400
4	150	10	4800
5	200	11	9600
6	300	12	19200

5120	Code number of reader/punch unit corresponding to device number 2
5121	Number of stop bits of reader/punch unit corresponding to device number 2
5122	Baud rate of reader/punch unit corresponding to device number 2
5130	Code number of reader/punch unit corresponding to device number 3
5131	Number of stop bits of reader/punch unit corresponding to device number 3
5132	Baud rate of reader/punch unit corresponding to device number 3
5140	Code number of reader/punch unit corresponding to device number 4
5141	Number of stop bits of reader/punch unit corresponding to device number 4
5142	Baud rate of reader/punch unit corresponding to device number 4
5150	Code number of reader/punch unit corresponding to device number 5
5151	Number of stop bits of reader/punch unit corresponding to device number 5
5152	Baud rate of reader/punch unit corresponding to device number 5
5160	Code number of reader/punch unit corresponding to device number 6
5161	Number of stop bits of reader/punch unit corresponding to device number 6
5162	Baud rate of reader/punch unit corresponding to device number 6

The method for setting these parameters is the same as for setting the specifications of the input/output unit corresponding to device number 1.

# 3.2.2 Data Output

3.2.2.1	1 Display the parameter screen.
CNC parameter output	1) Press the $\begin{bmatrix} \text{SERVICE} \end{bmatrix}$ key.
	2) Press the $\bigcirc$ function menu key.
	3) Press the [CHAPTER] soft key.
	4) Press the [PARAM] soft key.
	The parameter screen can also be displayed by pressing the service key several times.
	2 Press the D operation menu key to display [PUNCH] in the soft key menu.
	<ul><li>3 Press the [PUNCH] soft key. Then, the soft key menu changes, and the [PARAM] soft key is displayed.</li></ul>
	4 Press the [PARAM] soft key to start parameter output.
3.2.2.2 Outputting PMC parameter	<ul> <li>(1) Setting the input/output channel</li> <li>When inputting and outputting data, the input/output channel must be correctly set. Once the input/output channel has been set, the setting is maintained even after the CNC is turned off. Therefore, further channel setting is normally not required. If the input/output channel must be again set for some reason, follow the steps below.</li> <li><b>1.</b> Press the PMC key to display the PMC screen. When the lower soft key list as shown in the figure below is displayed on the PMC screen, steps <b>2.</b> to <b>8.</b> are not needed.</li> </ul>
	2. Press the $PMC_{CNC}$ key to display the NC screen. Then put the CNC in the MDI mode or emergency stop mode.
	<b>3.</b> Press the $\begin{bmatrix} \text{SETTING} \end{bmatrix}$ soft key to display the setting screen.
	<ol> <li>Enter 8000 and press the [INP–NO.] soft key. Parameter No. 8000 is now displayed.</li> </ol>
	<b>5.</b> If PWE, the lowest bit of parameter No. 8000, is set to 0, change
	it to 1. Then press the $\left( \begin{array}{c} \text{INPUT}\\ \text{INSERT} \end{array} \right)$ soft key. This sets the PWE bit to 1
	and puts the NC in the alarm mode.
	6. Press the $\boxed{PMC}_{CNC}$ soft key to display the PMC screen.

#### \_\_\_\_ 208 \_\_\_\_

7. Press the [PCPRM] soft key. Then press the [KEEPRL] soft key to display the keep relay screen. Press the ↓ page key until the screen which contains the K17 data line is displayed. When this screen is displayed, place the cursor at the K17 data using the cursor keys. Then enter 10000000 and press the <sup>INPUT</sup>/<sub>INSERT</sub> soft key. This sets the highest bit of the K17 data to 1. (Keep record of the original K17 data until step 10.)



- **8.** Press the return key on the left of the soft keys several times to display the soft key menu as shown in the figure in step **1**.
- **9.** Press the soft keys [I/O], [FDCAS], and [CHANEL] in that order. Then enter the valid channel number using the keyboard and press the [EXEC] key.





#### NOTE

To change the baud rate, press the [PCPRM] soft key on the menu as shown in the figure in step **1.**, and press the MODE soft key. Then place the cursor at DATA TRANSFER RATE (AUX) using the key. Press the soft key to display the desired baud rate.

(2) Outputting PMC data

- 1. Connect the reader/punch interface of the CNC to the device which outputs PMC data. Then turn the CNC on.
- 2. Press the NC/PC soft key to display the PMC screen.



**3.** Press the [PCPRM] soft key to display the PC parameter screen. The soft keys are displayed as shown below.



4. Press the [I/O] soft key. (For the 9" CRT, press the [-ETC-] key.)



**5.** Press the soft keys [OUTPUT], [PARAM], and [S.FORM] in that order. Enter the file name using the keyboard and press the [ADD] key. Then the device outputs the data.



**6.** The corresponding addresses are displayed to show that the data is normally output.

#### • PMC–NB

- (1) Connect a PMC data output device to the reader/punch interface, then turn on the power.
- (2) Press the  $PMC_{CNC}$  key to display the PMC screen. When the soft keys in the lower row shown below are displayed, operations (1) through (9) are not required.



- (3) Press the PMC key to display the CNC screen. Then, set the MDI mode or emergency stop state.
- (4) Press the [SETTING] soft key to select the setting screen.
- (5) Key in 8000, then press the [INP–NO.] soft key. Data No. 8000 is displayed.
- (6) When the least significant bit (PWE) of data No. 8000 is 0, key in 1, then press the [INPUT] soft key. Then, PWE = 1 is set, and the CNC is placed in the alarm state.
- (7) Press the  $\begin{vmatrix} PMC \\ CNC \end{vmatrix}$  key to display the PMC screen.

(8) Press the [PCMCPRM] soft key then the [KEEPRL] soft key. A list

of keep relays is displayed. Position the cursor, using the [] key,

to the K17 data then key in 10. Next, press the  $\begin{bmatrix} INPUT \\ INSERT \end{bmatrix}$  key to set bit 1

of K17 to 1. (Memorize the K17 setting before making this modification as it will be used again in step (11).)



- (9) Press the 🖂 key (leftmost soft key) several times to display the soft key menu of (1).
- (10) Press the [I/O] soft key to display the I/O screen.
- (11) Key in the correct channel number from the keyboard, then press the  $\sqrt[|NPUT]_{|NSERT}$  key.

Example:	"1"		key
----------	-----	--	-----

<ul> <li>Channel number</li> </ul>	<ul> <li>(12) Press the [FDCAS] soft key to select the FANUC Floppy Cassette as the I/O device.</li> <li>(13) Press the [PCPRM] soft key to select PMC data as the data type.</li> <li>(14) Press the [WRITE] soft key to select data output.</li> <li>(15) Enter a desired file name from the keyboard, then press the [EXEC] key. Example: "@ABC" [EXEC] key</li> <li>Channel 1: JD5A, Channel 2: JD5B</li> </ul>			
• Transfer speed	Specify a desired value on the screen, displayed by pressing the [SPE]			
modification	key on the I/O screen.			
3.2.2.3	1 Display the pitch error screen.			
Pitch error compensation data	1) Press the $\left( \overset{\text{SERVICE}}{\longrightarrow} \right)$ key.			
output	2) Press the $\bigcirc$ function menu key.			
	3) Press the [CHAPTER] soft key.			
	4) Press the [PITCH] soft key.			
	The pitch error screen can also be displayed by pressing the $\begin{bmatrix} SERVICE \end{bmatrix}$ key			
	several times.			
	2 Press the b operation menu key to display [PUNCH] in the soft key			
	<ul><li>3 Press the [PUNCH] soft key. Then, the soft key menu changes again to display the [PITCH] soft key.</li></ul>			
	4 Press the [PITCH] soft key to start pitch error compensation data output.			
3.2.2.4	1 Display the custom macro variable screen.			
Custom macro variable	1) Press the $setting$ key.			
	2) Press the $\bigcirc$ function menu key.			
	3) Press the [CHAPTER] soft key.			
	4) Press the [MACRO] soft key.			
	The custom macro variable screen can also be displayed by pressing the $service$ key several times.			
	2 Press the 🕞 operation menu key to display [PUNCH] in the soft key menu.			
	3 Press the [PUNCH] soft key. Then, the soft key menu changes again to display the [COMMON VARIABLE 2] soft key.			
	4 Press the [COMMON VARIABLE 2] soft key to start custom macro variable value output.			

3.2.2.5 Tool offset data output	1 2 3 4	<ul> <li>Display the tool output value screen.</li> <li>1) Press the offset key.</li> <li>2) Press the control function menu key.</li> <li>3) Press the [CHAPTER] soft key.</li> <li>4) Press the [TOOL] soft key.</li> <li>The tool offset value screen can also be displayed by pressing the offset key several times.</li> <li>Press the press the press the pressing the operation menu key to display [PUNCH] in the soft key menu.</li> <li>Press the [PUNCH] soft key. Then, the soft key menu changes again to display the [TOOL] soft key.</li> </ul>
	т	ress are [1001] son key to start toor onset data output.
3.2.2.6	1	Select edit mode.
Part program output	2	1) Press the Proglam contents screen.
		<ol> <li>Press the function many kay.</li> </ol>
		<ul> <li>2) Press the [CHAPTER] soft key</li> </ul>
		<ul><li>4) Press the [TEXT] soft key.</li></ul>
		The program contents screen can also be displayed by pressing the $PROG$ key several times.
	3	Press the D operation menu key to display [PUNCH] in the soft key
	4	Press the [PUNCH] soft key. Then, the soft key menu changes again as shown below.
		ALL THIS PROGRAM (PROG#) FILE#
		1) Outputting all programs
		Press the [ALL] soft key.
		2) Outputting a specified program
		Press the [(PROG#)] soft key, then key in a desired program number. Then, the soft key menu displays [EXEC]. Press the [EXEC] soft key to start output of the program having the specified program number.
		<ol> <li>Outputting the program currently displayed on the screen Press the [THIS PROGRAM] soft key.</li> </ol>

# 3.2.3 Data Input

<b>3.2.3.1</b>	1	Set the emergency stop state.
CNC parameter input 2	2	Display the parameter screen.
		1) Press the $service$ key.
		2) Press the $\bigcirc$ function menu key.
		3) Press the [CHAPTER] soft key.
		4) Press the [PARAM] soft key.
		The parameter screen can also be displayed by pressing the $service$ key
		several times.
3	3	Check that bit 0 of setting data No. 8000 is set to 1. If the bit is set to 0, set the bit to 1 according to the parameter setting procedure described in Section 3.1.
4	4	Press the 🗁 operation menu key to display [READ] in the soft key menu.
5	5	Press the [READ] soft key. Then, the soft key menu changes again to display the [PARAM] soft key.
6	6	Press the [PARAM] soft key to start parameter input.
7	7	Upon the completion of parameter input, turn the power off, then back on again.

### 3.2.3.2 Inputting CNC parameter

• PMC–NA

(1) Setting the input/output channel

When inputting and outputting data, the input/output channel must be correctly set. Once the input/output channel has been set, the setting is maintained even after the CNC is turned off. Therefore, further channel setting is normally not required. If the input/output channel must be again set for some reason, follow the steps below.

1. Press the  $\begin{bmatrix} PMC \\ CNC \end{bmatrix}$  key to display the PMC screen. When the lower soft

key list as shown in the figure below is displayed on the PMC screen, steps **2.** to **8.** are not needed.



Press the PMC key to display the NC screen. Then put the CNC in the MDI mode or emergency stop mode.

\_\_\_\_ 214 \_\_\_\_

- **3.** Press the [SETTING] soft key to display the setting screen.
- **4.** Enter 8000 and press the [INPU–NO.] soft key. Parameter No. 8000 is now displayed.
- **5.** If PWE, the lowest bit of parameter No. 8000, is set to 0, change it to 1. Then press the [INPUT] soft key. This sets the PWE bit to 1 and puts the NC in the alarm mode.
- 6. Press the  $\begin{bmatrix} PMC \\ CNC \end{bmatrix}$  key to display the PMC screen.
- 7. Press the [PCPRM] soft key. Then press the [KEEPRL] soft key to display the keep relay screen. Press the ↓ page key until the screen which contains the K17 data line is displayed. When this screen is displayed, place the cursor at the K17 data using the cursor keys. Then enter 10000000 and press the <sup>INPUT</sup> key. This sets the highest bit of the K17 data to 1. (Keep record of the original K17 data until step 10.)



- **8.** Press the return key on the left of the soft keys several times to display the soft key menu as shown in the figure in step **1**.
- **9.** Press the soft keys [I/O], [FDCAS], and [CHANEL] in that order. Then enter the valid channel number using the keyboard and press the [EXEC] key.



**10.**If the K17 data for the keep relay was changed in step **7.**, restore it to the original setting.

#### NOTE

To change the baud rate, press the [PCPRM] soft key on the menu as shown in the figure in step **1.**, and press the [MODE] soft key. Then place the cursor at DATA TRANSFER RATE (AUX) using the key. Press the soft key to display the desired baud rate.

# 3.2.3.3 Inputting PMC data

- **1.** Connect the reader/punch inerface of the CNC to the input device which contains PMC data. Then turn the CNC on.
- 2. Put the CNC in the MDI mode or emergency stop mode.
- 3. Press teh [SETTING] soft key to display the setting screen.
- **4.** Enter 8000 and press the [INP–NO.] softkey. Prameter No. 8000 is displayed.
- **5.** If PWE, the lowest bit of paramter No. 8000, is set to 0, change it to 1. Then press the [INPUT] soft key. This sets the PWE bit to 1 and puts the NC in the alarm mode.
- 6. Press the  $\begin{bmatrix} PMC \\ CNC \end{bmatrix}$  soft key to display the PMC screen.



**7.** Press the PCPRM soft key to display teh PC parameter screen. The sofy keys are displayed as shouwn below.



8. Press the I/O soft key. (For 9" CRT, press the [-ETC-] key.)

INPUT OUTPUT

**9.** Press the INPUT sofy key. Then enter the name or number of the file and press the [EXEC] key.



**10.** The corresponding addresses are displayed to show that the data has been correctly ihnput.

#### NOTE

When data is read, if RAM ENABLE OFF is displayed, this means that the RAM for the PMC is protected. Press the [MODE] soft key on the menu as shown in the figure in step **7.**, Then place the cursor at RAM ENABLE using the key and press the [ON] softkey.

(1) Connect a PMC data input device to the reader/punch interface, then turn on the power.

(2) Press the  $\begin{bmatrix} PMC \\ CNC \end{bmatrix}$  key to display the PMC screen. When the soft keys in the lower row shown below are displayed, operations (1) through (9) are not required.



(3) Press the  $\begin{bmatrix} PMC \\ CNC \end{bmatrix}$  key to display the CNC screen. Then, set MDI mode or the emergency stop state.

(4) Press the [SETTING] soft key to select the setting screen.

- (5) Key in 8000, then press the [INP–NO.] soft key. Data No. 8000 is displayed.
- (6) When the least significant bit (PWE) of data No. 8000 is 0, key in 1, then press the [INPUT] soft key. Then, PWE = 1 is set, and the CNC is placed in the alarm state.
- (7) Press the  $\begin{bmatrix} PMC \\ CNC \end{bmatrix}$  key to display the PMC screen.

(8) Press the [PCMCPRM] soft key then the [KEEPRL] soft key. A list

of keep relays is displayed. Position the cursor, using the  $|\downarrow|$  key,

to the K17 data then key in 10. Next, press the [INPUT] key to set bit 1

of K17 to 1. (Memorize the K17 setting before making this modification as it will be used again in step (11).)



#### • PMC–NB

	<ul> <li>(9) Press the  key (leftmost soft key) several times to display the soft key menu of (1).</li> <li>(10) Press the [I/O] soft key to display the I/O screen.</li> <li>(11) Key in the correct channel number from the keyboard, then press the  keyboard, then press the  keyboard key.</li> <li>Example: "1"  key</li> <li>(12) Press the [FDCAS] soft key to select the FANUC Floppy Cassette</li> </ul>
	as the I/O device.
	<ul><li>(13) Press the [READ] soft key to select data input.</li><li>(14) Set the americanaly stop state</li></ul>
	<ul><li>(14) Set the energency stop state.</li><li>(15) Enter a desired file number from the keyboard, then press the [EXEC] key.</li><li>Example: "1" [EXEC] key</li></ul>
Channel number	Channel 1: JD5A, Channel 2: JD5B
<ul> <li>Transfer speed modification</li> </ul>	Specify a desired value on the screen displayed by pressing the [SPEED] key on the I/O screen.
3.2.3.4 Pitch error compensation data input	<ol> <li>Set the emergency stop state.</li> <li>Display the parameter screen.         <ol> <li>Press the <ul></ul></li></ol></li></ol>
3.2.3.5 Custom macro variable value input	<ol> <li>Select edit mode.</li> <li>Set memory protection key KEY2 to ON (KEY2 = 1).</li> <li>Prepare a program for custom macro variable value input on the I/O device side.</li> <li>Display the program contents screen.         <ol> <li>Press the PROG key.</li> <li>Press the I function menu key.</li> </ol> </li> </ol>

3)	Press	the	[CHAP	TER]	soft key.
----	-------	-----	-------	------	-----------

4) Press the [TEXT] soft key.

The program contents screen can also be displayed by pressing the

PROG key several times.

- 5 Press the ▷ operation menu key to display [READ] in the soft key menu.
- 6 Press the [READ] soft key, then enter  $O_{?}$  Program Number . Next,

press the [EXEC] soft key to register the program for macro variable value input.

NOTE For Program Number, enter the number of the program to be used.

7 Select memory (automatic operation) mode, then press the cycle start button to start automatic operation.

The program runs, and the custom macro values are set.

- 8 Upon the completion of the operation, display the custom macro variable screen.
- 9 By switching between pages with the page keys 1 and 1, check that the custom macro variable values have been entered correctly.

10 Select edit mode.

11 Display the program contents screen.

12 Delete the program registered for custom macro variable value input.

Enter	$O_{\gamma}$		Program Number		DELETE	to delete the program.
-------	--------------	--	----------------	--	--------	------------------------

#### 3.2.3.6 Tool offset data input

- 1 Select edit mode.
- 2 Set memory protection key KEY1 to ON (KEY1 = 1).
- 3 Prepare a program for tool offset data input on the I/O device side.
- 4 Display the program contents screen.
  - 1) Press the PROG key.
  - 2) Press the  $\frown$  function menu key.
  - 3) Press the [CHAPTER] soft key.

4) Press the [TEXT] soft key.

The program contents screen can also be displayed by pressing the ROG key several times.

- 5 Press the 🕞 operation menu key to display [READ] in the soft key menu.
- 6 Press the [READ] soft key, then enter  $|O_2|$  Program Number . Next,

press the [EXEC] soft key to register the program for tool offset data input.

\* For Program Number, enter the number of the program to be used.

		<ul> <li>7 Select memory (automatic operation) mode, then press the cycle start button to start automatic operation. The program runs, and the tool offset data is set.</li> <li>8 Upon the completion of the operation, display the tool offset value screen.</li> <li>9 By switching between pages with the page keys ↑ and ↓, check that the tool offset data has been entered correctly.</li> <li>10 Select edit mode.</li> <li>11 Display the program contents screen.</li> <li>12 Delete the program registered for tool offset data input. Enter O<sub>?</sub> Program Number of the operation of the program.</li> </ul>							
3.2.3.7 Part program registratio		1 Check	and set t	he follov	ving par	ameters	as requir	ed.	
r art program rogion and	#7	#6	#5	#4	#3	#2	#1	#0	
0011							,,,,	NE8	
2200	#7 NPE NM9	Specifies enabled or 0 : Enabl 1 : Disab #6 Specifies codes in p 0 : Regar 1 : Not re Specifies registration 0 : Regar 1 : Not re	whether r disabled ed led #5 whether I orogram r ded as pr egarded a whether N on. ded as a garded as a	the edit 1. #4 NM9 M02, M3 registrati rogram e s progra M99 is to program s a progr	#3 NPE 30, and N on. nd codes m end cod be regar end cod ram end	#2 199 are to sodes ded as a p le code	#1	#0 #0 rded as pr	9 is to be ogram end
2201	#7	#6	#5	#4	#3	#2	#1	#0	
2201	ND9	Specifies enabled of 0 : Enabl 1 : Disab 2 Sel 3 Set	whether r disabled ed led ect edit n memory	the edit 1. node. protecti	ing of I	Drograms	O9000	to O9999	19 is to be

4 Prepare a program for part program input on the I/O device side.

- 5 Display the program contents screen.
  - 1) Press the |PROG| key.
  - 2) Press the  $\frown$  function menu key.
  - 3) Press the [CHAPTER] soft key.
  - 4) Press the [TEXT] soft key.

The program contents screen can also be displayed by pressing the PROG key several times.

- 6 Press the ▷ operation menu key to display [READ] in the soft key menu.
- 7 Press the [READ] soft key. Then, the soft key menu changes again as shown below.

ALL PROGRAM (PROG#)	FILE#	Ξ#	
---------------------	-------	----	--

(1) Input of all programs

Press the [ALL] soft key.

(2) Input of one program (with a program number specified)

Press the [(PROG#)] soft key, key in a desired program number, then press the [EXEC] soft key. The program is entered with the typed program number.

(3) Output of one program (with no program number specified)

Press the [PROGRAM] soft key. Then, soft keys [NEW] and [ADD] are displayed. When you press the [NEW] soft key, the program is entered with its number already assigned. When you press the [ADD] soft key, the program is entered at the end of the currently selected program.

# 3.2.4 15–MFB Data Input/Output

#### 3.2.4.1 Conversational data input/output

Conversational data is read from an external storage device (reader), or punched out to an external storage device (punch). For conversational data input/output, the data input/output screen shown below, which is an auxiliary screen, is used.

D	ATA INPUT/OUTPUT		01000	N01000
	1) PARAMETER	: P-9999		
	2) TOOL FILE	: т-9999		
	3) CUTTING CONDITION FILE	: F-9999	No.	DATA
	4) PRE-TOOL LIST	: R-9999	0060	1
	5) PASCAL	: S-9999 OR		
	6) CONVERSATIONAL DATA	: M-9999 PUNCH		
>	7) PROGRAM 1 PROGRAM ALL PROGRAM : 0 ????	: 0???? : 0-9999 :,0 ????		
	READ PUNCH			

As shown on the above screen, conversational data can be read or punched by entering necessary address and program number information and pressing the respective soft key. The procedure is described below.

3.2.4.2	1. Set a data input/output parameter.
Conversational data input	• Press conversational function key setting to display the setting screen.
	• Set a parameter required for data input/output. In the parameter, set the same data as that of the NC parameter having the same number.
	2. For program input, release the memory protection set using protection key KEY3.
	3. For parameter input, enable parameter setting by NC mode setting (PWE = 1).
	4. Mount the floppy disk containing the data to be entered.

5. Display the data input/output screen.

6. Enter address and program number information.

Parameter	:	P+	9	9	9	9
Tool file	:	T	9	9	9	9
Cutting condition file	:	(F <sup>∞</sup> , (−)	9	9	9	9
Pre-tool list	:	R	9	9	9	9
PASCAL	:	S <sub>¥</sub> <sup>−</sup> <sub>+</sub>	9	9	9	9
Conversational data	:	$M_{sp}$ $-$	9	9	9	9
All programs	:	$\left[ O_{2} \right] \left[ - \right]_{+}$	9	9	9	9

7. Press [READ] to read the specified data.

(Notes on program input)

- Specifying the conversational parameter (No. 000/RDAL) enables the entry of all programs simply by pressing [READ] without entering O–9999.
- Enter  $O_? \xrightarrow{-} 9 9 9 9 ..., R E_s P_<$ , in this order, to replace the program with a previously registered

in this order, to replace the program with a previously registered program having the same program number.

# 3.2.4.3 Conversational data output output 1. Set a data input/output parameter. (See Item 1 of Section 3.2.4.2.) 2. For program output, set a desired punch code with the conversational setting data (No. 058/EIA). 3. Set the I/O device to enable output. 4. Display the data input/output screen. 5. Enter address and program number information. (See Item 6 of Section 3.2.4.2.)

6. Press [PUNCH] to punch the specified data.



# INTERFACE BETWEEN NC AND PMC

This chapter describes the signals between the machine operator's panel, power magnetics cabinet and the PMC, connection of the signals between PMC and CNC, and confirmation method of on/off state of these signals. It also describes system configuration of PMC, parameters of PMC, ladder and how to display time chart of the signals on the CRT. It also describes a method of inputting/outputting PMC parameters to an external device.

4.1	GENERAL OF INTERFACE	225
4.2	SPECIFICATION OF PMC	226
4.3	PMC SYSTEM CONFIGURATION	230
4.4	PMC SCREEN	231
4.5	SIGNAL AND SYMBOL CORRESPONDENCE	
	TABLE	253

# 4.1 GENERAL OF INTERFACE



\_\_\_\_ 225 \_\_\_\_

# 4.2 SPECIFICATION OF PMC

# 4.2.1 Specification

Model		PMC-RA1	PMC-RB3	
Programming method la	inguage	Ladder C PASCAL	Ladder C	
Number of ladder level		3	3	
Level-1 Cycle Time		8 ms	8 ms	
Basic Instruction Execu	tion Time	0.2 (μs/step)	0.1 (μs/step)	
Program capacity				
Ladder (step)		Approx. 8,000	Approx. 8,000	
		Approx.16,000	Approx. 8,000	
			Approx.16,000 (Note2)	
			Approx.24,000 (Note2)	
Symbol/comment (Not	e 1)	1 to 64KB	1 to 128KB	
Message		0.1 to 64KB	0.1 to 64KB	
Language only		Max.896KB	Max.896KB	
Instruction (Basic (Fund	c) tion)	12 kinds 51 kinds	14 kinds 68 kinds	
Internal relay	(R)	2000 byte	1618 byte	
Message request	(A)	25 byte	25 byte	
Non-volatile				
Var. Timer	(T)	80 byte	80 byte	
Counter	(C)	80 byte	80 byte	
Keep relay	(K)	19 byte	20 byte	
Data table	(D)	3000 byte	3000 byte	
Subprogram	(P)	-	512 programs	
Label	(L)	-	9999 labels	
Fixed timer		Timer No. 100 devices specified	Timer No. 100 devices specified	
Input/output				
• I/O Link	(I)	1024 points max.	1024 points max.	
	(O)	1024 points max.	1024 points max.	
Sequence program stor	age media	Flash memory	Flash memory	

#### NOTE

1 The standard sizes of a symbol, comment, and message are as follows:

ſ	Data	PMC-NA	PMC-NB
	Symbol, comment	16KB	28KB
	Message	4KB	2.1KB

2 The use of more than about 8000 ladder program steps requires the installation of optional DRAM.

# 4.2.2 Address

Char- acter	Signal description	Byte	Address	
G	PMC→CNC	512	G0.0 to G511.7	
F	CNC→PMC	320	F0.0 to F319.7	
Y	PMC→MT	128	Y0.0 to Y127.7	
Х	MT→PMC	128	X0.0 to X127.7	
A	Message request signal	25	A0.0 to A24.7	
R	Internal relay (NA)	1000 50 1000	R0.0 to R499.7 R500.0 to R549.7 R2000.0 to R2999.7	Operation results (reserved by the system)
	Internal relay (NB)	1500 50 18	R0.0 to R1499.7 R9000.0 to R9099.7 R9100.0 to R9117.7	Operation results (reserved by the system)
Т	Variable timer	80	T0.0 to T79.7	
К	Keep relay (NA) (NB)	17 2 3	K0.0 to K16.7 K17.0 to K18.7 K17.0 to K19.7	Reserved by the system Reserved by the system
С	Counter	80	C0.0 to C79.7	
D	Data table	3000	D0.0 to D2999.7	

# 4.2.3 Built–in Debug Function

	1
Function	Contents
Display of sequence program	Dynamic display of ladder diagram
Diagnostic function	<ul> <li>Title data display</li> <li>Signal status (symbol can be displayed)</li> <li>PMC alarm display</li> <li>Signal trace</li> <li>Memory contents display</li> <li>Signal waveform display (PMC–NB only)</li> <li>Task status display</li> <li>I/O connection status display</li> </ul>
Setting and displaying data	<ul> <li>Variable timer</li> <li>Counter</li> <li>Keep relay</li> <li>Data table</li> </ul>
Sequence program edit function	Ladder diagram editing



	_	#7	#6	#5	#4	#3	#2	#1	#0	
R9002										
R9003	Γ									remainder (used by DIVB
R9004	Γ									
R9005										

# 4.2.5 Execution Period of PMC



# 4.3 PMC SYSTEM CONFIGURATION



# 4.4 PMC SCREEN

# 4.4.1 Display Method

#### • PMC-NA

To display the PMC screen, press the  $\left[\begin{array}{c} PMC\\ CNC \end{array}\right]$  key.

THERE IS NO ALARM <	— Displays the alarm status.
[PCMDI][PCLAD][PCDGN][PCPRM][ ] PMC parame PMC diagnos Ladder dyna User PMC so	eter screen stic screen mic display creen
[ RUN ][ EDIT ][ I/O ][SYSPRM][ ] System para Inputting/out Editing seque Running/stop	meter screen butting sequence program ence program oping sequence program

#### • PMC-NB

PMC CONTROL SYSTEM MENU MONIT RUN	
SELECT ONE OF FOLLOWING SOFT KEYS	
PMCLAD: DYNAMIC LADDER DISPLAYPMCDGN: DIAGNOSIS FUNCTIONPMCPRM: PARAMETER (T/C/K/D)RUN/STOP: RUN/STOP SEQUENCE PROGRAMEDIT: EDIT SEQUENCE PROGRAMI/O: I/O SEQUENCE PROGRAMSYSPRM: SYSTEM PARAMETERMONIT: PMC MONITOR	₩hen built–in program- mer is run- ning.
$ \left( \begin{array}{c} PMCLAD \end{array} \right) \left( \begin{array}{c} PMCDGN \end{array} \right) \left( \begin{array}{c} PMCPRM \end{array} \right) \left( \begin{array}{c} \end{array} \right) \left( \begin{array}{c} \end{array} \right) \left( \begin{array}{c} \end{array} \right) $	)
PMC parameter screen Status display of PMC I/O sign Dynamic display of sequence p	al program
$\left(\begin{array}{c} \text{stop} \end{array}\right) \left(\begin{array}{c} \text{edit} \end{array}\right) \left(\begin{array}{c} \text{i/o} \end{array}\right) \left(\begin{array}{c} \text{sysprm} \end{array}\right) \left(\begin{array}{c} \text{monit} \end{array}\right)$	
System parameter Input/output of sequence p Editing sequence p RUN/STOP of sequ	screen Jence program rogram Jence
# 4.4.2 PMCLAD Screen

Press soft key **[PMCLAD]**, and a sequence program is displayed dynamically and operation monitoring can be confirmed :

## • PMC-NA

Ladder display	Numb	er of net displayed RUN/STOP : ↓	d status
LADDER N LOG1	IET 0001-0004 MC	DNIT RUN	– Comment
x008.4	*ESP	EMERGENCY STOP	
	POR	POWER ON RESET	
( TOP ) ( BOTTOM ) (	( SRCH ) ( W-SRCH	I)(N-SRCH)	
Other soft keys	$\left(\begin{array}{c} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\$	Switched ea	ch

• Contents displayed

	Display			
Color	Monochrome PDP	Monochrome STN	Contact	Relay
Green	Dark (low intensity)	Dark or normal video(*)	Open	Off
White	Bright (high intensity)	Bright or reverse video(*)	Close	On

\* If the gray scale of the PMC mode screen is set to UNUSE, "reverse/normal video" is selected.

•	Search	method
-	Search	method

• PMC–NB

- 1. Use the cursor keys to change display positions.
- 2. [TOP]:Searches top of ladder.
- 3. [BOTTOM]:Search bottom of ladder.
- 4. Address.bit,[SRCH] or Signal name, [SRCH]
- 5. Address.bit,[W-SRCH] or Signal name ,[W-SRCH]
- 6. Net no.[N-SRCH]:Ladder is displayed from the specified net.
- 7. Functional instruction no. [F–SRCH] or Functional instruction name [F–SRCH]
- 8. [ADRESS]:Signal is displayed by address and bit no.
- 9. [SYMBOL]:Signal is displayed by signal name (symbol). (If symbol is not registered at program preparation time, the address of the signal is displayed).

### [Remarks]

- The search function searches a signal in the forward direction and displays the ladder with the searched signal at its head. Because there may exist plural contacts, repeat the search operation to find plural locations, repeat the search operation to find plural locations with the specified signal.
- If a specified signal is not found up to the end of the program (ladder), execution returns to the head of a program and search continues.

Press soft key [PMCLAD]. A ladder program is displayed dynamically, allowing operation monitoring to be confirmed.



Contents displayed

(1) Green (low brightness) display Contacts: open

Relay: off

(2) White (high brightness) display

Contacts: closed Relay: on

— 234 —

- Search method
- (1) Use the page and cursor keys to change the display positions.



(2) Enter the item for which a search is to be made, then press a page or cursor key.

Enter an address and bit, then press a page or cursor key.

Enter a net number, then press a page or cursor key.

(3) Press the [SEARCH] soft key, then press any of the following soft keys:

(a) [TOP] :	Displays the first net of the ladder program.
(b)[BOTTOM]:	Displays the last net of the ladder program.
(c) [SRCH] :	Searches for the specified address and bit number, or symbol. "address.bit," "address," or "symbol" Example: "X0.0" [SRCH] key
(d) [W–SRCH] :	Searches for a relay coil according to the specified address and bit number, or symbol. "address.bit," "address," or "symbol" Example: "Y0.0" [W–SRCH] key
(e) [N–SRCH] :	Searches for a net number. "net–number"
(f) [F–SRCH] :	Searches for a functional instruction. "functional-instruction-number" or "functional- instruction-name" Example: "1" [F-SRCH] "END1" [F-SRCH]

 Changing the display method (1) Address or symbol display

- (a) [ADRESS] : Displays a signal using an address and bit number.
- (b) [SYMBOL]: Displays a signal using a symbol.

(Signals for which no symbol has been registered are displayed using an address and bit number.)

(2) Dump display

[DUMP] : Displays the signal status at the bottom of the screen.



(a) [SEARCH] : Searches for the display start address.

- (b)[BYTE] : Displays the status in byte format (1 byte).
- (c) [WORD] : Displays the status in word format (2 bytes).
- (d) [D.WORD]: Displays the status in long format (4 bytes).
- (3) Parameter display
  - [DPARA] : Displays the values of functional instruction parameters.
  - [NDPARA] : Does not display the values of functional instruction parameters.



## 4.4.3 PMCDGN Screen • TITLE screen

Press soft key [PMCDGN] then PMC's diagnostic screen is displayed.

The title data registered when a ladder program is prepared is displayed.



						_
PMC T	ITLE DATA :	#1		MON	IT RUN	
	PMC PR	OGRAM NO.	:			
	EDITIC	N NO.	:			
	PMC CC	NTROL PRO	GRAM			
	SERIES	: 4063 E	DITION	r: 08	3	
	(SERIE	s: 4065 1	EDITIO	N: 0	8)	
	PMC TY	PE CONTROL	L : RB	3 PRC	GRAM :	RB3
		MEMORY USI	ED	: F	¢В	
		LADDER		: F	¢В	
		SYMBOL		: F	¢В	
		MESSAGE		: F	¢В	
		SCAN TIME		: 1	ISEC	
1		SCAN MAX	: 016	MS MI	N: 00	8 MS
	LE $\left( \begin{array}{c} \mathbf{STATU} \\ \mathbf{STATU} \end{array} \right)$	S ) ( ALARM		ACE		
			, , , , , , , , , , , , , , , , , , ,	,		
Other soft	keys					
		<b>,</b> ) (	١٢	١	ιí	)
M.SR	ANALY:	• ) (	λĹ		Ι	J
1st page	PMC PROGRA	M NO. :			777-	Set when PMC
1 0	EDITION NO.			: 2		is .
						prepared
	SERIES :			3- 3	Series and	d edition of PMC
				C	control sol	tware
		D :		KB KB		any used and
	SYMBOL			KB	exec	ution time is
	MESSAGE	:		KB	displ	ayed.
	SCAN TIME	:		MSEC	)	
2nd page	MACHINE TOO	DL BUILDER N	IAME :	$\mathcal{I}$		
	MACHINE TOO	DL NAME :				
	PROGRAM DE			(	Set wh	en PMC
				2	is prep	ared.
3rd page	DATE OF DRA	WING :		(		
	ROM WRITTE	NBY:		)		
	REMARKS :					

### • STATUS screen

On/Off state of input/output signals and internal relay is displayed.

PMC SIG	NAL S	TATUS	ł			MONIT	RUN	,	
ADDRESS	7	6	5	4	3	2	1	0	
	ED7	ED6	ED5	ED4	ED3	ED2	ED1	ED0	Signal
G0000	0	0	0	0	1	0	1	0	name
	ED15	ED14	ED13	ED12	ED11	ED10	ED9	ED8	Signal state
G0001	0	0	0	0	0	0	0	0	0:Ŏff
	ESTB	EA6	EA5	EA4	EA3	EA2	EA1	EA0	1:On
G0002	0	0	0	0	0	0	0	0	
G0003	0 FIN	0	0	0	0	0	0	0	Signal state reverses for
G0004	0	0	0	0	0	0	0	0	signals with *. 0: On 1: Off
( SEARCH	)(		)(	)	(	)(		)	

[Search Method]

- Page keys  $\left[ \begin{smallmatrix} \mathsf{PAGE} \\ \bullet \end{smallmatrix} \right]$  :Forward and Backward by screen
- Cursor keys 🖡 📔 🕈 Errward and Backward by diagnostic number
- To search a specified address or signal name, input an address number or signal name and press [SEARCH].

• Alarm screen

Displays an alarm generated in PMC.

/	·				
	PMC ALARM MESSAGE MC	NIT	RUN		Alarm dis- play
	EKJZ NO T/O DEVICE				For details of alarms, refer to Appendix B List of Alarms.
			ALM	-	_ Blinked
	$\left(\begin{array}{c} \texttt{title} \end{array}\right) \left(\begin{array}{c} \texttt{status} \end{array}\right) \left(\begin{array}{c} \texttt{alarm} \end{array}\right) \left(\begin{array}{c} \texttt{trace} \end{array}\right)$	)(			

• TRACE (trace) screen

The state of the specified signal is stored into trace memory every time the state changes. This function is useful for investigating any intermittent fault. Pressing the [TRACE] key displays the TRACE screen.

• PMC–NA

Trace address TRACE EXEC 1ST ADDRESS = X0 2ND ADDRESS = Y0 7 6 5 4 3 2 1 0 7 6 5 4 3 2 1 0 0 0 0 0 0 1 1 1 0000011100000 Trace result 0 0 0 0 0 0 0 0 1:On state 0001 0 0 0 0 0 0 0 0 0:Off state 0 0 0 0 0 0 0 0 00020000000000 0 0 0 0 0 0 0 0 0003 0 0 0 0 0 0 0 0 0004 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 [ BYTE ] [1.BYTE] [2.BYTE] [M.WORD] [ EXEC]

(1) Setting the address

Soft key [BYTE] Traces eight bits (1–byte setting). "address" [BYTE] key Example: "X0" [BYTE] key

Soft keys [1.BYTE] and [2.BYTE]

Traces two addresses which are not consecutive. "address" [1.BYTE] or [2.BYTE] key Example: "X0" [1.BYTE] key "Y0" [2.BYTE] key

Soft key [M.WORD] A physical address can be specified for a trace. Traces 16 consecutive bits. "physical–address" [M.WORD] key Example: "FF9800" [M.WORD] key

### (2) Executing a trace

### Soft key [EXEC]

Pressing the [EXEC] key starts tracing. Any previous trace results are cleared and tracing is started from the beginning. The trace result is updated only when the signal state is changed. The latest trace results, consisting of 256 bytes, are always stored regardless of how much time has elapsed.

Soft key [STOP]

Pressing the [STOP] key stops tracing. The trace results are maintained.

(3) Displaying the trace results

The latest trace result is indicated by the cursor. The cursor moves on the CRT screen as the trace results are updated.

If the cursor moves off the screen, the latest trace result can be

displayed by scrolling the screen using the 4 cursor key.

## • PMC–NB

1. Trace parameter screen

(						
	PMC SIGNAL TRACE		1	MONIT	RUN	
	TRACE MODE (0:1BYTE/1:2BYTE/2 1STTRACE ADDRESS ADDRESS TYPE ADDRESS MASK DATA 2NDTRACE ADDRESS ADDRESS TYPE ADDRESS MASK DATA	: Wo CO : : CO : : CO : :	ORD) NDITION (0:PMC/1:PH NDITION (0:PMC/1:PH	Y)		
	(T.DISP)(EXEC)	(	)(	)(		)
	1				_	

Changes to a trace memory display screen (Screen on the next page)

Select each item by cursor key

a. TRACE MODE: Select the trace mode
0=Records changes of 1-byte signals
1=Records changes of independent 2-byte signals
2=Records changes of consecutive 2-byte signals

- b. ADDRESS TYPE:
  0=PMC address is used for tracing address.
  1=Physical address is used for tracing address.
  (Mainly used for C-language program)
- c. ADDRESS:Set a tracing address.

d. MASK DATA: The bits to be traced are specified by a hexadecimal number (2 digits).

For example, to trace the signals at bit 7,6,5 and 0, set E1 (hexadecimal) to MASK DATA.

	#7	#6	#5	#4	#3	#2	#1	#0			
E1%	1	1	1	0	0	0	0	1			
However	:, e	ven	if	bit	4,3	3,2	and	1	changes,	tracing	(memory
registrati	on)	can	not	be d	lone	e bu	t sig	nal	status is 1	nemorize	ed when a
tracing is	sexe	ecute	ed.								
[Corresp	ond	ence	of	bina	ry a	nd	hexa	dec	imal num	per]	
00002	: 0 <sub>16</sub>	5 0	001	2:1	16	00	$10_2$ :	216	, 0011 <sub>2</sub> :	316	
01002	: 416	<sub>5</sub> 0	101	2:5	16	01	$10_2:$	616	01112:	7 <sub>16</sub>	
10002	: 8 <sub>16</sub>	<sub>5</sub> 1	001	2:9	16	10	$10_2$ :	$A_1$	<sub>6</sub> 1011 <sub>2</sub> :	B <sub>16</sub>	
11002 :	$C_{10}$	6 1	101	2 : D	<b>)</b> <sub>16</sub>	11	$10_2:$	$E_{16}$	5 1111 <sub>2</sub> :	F <sub>16</sub>	

2. Trace memory contents display screen



played by 1 and 0.

- a. Soft key [**TRCPRM**]: Return to the trace parameter setting screen (screen of previous page)
- b. Soft key [EXEC]: Starts tracing. Trace memory is cleared and each time a specified signal changes, its status is recorded. Trace memory is 256 bytes and if tracing is executed 128 times by 2–byte tracing, tracing is executed again from the head of memory.
- c. Soft key **[STOP]**: Ends the tracing.

\*The tracing parameters are held even if the power is turned off.



- #5 Tracing starts by [EXEC].
  - 1: Tracing starts automatically after power on

- ANALYS screen
- PMC–NB

Change of signals is displayed as the same display as that on the oscilloscope.

**1.** Parameter setting screen (1st page)

```
PMC SIGNAL ANALYSIS(PARAM)
                                  MONIT RUN
SAMPLING TIME
                    :
                             10 (1-10 SEC)
   (a)
TRIGGER ADDRESS
                    : G0007.2
   (b)
CONDITION
                              0
                    :
   (c)
(0: START 1: TRIGGER-ON 2: TRIGGER-OFF)
TRIGGER MODE
                    :
                              0
   (d)
(0: AFTER 1: ABOUT 2: BEFORE 3: ONLY)
 SCOPE ] [ DELETE ] [ INIT ] [ ADDRESS ] [
```

(a) Set a sampling time.

(b) Specifies an address from which recording of signals is started.

- (c) Set a condition under which recording is initiated.
  - 0: Started by soft key [START]
  - 1 : Started by rise of a trigger signal after you press the soft key [START]
  - 2 : Started by fall of a trigger signal after you press the soft key [START]

(d) Set a trigger mode

- 0: Record signal status after the trigger condition is satisfied
- 1 : Record signal status before and after the trigger condition is satisfied.
- 2: Record signal status before the trigger condition is satisfied.
- 3 : Record signal status when the trigger condition is satisfied. (Display is same as trace memory).

Select each item by cursor key

2. Parameter setting screen (2nd page)

```
PMC SIGNAL ANALYSIS(PARAM)
   MONIT RUN
   SIGNAL ADDRESS
  1 : X0000.0
  9 : Y0000.0
  2:X0000.1
  10 : R0000.1
  3 : X0002.0
   11 :
  4 : X0005.0
  12 :
  Up to 16
   13 :
  signals
  5:
  6:
   14 :
  7:
  15 :
  8:
  16 :
                       SCOPE \left( DELETE \right) \left( INIT \right) \left( ADDRESS \right) \left( INIT \right) \left( ADDRESS \right) \left( INIT \right) \left( ADDRESS \right) \left( INIT \right) \left(
```

- a. Soft key [SCOPE] : Select signal waveform display screen
- b. Soft key [DELETE] : Delete data on the cursor position
- c. Soft key [INIT] : Initialize parameters of signal waveform display
- d. Soft key [ADDRESS] or [SYMBOL] :

Switch addresses and symbols for display

3. SCOPE screen

The above screen is for a system with graphic display.

I and \* are used for display if graphic function is not equipped.

- a. Soft key [SGNPRM] : Returns to parameter screen.
- b. Soft key [START] or [STOP] :Start or stop the record. (If TRIGGER MODE=3, signal is displayed when you press STOP key.)
- c. Soft key [T.SRCH] :Displayed for a specified time.
- d. Soft key [ADDRESS] or [SYMBOL]:Switch addresses and symbols for display
- e. Soft key [EXCHG] : Change order of signals displayed.
  Press soft key [EXCHG]
  Move the cursor to a signal to be changed.
  Press soft key [SELECT].
  Move the cursor to the destination.
  Press [TO] and [EXEC], then the signal changes its order.
- f. Soft key [SCALE]: Changes time scale for graphic display. Scale changes from 256 to 512, and to 1024 msec every time you press the key.
- g. Cursor key  $| \leftarrow | | \rightarrow |$ : Scrolls time axis forward and backward

## 4.4.4 PMCRAM Screen

 Inputting PMC parameters from the MDI (1) Set to MDI mode or emergency stop state.

(2) Set PARAMETER WRITE (on setting screen) to 1 or set the program protect signal (KEY4) to 1.

	PWE	KEY4	
Timer	0	_	
counter	0	0	Either one
Keep relay	$\bigcirc$	-	
Data table	$\bigcirc$	0	Either one

(3) Press a soft key and select a required screen.

[TIMER]: Timer screen[COUNTR]: Counter screen

- [KEEPRL] : Keep relay screen
- [DATA] : Data table screen

(4) Press cursor key and move the cursor to a desired number.

(5) Input a numeric key and press  $\begin{bmatrix} INPUT \\ INSERT \end{bmatrix}$  key and data is input.

(6) After the data is input, set PARAMETER WRITE or KEY4 on setting screen to 0.

• TIMER screen

This screen is used for setting timer time of the functional instruction (SUB 3).

		Pag	e no. (scr	een is scrolled	by page I	key)	
			Tim	er no. specified	d by funct	tional i	nstructio
				Address s	pecified b	y ladd	ler
PMC	PARAMETER	(TIMER)	¥ #001 ▼	MONIT	RUN		
NO.	ADDRESS	DATA	NO.	ADDRESS	DATA		
01	<b>T</b> 00	480	11	T20	0	-	- Timer
02	T02	960	12	T22	0		delay
03	T04	0	13	т24	0		(msec
04	<b>T</b> 06	0	14	T26	0		(
05	T08	0	15	т28	0		
06	<b>T10</b>	0	16	т30	0		
07	T12	0	17	т32	0		
80	<b>T14</b>	0	18	т34	0		
09	<b>T16</b>	0	19	Т36	0		
10	<b>T18</b>	0	20	т38	0		
( TI	IMER ) ( COUI	NTR $\Big) \Big($ ke	EPRL $\Big) \Big($	data ) (		) ]	

Timer set time : Timer no. 1–8 is max. 1572.8 sec and its accuracy is 48ms.

Timer no. 9 is max. 262.1 sec and its accuracy is 8ms.

## • COUNTER screen

This screen sets and displays max. value of counter and current value of the counter instruction (SUB 4).



• KEEP RELAY screen

Address specified by ladder

PMC PAP	RAMETER	( KEEP	REALAY	);	#001	MONIT	RUN
NO.	ADDRESS	DATA	A 1	NO.	ADDRES	5 DAI	'A
01	к00	00000	000	11	K10	0000	0000
02	K01	00000	000	12	К11	0000	0000
03	K02	00000	000	13	К12	0000	0000
04	к03	00000	000	14	к13	0000	0000
05	к04	00000	000	15	к14	0000	0000
06	к05	00000	000	16	к15	0000	0000
07	к06	00000	000	17	К16	6666	6666
08	к07	00000	000	18	K17	6666	6666
09	к08	00000	000	19	к18	6666	6666
10	к09	00000	000	20	к19	6666	6666
( TIMER		ITR ) (	KEEPRL	) (	DATA	(	)

Address specified by ladder
 Used by PMC system

\_\_\_\_ 246 \_\_\_\_

## • PMC-NA

(1) Nonvolatile memory control



#7 (MWRTF2) Nonvolatile memory writing status

#6 (MWRTF1) Nonvolatile memory writing status

(2) PMC system parameters

	#7	#6	#5 #4	#3	#2	#1	#0
K017							
	#6	1 : Writing program 0 : The I/O s program	o flash EE has been edi creen is used has been edi	PROM is ted. l for writing ted.	always g to flash	checked	after a sequence M after a sequence
	<b>#5</b> 1 : A sequence program is started upon power-on.						
		0: A sequence program is executed by pressing the RUN key of PMC screen.					
	#3	<ol> <li>The rate of bps.</li> <li>The rate of bps.</li> </ol>	of transfer to of transfer to	and from e and from e	external i external i	nput/outp nput/outp	out devices is 9600 out devices is 4800
		External inpu ROM WRIT FANUC PRI	t/output dev ER and FA NTER.)	vices refer t WRITER.	to a FAN (4800 b	NUC FLC ops is alw	PPY CASSETTE avs selected for a
	#2	1 : The rate of 4800 bps 0 : The rate of 9600 bps	f transfer to f transfer to	and from F. and from F.	APT LA	DDER or DDER or	FAPT PASCAL is
	#1	1 : The conte 0 : The conte	ents of PMC ents of PMC	data can b data canno	e initializ ot be initi	zed. ialized.	



Used by the system. Do not change the setting. Usually set to 0.

### • PMC–NB

(1) Nonvolatile memory control

	#7	#6	#5	#4	#3	#2	#1	#0
K016								

**#7 (MWRTF2)** Writing status in nonvolatile memory

#6 (MWRTF1) Writing status in nonvolatile memory

(2) PMC system parameter

The following keep relays are used by the system, therefore they cannot be used in the sequence program.

	#7	#6	#5	#4	#3	#2	#1	#0	
K017									
#6 ANAST	<b>FAT</b> 0 1	: Pressir functio : Turnin functio	ng [EXE on. g power on.	C] key in to on in	nitiates s iitiates sa	ampling ampling	by signa by signal	l waveforr waveforr	n display n display
#5 TRCST	<b>FAT</b> 0 1	: Signal : Signal functio	tracing tracing on.	starts by starts a	soft key automatio	[EXEC cally by	] in signa power	l trace fun on in sig	ction. nal trace
#4 MEMI	<b>INP</b> 0 1	: Data ir : Data ir	nput can nput can	not be do be done	one in me	emory conte	ontents d ents displ	isplay fund ay functio	etion. n.
#2 AUTOR	UN 0	: A sequ turned	ience pr on.	ogram i	s execut	ed autor	natically	after the	power is
	1	: A sequ	ence pro	ogram is	executed	d by seq	uence pro	ogram soft	key.
#1 PRGR	<b>AM</b> 0 1	): Built–i : Built–i	n progra n progra	ammer is ammer is	s not used s used.	d.			
#0 LADMA	<b>SK</b> 0 1	: Dynam : Dynam	nic displanic displa	ay of lad ay of lad	lder is ex lder is no	ecuted. ot execut	ed.		

#	7 #6	#5	#4	#3	#2	#1	#0
K018							

- **#7 IGNDINT** 0: When the screen is switched to the PCMMDI screen, the CRT is initialized.
  - 1 : When the screen is switched to the PCMMDI screen, the CRT is not initialized.
  - \* This flag is used to control whether the PMC management software initializes the CRT when switching to the PMCMDI screen from another screen is performed. When this flag is set to on, the CRT must be initialized using the application.
- **#3 TRNSRAM** 0 : A ladder program is not automatically sent to the backup RAM after on–line editing is completed.
  - 1 : A ladder program is automatically sent to the backup RAM after on-line editing is completed.
- **#2 TRGSTAT** 0 : The trigger stop function does not automatically start when the power is turned on.
  - 1: The trigger stop function automatically starts when the power is turned on.

- **#1 DBGSTAT** 0: In the C language debug function, the automatic break processing does not start when the power is turned on.
  - 1 : In the C language debug function, the automatic break processing starts when the power is turned on.
- **#0 IGNKEY** 0: Function keys are enabled when a user program displays the user screen.
  - 1 : Function keys are disabled when a user program displays the user screen.
  - \* When this bit is set to 1 of the user screen, the screen cannot be switch to the NC screen using function keys. A program which always sets this bit to 0 or which changes the screen to the NC screen is required.

#6 #5 #4 #3 #2 #1 #0 #7 K019

These bits are status of not used for PMC management software are used by system. Do not change the values. Usually all the bits are 0.

• DATA (data table) screen

A data table is displayed according to the parameters specified for the control data.

/					
	DATA	TABLE CON	NTROL DATA		
	NO.	ADDRESS	PARAMETER	NO.OF DATA	
	000	D0000		3	
	001	D0002	00000000	20	
	001	D0010	0000010	20	
	001	D0018	00001000	50	

DATA	TABLE DAT	<b>FA #001</b>		Σ
NO.	ADDRESS	DATA		$\square$
0000	D0026	20		
0001	D0027	30		
0002	D0028	40		
•	•			
•	•			
•	•			
0019	D0045	99		
			)	
$\sim$				/
ノ				
				$\sim$

### • PMC–NA

(1)Control data table



a) Parameter format



- **#7** 1 : The data table is used for teaching data.
  - 0: The data table is not used for teaching data.
- **#6** 1 : The contents of the data table cannot be modified from the MDI. 0 : The contents of the data table can be modified from the MDI.
- **#3** 1 : The data length for the data table is 4 bytes.
  - 0: The data length for the data table is 1 or 2 bytes.
- **#2** 1 : When the contents of the data table are modified from the MDI, the same data cannot be entered.
  - 0: When the contents of the data table are modified from the MDI, the same data can be entered.
- #1 1 : The data length for the data table is 2 bytes.0 : The data length for the data table is 1 byte.
- **#0** 1 : The data format for the data table is BCD. 0 : The data format for the data table is binary.

Poi The and	nt e corresp t the set	condence tings of	e between the bits 3 and 1 is	data length as follows:
	#3	#1	Data length	
	1	1	1 bytes	
	1	0	4 bytes	
	0	1	2 bytes	
	0	0	1 byte	
	L	1	1	

\_\_\_\_ 250 \_\_\_\_

(2) Data table

DATA	TABLE DA	<b>FA #001</b>	Data table group number
NO.	ADDRESS	DATA	
0000	D0026	20	
0001	D0027	30	
0002	D0028	40	
•			
•			
•			
0019	D0045	99	
			)

### • PMC–NB

(1) Data table setting screen



- a. Soft key [G.DATA] : Select data display screen of data table. (Next screen)
- b. NO. OF GROUPS [G.CONT]: Set the no. of groups of data table.
- c. Group No. [NO.SRH]: Move the cursor to a specified group.
- d. Soft key [INIT]: Initializes the setting of data table.
   No. of groups is 1, ADDRESS is D0000, PARAMETER is 0000000, TYPE is 0, NO. OF DATA is 1860.
- \* This operation is done usually when a sequence program is prepared. When PMC parameters are set, internal parameters are not affected.



#### TYPE

- 0 : 1–byte length 1 : 2–byte length 2 : 4–byte length
- e. Using the page key, next screen/previous screen can be selected. (Only when the screen page number is displayed)
- (2) Data display screen



- a. Soft key [C.DATA] :Returns to the data table setting screen. (Screen in item (1))
- b. Group No. [G–SRCH]: Head of the specified group is selected.
- c. Address [SEARCH]: Searches an address in a group currently selected.

# 4.5 SIGNAL AND SYMBOL CORRESPONDENCE TABLE

			P	PMC address			
	Symbol	Signal name	For M series and	For TT	series		
			T series	HEAD#1	HEAD#2		
	ABS	Absolute Selection Signal	G004.5	G09	9.5		
	*ACTF1 to 10	Axis selection signal in actual speed display	G067.4, G071.4 to G103.4	G131.4, G135.4 to G167.4			
	AE1 to 3	Measuring position reached signals	G001.2 to 4	G001.2 to 4	G049.2 to 4		
	AF1X0 to 7	Miscellaneous function BCD code sig- nals (PMC axis control)	F141	F103			
	AF2X0 to 7	Miscellaneous function BCD code sig- nals (PMC axis control)	F142	F104			
	AF3X0 to 7	Miscellaneous function BCD code sig- nals (PMC axis control)	F143	F1	05		
	AFL	Auxiliary Function Lock Signal	G004.0	G09	9.0		
	*AFV0 to 7	Second Feedrate Override	G013.0 to 7	G013.0 to 7	G061.0 to 7		
	AGJ	Manual arbitrary angle feed selection signal	G003.7	G097.7			
A	*AIT	Automatic operation all–axis interlock signal	G001.0	G001.0	G049.0		
	AJA0 to 7	Manual arbitrary angle feed direction signals	G017.0 to 7	G123.	0 to 7		
	AJA8 to 12	Manual arbitrary angle feed direction signals	G016.0 to 4	G122.	0 to 4		
	AJP1A to D, AJP2A to D AJSTB	Manual arbitrary angle feed axis selec- tion signal Manual arbitrary angle feed direction selection signals	G018.0 to 3 G018.4 to 7 G016.7	G124. G124. G12	0 to 3 4 to 7 22.7		
	+AJ, –AJ	Manual arbitrary angle feed signals	G016.5, G016.6	G122.5,	G122.6		
	AL	Alarm signal	F000.1	F09	6.1		
	ALMA	Serial spindle interface status signal (1st spindle)	F229.0	F229.0			
	ALMB	Serial spindle interface status signal (2nd spindle)	F245.0	F24	5.0		
	ALNGH	Signal for executing handle feed in the direction of the tool axis	G156.0				

			PMC address			
	Symbol	Signal name	For M series and	For TT	series	
			T series	HEAD#1	HEAD#2	
	*APF00 to 15	Second Feedrate Override B	G146 to G147			
	AR0 to AR15	Actual Spindle Speed Signal	F012 to F013	F008 to F009	F056 to F057	
A	ARSTA	Alarm Reset Signal	G226.0	G22	26.0	
	ARSTB	Alarm Reset Signal	G234.0	G23	34.0	
	AXC1,2,4	Axis interchange signals	G041.0 to 2			
	B0 to B31	Second Auxiliary Function Code Sig- nal	F028 to F031	F028 to F031	F076 to F079	
	BATL	Low battery voltage alarm signal	F040.7	F12	20.7	
	BCAN	Block Cancel Signal	G157.6			
	BCLP	B–axis clamp signal	F007.1			
	BDT1 to 9	Optional Block Skip Signal	G004.2 G007.0 to 7	G004.2 G007.0 to 7	G052.2 G055.0 to 7	
	BDT10	Optional block skip signal of software operator's panel	F130.2			
	*BECLP	B-axis clamp completion signal	G019.7			
В	*BEUCL	B-axis unclamp completion signal	G019.6			
	BF	Second Auxiliary Function Strobe Sig- nal	F008.3	F004.3	F052.3	
	BFIN	Second Auxiliary Function End Signal	G046.3	G006.3	G054.3	
	BGEDT	Background editing state output signal	F043.3	F12	20.4	
	BRN	Block Restart Selection Signal	G002.6			
	*BSL	Block start interlock signal	G001.1	G001.1	G049.1	
	BUCLP	B-axis unclamp signal	F007.0			
	BUF1 to 10	Buffer full signal (PMC axis control)	F066.5, F070.5 to F102.0	F130.5, to F1	F134.5 66.5	
	CD1X0 to 7 CD2X0 to 7 to CD10X0 to 7	Axis control command code signals (PMC axis control)	G385 G393 to G457	G3 G3 G4	385 393 to 157	
C	CDV0 to 7	Cutting depth override signals	G027			
Ĭ	*CHF	Chamfering Signal	G008.0	G008.0	G056.0	
	*CHLD	Chopping hold signal	G044.7			
	*CHP0	Chopping speed override signal	G044.0			

			PMC address			
	Symbol	Signal name	For M series and	For TT	series	
			T series	HEAD#1	HEAD#2	
	*CHP2	Chopping speed override signal	G044.1			
	*CHP4	Chopping speed override signal	G044.2			
	*CHP8	Chopping speed override signal	G044.3			
	CNCA1 to 10	Axis control command read completion signal (PMC axis control)	F066.7, F070.7 to F102.7	F130.7, to F	F130.7, F134.7 to F166.7	
	CNGTL	Signal for changing the tool length compensation in the direction of the tool axis with the handle	G156.3			
С	*CSL	Cutting block start interlock signal	G000.1	G000.1	G048.1	
	*CSMZ	In-position Check Signal	G008.1	G008.1	G056.1	
	CSS	Constant surface speed signal	G001.7	F000.7	F048.7	
	CTH1A	Clutch/Gear Signal (1st spindle)	G227.3	G22	27.3	
	CTH1B	Clutch/Gear Signal (2nd spindle)	G235.3	G23	G235.3	
	CTH2A	Clutch/Gear Signal (1st spindle)	G227.2	G22	27.2	
	CTH2B	Clutch/Gear Signal (2nd spindle)	G235.2	G23	35.2	
	D	Manual data input selection signal	G003.3	GOS	97.3	
	*DEC1 to 10	Reference Point Return Deceleration Signals	G064.5, G068.5 to G100.5	G128.5, G132.5 to G100.5		
	DEN	Distribution End Signal	F001.0	F000.0	F048.0	
	DEN1 to 10	Distribution completion signal (PMC axis control)	F066.6, F070.6 to F102,6	F130.6, to F	F130.6, F134.6 to F166.6	
	DIST0 to 23	Incremental feed distance selection signals	G021 to G023	G107 to	o G109	
D	DIST24 to 26	Incremental feed distance selection signals	G020.0 to 2	G106.	.0 to 2	
	DLK	Display Lock Signal	G004.6	GOS	99.6	
	DM00	Decode M Signal	F009.4	F005.4	F053.4	
	DM01	Decode M Signal	F009.5	F005.5	F053.5	
	DM02	Decode M Signal	F009.6	F005.6	F053.6	
	DM30	Decode M Signal	F009.7	F005.7	F053.7	
	DRNO	Dry run signal of software operator's panel	F130.1			
	DRN	Dry Run Signal	G004.1	G09	99.1	

			PMC address			
	Symbol	Signal name	For M series and	For TT	series	
			T series	HEAD#1	HEAD#2	
	DT1X0 to 31 DT2X0 to 31	Axis control data signals (PMC axis control)	G388 to G391 G396 to G399	G388 t G396 t	o G391 o G399	
	to DT10X0 to 31		to G460 to G463	G460 t	o o G463	
D	DTCH1 to 10	Cancel controlled axis signals	G064.7, G068.7 to G100.7	G128.7, to G	, G132.7 164.7	
	DVAL	Velocity control servo alarm ignore sig- nal	G026.1	G1 <sup>2</sup>	10.7	
	*+/-ED1 to 10	External deceleration signals	G064.2, G064.3 G068.2, G068.3	G128.2, G132.2,	, G128.3 , G132.3	
			G100.2, G100.3	G164.2,	, G164.3	
	EDT	Tape storage and edit selection signal	G003.6	G09	97.6	
	EDT0	Tape storage and edit selection signal of software operator's panel	F129.6			
	EF	External Operation Signal	F008.4	F004.4	F052.4	
	EGBM1 to 10	EGB mode confirm signal	F066.3, F070.3 to F102.3			
	EIA0 to EIA7	Address signals for external data input	G033	G1	113	
	EID0 to EID47	Data signals for external data input	G034 to G039	G114 t	o G119	
	EIHEAD	Tool post specification signal for exter- nal data input		G1 <sup>2</sup>	12.4	
	EIREND	Read end signal for external data input	F032.5	G1 <sup>2</sup>	12.5	
Е	EISTB	Strobe signal for external data input	G032.7	G1 <sup>2</sup>	12.7	
	EOA0 to EOA7	Address signals for external data out- put	F033	F1	13	
	EOD0 to EOD47	Data signals for external data output	F034 to F039	F114 t	o F119	
	EOHEAD	Tool post specification signal for exter- nal data output		F11	12.4	
	EOREND	Read end signal for external data out- put	G032.5	G1 <sup>2</sup>	12.5	
	EOSTB	Strobe signal for external data output	F032.7	F11	12.7	
	ERDRQ	External data output request signal	G032.6	G1 <sup>2</sup>	12.6	
	ERS	External reset signal	G000.7	G09	96.7	
	ESEND	External search end signal	F007.5	F003.5	F051.5	
	*ESP	Emergency stop signal	G000.4, X006.4	G096.4	, X006.4	
	*ESPA	Emergency Stop Signal	G226.1	G22	26.1	

			PMC address		
	Symbol	Signal name	For M series and	For TT	series
			T series	HEAD#1	HEAD#2
	*ESPB	Emergency Stop Signal	G234.1	G23	34.1
E	EUI00 to 15	P–code macro input signals	G144.0 to G145.7		
	EUO00 to 15	P-code macro output signals	F166.0 to F167.7		
	EXPUN	External punch start signal	G032.0	G11	2.0
	EXRD	External read start signal	G032.1	G11	2.1
	EXSTP	External read/punch stop signal	G032.2	G11	2.2
	F1D	F1 Digit Selection Signal	G005.3		
	FD1X0 to 15 FD2X0 to 15 to	Feedrate specification signals (PMC axis control)	G386 to G387 G386 to G387 to	G386 ti G394 ti to	o G387 o G395 o
	FD10X0 to 15		G458 to G459	G458 to	o G459
	FFIN	Canned Cycle Auxiliary Signal End Signal	G005.2	G005.2	G053.2
	FIN	End Signal	G005.1	G005.1	G053.1
	FIN1X	Miscellaneous function completion signal (PMC axis control)	G046.4	G110.4	
F	FIN2X	Miscellaneous function completion signal (PMC axis control)	G046.5	G11	0.5
	FIN3X	Miscellaneous function completion signal (PMC axis control)	G046.6	G11	0.6
	FMF	Canned Cycle Auxiliary Signal Read- out Signal	F008.5	F004.5	F052.5
	FRP1 to 10	Floating Reference Point Return End Signals	F065.5, F069.5 to G101.5	F129.5, to F1	F133.5 65.5
	*FV00 to *FV70	Feedrate override signals of software operator's panel	F133		
	*FV0 to 7	Feedrate Override	G012.0 to 7	G012.0 to 7	G060.0 to 7
	GOQSM	Signal for selecting the mode for writ- ing tool compensation	G028.7	G028.7	G076.7
G	GS1	Spindle Gear Selection Signal	G026.4	G02	26.4
	GS2	Spindle Gear Selection Signal	G026.5	G02	26.5
	GS4	Spindle Gear Selection Signal	G026.6	G02	26.6

			PMC address			
	Symbol	Signal name	For M series and	For TT	series	
			T series	HEAD#1	HEAD#2	
	Н	Manual handle feed selection signal	G003.1	GO	97.1	
	HD00 to 2 HD03	Signals for outputting the states of the high–speed skip signal and the high–	F047.0 to 2 F047.3	F107.	0 to 2	
	HD04 to 6	speed measuring position reach signal	F047.4 to 6	F107.	4 to 6	
	НО	Manual handle feed selection signal of software operator's panel	F129.1			
Н	HS1A to D	Manual handle feed axis selection sig- nal	G011.0 to 3	G103	.0 to 3	
	HS2A to D		G011.4 to 7	G103	.4 to 7	
	HS3A to D		G010.0 to 3	G102	.0 to 3	
	HS1A0 to HS1D0	Manual handle feed axis selection sig- nals of software operator's panel	F131.0 to 3			
	IBATL	Low voltage alarm signal for RAM_FILE battery	F045.6	F120.6		
	IHEAD1	Signal for selecting a tool post in the memory mode	G110.0			
	IHEAD2	Signal for selecting a tool post in the memory mode	G110.1			
	IMGY	Signal for selecting the virtual axis control mode	G157.3			
	INCH	Inch input signal	F001.3	F097.3		
1	INDXA	Spindle Orientation Stop Position Change Command (1st spindle)	G229.0	G22	29.0	
	INDXB	Spindle Orientation Stop Position Change Command (2nd spindle)	G237.0	G23	37.0	
	INP1 to 10	Position signals	F064.6, F068.6 to F100.6	F128.6, to F1	F132.6 64.6	
	INTGA,B	Velocity integrating control signals	G226.5, G234.5	G226.5,	G234.5	
	IPEN	Distribution End Signal	F001.1	F000.1	F048.1	
	*IT	All-axis interlock signal	G000.0	GOS	96.0	
	*IT1 to 10	Axis interlock signals	G064.4, G068.4 to G100.4	G128.4, to G1	G128.4, G132.4 to G164.4	
	J	Jog feed selection signal	G003.2	G09	97.2	
J	+/–J1 to 10	Feed axis and direction selection sig- nal	G065.0, G065.1 to G101.0, G101.1	G129.0, to G165.	G129.1 0, G165.1	

			PMC address		
	Symbol	Signal name	For M series and	For TT	series
			T series	HEAD#1	HEAD#2
	+/ – J1O to +/ – J4O +/ – J5O to +/ – J6O	Feed axis and direction selection sig- nals of software operator's panel	F136.0 to F136.7 F138.0 to F138.3		
J	JO	Manual continuous feed selection sig- nal of software operator's panel	F129.2		
	*JV0O to *JV15O	Manual feedrate override signals of software operator's panel	F134 to F135		
	*JV0 to 15	Manual feedrate override signals	G014 to G015	G104 to	o G105
	KEY1 to 4	Memory protection keys	G005.4 to 7	G100.	4 to 7
К	KEY0	Memory protection key of software op- erator's panel	F131.4		
	*+/L1 to 10	Overrun signals	G064.0, G064.1 to G100.0, G100.1	G128.0, to G164.0	G128.1 ), G164.1
L	LDT1A	Load Detect Signal 1 (1st spindle)	F229.4	F229.4	
	LDT1B	Load Detect Signal 1 (2nd spindle)	F245.4	F24	5.4
	LDT2A	Load Detect Signal 2 (1st spindle)	F229.5	F229.5	
	LDT2B	Load Detect Signal 2 (2nd spindle)	F245.5	F245.5	
	M0 to M31	Miscellaneous Function Code Signal	F016 to F019	F016 to F019	F064 to F067
	M200 to M215	Miscellaneous Function Code Signal	F144 to F145		
	M300 to M315	Miscellaneous Function Code Signal	F146 to F147		
	M400 to M415	Miscellaneous Function Code Signal	F148 to F149		
	M500 to M515	Miscellaneous Function Code Signal	F150 to F151		
	MA	Control unit ready signal	F000.7	F09	96.7
	MABS	Absolute Selection Check Signal	F004.5	F10	00.5
м	MAFL	Auxiliary Function Lock Check Signal	F004.0	F10	0.0
	MAGJ	Manual arbitrary angle feed selection check signal	F003.7	F09	99.7
	MBCAN	Block Cancel Check Signal	G157.4		
	MBDT1	Optional Block Skip Check Signal	F004.2	F001.2	F049.2
	MBDT2 to 9	Optional Block Skip Check Signal	F005.0 to 7	F002.0 to 7	F050.0 to 7
	MD	Manual data input selection check sig- nal	F003.3	F09	99.3
	MD1 to 10	Signals indicating direction of move- ment	F064.3, F068.3 to F100.3	F128.3, to F1	F132.3 64.3

			PMC address		
	Symbol	Signal name	For M series and	For TT	series
			T series	HEAD#1	HEAD#2
	MDIO	Manual data input selection signal of software operator's panel	F129.3		
	MDLK	Display Lock Check Signal	F004.6	F100.6	
	MDRN	Dry Run Check Signal	F004.1	F10	0.1
	MDTCH1 to 10	Controlled axis canceled signals	F064.7, F068.7 to F100.7	F128.7, F132.7 to F164.7	
	MEDT	Tape storage and edit selection check signal	F003.6	F09	99.6
	MEM	Memory mode selection	G003.5	G09	97.5
	MEMO	Memory mode selection signal of soft- ware operator's panel	F129.5		
	MF	Miscellaneous Function Strobe Signal	F008.0	F004.0	F052.0
	MF1X	Miscellaneous function read signal (PMC axis control)	F046.0	F10	06.0
	MF2 to 5	Miscellaneous Function Strobe Signal (2nd)	F045.1 to 4		
	MF2X, MF3X	Miscellaneous function read signal (PMC axis control)	F046.1 to 2	F106.1	
	MFIN	Miscellaneous Function End Signal	G046.0	G006.0	G054.0
м	MFIN2 to 5	Miscellaneous Function End Signal (2nd and 5th)	G047.1 to 4		
	MH	Manual handle feed selection check signal	F003.1	F099.1	
	MI1 to 10	Mirror image signals	G065.2, G069.2 to G101.2	G129.2, to G1	G133.2 165.2
	MIFIN	Manual intervention compensation fin- ish signal	F046.3	F012.5	F060.5
	MIGET	Manual intervention compensation re- quest signal	G046.7	G008.3	G056.3
	+/-MIT1 to 3	Manual feed interlock signals for each axis	G066.0, G066.1 G070.0, G070.1 G074.0, G074.1	G130.0, G134.0, G138.0,	G130.1 G134.1 G138.1
	+/MIT4 to 10	Manual feed interlock signals for each axis		G142.0, to G1 G142.1, to G1	G146.0 166.0 G146.1 166.1
	MJ	Manual continuous feed selection check signal	F003.2	F09	99.2
	MLK	All Axis Machine Lock Signal	G004.7	G09	99.7
	MLK1 to 10	Machine Lock Signals	G065.3, G069.3 to G101.3	G129.3, to G1	G133.3 165.3

			PMC address		
	Symbol	Signal name	For M series and	For TT series	
			T series	HEAD#1 HEAD#	2
	MLKO	Machine lock signal of software opera- tor's panel	F130.7		
	MMEM	Memory mode selection check signal	F003.5	F099.5	
	MMI1 to 10	Mirror image check signals	F065.0, F069.0 to F101.0	F129.0, F133.0 to F165.0	
	MMLK	All Axis Machine Lock Check Signal	F004.7	F100.7	
	MMLK1 to 10	Machine Lock Check Signals	F065.1, F069.1 to F101.1	F129.1, F133.1 to F165.1	
	MMOVL	Simultaneous auto/manual operation selection check signal	F002.4	F098.4	
	MOVL	Simultaneous auto/manual operation selection Automatic/manual simultaneous op- eration selection signal	G002.4	G098.4	
	MP1,2,4	Manual handle feed distance selection signal	G006.2 to 4	G101.2 to 4	
	MP1O, 2O, 4O	Manual handle feed distance selection signals of software operator's panel	F132.2 to 4		
	MR0 to 15	Maximum Spindle Speed Signal	F014 to F015	F010 to F011 F058 to F	059
М	MRDYA	Machine Ready Signal (1st spindle)	G227.7	G227.7	
	MRDYB	Machine Ready Signal (2nd spindle)	G235.7	G235.7	
	MS	Incremental feed selection check sig- nal	F003.0	F099.0	
	MSBK	Single Block Check Signal	F004.3	F100.3	
	MSBK1 to 10	Block stop inhibit signal (PMC axis control)	G384.7, G392.7 to G456.7	G384.7, G392.7 to G456.7	
	MSCNTR1 to 10	Spindle contour Control Mode Switch Verify Signal (1st spindle)	F067.7, F071.7 to F103.7	F131.7, F135.7 to F167.7	
	MSPPHS	Spindle phase synchronization completion signal	F046.7	F111.7	
	MSPSYC	Spindle speed synchronization completion signal	F046.6	F111.6	
	МТ	Tape mode selection check signal	F003.4		
	MTCHIN	Teach-in selection check signal	F002.3		
	MV1 to 10	Signals indicating movement	F064.2, F068.2 to F100.2	F128.2, F132.2 to F164.2	
	MZRN	Manual Reference Point Return Selec- tion Check Signal	F002.7	F098.7	

			PMC address		
	Symbol Signal name	Signal name	For M series and	es and For TT series	
			T series	HEAD#1	HEAD#2
N	NOT3DM	Signal that specifies whether the manual interruption function for three- dimensional coordinate conversion	G157.7		
	NRROA, B	Signals for executing a shortcut rota- tion when the stop position in spindle orientation is changed (1st spindle)	G229.2, G237.2	G229.2,	G237.2
	OFN0 to OFN5	Tool compensation number input sig- nals	G028	G028	G076
	OHALM	Alarm classification signal	F006.2	F10	1.2
	OMEP	Override playback signal	G010.6		
	OME	Override storage signal	G010.5		
	OP	Cycle Operating Signal	F000.5	F09	6.5
	OPU0 to OPU7	General–purpose signals of software operator's panel	F137		
0	ORARA, B	Orientation Complete Signal	F229.7, F245.7	F229.7,	F245.7
	ORCMA, B	Spindle Orientation Command	G227.6, G235.6	G227.6, G235.6	
	OTALM	Alarm classification signal	F006.3	F101.3	
	OV1X0 to 7 OV2X0 to 7 to	Override signal for each axis in PMC axis control	G368 G369 to	G368 G369 to	
	OV10X0 to 7		6377	G377	
	OVA0 to 7	Override signals for PMC axis control in the simultaneous start mode	G383	G383	
	OVC	Override Cancel	G004.4	G004.4	G052.4
	PBATL	Low voltage alarm signal for the abso- lute position detector battery	F040.6	F12	20.1
	PBATZ	Zero voltage alarm signal for the abso- lute position detector battery	F040.5	F12	0.2
	PCAX1 to 10	PMC axis control signal	G066.3, G070.3 to G102.3	G130.3, to G1	G134.3 66.3
P	PK1 to 10	Parking signal	G065.4, G069.4 to G101.4		
	PMCA1 to 10	Axis control command read strobe sig- nal (PMC axis control)	G066.7, G070.7 to G102.7	G130.7, to G1	G134.7 66.7
	PRC	Measuring position record signal	G008.5	G10	)1.0
	PRTSF	Required parts count arrival signal	F043.6	F012.6	F060.6
	PSALM	Alarm classification signal	F006.0	F10	01.0
	PSW01 to 10	Position switch output signal	F165.0, F165.1 to F164.1	F193.0, to F1	F193.1 92.1

			PMC address		
	Symbol	Signal name	For M series and	For TT	series
			T series	HEAD#1	HEAD#2
	RAST1 to 10	Reference Point Auto Setting Signal	G067.2, G071.2 to G103.2	G131.2, to G1	G135.2 67.2
	RCFNA, B	Switching completion signals	F228.3, F244.3	F228.3,	F244.3
	RCHA, B	Power line status check signals	G226.7, G234.7	G226.7,	G234.7
	RCHPA, B	Power line switching signals	F228.2, F244.2	F228.2,	F244.2
	RGHTH	Signal for executing handle feed per- pendicular to the tool axis	G156.1		
	RI0 to 12	Spindle Motor Command Voltage Sig- nal	G024 to G025	G024 to G025	G072 to G073
	RISGN	Spindle Motor Command Voltage Sig- nal	G024.7	G24.7	G072.7
	RMTI0 to 7	Remote buffer input signal	G152.0 to 7		
	RMTO0 to 7	Remote buffer output signal	F152.0 to 7		
	RNDH	Signal for rotating the tool around the center of the tool tip with the handle	G156.2		
	RO0 to RO15	Command Spindle Speed Signal	F010 to F011	F006 to F007	F054 to F055
R	ROTAA, B	Rotation Direction Command at Changing Spindle Orientation Stop	G229.1, G237.1	G229.1,	G237.1
	ROV1	Rapid Traverse Override	G006.5	G101.5	
	ROV10 to 20	Rapid traverse override signals of soft- ware operator's panel	F132.5 to 6		
	ROV2	Rapid Traverse Override	G006.6	G10	1.6
	RPBSY	Read/punch busy signal	F007.4	F102	2.4
	RPD	Rapid traverse signal	F001.5	F000.5	F048.5
	RRW	Reset and rewind signal	G000.6	G09	6.6
	RSLA, B	Switching request signals	G226.6, G234.6	G226.6,	G234.6
	RSPC	Spindle constant speed signal (Rigid tapping)	F155.2		
	RSPM	Spindle rotation direction signal (Rigid tapping)	F155.1		
	RSPP	Spindle rotation direction signal (Rigid tapping)	F155.0		
	RST	Reset signal	F000.2	F090	6.2
	RST1 to 10	Reset signal (PMC axis control)	G066.6, G070.6 to G102.6	G130.6, to G1	G134.6 66.6

			PMC address			
	Symbol	Signal name	For M series and	and For TT series		
			T series	HEAD#1	HEAD#2	
	RT	Manual rapid traverse selection signal	G006.7	G1(	)1.7	
	RTAP	Rigid tapping signal	F040.4			
	RTO	software operator's panel				
	RTO	Manual rapid traverse selection signal of	F132.7			
R	RTRCT	Retract signal	G042.4			
	RTRCTF	Retract completion signal	F041.4			
	*RV0B to 6B	Rapid Traverse Override 1 %	G040.0 to 6	G120	0 to 6	
	RVSL	Retrace-in-progress signal	F044.2			
	RVS	Retrace signal	G029.4			
	RWD	Rewind signal	F000.0	F09	96.0	
	S	Incremental feed selection signal	G003.0	GOS	97.0	
	S0 to 31	Spindle Speed Function Code Signal	F020 to F023	F020 to F023	F068 to F071	
	SA	Servo ready signal	F000.6	F09	96.6	
	SARA	Speed Reach Signal (1st spindle)	F229.3	F229.3		
	SARB	Speed Reach Signal (2nd spindle)	F245.3	F245.3		
	SBK1 to 10	Block stop signals (PMC axis control)	G066.4, G070.4 to G102.4	G130.4, to G1	G130.4, G134.4 to G166.4	
	SBKO	Single block signal of software opera- tor's panel	F130.3			
	SBK	Single Block	G004.3	GOS	99.3	
s	SCLP	Spindle Clamp Signal	F042.1	F12	23.1	
	SCNTR1 to 10	Spindle Contour Control Mode Switch Signals	G067.7, G071.7 to G103.7	G131.7, to G1	G135.7 167.7	
	SDTA	Speed Detect Signal	F229.2	F22	29.2	
	SDTB	Speed Detect Signal	F245.2	F24	5.2	
	*SECLP	Spindle Clamp Completion Signal	G026.3	G02	26.3	
	*SEUCL	Spindle Unclamp Completion Signal	G026.2	G02	26.2	
	SF	Spindle Speed Function Strobe Signal	F008.1	F004.1	F052.1	
	SFIN	Spindle Speed Function End Signal (1st spindle)	G046.1	G006.1	G054.1	
	SFRA	Forward Rotation Command Signal (2nd spindle)	G227.5	G22	27.5	

			Р	PMC address	
	Symbol	Signal name	For M series and	For TT	series
			T series	HEAD#1	HEAD#2
	SFRB	Forward Rotation Command Signal	G235.5	G23	35.5
	SHA00 to SHA11	Signals for specifying the stop position in orientation of the serial interface spindle	G230 to G231 G238 to G239	G230 to G238 to	o G231, o G239
	SKIP1	Skip signal	G000.3	G000.3	G048.3
	SKIP2 to 4	Skip signals	G001.5 to 7		
	SLDMA0 to 15	Serial Interface Spindle Motor Torque Signal	F232 to F233	F232 to	o F233
	SLDMB0 to 15	Serial Interface Spindle Motor Torque Signal	F248 to F249	F248 to	o F249
	SO	Incremental feed selection signal of software operator's panel	F129.0		
	*SP	Feed Hold Signal	G000.5	G09	96.5
	SPA	Spindle override signal	G029.0		
	SPAL	Spindle Speed Fluctuation Alarm Sig- nal	F042.2		
	SPAL1,2,4,8	Spindle Alarm Code Signals	F040.0 to 3	F012.0 to 3	F060.0 to 3
S	SPAO	Spindle speed override checking sig- nal	F042.4		
	SPA	Spindle override signal	G029.0		
	SPB	Spindle override signal	G029.1		
	SPBO	Spindle speed override checking sig- nal	F042.5		
	SPB	Spindle override signal	G029.1		
	SPC	Spindle override signal	G029.2		
	SPCO	Spindle speed override checking sig- nal	F042.6		
	SPLDS	Signal for selecting the spindle load display	G047.5		
	SPL	Feed Hold Lamp Signal	F000.3	F09	6.3
	SPN0, 1	Spindle control check signals		F013.0, F061.0,	F013.1 F061.1
	SPO	Automatic operation stop signal of soft- ware operator's panel	F128.5		
	SPPHS	Spindle phase synchronization signal	G047.7	G11	1.7
	SPSTP	Spindle Stop Check Signal	G026.0	G02	26.0

		P	PMC address		
	Symbol	Signal name	For M series and	For TT series	
			T series	HEAD#1 HEAD#2	
	SPSYAL	Spindle synchronization alarm signal	F046.5	F111.5	
	SPSVC	Spindle synchronization signal	G047.6	G111.6	
	SRN	Program Restart Selection Signal	G002.5		
	SRV	Canned Cycle CCW Rotation Signal	F008.6	F004.6 F052.6	
	SRVA	Reverse Rotation Command Signal	G227.4	G227.4	
	SRVB	Reverse Rotation Command Signal	G235.4	G235.4	
	SSP	Canned Cycle Spindle Stop Signal	F008.7	F004.7 F052.7	
	SSPAA0 to 7	Serial Interface Spindle Alarm Code Signal (1st spindle)	F236	F236	
	SSPAB0 to 7	Serial Interface Spindle Alarm Code Signal (2nd spindle)	F252	F252	
	SSPDA0 to 15	Serial Interface Spindle Motor Speed Signal (1st spindle)	F234 to F235	F234 to F235	
	SSPDB0 to 15	Serial Interface Spindle Motor Speed Signal (2nd spindle)	F250 to F251	F250 to F251	
	SSTA	Speed Zero Detect Signal (1st spindle)	F229.1	F229.1	
5	SSTB	Speed Zero Detect Signal (2nd spindle)	F245.1	F245.1	
	ST	Cycle Start Signal	G005.0	G100.0	
	STFOVR	Feedrate override teaching signal	G031.6		
	STL	Cycle Start Lamp Signal	F000.4	F096.4	
	STP1 to 10	Axis control temporary stop signals (PMC axis control)	G066.5, G070.5 to G102.5	G130.5, G134.5 to G166.5	
	STSOVR	Spindle speed override teaching signal	G031.5		
	SUCLP	Spindle Unclamp Signal	F042.0	F123.0	
	SVALM	Alarm classification signal	F006.1	F101.1	
	*SVF1 to 10	Servo off signals	G064.6, G068.6 to G100.6	G128.6, G132.6 to G164.6	
	SYALM	Alarm classification signal	F006.4	F101.4	
	SYNC1 to 10	Synchronous control selection signals	G066.2, G070.2 to 102.2		
	SYNER	Excessive error alarm signal for simple synchronization	F153.1		

			PMC address		
	Symbol	Signal name	For M series and	For TT	series
			T series	HEAD#1	HEAD#2
	Т	Tape mode selection signal	G003.4		
	T0 to T31	Tool Function Code Signal	F024 to F027	F024 to F027	F072 to F075
	ТАР	Tapping signal	F001.4	F000.4	F048.4
	TCHIN	Teach-in selection signal	G002.3		
	TCHOVR	Override teaching mode signal	G031.7		
	TCLP	Turret clamp signal	F043.1		
	TDIR1	Turret rotation direction selection sig- nal	G030.0		
	TDIR2	Turret rotation direction selection sig- nal	G030.1		
	*TECLP	Turret clamp completion signal	G030.3		
	*TEUCL	Turret unclamp completion signal	G030.2		
	TF	Tool Function Strobe Signal	F008.2	F004.2	F052.2
	TFIN	Tool Function End Signal	G046.2	G006.2	G054.2
	THRD	Threading signal	F001.6	F000.6	F048.6
	TIALM	Alarm classification signal		F101.6	
Т	ТІСНК	Signal for checking tool post interference	F120.0		
	TL01 to TL64	Tool group signals	G009.0 to 6	G009.0 to 6	G057.0 to 6
	TL128	Tool group signals	G043.7		
	TL256	Tool group signals	G042.0		
	TLCHA	Tool change signal	F007.6	F003.6	F051.6
	TLCHB	New tool selection signal	F007.7	F003.7	F051.7
	TLMA	Torque in-limited Signal (1st spindle)	F229.6	F22	29.6
	TLMB	Torque in-limited Signal (2nd spindle)	F245.6	F24	15.6
	TLMHA	Torque Limit Command High Signal (1st spindle)	G227.1	G22	27.1
	TLMHB	Torque Limit Command High Signal (2nd spindle)	G235.1	G23	35.1
	TLMLA	Torque Limit Command Low Signal (1st spindle)	G227.0	G22	27.0
	TLMLB	Torque Limit Command Low Signal (2nd spindle)	G235.0	G23	35.0
	TLRST	Tool change reset signal	G010.7	G010.7	G058.7

			PMC address			
	Symbol	Signal name	For M series and	For TT	series	
			T series	HEAD#1	HEAD#2	
	TLSKP	Tool skip signal	G009.7	G009.7	G057.7	
	*TLV0 to 7	Tool life count override signals	G155.0 to 7			
	*TLV8 to 9	Tool life count override signals	G154.0 to 1			
	TMRON	General–purpose integrator start sig- nal	G008.7	G00	08.7	
	то	Tape mode selection signal of software operator's panel	F129.4			
	TRACT	Tool retraction mode signal	F044.3	F11	0.3	
	TRESC	Tool retraction signal	G031.0	G12	27.0	
'	TRHD1	First tool post retraction/recovery mode selection signal		G12	27.2	
	TRHD2	Second tool post retraction/recovery mode selection signal		G127.3		
	TRMTN	Tool moving signal	F044.4	F110.4		
	TRRTN	Tool recovery signal	G031.1	G127.1		
	TRSPS	Tool recovery completion signal	F044.5	F110.5		
	*TSB	Tail stock barrier selection signal	G030.7			
	TUCLP	Turret unclamp signal	F043.0			
	UI000 to UI031	Custom macro input signals	G048 to G051	G032 to G035	G080 to G083	
	UI100 to UI131	Custom macro input signals	G052 to G055	G036 to G039	G084 to G087	
	UI200 to UI231	Custom macro input signals	G056 to G059	G040 to G043	G088 to G091	
U	UI300 to UI331	Custom macro input signals	G060 to G063	G044 to G047	G092 to G095	
	UINT	Interrupt signal for custom macro	G000.2	G000.2	G048.2	
	UO000 to UO031	Custom macro output signals	F048 to F051	F032 to F035	F080 to F083	
	UO100 to UO131	Custom macro output signals	F052 to F055	F036 to F039	F084 to F087	
	UO200 to UO231	Custom macro output signals	F056 to F059	F040 to F043	F088 to F091	
	UO300 to UO331	Custom macro output signals	F060 to F063	F044 to F047	F092 to F095	
V	VCSKP1 to 10	Velocity command skip signals (PMC axis control)	G067.6 to G103.6	G131.6 t	o G167.6	
			P	MC address		
------------------	----------------	-----------------------------------------------------------------------------------------	---------------------------------------------------------------------	-----------------------------	----------------	--
	Symbol	Signal name	For M series and	For TT	series	
			T series	HEAD#1	HEAD#2	
	WHEAD	Signal for selecting a tool post for NC window input/output		G11	1.0	
14/	WN1,2,4,8,16	External workpiece number search signals	G019.0 to 4	G019.0 to 4 G067.0 to 4		
vv	WOQSM	Signal for selecting the mode for writ- ing the shift distance for the workpiece	G028.6	G028.6 G076.6		
	WOSET	Signal for writing the shift distance for the workpiece coordinate system	G026.7	G026.7 G074.7		
	ZD1 to 10	Reference Point Approach Signal/Ar- rival Signals				
ZP1 to 10		Reference Point Return End Signals	F064.0, F068.0         F128.0, F           to F100.0         to F16		F132.0 64.0	
	ZP21 to 210	2nd Reference Point Return End Sig- nals	F064.1, F68.1 to F100.1	F128.1, F132.1 to F164.1		
z	ZP31 to 310	3rd Reference Point Return End Sig- nals	F064.4, F068.4 to F100.4	F128.4, F132.4 to F164.4		
	ZP41 to 410	4th Reference Point Return End Sig- nals	F064.5, F068.5 to F100.5	F128.5, to F1	F132.5 64.5	
	ZRN	Manual Reference Point Return Selec- tion Signal	G002.7	G09	98.7	
	ZRNO	Manual reference position return selection signal of software operator's panel	F128.7			
Nu- me ric	3DM	Signal indicating that three–dimension- al coordinate conversion is in the manual	F157.5			
	without symbol	Key input	G128 to G139			
		Signals for specifying a speed in PMC axis control	n PMC See the description of PMC axis contro			



This chapter outlines troubleshooting in Section 5.1 and details the action to be taken for each failure in Section 5.2 and subsequent sections.

5.1	CORRECTIVE ACTION FOR FAILURES	271
5.2	POWER CANNOT BE TURNED ON	273
5.3	NO MANUAL OPERATION NOR AUTOMATIC	
	OPERATION CAN BE EXECUTED	276
5.4	JOG OPERATION CANNOT BE DONE	281
5.5	HANDLE OPERATION CANNOT BE DONE	285
5.6	AUTOMATIC OPERATION CANNOT BE DONE	288
5.7	CYCLE START LED SIGNAL HAS TURNED OFF	295
5.8	NOTHING IS DISPLAYED ON CRT	297
5.9	SR805 TO SR874	
	(RELATED TO READER/PUNCH INTERFACE)	298
5.10	REFERENCE POSITION DEVIATES	310
5.11	PS200 (GRID SYNCHRONOUS IS FAILED)	311
5.12	ALARM OT32 (NEED ZRN (ABS PDR))	314
5.13	ALARM SV101 (DATA ERROR (ABS PCDR))	315
5.14	ALARM OT34 (BATTERY ZERO (ABS PCDR))	316
5.15	ALARM SV110 (PULSE CODER ALARM1 (SERIAL))	317
5.16	ALARM SV114 (ABNORMAL REV DATA)	317
5.17	ALARM SV115 (ABNORMAL COMMUNICATION	
	(SERIAL PCDR))	318
5.18	ALARM SV23 (SV OVER LOAD)	319
5.19	ALARM 700 (OVERHEAT AT CONTROL SIDE)	321
5.20	ALARM OT117 (SPINDLE SPEED FLUCTUATION	
	DETECTION ALARM)	322
5.21	ALARM OT300	
	(SPINDLE SERIAL LINK CANNOT BE STARTED)	323

## 5.1 CORRECTIVE ACTION FOR FAILURES

When a failure occurs, it is important to correctly grasp what kind of failure occured and take appropriate action, to promptly recover the machine.

Check for the failure according to the following procedure :



## 5.1.1 Investigating the (1) When and how many times (frequency of occurrences) **Conditions under** (2) With what operation (3) What failure occurred which Failure Occurred 1. When did the failure occur? Date and time? Occurred during operation? (how long was the operation?) Occurred when the power was turned on? Was there any lightening surge, power failure, or other disturbances to the power supply? How many times has it occurred Only once? Occurred many times ? (How many times per hour, per day, or per month?) 2. With what operation did it occur ? What was the NC mode when the failure occurred? Jog mode/memory operation mode /MDI mode /reference position return mode If during program operation, 1) Where in the program ? 2) Which program No. and sequence No. ? 3) What program ? 4) Occurred during axial movement? 5) Occurred during the execution of an M/S/T code ? 6) Failure specific to the program ? Does the same operation cause the same failure ? (Check the repeatability of the failure.) Occurred during data input/output ? <Feed axes and spindles> For a failure related to feed axis servo 1) Occurred at both low feedrate and high feedrate ? 2) Ocurred only for a certain axis?

For a failure related to spindles When did the failure occur ? (during power–on, acceleration, deceleration, or constant rotation)

3. What failure occurred ?

Which alarm was displayed on the alarm display screen on the CRT? Are the LEDs on each printed circuit board lit?

If machining dimensions are incorrect

- 1) How large is the error ?
- 2) Is the position display on the CRT correct ?
- 3) Are the offsets correct ?
- 4. Other information
  - Is there noise origin around machine?
     If the failure has not occurred frequently, the cause may be external noise to the power supply or inductive noise on machinery cables.
     Operate other machines connected to the same power line and see if noise come from the relays or compressors.
  - · Is it taken any countermeasure for noise in machine side?
  - Check the following for the input power supply voltage :
    - 1) Is there variation in the voltage ?
    - 2) Are the voltages different depending on the phase ?
    - 3) Is the standard voltage supplied ?
  - How high is the ambient temperature of the control unit? (0°C to 45°C during operation) Refer to manual about noise.
  - Has excessive vibration been applied to the control unit? (0.5 G or less during operation)
- 5. When you contact our service center, specify the following items :
  - 1) Name of the NC unit
  - 2) Name of the machine tool builder and type of machine
  - 3) Software series/version of the NC
  - 4) Specifications of the servo amplifier and motor (for a failure related to the servo)
  - 5) Specifications of the spindle amplifier and spindle motor (for a failure related to a spindle)

See the drawing issued by the machine tool builder for the locations of the NC unit and servo/spindle amplifiers.

We use the following specification codes :

Servo/spindle amplifier : A06B–□□□−H□□□ Servo/spindle amplifier : A06B–□□□−B□□□

#### NOTE

□ represents a number

## 5.2 POWER CANNOT BE TURNED ON

**Points** 

## **Causes and Remedies**

#### 1. LED is turned off

WARNING

Maintenance of a CNC unit involves many dangers and, therefore, must be performed only by a qualified technician.

Confirm the green LED PIL and red LED ALM on the front of power unit.

- 1) Proceed to item 1 when green LED PIL is turned off.
- 2) Proceed to item 2 when green LED is lit and red LED AML is turned off.
- 3) Check item 3 when red LED ALM is lit.
- (1) Fuse F1 or F2 on the power unit front panel is blown.
  - (a) Input power voltage is too high.
  - (b) Power unit is faulty.
- (2) Input voltage is low

Measure voltage at R and S terminals of connector CPI to confirm appropriate voltage is supplied.

If it is not normal, check machine side magnetics circuit.

(3) Power supply unit is faulty.

Conditions for power on are as follows:



Fig. 5.2 (a)

For details, refer to 2.5.1 Configuration of the Power Supply Unit.

#### 3. LED ALM is lit

(1) Fuse F3 is blown on the front panel of power unit Check whether +24V is short–circuited or grounded. (See Fig. 5.2(b)).

Check whether +24 v is short-chedhed of grounded. (See Fig. 5.2(b)).



#### 2. Conditions for power on are not satisfied. (PIL is lit and ALM is off)

#### Fig. 5.2 (b)

For details, refer to 2.4. 9"CRT unit is faulty.

- (2) Power supply unit is faulty.
  - (a) Remove connector CP2, CP3, CP5, and CP6.
  - (b) Turn off the power of the machine and retract the power unit from the controller.
  - (c) Turn on power of NC.
  - (d) When LED ALM is lit, power unit is faulty. If ALM is not lit, power supply unit is normal.

#### WARNING

When a work is conducted with power supply unit removed, perform the work within 30 minutes (Data in memory may be lost)

- (3)Load (+5V) is grounded or short-circuited
  - (a) With power supply unit installed on the control unit, turn off the power on the machine side.
  - (b) Remove cables (1) to (3) in the Fig. 5.2 (c), turn on power of NC and check LED ALM.

#### NOTE

To release lightening of ALM, turn off NC power.

(c) When LED ALM is turned off while removing the cable, the load connected by the removed wire may be faulty.

#### CAUTION

When removing the cable note the following :

- 1 If 6V battery is connected as shown Fig. 5.2 (c), absolute position of the machine may be lost when cable (2) is removed. Therefore, the machine position must be established by reference position return ,after releasing the alarm.
- 2 If 6V battery is not connected, the above operation is not needed.



Fig. 5.2 (c)

- (d) If AlM does not light by power on of NC, any of load connected to (1) to (3) may be faulty. Check whether grounding or short-circuiting exists or not. If it is present, replace the appropriate part or cable.
- (4) Short–circuiting within the controller (PCB may be faulty)

Power is supplied to PCBs through the back panel.

Check it by the steps below :

- 1) Remove a PCB in a slot and turn on power, then confirm lightening of LED ALM. Repeat this operation to each PCB.
- 2) When ALM does not light at power on with a PCB removed, the PCB may be faulty.

#### WARNING

Perform an operation with a PCB removed within 30 minutes, otherwise data in memory may be lost.

## 5.3 NO MANUAL OPERATION NOR AUTOMATIC OPERATION CAN BE EXECUTED

**Points** 

(1) Execute the following procedure when no manual nor automatic operation is done

(2) Check whether position display shows correct position

(3) Check CNC status display

(4) Check CNC internal status using diagnostic function

#### Causes and Countermeasures

- 1. Position display (relative, absolute, machine coordinate) does not change
- (1) Check CNC status display (Refer to 2.10 NC STATUS DISPLAY FOR DETAIL)
  - (a) Emergency stop status (Emergency stop signal is turned on)
     If status display shows EMG the emergency stop signal is input.
     Check the following signal using the PMC's diagnostic function (PMCDGN).



ESP=0 indicates that emergency stop signal is input.

(b) It is a reset status

When RESET is displayed, any of a reset is functioned. Check the following signal using the PMC's diagnostic funciton (PMCDGN).

1 An input signal from the PMC functions

	#7	#6	#5	#4	#3	#2	#1	#0	
G0000	ERS	RRW							
G096	ERS	RRW							(TT series)

When ERS is 1, external reset signal is input. When RRW is 1, reset & rewing signal is input.

2 RESET key on the MDI keyboard functions

When the signals in (1) are 0, RESET key may be functioning.

Check the contact of RESET key using a tester.

When it is abnormal, change the keyboard.

(c) Confirm the status of modes

Operation mode status is displayed on the lower part of CRT as follows :

If nothing is displayed, mode select signal is not input. Check mode select signal using PMC's diagnostic function (PMCDGN). For details, refer to section **1.6 NC STATUS DISPLAY**.

#### (Example of display)

- JOG : Manual operation (JOG) mode
- HND: Manual handle (MPG) mode
- MDI: Manual data input (MDI) mode
- MEM : Automatic operation (Memory) mode
- EDIT: EDIT (Memory edit) mode

<Mode selection signal>

	#7	#6	#5	#4	#3	#2	#1	#0	
G003		EDT	MEM	Т	D	J	Н	S	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	-
G097		EDT	MEM		D	J	Н	S	(TT series)
	$\downarrow$	-							
Incremental (INC) feed	0	0	0	0	0	0	0	1	
Manual handle (HND) feed	0	0	0	0	0	0	1	0	
Jog (JOG) feed	0	0	0	0	0	1	0	0	1
Manual data input (MDI)	0	0	0	0	1	0	0	0	
Tape command (TAPE)	0	0	0	1	0	0	0	0	]
Memory command (MEM)	0	0	1	0	0	0	0	0	
Tape storage and editing (EDT)	0	1	0	0	0	0	0	0	]

- (2) Check the status according to CNC diagnostic function Nos. 1000 and 1001. Investigate any items for which 1 is displayed on the right. No. 1000
  - a. INPOSITION CHECK FEEDRATE OVERRIDE 0
  - b. JOG FEED OVERRIDE 0
  - c. INT./START LOCK ON SPEED ARRIVAL ON WAIT REVOLUTION STOP POSITION CODER FOREGROUND READING

#### No. 1001

#### BACKGROUND READING

a. In-position check (positioning check) is being performed.

The system indicates that axis movement has not been completed. Check the state of the following diagnostic number. (This item will be 1 under the following condition.)

Diagnostic No. 3000 (position deviation) > Parameter No. 1827 (in–position width)

(i) Check the value of the parameter using the parameter list.

 Servo loop gain for each axis
 (Standard value: 3000)

 (ii) The servo system may be erroneous. Investigate the servo system according to the description of servo alarms SV023, SV008, and SV009.

b. The manual feedrate override is 0%.

Check the signals by using the PMC diagnostic function (PMC DGN).

	#7	#6	#5	#4	#3	#2	#1	#0	_
G014	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	_
G015	*JV7	+JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	-
G104	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8	(TT series)
	#7	#6	#5	#4	#3	#2	#1	#0	-
G105	*JV7	+JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0	(TT series)

When the override is 0%, the bits of the above addresses are set to all 1 or all 0.

c. An interlock/start lock signal is being input.

Check the signal by using the PMC diagnostic function (PMC DGN).

(i) The interlock signal (\*IT) is being input.



0 in the \*IT bit indicates that the interlock signal is being input.

(ii) An axis interlock signal (\*ITn), servo off signal (\*SVFn), or controlled axis detachment signal (DTCHn) is being input.



The address for the nth axis is as follows:

M/T series: 64 + (n-1)\*4

TT series: 128 + (n-1)\*4

0 in the \*ITn or \*SVFn bit or 1 in the DTCHn bit indicates that the corresponding signal is being input.

(iii) The automatic operation all-axis interlock signal (\*AIT) or block start interlock signal (\*BSL) is being input.

#1 #0 #5 #4 #3	#2	#1	#0	_
G001		*BSL	*AIT	(M/T series)
#7 #6 #5 #4 #3	#2	#1	#0	_
G001		*BSL	*AIT	(TT series HEAD #1)
<i>#</i> 7 <i>#</i> 6 <i>#</i> 5 <i>#</i> 4 <i>#</i> 3	#2	#1	#0	, 
G049		*BSL	*AIT	(11 series   HEAD #2)

0 in the \*AIT or \*BSL bit indicates that the corresponding signal is being input.

(iv) The cutting block start interlock signal (\*CSL) is being input.



0 in the \*CSL bit indicates that the interlock signal is being input.

(3) Check the following parameters to determine whether controlled axis detachment has been specified.



#7 (RMVx) 0: Does not place the relevant axis in the controlled axis detached state.1: Places the relevant axis in the controlled axis detached state.

	#7	#6	#5	#4	#3	#2	#1	#0
1005	RMBx							

- **#7 (RMBx)** The controlled axis detachment signal for the relevant axis (DTCHn) and the setting of bit 7 of parameter No. 0012 (RMVx) are:
  - 0: Disabled.
  - 1: Enabled.
  - (4) If the option for index table indexing is being used, check the setting of the index table indexing axis. If the index table indexing sequence on the PMC is incorrect, the index table indexing axis is placed in the servo off state.

#### 7631

Index table indexing controlled axis number

When this parameter is set to 0, the fourth axis is the index table indexing axis.

2. Position display (machine coordinates) does not change The machine lock signal (MLK) is being input.

-									
	#7	#6	#5	#4	#3	#2	#1	#0	_
G004	MLK								(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	_
G099	MLK							*IT	(TT series)
	#7	#6	#5	#4	#3	#2	#1	#0	_
G065					MLK1				(M/T series first axis)
	#7	#6	#5	#4	#3	#2	#1	#0	
G129					MLK1				first axis)

The address for the nth axis is as follows:

M/T series: 65 + (n-1)\*4

TT series: 129 + (n-1)\*4

MLK All-axis machine lock

MLKn Axis machine lock

1 in each bit indicates that the corresponding machine lock signal is being input.

## 5.4 JOG OPERATION CANNOT BE DONE

#### **Points**

(1) Check whether position display is operating.

(2) Check CNC status display

(3) Check internal status using Diagnostic funciton

### **Causes and Remedies**

1. Position display (relative, absolute, machine cooordinate) does not change

(1) Check mode selection status (JOG mode is not selected)

When status display shows JOG, it is normal. When status display does not show JOG, mode select signal is not selected correctly. Confirm the mode select signal using PMC's diagnostic function (PMCDGN).

<Mode select signal>



(2) Feed axis and direction select signal is not input Check the signal using PMC's diagnostic function (PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0
G100	+J8	+J7	+J6	+J5	+J4	+J3	+J2	+J1
G102	–J8	–J7	-J6	–J5	–J4	–J3	–J2	–J1

Example)

When +X button is pressed on the operator's panel, signal+J1 turns to 1.

- \* This signal is effected at its rise. If axis selection signal is input before JOG mode is selected, axis movement does not occur. Turn the signal to off, then on.
- (3) Check the status according to CNC diagnostic function Nos. 1000 and 1001. Investigate any items for which 1 is displayed on the right. No. 1001
  - a. INPOSITION CHECK FEEDRATE OVERRIDE 0
  - b. JOG FEED OVERRIDE 0
  - c. INT./START LOCK ON SPEED ARRIVAL ON WAIT REVOLUTION STOP POSITION CODER FOREGROUND READING

#### No. 1001

#### BACKGROUND READING

a. In-position check (positioning check) is being performed.

The system indicates that axis movement has not been completed. Check the state of the following diagnostic number. (This item will be 1 under the following condition.)

Diagnostic No. 3000 (position deviation) > Parameter No. 1827 (in–position width)

(i) Check the value of the parameter using the parameter list.

1825	Servo loop gain for each axis	(Standard value: 3000)			
	(ii) The serve system m	au ha arrangous Investigate			

- (ii) The servo system may be erroneous. Investigate the servo system according to the description of servo alarms SV023, SV008, and SV009.
- b. The manual feedrate override is 0%.

Check the signals by using the PMC diagnostic function (PMC DGN).

	#7	#6	#5	#4	#3	#2	#1	#0	_
G014	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	_
G015	*JV7	+JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	
G014	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8	(TT series)
	#7	#6	#5	#4	#3	#2	#1	#0	-
G015	*JV7	+JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0	(TT series)

When the override is 0%, the bits of the above addresses are set to all 1 or all 0.

c. An interlock/start lock signal is being input.

Check the signal by using the PMC diagnostic function (PMC DGN).

(i) The interlock signal (\*IT) is being input.



0 in the \*IT bit indicates that the interlock signal is being input.

		(ii)	An axi	s interloo led axis	ck signal detachm	(*ITn), ent sign	servo of	f signal ( Hn) is be	(*SVFn), or						
	#7	#6	#5	#4	#3	#2	#1	#0	mg mput.						
G064	DTCH1	*SVF1		*IT1					(M/T series						
									I first axis)						
	#7	#6	#5	#4	#3	#2	#1	#0	, (TT corico						
G128	DTCH1	*SVF1		*IT1					first axis)						
	The address for the nth axis is as follows: M/T series: $64 + (n - 1)*4TT$ series: $128 + (n - 1)*40 in the *ITn or *SVFn bit or 1 in the DTCHn bit indicates that$														
			the cor	*11 n or	*SVFn0	lic hain	ine DIC	HII DIL II	idicates that						
		<i>(</i> )		respond	ing signa			1 .	1 (* * 177)						
		(111)	The au	tomatic	operation	n all-axi	s interio	ck signa	1 (*AII) or						
			DIOCK S	start inter	TIOCK SIG	nal (*BS	L) is bei	ing input							
	#7	#6	#5	#4	#3	#2	#1	#0							
G001							*BSL	*AIT	(M/T series)						
	#7	#6	#5	#4	#2	#2	#1	#0	1.						
G001	#7	#0	#5	#4	#3	#2	*BSI	#0 *AIT	(TT series						
									I HEAD #1)						
	#7	#6	#5	#4	#3	#2	#1	#0	1 (TT series						
G049							*BSL	*AIT	HEAD #2)						
			0 in the signal i	e *AIT o is being	or *BSL input.	bit indi	cates tha	t the con	responding						
		(iv)	The cu	tting blo	ck start ii	nterlock	signal (*	CSL) is	being input.						
	#7	#6	#5	#1	#3	#2	#1	#0							
G000	#7	#0	#5	#4	#3	#2	*CSL	#0	(M/T series)						
									] (						
G000	#7	#6	#5	#4	#3	#2	#1 *CSI	#0	(TT series						
0000							COL		HEAD #1)						
	#7	#6	#5	#4	#3	#2	#1	#0	(TT corios						
G048							*CSL		HEAD #2)						
			0 in the input.	e *CSL	bit indica	ates that	the inter	lock sig	nal is being						
	(4	) Check detachi	the follo nent has	wing par been sp	cameters ecified.	to deterr	nine whe	ether cor	trolled axis						
	#7	#6	#5	#4	#3	#2	#1	#0	_						
0012	RMVx								]						

#7 (RMVx) 0: Does not place the relevant axis in the controlled axis detached state.1: Places the relevant axis in the controlled axis detached state.

	#7	#6	#5	#4	#3	#2	#1	#0
1005	RMBx							

**#7 (RMBx)** The controlled axis detachment signal for the relevant axis (DTCHn) and the setting of bit 7 of parameter No. 0012 (RMVx) are:

0 : Disabled.

1: Enabled.

(5) If the option for index table indexing is being used, check the setting of the index table indexing axis. If the index table indexing sequence on the PMC is incorrect, the index table indexing axis is placed in the servo off state.

7631	Index table indexing controlled axis number		]					
	When this parameter is set to 0, the fourth axis is the indexing axis.							
	(6) Jog feed rate setting (Parameter) is not correct							
1423	Jog feedrate per axis [mi	m/min]	]					

## 5.5 HANDLE OPERATION CANNOT BE DONE

Points	(1) Check another manual operation (JOG) is accepted.
	(2) Check CNC status display
Causes and Countermeasure	
1 JOG operation is not acceptable, either	Consult with sections 5.3 and 5.4.
2 When only handle operation (MPG) cannot be done	(1) Check CNC status display at lower left corner of the CRT When the status display shows HND, mode selection is correct. If it is not HND, mode select signal is not input correctly. Check the mode select signal using the PMC's diagnostic function (PMCDGN).



(2) Manual handle feed axis select signal is not input

Check the signals using PMC's diagnostic function (PMCDGN).

	#7	#6	#5	#4	#3	#2	#1	#0	_
G010					HS3D	HS3C	HS3B	HS3A	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	
G011	HS2D	HS2C	HS2B	HS2A	HS1D	HS1C	HS1B	HS1A	
	#7	#6	#5	#4	#3	#2	#1	#0	
G102					HS3D	HS3C	HS3B	HS3A	
	#7	#6	#5	#4	#3	#2	#1	#0	
G103	HS2D	HS2C	HS2B	HS2A	HS1D	HS1C	HS1B	HS1A	(TT series)

When axis select switch for manual handle feed is selected on the machine operator's panel, if the signals are input as follows, it is normal.

Selected axis	HSnD	HSnC	HSnB	HSnA
no selection	0	0	0	0
2nd axis	0	0	0 1	0
3rd axis	0	0	1	1
4th axis	0	1	0	0
5th axis 6th axis	0	1	0	0
7th axis	0	1	1	1
8th axis	1	0	0	0

#### NOTE

In the above table, n is the number of the manual pulse generator (MPG) and up to 3 MPGs can be used. A feed axis is selected by 4–bit code of A to D.

(3) Manual handle feed multiplication is not correct

Check the following signals using PMC's PCDGN. Also confirm the following parameters based on the parameter list.



(4) Checking manual pulse generator

(a) Incorrect of cable

Check disconnection of cable or short circuit.





(b) Manual pulse generator is faulty

When you rotate the MPG, the following signal is output. Measure the signal with synchroscope at screw terminal on back of MPG. If no signal is output, measure +5V voltage.



Check on and off ratio and phase difference of HA and HB.

## 5.6 AUTOMATIC OPERATION CANNOT BE DONE

Points	<ul><li>(1) Check manual operation is possible.</li><li>(2) Check the status of cycle start LED on machine operator's manual.</li><li>(3) Check status of CNC.</li></ul>
Causes and Remedies	When manual operation is either impossible, perform countermeasure, based on the previous item "Jog operation cannot be done". Confirm that a correct mode is selected according to the mode select status of CNC status display. Also, by confirming the automatic operation status it is possible to identify cycle operation, feed hold and cycle stop state.
1. When cycle operation is	"****" is displayed at status display on CRT.
not started (Cycle start	(1) Mode select signal is not correct.
LED does not light)	When the mode select signal is input correctly, following status display is done.
	MDI : Manual data input mode (MDI) MEM : Memory operation mode
	TAPE : Tape operation mode (not supported by the TT series)
	It status display does not show a correct status, check the mode signal with following diagnosis function of PMC side (PMCDGN).



MEM Memory operation mode

- T Tape operation mode
- **D** Manual data input (MDI) mode

(2) Cycle start signal is not input

This signal turns 1 when cycle start button is pressed and turns 0 when it is released. The cycle start actuates when it changes from 1 to 0. Check the state of the signal using PMC's diagnostic function (PMCDGN).





\_\_\_\_ 288 \_\_\_\_

(3) Feed hold signal is input

Under normal state, the feed hold signal is 1 when the feed hold button is not pressed.

Check the state of this signal using the PMC's diagnostic function (PMCDGN)



\*SP Feed hold signal

- 2. When cycle operation is being performed (the start lamp is lit)
- (1) Check the status according to CNC diagnostic function Nos. 1000 and 1001. Investigate any items for which 1 is displayed on the right. No. 1000
  - a. INPOSITION CHECK
  - b. FEEDRATE OVERRIDE 0
  - c. JOG FEED OVERRIDE 0
  - d. INT./START LOCK ON SPEED ARRIVAL ON WAIT REVOLUTION STOP POSITION CODER FOREGROUND READING
  - No. 1001

#### **BACKGROUND READING**

a. In-position check is being performed.

The system indicates that axis movement has not been completed. Check the state of the following diagnostic number. (This item will be 1 under the following condition.)

Diagnostic No. 3000 (position deviation) > Parameter No. 1827 (in-position width)

(i) Check the value of the parameter using the parameter list.

(Standard value: 3000) 1825 Servo loop gain for each axis

- (ii) The servo system may be faulty. Investigate the servo system according to the description of servo alarms SV023, SV008, and SV009.
- b. The feedrate override is 0%.

Check the state of the signals by using the PMC diagnostic function (PMC DGN).

<Normal override signal>

	#7	#6	#5	#4	#3	#2	#1	#0	(M/T series
G012	*FV7	*FV6	*FV5	*FV4	*FV3	*FV2	*FV1	*FV0	TT series
									HEAD #1)
	#7	#6	#5	#4	#3	#2	#1	#0	
G060	*FV7	*FV6	*FV5	*FV4	*FV3	*FV2	*FV1	*FV0	(TT series HEAD #2)

	#7	#6	#5	#4	#3	#2	#1	#0	(M/T series	
G013	*AFV7	*AFV6	*AFV5	*AFV4	*AFV3	*AFV2	*AFV1	*AFV0	TT series	
									" HEAD #1)	
	#7	#6	#5	#4	#3	#2	#1	#0		
G061	*AFV7	*AFV6	*AFV5	*AFV4	*AFV3	*AFV2	*AFV1	*AFV0	(TT series HEAD #2)	

<Second override>

c. The manual feedrate override is 0% (only for dry run).

When the dry run signal is turned on during cycle operation, the following override is enabled for the dry run feedrate. Check the state of the signals by using the PMC diagnostic function (PMC DGN).

	#7	#6	#5	#4	#3	#2	#1	#0	
G014	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	_
G015	*JV7	+JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	_
G104	*JV15	*JV14	*JV13	*JV12	*JV11	*JV10	*JV9	*JV8	(TT series)
	#7	#6	#5	#4	#3	#2	#1	#0	
G105	*JV7	+JV6	*JV5	*JV4	*JV3	*JV2	*JV1	*JV0	(TT series)

When the override is 0%, the bits of the above addresses are set to all 1 or all 0.

d. An interlock/start lock signal is being input.

Check the signal by using the PMC diagnostic function (PMC DGN).

(i) The interlock signal (\*IT) is being input.



0 in the \*IT bit indicates that the interlock signal is being input.

(ii) An axis interlock signal (\*ITn), servo off signal (\*SVFn), or controlled axis detachment signal (DTCHn) is being input.

	#7	#6	#5	#4	#3	#2	#1	#0	
G064	DTCH1	*SVF1		*IT1					(M/T series
							1		
	#7	#6	#5	#4	#3	#2	#1	#0	
G128	DTCH1	*SVF1		*IT1					(TT series
						1			

The address for the nth axis is as follows:

M/T series: 64 + (n-1)\*4

TT series: 128 + (n-1)\*4

0 in the \*ITn or \*SVFn bit or 1 in the DTCHn bit indicates that the corresponding signal is being input.

(iii) The automatic operation all-axis interlock signal (\*AIT) or block start interlock signal (\*BSL) is being input.

	#7	#6	#5	#4	#3	#2	#1	#0	_
G001							*BSL	*AIT	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	_
G001							*BSL	*AIT	(TT series HEAD #1)
	#7	#6	#5	# <i>Λ</i>	#3	#2	#1	#0	,
G049							*BSL	*AIT	(TT series
									$\exists \Pi \Box A D \# Z)$

0 in the \*AIT or \*BSL bit indicates that the corresponding signal is being input.

(iv) The cutting block start interlock signal (\*CSL) is being input.



0 in the \*CSL bit indicates that the interlock signal is being input.

(2) Check the following parameters to determine whether controlled axis detachment has been specified.



#7 (RMVx) 0: Does not place the relevant axis in the controlled axis detached state.1: Places the relevant axis in the controlled axis detached state.



- **#7 (RMBx)** The controlled axis detachment signal for the relevant axis (DTCHn) and the setting of bit 7 of parameter No. 0012 (RMVx) are:
  - 0: Disabled.
  - 1: Enabled.
  - (3) If the option for index table indexing is being used, check the setting of the index table indexing axis. If the index table indexing sequence on the PMC is incorrect, the index table indexing axis is placed in the servo off state.

#### 7631

Index table indexing controlled axis number

When this parameter is set to 0, the fourth axis is the index table indexing axis.

- (4) If only rapid traverse for positioning (G00) fails to function, check the following parameter and signal sent from the PMC:
  - a. Rapid traverse rate setting

1420	Rapid traverse rate for each axis (mm/min)										
		b. Rap									
	#7	#6	#5	#4	#3	#2	#1	#0			
G006		ROV2	ROV1						(M/T series)		
	#7	#6	#5	#4	#3	#2	#1	#0	_		
G101		ROV2	ROV1						(TT series)		
								1	_		
		Rapid tra	verse ov	erride	0.46						
		ROV2	RC	DV1	Override value						
		0		0	100%						
		0		1		50%					
		1		0	Fm% *1						
		1		1	F% *2						

- (0: Low, 1: High)
- \*1 Fm is a percentage between 0 and 100%, specified with parameter No. 1412 (common to all axes).
- \*2 Fo is the absolute value of the feedrate between 0 and the rapid traverse rate, specified with parameter No. 1421 (for each axis).

	#7	#6	#5	#4	#3	#2	#1	#0	_
G040	1	*RV6B	*RV5B	*RV4B	*RV3B	*RV2B	*RV1B	*RV0B	(M/T series)
	#7	#6	#5	#4	#3	#2	#1	#0	
G120	1	*RV6B	*RV5B	*RV4B	*RV3B	*RV2B	*RV1B	*RV0B	(TT series)

Override value  $\sum_{i=0}^{6} \{2i \times Vi\}$ .

Vi = 0 when \*RViB is high Vi = 1 when \*RViB is low

The above expression means that each signal has the following weight:

\*RV0B : 1% \*RV4B : 16% \*RV1B : 2% \*RV5B : 32% \*RV2B : 4% \*RV6B : 64% \*RV3B : 8%

When all the signals are low, the override value is assumed to be 0%, in the same way as when all the signals are high. If the specified override value exceeds 100%, 100% is assumed.

The following parameter is used to specify which of the above methods of specifying rapid traverse override is applied.

	#7	#6	#5	#4	#3	#2	#1	#0	
1402								ROV8	
[Parameter	input]								
[Data	type]	Bit type							
]	ROV8	Rapid trav	erse ove	rride is s	specified	as:			
		0 : Fo, Fn	n, 50%, c	or 100%	, using tv	wo input	signals,	ROV1 a	nd ROV2.
		1:0 to 1 *RV6	00% (in	steps of	f 1%), u	sing sev	en input	signals,	*RV0B to
		(5) Only fe	eed (othe	r than G	(00) does	s not fund	ction		
		(a) Max	ximum fe	eed rate	set by pa	rameter	is incorr	ect.	
1422	Maxim	um feedrate					[1	mm/min]	
	L	Fee	d rate is (	clamned	at this u	inner fee	d rate		
		(b) Fee	d rate is a	specified	1 by feed	l per revo	olution (	mm/rev)	
		(i)	Positio	n coder (	does not	rotate	oracion (		
		(-)	Check The fol	the conn lowing f	ection b	etween s conside	pindle a red:	nd positio	on coder
			· T imi	ng belt i	s broker	1			
			· Key i	s remov	ed				
			· Coup	ling is lo	oose				
			· Conn	ector of	signal ca	able is lo	osened		
		(ii)	Position	n coder i	is faulty				
		(c) Thr	ead cuttin	ng does	not oper	ate			
		(i) I	Position of	coder do	es not ro	otate			
			Check to The fol	the conn lowing f	ection b failure is	etween s consider	pindle a red:	nd positio	on coder
			· Timir	ng belt is	s broken				
			· Key i	s remov	ed				
			· Coup	ling is lo	oose				
			· Conn	ector of	signal ca	able is lo	osened		
		(ii)	Position	n coder i	is faulty				
			Position serial in analog For det	n coder nterface interface ails of co	is conne spindle i e spindle onnectio	ected to s used or is used. n, refer t	the spin connect to the fol	dle ampled to the lowing.	ifier when CNC when
			<t serie<br="">Whether correctle the CF display</t>	es> er A/B p ly, can b RT scree ed when	hase sign e judged en (posi PARAM	nals from also by tion scr A 3105#2	n the pos the spino reen). (H 2=0).	sition cod dle speed However,	er are read display on it is not

## <Serial spindle amplifier>



# <Analog interface spindle amplifier>



\_\_\_\_ 294 \_\_\_\_

- Shield

- - - 4

Connector:Cannon connector

Connector:20-pins half pitch

## 5.7 CYCLE START LED SIGNAL HAS TURNED OFF

### **Points**

(1) After cycle operation is started, then stopped, check as follows:(2) Confirm cycle start LED on machine operator's panel.(3) Confirm CNC's diagnostic function

### **Causes and Remedies**

(1) If the cycle start LED signal (STL) has been turned off due to a reset, check CNC diagnostic No. 1010.

	#7	#6	#5	#4	#3	#2	#1	#0
1010					RST	ERS	RRW	ESP

Each bit indicates the following state when set to 1.

- a. ESP Emergency stop state
- b. RRW The reset & rewind signal is turned on.
- c. ERS The external reset signal is turned on.
- d. RST The reset key has been pressed.
- \* Details of signals a to d are as follows: Confirm the signals concerned using diagnostic function (PMCDGN).

**a. Emergency stop is input** When I/O card is not used:



**\*ESP=0** : Emergency stop signal is input :

## b. Reset & rewind signal is

input



**#6 (RRW)** When this signal is 1, the reset & rewind signal is input.

 \* This signal is usually used for a confirmation signal of M30 when an M30 is specified in a program as the end of a program. Therefore, when M30 is executed, this signal is input.

## c. External reset signal is

input		#7	#6	#5	#4	#3	#2	#1	#0	_			
	G0000	ERS								(M/T series)			
	,	#7	#6	#5	#4	#3	#2	#1	#0	-			
	G096	ERS								(TT series)			
	#7 (I	ERS) V	When the	bit is 1,	externa	l reset sig	nal is in	put.					
		*	This si	gnal is u	sually u	used for a	confirm	ation sig	nal of M	02 when an			
			M02 is	specifie	d in a p	orogram as	s the end	l of a pro	ogram.				
			Theref	ore, whe	n M02	is execute	ed, this s	ignal is i	input.				
d. Reset button on	the MDI	A	n automa	atic oper	ation is	put into a	reset sta	atus whe	n RESE'	Γ key on the			
is pressed		Ν	IDI pane	l is press	sed.								
		(	) When		o o10 <i>mm</i>	has some	moted or	vala ana	notion is	nut into the			
		(2	reset st	any serverate and o	operatio	n as gene	rated, cy	vcie oper	ration is	put into the			
			See the	messag	e scree	n to identi	fv the al	arm whi	ich has b	een issued.			
				0			5						
		(3	3)Cycle o	operation	n may b	e in the fe	eed hold	state.					
			The cy	cle opera	ation be	ecomes fee	ed hold s	state in t	he follow	ving cases:			
			(a) Mo	des are sy	witched	l from an a	utomatio	c operati	on mode	to a manual			
		_	ope	ration m	ode.								
						Tape oper	ation (TA	PE)					
			Automa	atic opera	tion	on Automatic operation (MEM)							
						Manual data input (MDI)							
			Manu	ol on oroti		Jog feed (JOG)							
			Handle/step										
		L	(b) Fee	d hold si	gnal is	input.							
		<	Feed hol	d signal:	>								
		#7	#6	#5	#4	#3	#2	#1	#0	_			
	G0000			*SP						(M/T series)			
		#7	#6	#5	#4	#3	#2	#1	#0	] / <del></del> · · ·			
	G096			*SP						(II series)			
	#5 (	*SP) V	Vhen this	signal is	s 0, the	feed hold	signal is	s input.					

(4) Single–block stop may occur during cycle operation. Check the following signal: #7 #6 #4 #3 #0 #5 #2 #1 G004 SBK #6 #5 #3 #2 #7 #4 #1 #0 (TT series) G096 SBK

**#3** (SBK) When this signal is 1, the single block signal is input.

## 5.8 NOTHING IS DISPLAYED ON CRT

#### Points

Judgement of the point

Check whether it is a trouble of display or a trouble of the system.

Check whether the STATUS LED on the main board shows the following state.

If the status shows the above state, the system is normal. Therefore, display system may be faulty.

If the status shows other state, a hardware other than the display system may be troublesome.

## **Causes and remedies**

1. When the display system is in toruble

(1) Confirmation item

- 1 Is power supplied to the display?
- 2 Is a video signal connected? Isn't it disconnected? or braked?
- (2) Causes and remedies
  - 1 Power to the display is faulty. (Exchange power supply unit).
  - 2 Cable connection is faulty. (Correct the connection).
  - 3 Module is faulty (Exchange CRT control module)
  - 4 Display is faulty.
  - \* The CRT control module is mounted on the main CPU board or option 1 board. The location of the module is described in:

Sections 2.5.2 to 2.5.5 : Main CPU board Section 2.5.19 : Option 1 board

2. When system is in trouble

When STATUS LED on the main board is other than above, check LEDs on the main CPU board and other optional boards, identify the trouble and make an appropriate action.





#### Cause

(a) A parameter setting related to the reader/punch interface is invalid.

(b) The external input/output device or host computer is faulty.

(c) The I/O interface module is faulty.

(d) The cable between the NC and input/output device is faulty.

#### Action a

 Parameters related to reader/punch interfaces A parameter setting related to the reader/punch interface is invalid.

Correlation diagrams for parameters related to reader/punch interfaces are given below.

Parameters related to the reader/punch interface

The correlation diagrams of the parameters related to the reader/punch interface are given below.

1) Main CPU board + Option 1 board (with communication functions)



- Channel 1 : JD5A of the main CPU board
- Channel 2 : JD5B of the main CPU board
- Channel 10 : JD5C (RS–232–C) or JD6A (RS–422) of OP1. Only one of the two can be used. Which is used is specified with bit 0 of parameter No. 5000.
- 2) Main CPU board + Additional axis board (SUB, ADAX)



- Channel 1 : JD5A of the main CPU board
- Channel 2 : JD5B of the main CPU board
- Channel 3 : JD5J of the sub-board
- Channel 13 : JD6D of the sub-board

- Series 15–B

   JD5A

   JD5B

   JD5B

   Main

   SUB

   OP 1

   R/P

   R/P
  - Channel 1 : JD5A of the main CPU board Channel 2 : JD5B of the main CPU board Channel 3 : JD5J of the sub-board Channel 13 : JD6D of the sub-board Channel 10 : JD5C or JD6A of OP1. Only one of the two can be used. Which is used is specified with bit 0 of parameter No. 5000. Connector for RS-232-C : JD5A, JD5B, JD5C, JD5J Connector for RS-422 : JD6A, JD6D

#### NOTE

The option 1 board contains a remote buffer.

Each reader/punch unit is temporarily assigned device numbers 1 to 6.

When you have four reader/punch units, for example, assign device numbers 1 to 4 to them.

Set the specifications of the assigned reader/punch units in parameter Nos. 5110 to 5162. Set the device numbers of the reader/punch units connected to channels 1, 2, 3, and 13 in parameter Nos. 5001, 5002, 5003, and 5013.

Set the specifications of the host computer connected to the remote buffer in parameter Nos. 5071 to 5084. A parameter that specifies which reader/punch unit is connected to channel 10 is not provided because the remote buffer is always connected to channel 10.

Parameter Nos. 0020 to 0023 select which channels are used as input/output units for foreground/background. These parameters are normally set on a dedicated screen called the SETTING HANDY screen.

 Main CPU board + Sub-board (additional axis) + Option 1 board (with communication functions)



Settings

	#7	#6	#5	#4	#3	#2	#1	#0
0000			DNC	EIA	NCR	ISP	CTV	TVC

[Setting input]

[Data type] Bit

TVC Specifies whether TV check is performed.

- 0: Do not perform.
- 1 : Perform.
- CTV Specifies whether characters are counted for TV check during control out.
  - 0: Count.
  - 1: Do not count.
  - ISP Specifies whether ISO codes contain a parity bit.
    - 0 : Contain parity bit.
    - 1 : Do not contain parity bit.
      - (A parity bit is located at channel 8 in a punched tape in the ISO code.)
- NCR Specifies how to punch an EOB (end–of–block) code when using ISO codes.
  - 0: Punch LF CR CR.
  - 1 : Punch LF.
- **EIA** Specifies the code system to use for punch codes.
  - 0: ISO code
  - 1: EIA code

Parameter

Interface No. of input device for foreground

[Setting input]

0020

[Data type] Bit

Assignment of input device numbers for foreground

- 0: Reader connected to JD5A of main CPU board
- 1 : Reader connected to JD5A of main CPU board (Settings 0 and 1 are identical.)
- 2: Reader connected to JD5B of main CPU board
- 3: Reader connected to JD5J of the subboard
- 13: Reader connected to JD6D of the subboard

Perform system reset after setting this parameter.

0021

Interface No. of output device for foreground

#### [Setting input]

#### [Data type] Bit

Assignment of output device numbers for foreground

- 1 : Punch connected to JD5A of main CPU board
- 2: Punch connected to JD5B of main CPU board
- 3 : Punch connected to JD5J of the subboard
- 13: Punch connected to JD6D of the subboard

Perform system reset after setting this parameter.

0022

Interface No. of input device for background

#### [Setting input]

#### [Data type] Byte

Assignment of input device numbers for background

- 0 : Reader connected to JD5A of main CPU board
- 1 : Reader connected to JD5A of main CPU board (Settings 0 and 1 are identical.)
- 2 : Reader connected to JD5B of main CPU board
- 3 : Reader connected to JD5J of the subboard
- 13: Reader connected to JD6D of the subboard

Perform system reset after setting this parameter.

0023 Interface No. of output device for background

#### [Setting input]

#### [Data type] Byte

Assignment of output device numbers for background

- 1 : Punch connected to JD5A of main CPU board
- 2 : Punch connected to JD5B of main CPU board
- 3 : Punch connected to JD5J of the subboard
- 13: Punch connected to JD6D of the subboard

Perform system reset after setting this parameter.

5001	Device number of reader/punch unit connected to JD5A of MAIN
5002	Device number of reader/punch unit connected to JD5B of MAIN
5003	Divice number of reader/punch unit connected to JD5J of additional axis board

#### [Setting input]

[Data type] Byte

[Valid data range] 1 to 6

Set the device numbers of the reader/punch units connected to connectors CD4A, CD4B, and CD4.

Set the code numbers of the reader/punch units corresponding to device numbers 1 to 6 in parameter Nos. 5100 to 5162.

5013

Device number of reader/punch unit connected to JD6D of additional axis board

#### [Setting input]

[Data type] Byte

[Valid data range] 1 to 6

Set the device numbers of the reader/punch units connected to the RS-422 interface.

Set the code numbers of the reader/punch units corresponding to device numbers 1 to 6 in parameter Nos. 5100 to 5162.
5060 HDLC baud rate in DNC1

### [Setting input]

[Data type] Byte

Set this parameter to 51 because the HDLC baud rate is fixed at 460K bps in DNC1.

## Action **b**

- The external input/output device or host computer is faulty
- (1) Check that the communication settings made for the external input/output device or host computer are the same as those made for the NC (such as the baud rate and number of stop bits). If they are found to be different, correct the settings.
- (2) If an alternative input/output device is available, check whether communication is normal when that device is used.

## Action c

- The I/O interface module or communication control module is faulty
- The module mounted on one of the following optional printed circuit boards, depending on the setting of parameter No. 0020, may be defective. Replace the module.

Setting of parameter No. 0020	Module is mounted on:	Remarks
0, 1, 2	Main CPU printed circuit board	See Sections 2.5.2 to 2.5.5.
3, 13	Sub–CPU printed circuit board	See Sections 2.5.15 to 2.5.17.
4, 10	Option 1 printed circuit board	See Section 2.5.19.

# Action d

- Cable between NC and I/O device is faulty
- Check the cable for disconnection or wrong connection.



Cable connection>									
R232–1 R232–2 R232–9	(JD5A) (JD5B) (JD5J)								

<





### NOTE

- 1 When CS is not used, connect it to RS.
- 2 For protocol A or extended protocol A: When DR is not used, connect it to ER. Always connect CD to ER.



#### NOTE

Always use a twisted pair cable.



# 5.11 PS200 (GRID SYNCHRONOUS IS FAILED)

## Contents

(1) Reference position return was executed when the following condition is not satisfied:

The CNC received one rotation signal at least one time when the axis is moving to the reference position at a speed higher than a speed equivalent to 128 pulses of position error amount (DGN3000).

(2) After turning on the absolute pulse coder for the first time, reference position return was performed, either manually or with G28, before establishing the position for the pulse coder. A normal reference position thus could not be obtained.

#### Countermeasures





## CAUTION

- 1 After the pulse coder or motor is exchanged, reference position or machine's standard point may be different from former one. Please set it correctly.
- 2 When the main board is exchanged, all the data stored in memory is lost. Reset all the NC data again, referring to the Chapter 3.

#### NOTE

A speed more than 128 pulses is required because if speed is lower that this, one-rotation signal does not function stably, causing improper position detection.

# 5.12 ALARM OT32 (NEED ZRN (ABS PDR))

## Remedies

• When reference position return function is present

Absolute position data in the absolute pulse coder was lost.

(This alarm will be generated when absolute pulse coder is exchanged or position feedback signal cable of the absolute pulse coder is disconnected).

Machine position must be memorized using the following method:

- (1) Execute manual reference position return only for an axis for which this alarm was generated. When manual reference position return cannot be executed because of an another alarm, set parameter 1815#5 to 0 and release the alarm and perform manual operation.
- (2) Press key at the end of reference position return to release the alarm.
- When reference position return function is not present

Execute dogless reference position setting to memorize the reference position.

 When serial pulse coder is changed Since the reference position is different from the former one, change the grid shift value (PRM 1850) to correct the position.

## **Related parameters**

	#7	7	#6	#5	#4	#3	#2	#1	#0
1815				APC x	APZx				

**#5 (APCx)** 0 : Position detector is incremental pulse coder. 1 : Position detector is absolute pulse coder.

#4 (APZx) Reference position of absolute pulse coder is :

- 0: not established
- 1 : established

# System configuration

Main CPU board     Sub CPU board	AMPx PWM signal Servo Power cable
Additional axis	APCBAT
board	Battery unit 6V
Axis CPU	PC Servo motor
board     board	PC : pulse coder

# 5.13 ALARM SV101 (DATA ERROR (ABS PCDR))

**Points** 

Absolute pulse coder, cable or servo module is faulty.

Check the details of the error using the CNC diagnostic function. The diagnostic number for each axis is obtained as follows:

 $3018 + (n - 1) \ge 20$  (n: axis number = 1, 2, 3, ...)

### **Causes and Remedies**

	#7	#6	#5	#4	#3	#2	#1	#0				
Diagnostic	APMVAL	APPER	APFER	APTER	APCER		APPLSM					
	(1	)#1 (AP ⇒ Ass )#3 (AP #4 (AP #5 (AP #3 (AP)	PLSM) sociate tl CER) A TER) A PFER) A PER) A	A mispu ne refere commun time–ov framing parity e	Ilse alari nce positi nication e ver error gerror has rror has	n has be tion with error has o has occu s occurred	en issued absolute occurred duri rred during during d	l. e position during da ng data g data tra lata trans	n detection. ata transfer. transfer. ansfer. sfer.			
	<ul> <li>⇒ (i) If the error recurs, identify the error by applying the abov diagnostic. If the diagnostic always indicates the same error replace the feedback cable, servo interface module, or puls coder.</li> </ul>											
		(ii)	If the d any oth by exte	iagnostio her failur ernal nois	e does no e is dete se.	ot always cted, the	indicate error ma	the same y have b	e error, or if been caused			
	(3	)#7 (AP	MVAL)	An exc	essive m	otor shif	t alarm h	as been	issued.			
		(	This alar exceedin	m is issu g 24000	ed if the detectio	machine n unit pu	is shifted Ilses, upo	l by a lar on power	rge amount, r–on.			
		$\Rightarrow$	The mac	hine mus	st be prev	vented fr	om shifti	ng upon	power-on.			
	1	NOTE If the code point	e feedba r is repla will dif	ack cat aced, th fer from	ole, serv e refere n those	vo inter nce pos before	face mo sition and replacer	odule, o d mach ment.	or pulse ine zero Perform			

adjustment and setting as necessary after replacement.

\_\_\_\_\_ 315 \_\_\_\_

# 5.14 ALARM OT34 (BATTERY ZERO (ABS PCDR))

### Remedies

This alarm is issued when the battery for the absolute pulse coder has failed (its voltage has dropped to 0 V). Absolute position data is lost when the battery is replaced. After replacing the battery, therefore, perform reference position return to re–set the machine position.

For the battery boxes connected to the following connectors, replace that battery which corresponds to the axis for which an alarm has been issued, as described in Section 2.8.2.

## CAUTION

- 1 Change the batteries while power of NC is supplied.
- 2 Do not change the battery (memory backup battery) for the control unit.
- 3 The CNC is constantly monitoring the state of each battery. Once the voltage of a battery has fallen below the rated value, a yellow blinking "BAT" indication appears at the bottom right of the CRT. As soon as this indication appears, use the diagnostic screen to identify the low-voltage battery, then replace that battery.



- **PBATL** Indicates that the voltage of the battery for the absolute pulse coder has fallen below the rated value. Replace the battery as described above.
  - **BATL** Indicates that the voltage of the backup battery, used to maintain the contents of the memory containing command programs and parameters, has fallen below the rated value. Replace the battery on the control unit.

# 5.15 ALARM SV110 (PULSE CODER ALARM1 (SERIAL))

Points

Check the details of the alarm using the CNC diagnostic function.

The serial pulse coder or feedback cable has been found to be defective.

• When diagnostic number 0202 shows 1

	#7	#6	#5	#4	#3	#2	#1	#0
3016+(n−1)×20		CSAL		PHAL			CKAL	SPHAL
I N : AXIS NUMBER I								

- #6 (CSAL) Check sum alarm has generated.
- #4 (PHAL) Phase data abnormal alarm has generated.
- #1 (CKAL) Clock alarm has generated.
- #0 (SPHAL) Soft phase data abnormal alarm has generated.
  - Check the contens using the above diagnostic function if the alarm generates repeatedly. If diagnostic data is the same, serial pulse coder may be faulty. ⇒Refer to Caution
  - 2 When diagnostic result does not the same, or other abnormality is detected, an external noise may be generated.

# CAUTION

Reference position and machine's standard position are different from the ones before, adjust and set them correctly.

5.16 ALARM SV114 (ABNORMAL REV DATA) Erroneous rotation speed count data from the serial pulse coder has been detected.

- 1 If the alarm generates repeatedly, serial pulse coder may be faulty.  $\Rightarrow$ Refer to Caution
- 2 When diagnostic result does not the same, or other abnormality is detected, an external noise may be generated.

# CAUTION

Reference position and machine's standard position are different from the ones before, adjust and set them correctly.

# 5.17 ALARM SV115 (ABNORMAL COMMUNICATION (SERIAL PCDR))

An error is generated in communication with serial pulse coder.

# **Points**

Check the details by the diagnostic function of the CNC.

		#7	#6	#5	#4	#3	#2	#1	#0
DGN $3017+(n-1)\times 20$	$3017+(n-1)\times 20$		CSA		PHA	RCA		СКА	SPHA
	In Axis number I								

- **#7 (DTE)** Data error has generated.
- #6 (CRC) Serial communication error has generated.
- **#5 (STB)** Stop bit error has generated.
  - #7 (DTE):Response from serial pulse coder is absent. (Causes)
    - 1 Signal cable is disconnected
    - 2 Serial pulse coder is faulty.  $\Rightarrow$  See Caution.
    - 3 + 5V to the serial pulse coder is lowered.
  - #6 (CRC), #5 (STB):Serial communication is in faulty (Causes)
    - 1 Signal cable is disconnected.
    - 2 Serial pulse coder is faulty  $\Rightarrow$  See Caution.
    - 3 Main CPU board, sub CPU board, additional axis board, or axis CPU board (multiple axis/multi–path), is faulty ⇒ See Note

## CAUTION

After the serial pulse coder is changed, reference position or machine's standard point is different from the one before replacement. Therefore reset and adjust it again.

## NOTE

All the data stored in memory is lost when the main board is changed. Set NC data again, referring to "chapter 3 data input/output".

# 5.18 ALARM SV23 (SV OVER LOAD)

Amplifier or overheat of motor is detected.



## • SVM fan alarm



# 5.19 ALARM 700 (OVERHEAT AT CONTROL SIDE)

Remedies

Because an ambient temperature of the control unit becomes high, a thermostat mounted on the back panel of NC functions and informs an alarm.



# 5.20 ALARM OT117 (SPINDLE SPEED FLUCTUATION DETECTION ALARM)

Remedies

Spindle speed changes abnormally due to load.



#### Remedies

- **PRM 5701** : A ratio of spindle speed at which actual spindle speed is regarded as arrived at a command spindle speed.
- **PRM 5702** : Spindle speed fluctuation ratio up to which the spindle speed fluctuation detection alarm is not issued.
- **PRM 5721** : Spindle speed fluctuation that is not regarded as the spindle speed fluctuation alarm.
- **PRM 5722** : Time when a spindle speed changed to when spindle speed fluctuation detection is started.

# 5.21 ALARM OT300 (SPINDLE SERIAL LINK CANNOT BE STARTED)

## Causes

normally in a system using a serial spindle.

Alarm OT300 is issued when the spindle amplifier cannot be started

- (1) Optical cable is in poor contact or spindle amplifier power is off.
- (2) When display of spindle amplifier shows SU–01 or an alarm other than AL–24 is displayed, power to the NC is turned on.

In this case, this alarm usually occurs when the NC's power is turned off while the serial spindle is operating. Turn off the power of serial spindle once, then turn it on and starts the system.

- (3) Combination of hardware is wrong.
- (4) When the 2nd spindle is at the state of (1) to (3).

When the 2nd spindle is used, parameter is set as follows : Bit 1 of parameter no.5606 is 1: No. of serial spindles connected is 2.

(5) Parameter setting is failed.

## Diagnosis

	#7	#6	#5	#4	#3	#2	#1	#0
1500	SALMI		CALM	CMER	CER	SNER	FRER	CRER

Information in the LSI chip for the Serial Interface Controller (SIC)

- **CPER** 1 : CRC error (warning)
- FRER 1: Framing error (warning)
- SNER 1: Wrong transmission/reception station
- CER 1 : Receive error
- CMER 1: No reply during automatic scanning
- CALM 1 : Communication alarm in the spindle amplifier
- SALMI 1 : System alarm in the spindle amplifier

	#7	#6	#5	#4	#3	#2	#1	#0
1501							SICTYP	

Information in the LSI chip for the Serial Interface Controller (SIC), Printed circuit board (P), and others

**SICTYP** The conditions for controlling a serial spindle are:

- 0 : Not satisfied.
- 1 : Satisfied.

	#7	#6	#5	#4	#3	#2	#1	#0
1502			SREQ1	SSTB1				

NC internal processing sequence information and spindle status 1

- SSTB 1: NC ready to communicate but the first spindle is not
- SREQ 1: NC operable but the first spindle is requesting a parameter

	#7		#6	#5	#4	#3	#2	#1	#0	1	
1503	SLE	S2		SREQ2	SSTB2	SSPRM2	SNCRRM2	SNOTC2			
		NC i	nterna	al proces	ssing seq	uence in	formatio	n and sp	indle sta	tus 2	
SN	OTC2	1 : N	lo SI	C2–LSI	connecte	ed to the	serial lin	e			
SNO	CRM2	1 : N	IC SI	C2–LSI	error (pa	arameter	check er	ror)			
SSI	PRM2	1 : N (j	VC SI paran	C2–LSI neter che	commur ck error	nication b	ousy high	ı, or spin	dle SIC	2–LSI error	
S	STB2	1: N	VC rea	ady to co	to communicate but the second spindle is not						
SI	REQ2	1: N	VC op	erable b	ut the se	cond spin	ndle is re	questing	, a paran	neter	
S	LES2	1 : N s	/lore pecifi	spindle ed by pa	amplifie arameter	ers conne	ected that	an the n	umber	of spindles	
		Chec	k the	details o	f the ala	rm accore	ling to di	agnostic	Nos. 15	00 to 1503.	
		(1)15 15	500#2 500#7	2 (SNER / (SALM	), 1500# II)	3 (CER),	1500#4	(CMER)	), 1500#	5 (CALM),	
			An amp	error ha olifier.	is occuri	red durir	ig comm	nunicatio	n with	the spindle	
		This error may occur as a secondary error for an error indicated by diagnostic No. 1501, 1502, or 1503. If another error has occurred, first apply appropriate countermeasures for that error.									
			If o nois	nly this se.	error h	as occur	red, app] ↓	ly count	ermeasu	res against	
		(2)15	If t com 501#1	he abov municat	we fails tion cabl $(P) = 0$	to clea e, or spir	r the endle amp	rror, the lifier ma	e spindl y be fau	le module, lty.	
			The	conditio	ons for c	ontrollin	g a serial ↓	spindle	are not	satisfied.	
			Che	ck that a	a serial s	pindle m	odule is i	installed			
			Che Che be u	ck that t ck that p ised.	he serial paramete	spindle er No. 56	option pa 06 is set	arameter so that a	s are set a serial s	pindle is to	
		(3) 15	502#4	(SSTB1)	), 1503#4	4(SSTB2)	), 1502#5	S(SREQ1	), 1503#	5(SREQ2)	
			Syn	chroniza	ation wit	h a serial	spindle ↓	is not es	tablishe	1.	
			Col para con	late the umeter 1 nected.	number No. 560	of conn 6, with	ected ser the nur	rial spine mber of	dles spe spindle	cified with es actually	
			If th	ne numbe	ers mate	h, the spi	ndle mo	dule, coi	nmunic	ation cable.	
			or s	pindle a	mplifier	may be f	aulty.	,			

\_\_\_\_\_ 324 \_\_\_\_\_

#### (4)1503#1 (SNOTC2)

The spindle amplifier cannot be recognized.

Check the state of the communication cable.

If no problem is identified, the spindle module, communication cable, or spindle amplifier may be faulty.

#### (5)1503#2 (SNCRM2)

An error has occurred during testing of the spindle module.

The spindle module may be faulty.

#### (6)1503#3 (SSPRM2)

An error has occurred during testing of the entire spindle control system including the spindle amplifier.

. .

 $\downarrow$ 

This error may occur as a secondary error for another error. If another error has occurred, first apply appropriate countermeasures for that error.

If only this error has occurred, the spindle module, communication cable, or spindle amplifier may be faulty.

#### (7)1503#7 (SLES2)

The number of spindles actually connected is less than the number of spindles specified with a parameter.

Collate the number of connected serial spindles, specified with parameter No. 5606, with the number of spindles actually connected.

 $\downarrow$ 

If the numbers match, the spindle module, communication cable, or spindle amplifier may be faulty.

# **APPENDIX**



# **MAINTENANCE PARTS**

Maintenance parts can be classified into two types: repairable parts and consumable parts. Repairable parts are covered in Section 2.6. This appendix lists consumable maintenance parts (fuses, batteries, fans, keyboards, etc.).

A.1 MAINTENANCE PARTS FOR THE FANUC

Series 15–B ...... 330

# A.1 MAINTENANCE PARTS FOR THE FANUC SERIES 15–B

# Maintenance parts (consumables)

Consumable maintenance parts are not repaired. In the event of their being damaged, they are discarded and replaced.

1	Name	Ordering code	Drawing number	Remarks		
Fan motor	For two-slot case		A90L-0001-0378	One fan motor for 2.4W every two slots		
	For one-slot case		A90L-0001-0385#A	Two fan motors for a three–slot cabinet		
Battery		A02B-0120-K106	A98L-0031-0007	For power supply of conven- tional type		
		A02B-0200-K103	A98L-0031-0012	For CE marking compatible power supply		
Power fuse	For AI power supply	A02B-0120-K102	A60L-0001-0245#GP75	F1(7.5A)		
	(conventional type)		A60L-0001-0245#GP75	F2(7.5A)		
			A60L-0001-0075#3.2	F3(3.2A)		
			A60L-0001-0046#5.0	F4(5AS)		
			A60L-0001-0290#LM03	F5(0.3A)		
	For BI power supply	A02B-0120-K103	A60L-0001-0245#GP100	F1(10A)		
	(conventional type)		A60L-0001-0245#GP100	F2(10A)		
			A60L-0001-0075#5.0	F3(5A)		
			A60L-0001-0046#5.0	F4(5AS)		
			A60L-0001-0290#LM03	F5(0.3A)		
	For AI power supply	A02B-0200-K100	A60L-0001-0245#GP75	F1(7.5A)		
	(CE marking compatible)		A60L-0001-0075#3.2	F3(3.2A)		
			A60L-0001-0046#5.0	F4(5AS)		
	For BI power supply	A02B-0200-K101	A60L-0001-0245#GP100	F1(10A)		
	compatible)		A60L-0001-0075#5.0	F3(5A)		
			A60L-0001-0046#5.0	F4(5AS)		
	For CE marking compatible opera-	A02B-0163-K111	A60L-0001-0175#3.2A	FU1(3.2A) for A16B–2202–073X		
	tion unit		A60L-0001-0290#LM50	FU2(5.0A) for A16B–2202–073X		
	For connection unit	A02B-0072-K103	A60L-0001-0046#1.6	FS1(1.6A) for A20B–1005–0310		
	For multi-axes input	A02B-0162-K111	A60L-0001-0290#LM10	For A14B-0076-B401		
	unit		A60L-0001-0175#1.0A	1		
		A02B-0162-K112	A60L-0001-0290#LM10	For A14B-0076-B402		
			A60L-0001-0175#2.0A			

# **Maintenance parts**

# • Maintenance parts (consumables)

Consumable maintenance parts are not repaired. In the event of their being damaged, they are discarded and replaced. In the following table, keyboards, key sheets, and display devices are handled as consumables.

N	lame		Unit drawing number	Key sheet	Keyboard	Display device	Re- marks
9" CRT/MDI	Monochro	me,	A02B-0162-C041	A02B-0162-K101	A86L-0162-0196/02	A61L-0001-0093	
unit ve	vепісаі туре		A02B-0162-C044				
			A02B-0163-C244	A02B-0163-K101			
			A02B-0163-C444	A02B-0163-K121			
	Monochro	me,	A02B-0162-C042	A02B-0162-K101			
	norizontai	туре	A02B-0162-C045	_			
			A02B-0163-C245	A02B-0163-K101			
			A02B-0163-C445	A02B-0163-K121			
	Color,		A02B-0162-C051	A02B-0163-K101		A61L-0001-0095	
	vertical typ	be	A02B-0162-C054	_			
	Color, horizontal type		A02B-0162-C052				
			A02B-0162-C055	_			
9″ small CRT/MDI unit	Mono- chrome	Μ	A02B-0162-C101	A02B-0162-K102	A86L-0001-0157	A61L-0001-0093	
			A02B-0163-C301	A02B-0163-K102			
		Т	A02B-0162-C102	A02B-0162-K103			
			A02B-0163-C302	A02B-0163-K103			
	Color	М	A02B-0162-C103	A02B-0162-K102		A61L-0001-0093	
		Т	A02B-0162-C104	A02B-0162-K103		A61L-0001-0095	
9" PDP/MDI	Monochro	me,	A02B-0162-C062	A02B-0162-K104	A86L-0001-0196/02	A61L-0001-0116	
unit	norizontal	туре	A02B-0162-C065				
			A02B-0163-C265	A02B-0163-K104		A61L-0001-0116/S	
			A02B-0163-C465	A02B-0163-K124			
9" small	Mono-	Μ	A02B-0162-C105	A02B-0162-K105		A61L-0001-0116	
unit	chrome		A02B-0163-C305	A02B-0163-K105	1	A61L-0001-0116/S	
		Т	A02B-0162-C106	A02B-0162-K106	1	A61L-0001-0116	
			A02B-0163-C306	A02B-0163-K106	1	A61L-0001-0116/S	

N	ame	Unit drawing number	Key sheet	Keyboard	Display device	Re- marks
9.5″ LCD/	Color,	A02B-0162-C131	These units have a	A86L-0001-0197#02A	A61L-0001-0138	
	vertical type	A02B-0163-C331	keyboard and use	A86L-0001-0197#02AR		
		A02B-0162-C141	no key sheet.	A86L–0001–0197#02A		
		A02B-0163-C341		A86L-0001-0197#02AR		
		A02B-0162-C133		A86L-0001-0197#03B	· · · · ·	
		A02B-0163-C333		A86L-0001-0197#03BR		
	Color,	A02B-0162-C132		A86L–0001–0195#02A		
	horizontal type	A02B-0163-C332		A86L–0001–0195#02AR		
		A02B-0162-C142		A86L-0001-0195#02A		
		A02B-0163-C342	-	A86L-0001-0195#02AR		
		A02B-0162-C132		A86L-0001-0195#08B		
		A02B-0163-C332		A86L-0001-0195#08BR		
10" LCD/	Color,	A02B-0162-C071		A86L-0001-0197#02A	A61L-0001-0123	
	venical type	A02B-0162-C073		A86L-0001-0197#03B		
	Color,	A02B-0162-C072		A86L-0001-0195#02A		
	nonzontai type	A02B-0162-C074		A86L-0001-0195#08B		
10.4" LCD/	Color,	A02B-0163-C371		A86L-0001-0197#02AR	A61L-0001-0163	
graphic	vertical type	A02B-0163-C571		A86L-0001-0197#02AS		
tunction built-in type	Color,	A02B-0163-C372		A86L-0001-0195#03BR		
	nonzontai type	A02B-0163-C572	]	A86L-0001-0195#03BS		

# **Maintenance parts**

# • Maintenance parts (consumables)

Consumable maintenance parts are not repaired. In the event of their being damaged, they are discarded and replaced. In the following table, keyboards, key sheets, and display devices are handled as consumables.

Na	ame	Unit drawing number	Key sheet	Keyboard	Display device	Remarks
10.4" LCD/	Color,	A02B-0163-C381		A86L-0001-0197#02AR	A61L-0001-0163	
MMC–IV	ventical type	A02B-0163-C581		A86L-0001-0197#02AS		
	Color,	A02B-0163-C382		A86L-0001-0195#03BR		
	type	A02B-0163-C582		A86L-0001-0195#03BS		
10" PDD/ MDI unit	Monochrome, vertical type	A02B-0162-C081	A86L-0001-0197#02A A61L-0001-0126			
	Monochrome, horizontal type	A02B-0162-C082		A86L-0001-0195#02A		
14" CRT/	Color,	A02B-0162-C091	0162–C091 These units have a A86L–000 membrane–type		A61L-0001-0094#A	
	ventical type	A02B-0162-C093	keyboard and use	A86L-0001-0197#03B		
		A02B-0162-C121	no key sheet.	A86L-0001-0197#02A		
		A02B-0163-C321		A86L-0001-0197#02AR	A61L-0001-0096	
		A02B-0163-C323		A86L-0001-0197#03BR		
		A02B-0163-C523		A86L-0001-0197#03BS		
	Color, horizontal type	A02B-0162-C092		A86L-0001-0194#02A	A61L-0001-0094#A	
		A02B-0162-C094		A86L-0001-0194#04B		
		A02B-0162-C122		A86L-0001-0194#02A		
		A02B-0163-C322		A86L-0001-0194#02AR	A61L-0001-0096	
		A02B-0163-C324		A86L-0001-0194#04BR		
		A02B-0163-C522		A86L-0001-0194#02AS		
Separate	Monochrome	A02B-0162-C046	No keyboard mounted	Ł	A61L-0001-0093	
unit	Color	A02B-0162-C056			A61L-0001-0095	
Separate	Monochrome	A02B-0162-C066			A61L-0001-0116	
unit		A02B-0163-C268			A61L-0001-0116/S	
Separate type 10.4" LCD unit, graphic function built–in type	Color	A02B-0200-C150			A61L-0001-0163	
Separate type 9.5″ STN unit, graphic function built–in type	Monochrome	A02B-0222-C110			A61L-0001-0154	

Na	ame	Unit drawing number	Key sheet	Keyboard	Display device	Remarks
Separate type MDI	For CRT	A02B-0162-C111	A02B-0162-K101	A86L-0001-0196/02 r	No display device mounted	Specify any of
		A02B-0162-C112				when using
		A02B-0163-C312	A02B-0163-K101	-	\86L-0001-0246	the sepa- rate-type 9" CRT unit.
		A02B-0163-C313	A02B-0163-K121			
	For PDP	A02B-0162-C111	A02B-0162-K104			Specify any of
		A02B-0162-C112		 A86L-0001-0246		these parts when using the sepa- rate-type
		A02B-0163-C312	A02B-0163-K104			
		A02B-0163-C313	A02B-0163-K124			9" PDP unit.
	For LCD	A02B-0163-C316	A02B-0163-K108			Specify any of
		A02B-0163-C318	A02B-0163-K128			these parts when using
		A02B-0163-C317	A02B-0163-K108			the sepa- rate-type
		A02B-0163-C319	A02B-0163-K128			10.4" LCD unit.

\* The "key sheet" stated here includes the key sheet for soft keys.

D	BOOT SYSTEM			
D				
		R 1	OVERVIEW	

B.1	OVERVIEW	336
B.2	SCREEN CONFIGURATION AND	
	OPERATING PROCEDURE	341
B.3	ERROR MESSAGES AND	
	REQUIRED COUNTERMEASURES	355
B.4	SYSTEM ALARMS AND	
	REQUIRED COUNTERMEASURES	357

B.1 OVERVIEW	The Series 15–B boot system is designed to load the CNC system software (from flash memory into DRAM) and to start the CNC software in preparation for the execution of the CNC software. The boot system has the following functions related to the maintenance of the Series 15–B system.
	(1) Storing a file into flash memory
	• Reads a file into flash memory from an MS–DOS–formatted memory card conforming to the JEIDA V4.1 standard.
	(2)Confirming the series and edition of a file in flash memory and deleting a file from flash memory
	(3) Saving or restoring battery backup files of parameters, programs, and the like (SRAM area) to or from a memory card in batch mode
	(4) Saving a file from flash memory onto a memory card
	(5) Formatting a memory card
	This appendix describes the screens displayed upon the activation of the boot system, as well as those displayed by the functions described above and the corresponding operating procedures.

# B.1.1 Power–up Processing Sequence Display

(1)	RAM TEST	: END							
(2) (3)	ROM TEST DRAM ID	: END XXXX : XXXX	X (	ERROR ERROR	) )	dynamic dynamic	stop stop		
(4) (5)	SRAM ID FROM (CNC)	: XXXX : XXXX	(	PASS	)	_			
(6) (7)	(PMC)	: XXXX FARCH · FND	(	PASS	)	DESET 60	$\sim \sim$	SVSTEM	MONTTOP
(8)	LOADING CN	C DATA	(	ERROR	,	RESET RE	ε <b>γ</b>	SISIEM	MONITOR

#### Description

- (1) : Result of the work RAM test. If an error occurs, the error status is not displayed here but is instead indicated by the LED (LED E1).
- (2) : Result of the boot ROM parity test. When the test ends normally, the series and edition are displayed. If an error occurs, the system stops.
- (3) : ID of the DRAM module mounted on the CNC module. If the ID cannot be recognized, ERROR is displayed, and the system stops.
- (4) : ID of the high-speed SRAM module mounted on the CNC module. If the ID cannot be recognized, PASS is displayed. The system assumes that the high-speed SRAM is not mounted.

LED

- (5) : ID of the flash ROM module mounted on the CNC module. If the ID cannot be recognized, the status is indicated by the LED (LED 02).
- (6) : ID of the flash ROM module mounted on the PMC module. If the ID cannot be recognized, PASS is displayed. The system assumes that the module is not mounted.
- (7) : Result of the validity check made for the CNC basic software in flash ROM. This validity check is made based on the data recognition information only. A parity check is executed as part of the CNC power–up processing.If an error is detected, the SYSTEM MONITOR screen can be
  - selected by pressing the RESET key.
- (8) : Indicates that the CNC basic software is being transferred from the flash ROM module to DRAM (SRAM). (The transfer takes about 10 seconds.)

#### **B.1.2** When the system starts normally, the boot system automatically transfers a file from flash memory to DRAM. The user is normally not aware of **Starting the Boot** the boot system. The boot system should be operated from the menu System screen when maintenance is performed or when no file is found in flash memory. Selecting SYSTEM SYSTEM MONITOR is selected in either of the following two ways: MONITOR key while CNC DATA SEARCH: ERROR is (1)Pressing the RESET displayed (2) Turning the power on while holding down the page up/down keys PAGE ÷. NOTE When using a 9" small MDI unit, turn the power on while holding down cursor keys ( ) instead of the page 1 Ŧ PAGE 1 up/down keys ( ). With the 9" small MDI unit, set 1 the keyboard as described below, before selecting

\_\_\_\_\_ 337 \_\_\_\_

SYSTEM MONITOR.

Setting the 9" small MDI	When the following display appears, select the MDI unit to be used. To
unit	use a lathe–system MDI unit, press the with the model of the term of term o
B.1.3	The boot system manages the files in flash memory by dividing them into
System File and User	two large categories: system files and user files. These two file types
File	differ as described below:
• System files	Files of the CNC or servo control software provided by FANUC
• User files	User–created files of a PMC sequence program (ladder), P–CODE macro program, or the like

#### • Files that can be stored in flash memory

	Flash memory files				
File name	Description	CNC basic software			
NC BASIC	system	CNC basic software			
NC SUB CPU	system	CNC basic software (for system with sub–CPU)			
AXIS CPU	system	CNC basic software (for multiaxis system)			
OPTIONA1	system	CNC option installation software A1			
OPTIONA2	system	CNC option installation software A2			
OPTIONA3	system	CNC option installation software A3			
OPTIONA4	system	CNC option installation software A4			
SUBOPTS1	system	CNC option installation software S1			
HELP MSG	system	CNC help message software			
DG SERVO	system	Digital servo software			
MCR-CMPA	system	Macro compiler software			
MCR-CMPB	system	Macro compiler software (for system with sub–CPU)			
PCD 256A	user	P-code macro of 256K bytes			
PCD 512A	user	P-code macro of 512K bytes			
PCD 256M	user	P–code macro of 256K bytes (for system with sub–CPU)			
PCD 512M	user	P–code macro of 512K bytes (for system with sub–CPU)			
PMC-NA0A	user	PMC cassette A (for PMC–NA)			
PMC-NA0B	user	PMC cassette B (for PMC–NA)			
PMC-NA0C	user	PMC cassette C (for PMC–NA)			
PMC-NA0D	user	PMC cassette D (for PMC–NA)			
PMC-NA0E	user	PMC cassette E (for PMC–NA)			
PMC-NB0A	user	PMC cassette A (for PMC–NB)			
PMC-NB0B	user	PMC cassette B (for PMC–NB)			
PMC-NB0C	user	PMC cassette C (for PMC–NB)			
PMC-NB0D	user	PMC cassette D (for PMC–NB)			

#### NOTE

PMC-NB0E

The above file names are subject to change without notice.

PMC cassette E (for PMC-NB)

user

# B.1.4 Memory Cards for Use with the Boot System

The table below lists the functions and corresponding memory card types that can be used. Cards must be of TYPE 1 or 2 as defined in the Personal Computer Memory Card International Association (PCMCIA) standard, version 2.0 or later, or the Japan Electronic Industry Development Association (JEIDA) standard, version 4.1 or later. The format conforms to the DOS FAT file system.

The memory card has a maximum storage capacity of 32M bytes.

		Flash mer	mory card
	SRAM card	Supported (*1)(*2)	Not supported
File read	0	0	0
Card format	0	0	×
File write	0	0	×
File list	0	0	0

# NOTE

1 The following flash memory cards are supported:

- Intel Series 2 flash memory card (or equivalent)
- Intel Series 2+ flash memory card (or equivalent) Both types require the use of attribute memory. For other flash memory cards, see the rightmost column "Not supported" in the table shown above.
- The ATA flash memory card cannot be used.
- With the PMC–NA, the flash memory card is used only for the boot system.
- 2 Some flash memory cards, written using the memory card interface built into a personal computer, may use a format other than that indicated above. Such memory cards cannot be used.

# B.2 SCREEN CONFIGURATION AND OPERATING PROCEDURE

#### • Main menu

When the boot system starts, the main menu appears first. The main menu is described below:

(1)	SYSTEM MONITOR	
(2) (3) (4) (5) (6) (7)	<ol> <li>SYSTEM DATA LOADING</li> <li>SYSTEM DATA CHECK</li> <li>SYSTEM DATA SAVE</li> <li>FILE DATA BACKUP</li> <li>MEMORY CARD FORMAT</li> <li>END</li> </ol>	
(8)	*** MESSAGE *** SELECT MODE AND HIT INPUT KEY	
'	$\backslash$	

## (1) : Title

- (2) : Loading ROM data into flash ROM memory from a memory card
- (3) : Confirming the ROM data stored in flash ROM memory
- (4) : Writing the ROM data stored in flash ROM memory to a memory card
- (5) : Batch saving or restoration of battery backup file data by using a memory card
- (6) : Formatting a memory card
- (7) : Ending SYSTEM MONITOR
- (8) : Message field(For example, a quick operation guide may be displayed.)
- Operating procedure

Press a cursor key (  $\uparrow$  ) to choose the desired processing.

Position the cursor to a desired function, then press the  $\begin{bmatrix} INPUT \\ INSERT \end{bmatrix}$  key.

• Basic operation flow



1

# B.2.1 SYSTEM DATA LOADING Screen

- Description
- Screen configuration

A system file or user file is loaded into flash memory from a memory card.



- (1) : Title
- (2) : Memory card directory display
- (3) : ROM file name
- (4) : Ending the processing
- (5) : Message field (For example, a quick operation guide may be displayed.)
- Operating procedure

Position the cursor to the file to be loaded by pressing a cursor key (



The OK? INPUT/CANCEL message appears in the message field. To load the file, press the  $\begin{bmatrix} INPUT \\ INSERT \end{bmatrix}$  key. To cancel the selection, press the  $\begin{bmatrix} CAN \end{bmatrix}$  key.
<ul> <li>Status display during</li> </ul>	While a file is being loaded, the fo	ollo	wing statuses are displayed:
loading	(1)LOADING FROM IC-CARD	:	Data is being loaded from a memory card.
	(2) TEST DEVICE	:	The flash ROM module is undergoing a device test.
	(3) PROGRAM AND VERIFY	:	Data is being written to the flash ROM module.
	(4) PROGRAM COMPLETE	:	Writing to the flash ROM module has been completed.
	Once loading has been complet appears. Press the $\begin{bmatrix} INPUT \\ INSERT \end{bmatrix}$ key. An	ted, oth	the HIT INPUT KEY message er file can be selected.
	To terminate the processing, posit	tion trs a	the cursor to END, then press the gain.
• Others	1 Count display during file loadi While a file is being loaded, th displayed.	ing ne ao	ddress of the current access data is

\*\*\* MESSAGE \*\*\* LOADING FROM MEMORY CARD.  $\frac{\text{ADDRESS 001: 000022FF}}{(1) (2)} \leftarrow \text{The count is indicated.}$ 

- (1) : Unit number of the 128KB management unit in flash memory
- (2) : Relative address in the management unit

#### NOTE

The count display may stop for five or six seconds during loading. This occurs when data is read into an internal buffer from the memory card. Provided no error is displayed while the count stops, processing is being performed normally. Meanwhile, the LOADING FROM IC–CARD message appears.

— 343 —

### **B.2.2** SYSTEM DATA CHECK Screen

Description

The files in flash memory are listed. The list indicates the number of 128KB management units in each file and the series and edition of the software.

A user file can be deleted from flash memory.

Screen configuration



- (1) : Title
- (2) : Flash memory directory display
- (3) : ROM file name. The number of management units used is indicated in parentheses.
- (4) : Ending the processing
- (5) : Message field (For example, a quick operation guide may be displayed.)

 Operating procedure ROM files in flash memory are listed together with the number of management units (128KB management units) used in each file. To check the detailed information such as the series and edition of a ROM file, press a cursor key ( ) to position the cursor to that file. t ŧ 4 ⇒

> Then, press the INPUT key. The ROM FILE CHECK screen, which contains detailed information, appears.

INPUT To end the processing, position the cursor to END, then press the INSERT key. The main menu appears again.



## Displaying detailed information

- Operating procedure
- 1 Select a file for which detailed information is required. For example, select 4 NC BASIC (8).
- 2 The management unit numbers of the selected file and the series and edition of each management unit are listed. After checking the displayed data, press the INPUT key to return to the file selection screen.

```
(1)
     ROM FILE CHECK
(2)
     NC BASIC
(3)
     1. xxxx
               002
                        zzz
                    v
               001 y
     2.
        xxxx
                        zzz
     3.
               042 y
        XXXX
                        zzz
               041 y
     4.
        xxxx
                        ZZZ
               082
     5.
        XXXX
                    y
                        zzz
               081
     6.
        XXXX
                    У
                        zzz
               102
     7.
        XXXX
                    У
                        zzz
     8.
        xxxx
               101
                        zzz
                    У
                      ROM number
(4)
     *** MESSAGE ***
     HIT INPUT KEY
```

- (1) : Title
- (2) : Name of the file to be checked
- (3) : ROM series, edition, and internal management unit number of each management unit (128K bytes)
- (4) : Message field(For example, a quick operation guide may be displayed.)
  - xxxx : Series
    - y : Edition
    - zzz : Internal management unit number

Others

1 Parity information of the system file and user file

System files named NC BASIC, DG SERVO, OPTIONA1, and the like in flash memory contain parity information in each management unit. If a non–ASCII–code character or @ is displayed in the file name field or parity field on the check screen, the flash ROM may have been destroyed. Alternatively, a destroyed file may have been loaded. Retry loading from the memory card. A user file such as PMC–NA0A or PCD256A has no parity information in each management unit. A non–ASCII–code character or @ in the series/edition information displayed for the user file does not indicate that the file has been destroyed.

— 345 —

## Deleting a user file from flash memory

- Operating procedure
- 1 Select the SYSTEM DATA CHECK function of SYSTEM MONITOR. The files in flash memory are listed.
- 2 Position the cursor to the user file to be deleted. Then, press the key.

When using the keyboard for the 9" small unit, press the |CAN| key

instead of the DELETE key.

- 3 The DELETE OK? message appears.
- 4 To delete the file, press the  $\left[ \frac{|NPUT|}{|NSERT} \right]$  key. To cancel the deletion, press

the CAN key.

- When the INPUT key is pressed, the corresponding file is deleted.
- 5 Once the file has been successfully deleted, the following message appears. Press the  $\left|_{\text{INSERT}}^{\text{INPUT}}\right|$  key.

```
*** MESSAGE ***
DELETE COMPLETE. HIT INPUT KEY.
```

• Others

#### 1 User file deletion and system files

While user file deletion is being performed, the system files are protected so that they cannot be deleted by the user. User files are not protected.

The protected system files can be overwritten, however, by selecting SYSTEM DATA LOADING.

## **B.2.3** SYSTEM DATA SAVE Screen

Description

A user file is written to a memory card from flash memory. A user file stored in flash memory can be saved to a memory card, but no system files can be saved.

Screen configuration



- (1) : Title
- (2) : Flash memory directory display
- (3) : ROM file name. The number of management units used is indicated in parentheses.
- (4) : Ending the processing
- (5) : Message field (For example, a quick operation guide may be displayed.)

The ROM files in flash memory are listed together with the number of management units (128KB management units) in each file. Press a cursor key (

) to position the cursor to the file to be saved 4 -

INPUT to a memory card. Then, press the key.

The INPUT FILE NAME (CAN: RESET) message appears in the message field. Enter the name of the desired file on the memory card, then INPUT key. To abandon saving, press the RESET press the key. INSERT

INPUT To end the processing, position the cursor to END, then press the INSERT key. The main menu appears again.

\_\_\_\_\_ 347 \_\_\_\_

Operating procedure

• Others	1 System files and user files on the SYSTEM DATA SAVE screen The SYSTEM DATA SAVE screen enables the saving of user files only. System files cannot be saved.
	2 Name of saved file
	• A file name must be specified in line with MS–DOS conventions. (Up to eight characters for the file name and up to three characters for the extension)
	• If a file already on the memory card has the same name as the specified file name, that file will be overwritten.

### B.2.4 SRAM DATA BACKUP Screen

- Description
- Screen configuration

Data to be held while the CNC power is off (parameters, programs, etc.) can be saved to or restored from a memory card in batch mode.

Select FILE DATA BACKUP from the SYSTEM MONITOR main menu. The following screen appears.

- (1) FILE DATA BACKUP (2) (3) (3) (4) END (5) FILE SIZE : 1M BYTE (6) \*\*\* MESSAGE \*\*\* SELECT MODE AND HIT INPUT KEY
- (1) : Title
- (2) : Batch saving of data
- (3) : Batch restoration of data
- (4) : Ending the processing
- (5) : File size of the system (displayed after processing is selected)
- (6) : Message field(For example, a quick operation guide may be displayed.)

— 348 —

ullet

ullet

Operating procedure (outline)	To execute the batch saving of a backup data file (file SRAM), select STORE FILE. To execute batch restoration, select LOAD FILE. To terminate the processing, select END. To select the processing, press a cursor key ( ) ) to position the cursor, then press the $\begin{bmatrix} NPUT \\ NSERT \end{bmatrix}$ key. When the batch saving or restoration of a file is selected, the size of the system's backup RAM is displayed on the screen. To execute the selected processing, press the $\begin{bmatrix} NPUT \\ NSERT \end{bmatrix}$ key. To cancel the processing, press the $\begin{bmatrix} NPUT \\ NSERT \end{bmatrix}$ key. To cancel the processing, press the $\begin{bmatrix} CAN \\ NSERT \end{bmatrix}$ key. (See the detailed description given below.)
	<b>NOTE</b> The backup data is saved to file <u>FILEx.BAK</u> , where x is a value of 1 to 4. The original data can be saved in up to four files. If a single memory card cannot hold all the original data, the data can be saved using up to four memory cards. Details of the operating procedure are described later. Before saving backup data, check that the memory card contains no FILEx.BAK files. The names of the files already on the memory card can be listed in the FILE DIRECTORY field of the SYSTEM DATA LOADING screen, as described in Section B.2.1.
Saving data	<ul><li>** To save backup data, use a formatted memory card.</li><li>To execute the batch saving of backup data, perform the following steps:</li></ul>
	<ul> <li>(1) Select the STORE FILE function on the initial screen.</li> <li>(2) When the SET IC CARD NO.1 &amp; HIT INPUT KEY message appears in the message field, mount the first memory card. Then, press the INPUT INSERT key.</li></ul>
	To cancel the processing, press the RESET key. The initial screen appears again. (3) While data is being saved, the STORE TO IC-CARD message blinks. Once saving has been completed, the STORE FILE COMPLETE and HIT INPUT KEY messages appear in the message field. When the MIT INPUT KEY messages appear in the message field. When the MIT INPUT KEY message appears again. If the first memory card cannot hold all the data to be saved, the SET IC/CARD NO.2 & HIT INPUT KEY message appears in the message field. Mount the second memory card without turning the power off, then press the KEY. To cancel the processing, press the RESET key. The initial screen appears again.

— 349 —

(4) The backup data can be saved using up to four memory cards by performing step (3) repeatedly. If four memory cards cannot hold all the data, the FILE DATA SIZE ERROR and HIT INPUT KEY messages appear in the message field. When the Key is pressed, the initial screen appears again.

#### NOTE

Once batch saving starts, requests to replace the memory card are repeated until all the backup data has been normally saved (using up to four memory cards). To stop the processing, press the RESET key while the SET IC CARD NO.x & HIT INPUT KEY message is displayed.

• Batch–saved data is stored on the memory cards under the following file names:

First memory card : FILE1.BAK Second memory card : FILE2.BAK Third memory card : FILE3.BAK Fourth memory card : FILE4.BAK Note that a file on a memory card can be overwritten. (If the specified

name of a file to be saved duplicates that of a file already on the card, the old data will be overwritten.)

- For an explanation of the display during processing, see the description of the save/restore display.
- **Restoring data** To execute the batch restoration of backup data, perform the following steps:

(1) On the initial screen, select the LOAD FILE function.

(2) The SET FILE1.BAK & HIT INPUT KEY message appears in the message field. Mount the first memory card containing FILE1.BAK,

then press the  $\left[ \stackrel{\text{INPUT}}{\text{INSERT}} \right]$  key. To cancel the processing, press the  $\left[ \stackrel{\text{RESET}}{\text{RESET}} \right]$  key.

The initial screen appears again.

\* If FILE1.BAK cannot be found on the mounted memory card, or if any other error occurs, details are displayed in the message field. Follow the directions displayed in the message field. (When the HIT INPUT KEY message appears, the processing can be

continued by pressing the  $\begin{bmatrix} INPUT\\INSERT \end{bmatrix}$  key.)

lessing the

(3) While data is being restored, the LOADING FROM IC-CARD message blinks. Once data restoration has been completed, the LOAD FILE COMPLETE and HIT INPUT KEY messages appear in the message field. When the KINGERT key is pressed, the initial screen appears again.

\_\_\_\_\_ 350 \_\_\_\_\_

If all the required data cannot be restored from FILE1.BAK alone, the SET FILE2.BAK & HIT INPUT KEY message appears in the message field. Mount the second memory card containing FILE2.BAK without turning the power off, then press the [INPUT KEY To cancel the processing, press the RESET key. The initial screen appears again.

(4) Backup data stored using up to four memory cards can be restored by performing step (3) repeatedly. If all the required data cannot be restored from all of the four memory cards, the FILE DATA SIZE

ERROR and HIT INPUT KEY messages appear in the message field.

When the  $\begin{bmatrix} INPUT \\ INSERT \end{bmatrix}$  key is pressed, the initial screen appears again.

#### NOTE

The function for saving or restoring a file in batch mode of the boot system assumes that the backup RAM (file SRAM) used for saving and that used for restoration are of the same size. So, this function should be used in the following cases:

- 1 To restore a file when file all clear must be executed (the file SRAM module is not replaced)
- 2 To restore a file when the file SRAM module must be replaced and when the size of the new backup RAM is the same

If this function is used for any other purpose, file restoration may not be performed correctly. Similarly, if an error (a RAM parity error, for example) is found in the contents of the backup RAM during batch saving, file restoration may not be performed correctly.

When STORE FILE or LOAD FILE is selected, the size of the system battery backup file is displayed on the screen.

To save data, use memory cards conforming to the JEIDA V4.1 standard.

Prepare as many memory cards as necessary to give a total storage capacity that is greater than the displayed size. (The available storage capacity should be about 1.2 times greater than the displayed size.)

While data is being saved or restored, the size of data that has been saved or restored and the corresponding file name (on the memory card) are displayed.

 Save/restore display (screen display during batch saving/restoration of battery backup data) and notes

The file names are displayed in the following order: FILE1.BAK, FILE2.BAK, FILE3.BAK, FILE4.BAK.

The bottom line indicates either the name of the file currently being processed or which is about to be processed.

The displayed count changes up to the value indicated in the following table, according to the size of the system backup data file.

File size	Displayed count (hexadecimal)
64K BYTE	00010000
128K BYTE 256K BYTE	00020000
320K BYTE	00050000
512K BYTE	00080000
1M BYTE 2M BYTE	00100000

## B.2.5 MEMORY CARD FORMAT Function

- Description
- Screen configuration

A memory card can be formatted. Formatting is necessary to prepare a blank memory card or a memory card whose contents have been destroyed due to failure of the battery or some other reason.

- (1) MEMORY CARD FORMAT
  (2) ALL DATA OF MEMORY CARD IS LOST.
  (3) \*\*\* MESSAGE \*\*\* OK? INPUT/CANCEL
- (1) : Title
- (2) : Warning that all data will be lost as a result of formatting
- (3) : Message field(A quick operation guide may be displayed, for example.)
- Operating procedure
- (1) Mount a memory card in the memory card interface. The memory card must be unprotected.
- (2) Select 5 MEMORY CARD FORMAT from the SYSTEM MONITOR screen.
- (3) The OK INPUT/CANCEL message appears in the message field. To format the card, press the [INPUT] key. To cancel the processing, press the CAN key.
- (4) When the key is pressed, a message is displayed to warn that all data on the memory card will be lost. Another OK INPUT/CANCEL message appears in the message field. To format the card, press the

key. To cancel the processing, press the key.

- (5) While formatting is being performed, the EXECUTING message blinks in the message field.
- (6) Once formatting has been completed, the MEMORY CARD FORMAT HAS FINISHED HIT INPUT KEY message appears in the

message field. Press the  $\begin{bmatrix} INPUT\\ INSERT \end{bmatrix}$  key. The main menu appears again.

## B.2.6 LOAD BASIC SYSTEM

- **Description** The boot system terminates and the CNC starts.
- Operating procedure

Select 6: END from the MAIN MENU screen. The boot system terminates and the CNC starts.

If the CNC basic software is not correctly stored in flash memory, the main menu appears again.

## B.3 ERROR MESSAGES AND REQUIRED COUNTERMEASURES

The table below lists the error messages that may be output.

Error message	Description
IC CARD NOT READY	The IC memory card is not correctly mounted.
BATTERY ALARM (IC CARD)	A battery alarm occurred for the IC memory card.
ILLEGAL FORMAT FILE	The system cannot recognize the specified ROM file.
FLASH MEMORY NO SPACE	Flash memory has insufficient free space to store the specified ROM data.
IC-CARD MOUNT ERROR	An error occurred while the IC memory card was being mounted.
IC-CARD DISMOUNT ERROR	An error occurred while the IC memory card was being dismounted.
FILE OPEN ERROR	A file open error occurred.
FILE CLOSE ERROR	A file close error occurred.
FILE READ ERROR	A file read error occurred.
DIRECTORY SEARCH ERROR	No directory was found.
FILE SYSTEM xxxxxxxxxx	A file system error occurred.
DEVICE ERROR (CNC x) (PMC x)	A flash ROM memory device error occurred in the internal CNC or PMC device x.

If an error occurs, a corresponding error message is output, followed by the HIT INPUT KEY message. After checking the details, press the [NSERT] key. The main menu appears again.

#### NOTE

If a flash ROM device error is detected, the HIT INPUT KEY message does not appear but the system stops. (The corresponding hardware must be replaced.)

• SYSTEM ERROR screen

(1)	SYSTE	M ERRO	R xxx	х у				
(2)	DRAM	PARITY						
(3)	xxxxx	xxx						
(4)	XXXX	xxxx	xxxx	xxxx	xxxx	xxxx	XXXX	XXXX
	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX
	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX	XXXX
	XXXX	xxxx	xxxx	xxxx	xxxx	xxxx	xxxx	xxxx
(								

xxxx y	:	(xxxx) Boot ROM series
		( y) Boot ROM edition
XXXXXXXX	:	Stack pointer
XXXX	:	Contents of stack frame

• **Displayed items** (1) System error status, and series and edition of the boot ROM

(2) Type of system error

- (3) Value of the stack pointer upon the occurrence of the system error
- (4) Contents of the stack frame upon the occurrence of the system error. Data of 40K bytes is displayed.
- \* The meaning of the data depends on the type of the system error.
- \* If a system error occurs, report the following to FANUC:
  - (a) Contents of screen display
  - (b) LED status on the printed circuit board
  - (c) Operating procedure

## B.4 SYSTEM ALARMS AND REQUIRED COUNTERMEASURES

System alarm (RAM parity error) The first page of the system alarm screen is displayed as shown below.

(1) indicates the CPU of the board on which the RAM parity error is detected. (2) indicates the module, or similar, in which the RAM parity error was detected.

The indicated module, or similar, on the board may be defective. Replace the module.

<First page>

```
F15M14 A6D2A
RAM PARITY ERROR
(1) (2)
ERROR OCCURRED AT 1996-07-12 17:53:37
PROG COUNT : 00XXXXXX
CPU STATUS : XXXX
ACT TASK : 00XX
ERROR ADRS : 00XXXXXX (00000000)
PAGE UP OR DOWN
```

(1) and (2) display one of the following messages:

(1)		
¥1 CNC-MAIN	:	Main board
¥2 CNC–SUB	:	Sub–CPU board
¥3 CNC–AXIS	:	Axis CPU board
¥4 OTHER-CPU	:	Other printed circuit board
(2)		
¥5 CNC–DRAM	:	DRAM module (See Sections 2.5.2 to 2.5.6.)
¥6 CNC-SRAM	:	SRAM module (See Sections 2.5.3 and 2.5.5.)
¥7 SHARED–RAM	:	SRAM module on the sub-CPU board
		(See Section 2.5.13.)
¥8 FILE–RAM	:	FILE–SRAM module
		(See Sections 2.5.2 to 2.5.6.)
¥9 MAXIS–BUS	:	Multiaxis bus
		(This is not a module. The multiaxis main CPU
		or multiaxis butter board may be defective.)

### System alarm (DRAM SUM error)

The first page of the system alarm screen is displayed as shown below.

(1) indicates the CPU of the board on which the DRAM SUM error is detected. The DRAM module on the indicated board may be defective. Replace the DRAM module.

<First page>

```
F15M14 A6D2A
DRAM SUM ERROR
(1)
ERROR OCCURRED AT 1996-07-12 17:53:37
PROG COUNT : 00XXXXXX
CPU STATUS : XXXX
ACT TASK : 00XX
ERROR ADRS : 00XXXXXX (00000000)
PAGE UP OR DOWN
```

(1) displays one of the following messages:

(1)		
¥1 CNC–MAIN	:	Main board (See Sections 2.5.2 to 2.5.6.)
¥2 CNC–SUB	:	Sub–CPU board (See Sections 2.5.15 to 2.5.17.)
¥3 CNC–AXIS	:	Axis CPU board (See Section 2.5.11.)

# System alarm (bus error)

The first page of the system alarm screen is displayed as shown below.

A defective board can be identified from the ERROR ADRS value. This identification is possible only when the displayed ERROR ADRS value begins with 4.

<First page>



The second digit, n, of 4nXXXXX represents a possibly defective board, as follows (see Section 2.5).

- ¥2 n = 1: PMC board
- ¥3 n = 3: Sub–CPU board
- 4 n = 4: Graphic board
- $F_5 n = 5$ : Conversational board
- $F_{6}$  n = 6: Remote buffer
- Y7 n = 8: MMC board
- **¥**8 n = C: Tracing board

System alarm (line F emulator exception) The first page of the system alarm screen is displayed as shown below.

(1) indicates the CPU of the board on which a line F emulator exception is detected. If the indicated board is CNC–MAIN or CNC–SUB, the software installation may be defective. Check the option configuration, installation, and so on.

<First page>



(1) displays one of the following messages:

- (1)
- ¥1 CNC-MAIN: Main board
- ¥2 CNC–SUB : Sub–CPU board
- ¥3 CNC-AXIS : Axis CPU board

## System alarm (servo alarm)

The first page of the system alarm screen is displayed as shown below.

The servo modules indicated as SERVO CPU  $\frac{1}{2}$ / $\frac{4}{may}$  be defective.

In the example shown below, an error has occurred in the first, second, and fourth servo modules. Replace the corresponding servo modules.

```
<First page>
```

```
F15M14 A6D2A
SYSTEM ALARM
  SERVO CPU #1/2/ /4/ SERVO_ROM:9070A
ERROR OCCURRED AT 1995-07-12 21:14:50
PROG COUNT : XXXXXXXX
CPU STATUS : XXXX
ACT TASK
          : XXXX
ERROR ADRS : XXXXXXXX (0000000)
CPU NO.: #1
                #2
                     #3
                           #4
                                 #5
      : XXXX XXXX XXXX XXXX
ADSTS
                                XXXX
ALARMF : XXXX XXXX XXXX XXXX
                                XXXX
                  PAGE UP OR DOWN
```

Servo modules are mounted on the following printed circuit boards:

- Main CPU board (See Sections 2.5.2 to 2.5.4.)
- Sub–CPU board (See Sections 2.5.15 and 2.5.17.)
- Additional axis board (See Section 2.5.18.)
- Axis CPU board (See Section 2.5.11.)

System alarm (file SRAM backup voltage drop) The first page of the system alarm screen is displayed as shown below.

The following example indicates that the file SRAM backup battery on the main board is weak.

<First page>

```
F15M14 A6D2A
RAM PARITY ERROR (BATTERY LOW)
CNC-MAIN FILE-RAM
ERROR OCCURRED AT 1996-07-12 17:53:37
PROG COUNT : 00XXXXXX
CPU STATUS : XXXX
ACT TASK : 00XX
ERROR ADRS : 8XXXXXX (00000000)
BUS MASTER : CNC-MAIN
PAGE UP OR DOWN
```

- Replace the file SRAM backup battery.
- When the above continues to be displayed even after fitting a fresh file SRAM backup battery, the following may be defective:
  - File SRAM module (For an explanation of the mounting position, see Sections 2.5.2 to 2.5.6.)
  - Spindle module (For an explanation of the mounting position, see Sections 2.5.2 to 2.5.4.)
  - Main CPU PC board

#### (Important)

When the error indicated above is displayed, the data on part program storage has been lost. Before attempting to modify data (parameters, for example) on part program storage, make a backup copy on a floppy disk or other suitable media.



C.1 AL	ARM LIST (CNC)					364
--------	----------------	--	--	--	--	-----

- C.2 ALARM LIST (PMC) ..... 383

## C.1 ALARM LIST (CNC)

Number	Message displayed on CRT	Contents	Remarks
PS 003	TOO MANY DIGITS	Data entered with more digits than permitted. (See APPENDIX 2, "Table of Maximum Command Values.")	
PS 006	ILLEGAL USE OF NEGATIVE VALUE	A minus sign (–) was specified at an address where no minus sign may be specified, or two minus signs were specified.	
PS 007	ILLEGAL USE OF DECIMAL POINT	A decimal point (.) was specified at an address where no decimal point may be specified, or two decimal points were specified.	
PS 010	IMPROPER G-CODE	An illegal G code was specified. This alarm is also generated when a G code for an option that has not been added is specified.	
PS 011	IMPROPER NC-ADDRESS	An illegal address was specified. A command was specified for a slave axis during synchronous operation or independent operation of a slave axis.	
PS 012	INVALID BREAK POINT OF WORD	NC word(s) are delimited incorrectly.	
PS 013	ILLEGAL PROGRAM NO. POSITION	Address 0 or N is specified in an illegal location (i.e. after a macro statement, etc.)	
PS 014	ILLEGAL PROGRAM NO. FORMAT	Address 0 or N is not followed by a number.	
PS 015	TOO MANY WORDS IN ONE BLOCK	The number of words in a block exceeds the maximum.	
PS 016	EOB NOT FOUND	EOB (End of Block) code is missing at the end of a program input in MDI mode.	
PS 017	ILLEGAL MODE FOR GOTO/WHILE/DO	A GOTO statement or WHILE–DO statement was found in the main program in MDI or tape mode.	
PS 058	S–COMMAND OUT OF RANGE	The specified spindle speed exceeded the maximum number of revolutions allowed for the spindle motor (parameter No. 5619). (When SAL of parameter No. 5601 is 1)	
PS 059	COMMAND IN BUFFERING MODE	Manual intervention compensation request signal MIGET was in- put for a block containing no M code without buffering.	

T: Only for the Series 15–T and 15–TT used with lathes

#### NOTE

PSxxx indicates alarms related to programs or settings in the foreground. Background alarms corresponding to PSxxx are displayed in the format BGxxx.

Similarly, background alarms corresponding to RSxxx are also displayed in the format BGxxx.

Number	Message displayed on CRT	Contents	Remarks
PS 060	SEQUENCE NUMBER NOT FOUND	The specified sequence No. was not found during sequence num- ber search. The sequence No. specified as the jump destination in GOTOn or M99Pn was not found.	
PS 061	NO P, Q COMMAND AT G70–G72	Neither P nor Q was specified in a block of multiple repetitive canned cycles G70 to G73 for turning. (P: Sequence No. of the start cycle block Q: Sequence No. of the end cycle block)	Т
PS 062	ILL COMMAND IN G70–G76	<ul> <li>The value specified by address D in a G71, G72, or G73 block is zero or negative.</li> </ul>	Т
		<ul> <li>The value specified by address K or D in a G76 block is zero or negative, or the value specified by address A is out of bounds (valid range: 0° ≤ A° ≤ 120°).</li> </ul>	
		• The value specified by I, K, or D in a G74 or G75 block is negative.	
		<ul> <li>X is specified even though the value specified by I in a G74 or G75 block is zero, or Z is specified even though the value spe- cified by K is zero.</li> </ul>	
PS 063	P, Q BLOCK NOT FOUND	The blocks indicated by the sequence Nos. specified in P or Q in a block of multiple repetitive canned cycles G70 to G73 for turning were not found.	Т
PS 064	SHAPE PROGRAM NOT MONOTONOUS	The change in movement along the Z–axis in the G71 finishing program, or that along the X–axis in the G72 finishing program, is not monotonous.	Т
PS 065	ILL COMMAND IN P-BLOCK	Group 01 G code G00 or G01 has not been specified in the blocks indicated by P or Q in the blocks of multiple repetitive canned cycles G70 to G72 for turning.	
PS 066	ILL COMMAND IN PROGRAM	A group 01 G code other than G00, G01, G02, or G03, a single- shot G codes other than G04, or G65, G66, G67, M98, or M99 was specified in one of the blocks specified by the sequence numbers specified in P and Q of canned cycle G70, G71, or G72.	Т
PS 067	G70–G73 IN FORBIDDEN MODE	Multiple respective canned cycle G70, G71, G72, or G73 is specified in a mode other than memory mode.	Т
PS 069	ILL COMMAND IN Q-BLOCK	Chamfering or cornering is specified in a block indicated by the sequence No. specified in Q in a block of multiple repetitive canned cycles G70 to G73 for turning.	Т
PS 076	PROGRAM NOT FOUND	The program indicated by the program No. called by M98, G65, G66, G66.1, or a G, M, or T code could not be found.	
PS 077	PROGRAM IN USE	An attempt was made in the foreground to execute a program be- ing edited in the background.	
PS 079	PROGRAM FILE NO NOT FOUND	The specified program could not be found. This alarm occurs when a program specified by M198 is not registered in external memory. This alarm also occurs when a remote buffer is being used and an attempt is made to execute a program by specifying its program No. M198.	
PS 090	DUPLICATE NC, MACRO STATEMENT	An NC statement and macro statement were specified in the same block.	
PS 091	DUPLICATE SUB-CALL WORD	More than one subprogram call instruction was specified in the same block.	
PS 092	DUPLICATE MACRO-CALL WORD	More than one macro call instruction was specified in the same block.	
PS 093	DUPLICATE NC–WORD &M99	An address other than O, N, P, or L was specified in the same block as M99 during the macro continuous–state call state (G76).	

Number	Message displayed on CRT	Contents	Remarks
PS 094	G CANNOT BE ARGUMENT	Address G was used as the argument of a macro.	
PS 095	TOO MANY TYPE–2 ARGUMENTS	More than 10 sets of type–II arguments were specified for custom macros.	
PS 100	CANCEL WITHOUT MODAL CALL	Call mode cancel (G67) was specified even though macro continuous-state call mode (G66) was not in effect.	
PS 110	OVERFLOW: INTEGER	An integer went out of range during arithmetic calculations (valid range: $-2^{31}$ to $2^{31}-1$ )	
PS 111	OVERFLOW: FLOATING	A binary floating point number went out of range during arithmetic calculations.	
PS 112	DIVISION BY ZERO	An attempt was made to divide by zero in a custom macro.	
PS 114	VARIABLE NO. OUT OF RANGE	An illegal variable No. was specified in a custom macro.	
PS 115	READ PROTECTED VARIABLE	An attempt was made in a custom macro to use on the right side of an expression a variable that can only be used on the left side of an expression.	
PS 116	WRITE PROTECTED VARIABLE	An attempt was made in a custom macro to use on the left side of an expression a variable that can only be used on the right side of an expression.	
PS 118	TOO MANY NESTED BRACKETS	Too many brackets ([]) were nested in a custom macro.	
PS 119	ARGUMENT VALUE OUT OF RANGE	An argument of a function in a custom macro is out of range.	
PS 121	TOO MANY SUB, MACRO NESTING	<ol> <li>The total number of subprogram and macro calls exceeds the allowable range.</li> </ol>	
		<ol> <li>An M98 or M198 command was called by external memory or a subprogram. The program specified by M198 contains an M98 or M198 command.</li> </ol>	
PS 122	TOO MANY MACRO NESTING	Too many macros calls were nested in a custom macro.	
PS 123	MISSING END STATEMENT	The END command corresponding to a prior DO command was missing in a custom macro.	
PS 124	MISSING DO STATEMENT	The DO command corresponding to a post END command was missing in a custom macro.	
PS 125	ILLEGAL EXPRESSION FORMAT	There is an error in the format used in an expression.	
PS 126	ILLEGAL LOOP NO.	DO and END Nos. exceed the allowable range.	
PS 128	SEQUENCE NO. OUT OF RANGE	A sequence Nos. was out of range (valid range: 1 to 9999).	
PS 131	MISSING OPEN BRACKET	The number of left brackets ([) is less than the number of right brackets (]) in a custom macro.	
PS 132	MISSING CLOSE BRACKET	The number of right brackets (]) is less than the number of left brackets ([) in a custom macro.	
PS 133	MISSING "="	An equals sign (=) is missing in a custom macro.	
PS 134	MISSING "/"	A division sign (/) is missing in a custom macro.	
PS 135	MACRO STATEMENT FORMAT ERROR	There is an error in the format used in a macro statement in a custom macro.	
PS 136	DFA STATEMENT FORMAT ERROR	There is an error in the format used in a DFA statement in a custom macro.	
PS 137	IF STATEMENT FORMAT ERROR	There is an error in the format used in an IF statement in a custom macro.	

Number	Message displayed on CRT	Contents	Remarks
PS 138	WHILE STATEMENT FORMAT ERROR	There is an error in the format used in a WHILE statement in a custom macro.	
PS 139	SETVN STATEMENT FORMAT ERROR	There is an error in the format used in a SETVN statement in a custom macro.	
PS 141	ILLEGAL CHARACTER IN VAR. NAME	A SETVN statement in a custom macro contains a character that cannot be used in a variable name.	
PS 142	VARIABLE NAME TOO LONG	The variable name used in a SETVN statement in a custom macro is too long.	
PS 143	BPRNT/DPRNT STATE- MENT FORMAT ERROR	There is an error in the format used in a BPRNT or DPRNT statement specified for external output from a custom macro.	
PS 144	G10 FORMAT ERROR	There is an error in the G10 format.	
PS 145	G10.1 TIME OUT	The response to a G10.1 command was not received from the PMC within the specified time limit.	
PS 146	G10.1 FORMAT ERROR	There is an error in the G10.1 format.	
PS 150	G31 FORMAT ERROR	The G31.8 command contains one of the following errors : – No axis is specified. – More than one axis is specified. – P is omitted.	
PS 180	ALL PARALLEL AXES IN PARKING	All of the parallel axes for an address are parked (the parking signal is on).	
PS 181	ZERO RETURN NOT FINISHED	During automatic operation, a movement command was issued for an axis for which reference position has not been performed since power–on.	
PS 182	CIRCLE CUT IN RAPID TRAVERSE	F0 (rapid traverse in inverse feed or feed specified by an F code with one–digit number was specified during circular interpolation (G02, G03) or involute interpolation (G02.2, G03.2) mode.	
PS 183	TOO MANY SIMULTA- NEOUS CONTROL AXES	A move command was specified for more axes than can be controlled by simultaneous axis control.	
PS 184	TOO LARGE DISTANCE	Due to compensation or similar reasons, a movement distance was specified that exceeds the maximum allowable distance.	
PS 185	ZERO RETURN CHECK(G27) ERROR	The axis specified in G27 (reference position return check) has not returned to the reference position.	
PS 186	ILLEGAL PLANE SELECTION	There is an error in the plane selection command (parallel axes are being specified at the same time).	
PS 187	FEEDRATE IS 0 (F COMMAND)	The cutting feedrate has been set to 0 by an F code.	
PS 188	DRY RUN FEEDRATE IS 0	The maximum feedrate or the dry run feedrate has been set to 0 by parameter.	
PS 190	CUTTING FEEDRATE IS 0	The maximum cutting feedrate has been set to 0 by parameter.	
PS 191	RADIUS TOO LARGE	An arc was specified for which the difference in the radius at the start and end points exceeds the value set in parameter 2410.	
PS 192	ILLEGAL LEAD COMMAND (G34)	In variable lead threading, the lead compensation value set with address K is greater than the maximum allowed value (the lead is negative or greater than the maximum allowed size).	
PS 193	ILLEGAL OFFSET NUMBER	An incorrect offset No. was specified.	
PS 194	ZERO RETURN END NOT ON REF	The axis specified in G28 (automatic reference position return) was not at the reference position when positioning was completed.	
PS 195	ILLEGAL AXIS SELECTED (G96)	An incorrect value was specified in P in a G96 block or parameter 5640.	
PS 196	ILLEGAL DRILLING AXIS SELECT	An illegal axis was specified for drilling in a canned cycle for drilling.	

Number	Message displayed on CRT	Contents	Remarks
PS 197	OTHER AXIS ARE COMMANDED	A command was issued for another axis at the same time a command was being issued for the index table axis.	
PS 198	ILLEGAL INDEX ANGLE	A value other than an integer multiple of the degree increment used by the index table was specified.	
PS 199	ILLEGAL COMMAND IN INDEXING	An illegal command was specified for indexing using the index table.	
PS 200	PULSE CODER INVALID ZERO RETURN	The grid position could not be set during grid reference position return using a digital position detector, because the one-revolution signal was not received before leaving the deceleration dog.	
PS 201	ILLEGAL LEAD COMMAND (G35) G02.1/03.1	During circular threading, a command for changing the long axis was issued.	
PS 201	G02.1/03.1 FORMAT ERROR	The specified arc exceeds the range where interpolation can be performed.	
PS 205	TURRET REF. NOT FINISHED	Indexing was specified without first performing reference position return of the turret axis.	
PS 206	ILLEGAL TOOL NO.	An invalid tool No. was specified.	
PS 210	ILLEGAL WAITING M-CODE	An M command with three–digit number is issued to a tool post which then entered a waiting state while a different M command with three–digit number was issued for another tool post.	TT
PS 211	PROGRAM NUMBER ODD/ EVEN ERROR	An attempt was made to execute an even-numbered program on the first tool post or an odd-numbered program on the second tool post.	TT
PS 212	ILLEGAL BALANCE CUT- TING G-CODE	A G68 command was issued to a tool post which then entered a waiting state while a G69 command was issued for another tool post, or a G69 command was issued to a tool post which then entered a waiting state while a G68 command was issued for another tool post.	TT
PS 213	ILLEGAL USE OF PS213 G12.1/G13.1	Conditions are not correct for starting or cancelling polar coordinate interpolation.	
		· G12.1 or G13.1 was commanded in a mode other than G40.	
		<ul> <li>An illegal plane was selected (error in parameter 1032 or 1033).</li> </ul>	
PS 214	ILLEGAL USE OF G-CODE	A G code which cannot be specified in G12.1 mode was specified.	
PS 215	TOOL RETRACTION INCORRECT	The retract command was specified incorrectly (long axis was specified in threading).	
PS 217	ILLEGAL OFFSET VALUE	Illegal offset number	
PS 218	FORMAT ERROR	Illegal format	
PS 223	ILLEGAL SPINDOLE SELECT	Although spindle control is disabled (G10.7 P0), an S code is specified.	
PS 229	G10.7 FORMAT ERROR	Address P specified in the G10.7 block is not 0, 1, or 2.	
PS 270	OFFSET START/STOP IN C MODE	An attempt was made to start or cancel tool tip radius compensa- tion during arc mode.	
PS 271	CRC: ILLEGAL PLANE	An attempt was made to change the plane while offset C was in effect.	
PS 272	CRC: INTERFERENCE	The depth of cut is too great while offset C is in effect.	
PS 280	ILLEGAL COMMAND IN SPI- RAL	An illegal command was specified for spiral or conical interpola- tion. (R was specified.)	
PS 281	OVER TOLERANCE OF END POINT IN SPIRAL	The difference between the positions of the specified and calcu- lated end points exceeds the permissible value.	
PS 299	CRC: NO INTERSECTION	There is no point of intersection in offset C.	

Number	Message displayed on CRT	Contents	Remarks
PS 300	ILLEGAL ADDRESS	An illegal address was specified while loading parameters or pitch error compensation data from a tape.	
PS 301	MISSING ADDRESS	An address was found to be missing while loading parameters or pitch error compensation data from a tape.	
PS 302	ILLEGAL DATA NUMBER	An invalid data No. was found while loading parameters or pitch error compensation data from a tape.	
PS 303	ILLEGAL AXIS NUMBER	An invalid axis No. was found while loading parameters from a tape.	
PS 304	TOO MANY DIGITS	Data with too many digits was found while loading parameters or pitch error compensation data from a tape.	
PS 305	DATA OUT OF RANGE	Out–of–range data was found while loading parameters or pitch error compensation data from a tape.	
PS 306	MISSING AXIS NUMBER	A parameter which requires an axis to be specified was found without an axis No. while loading parameters from a tape.	
PS 307	ILLEGAL USE OF MINUS SIGN	Data with an illegal sign was found while loading parameters or pitch error compensation data from a tape.	
PS 308	MISSING DATA	An address not followed by a numeric value was found while load- ing parameters or pitch error compensation data from a tape.	
PS 400	PROGRAM DOES NOT MATCH	The program in memory does not match the program stored on tape.	
PS 410	G37 INCORRECT	No axis or more than one axis was specified in a tool measure- ment command block.	
PS 411	G37 SPECIFIED WITH D/H CODE	A D or H code was specified in the same block as an automatic tool–length measurement command.	
PS 412	G37 OFFSET NO. UNASSIGNED	No D or H code was specified before the tool length measurement command.	
PS 413	G37 SPECIFIED WITH T–CODE	A T code was specified in the same block as a tool length mea- surement command.	
PS 414	G37 OFFSET NO. UNASSIGNED	No T code was specified before the tool length measurement com- mand.	
PS 415	G37 ARRIVAL SGNL NOT ASSERTED	During tool measurement, the measurement position arrival signal went on before the machine was in the area specified by parameter $\epsilon$ , or the measurement position arrival signal did not go on at all.	
PS 418	SPINDLE & OTHER AXIS MOVE	Spindle and other axis are specified in the same block for spindle positioning.	
PS 419	SPINDLE NOT ZERO RETURNED	Orientation (zero position return) was not completed in spindle positioning.	
PS 421	SETTING COMMAND ERROR	Command for setting tool data (G10L70 to G11, G10L71 to G11) is specified incorrectly . (Tool number specified for tool offset.)	
PS 422	TOOL DATA NOT FOUND	The pot number, tool length compensation data, and cutter com- pensation data has not been set for the specified tool number (tool number specified for tool offset).	
PS 425	TOOL DATA CANNOT BE DELETED	Tool data specified by the tool selection command cannot be de- leted.	
PS 426	TOO MANY ADDRESSES	More than one of I, (J), K, or R was specified in the same block as chamfering or cornering. Example) G01X——K——R ;	
PS 427	TOO MANY AXES FOR I–R MOVE	There is no single–axis movement command specified in a block in which chamfering or corner rounding is specified. Example) G01X—Z—K—;	
PS 428	MISMATCH AXIS WITH CNR, CHF	I was specified with axis X or K was specified with axis Z in a block in which chamfering or corner rounding is specified. Example) G01X—I; G01ZK;	

Number	Message displayed on CRT	Contents	Remarks
PS 429	MISSING VALUE AT CNR, CHF	The specified movement distance is less than the specified cor- nering or chamfering amount in a block in which chamfering or cornering is specified.	
	MISSING VALUE AT CNR, CHF	When a block with cornering or chamfering was inserted, the original movement command range was exceeded.	М
PS 430	CODE ISN'T G01 AFTER CNR, CHF	The command following a block in which cornering or chamfering was specified is not G01.         Example)       N1 G01X—K—; N2 G00Z—I—;	
PS 431	MISSING MOVE AFTER CNR, CHF	The direction or movement distance specified in the block follow- ing a block in which cornering or chamfering is specified is incor- rect.	Т
PS 431	MISSING MOVE AFTER CNR, CHF	The block following a block in which cornering or chamfering is specified is not a linear or circular interpolation block.	M
PS 437	ILLEGAL LIFE GROUP NUMBER	A tool group number exceeded the maximum value.	
PS 438	TOOL GROUP NOT SET	A tool group which has not been set was specified in a machining program.	
PS 439	TOO MANY TOOLS	The number of tools specified in a single tool group exceeded the maximum allowed number.	
PS 440	T COMMAND NOT FOUND (G10L3)	No T command was specified in a program which sets a tool group.	
PS 441	NOT USING TOOL IN LIFE GROUP	An H99 or D command was specified when no tool that belongs to a group was being used.	
PS 442	ILLEGAL T COMMAND AT M06	The tool group of the tool specified in the tool command (return tool group) after the M06 command in a machining program does not match the current tool group.	
PS 443	NOT FOUND P, L COMMAND	No P or L command was specified at the beginning of a program that sets a tool group.	
PS 445	ILLEGAL L COMMAND	The value specified in an L command in a program that sets a tool group is 0 or a value greater than the maximum tool life.	
PS 446	ILLEGAL T COMMAND	The value specified in a T command in a program that sets a tool group is greater than the maximum allowed value.	Т
PS 446	ILLEGAL H D T COMMAND	The value specified by an H, D, or T command in a program that sets a tool group is greater than the maximum allowed value.	М
PS 447	ILLEGAL TYPE OF TOOL CHANGE	The tool change method is set incorrectly.	М
PS 448	UNUSABLE ADDRESS (G10L3)	A command that cannot be specified in a program that sets a tool group was specified.	
PS 449	NO TOOL LIFE DATA	A tool group was specified in a machining program even though no tool groups have been set.	
PS 450	IN PMC AXIS MODE	In the PMC axis control mode, the CNC issued a move command for the PMC axis. This alarm can be suppressed by setting NPAA of parameter No. 2405 to 1.	
PS 533	S CODE ZERO	The S code for rigid tapping is not specified.	

Number	Message displayed on CRT	Contents	Remarks
PS 573	EGB PARAMETER	EGB parameter setting error.	
	SETTING ERROR	(1) SYNAXS, bit 0 of parameter 1955, was erroneously set.	
		(2) The rotation axis was not specified (bits 0 and 1 of parameter No. 1006). The synchronous start command with the number of turns was specified for the slave axis.	
		(3) The number of pulses distributed per turn was not specified (parameter Nos. 5996 and 5997).	
PS 574	EGB FORMAT ERRO	Format error in the block in which the EGB command was specified	
		(1) No command was specified for the master or slave axis.	
		(2) Data which is out of range was specified for the master or slave axis.	
		(3) A travel distance was specified for the master axis although the axis was not an NC–controlled axis (parameter No. 5998 was set to 0).	
PS 575	ILL-COMMAND IN EGB MODE	One of the illegal commands shown below was specified during EGB synchronization.	
		(1) One of commands specified for the slave axis, such as G27, G28, G29, G30, and G53	
		(2) One of inch/millimeter conversion commands, such as G20 and G21	
PS 577	G80 FORMAT ERROR	Format error in that block in which the G80 code was specified	
		(1) R falls outside the valid range.	
PS 578	G80 PARAMETER SETTING	Erroneous G80 parameter setting	
	ERROR	(1) The acceleration/deceleration parameter is invalid.	
PS 580	ENCODE ALARM (PSWD & KEY)	When an attempt was made to read a program, the specified pass- word did not match the password on the tape and password on tape was not equal to 0. When an attempt was made to punch an encrypted tape, the pass- word did not range from one to 99999999 inclusive.	
PS 581	ENCODE ALARM (PARAMETER)	When an attempt was made to punch an encrypted tape, the punch code parameter was set to EIA. An incorrect command was specified for program encryption or protection.	
PS 585	G81 PARAMETER SETTING	Erroneous G81–parameter setting 1	
	ERROR	(1) SYNAXS, bit 0 of parameter 1955, was erroneously set.	
		<ul><li>(2) The slave axis was not specified as a rotation axis (bits 0 and 1 of parameter No. 1006).</li></ul>	
		(3) Parameter No. 5995 was not set.	
		(4) The acceleration/deceleration parameter is invalid.	
		(5) The automatic phase synchronization parameter is invalid.	
PS 586	G81 FORMAT ERROR	Format error in the block in which the G81 code was specified	
		(1) T (number of teeth) was not specified.	
		(2) Data which was out of range was specified for T or L.	
		(3) An overflow occurred in the calculation of synchronous coeffi cients.	
		(4) R falls outside the valid range.	
		(5) The synchronous feedrate for the workpiece axis is greater than or equal to the rapid traverse rate (parameter No. 1420).	

Number	Message displayed on CRT	Contents	Remarks
PS 587	ILL–COMMAND IN G81 MODE	One of the illegal commands shown below was specified during G81 synchronization.	
		(1) One of commands specified for the C–axis, such as G27, G28, G29, G30, and G53	
		(2) One of inch/millimeter conversion commands, such as G20 and G21	
PS 610	ILLEGAL G07.1 AXIS	Axis which cannot perform cylindrical interpolation was specified. More than one axis was specified in a G07.1 block. An attempt was made to cancel cylindrical interpolation for an axis that was not in cylindrical interpolation mode.	
PS 611	ILLEGAL G–CODE USE (G07.1 MODE)	A G code was specified that cannot be specified in cylindrical interpolation mode.	
PS 625	TOO MANY G68 NESTING	3-dimensional coordinate switching (G68) was specified more than twice.	
PS 626	G68 FORMAT ERROR	There is a format error in a G68 block. This alarm occurs in the below cases:	
		(1) When I, J, or K is missing from the block in which G68 is speci- fied (when the coordinate rotation option is not available)	
		(2) When I, J, and K specified in the block in which G68 is speci- fied are all 0	
		(3) When R is not specified in the block in which G68 is specified	
		Note) For the 15–T/TT, read G68 as G68.1.	
PS 630	HPCC:ILLEGAL START U/ CANCEL	G05P10000 was specified in a mode which cannot enter the HPCC mode (See Section 2.1.1) The HPCC mode was canceled without canceling the cutter com- pensation mode (G41/ G42).(G40 is required before G50P0.)	
PS 631	HPCC:NOT READY STATE	The RISC processor board is not ready for operation.	
PS 632	HPCC:ILLEGAL PARAMETER	The setting of a parameter is invalid.	
PS 633	HPCC:CRC OFS REMAIN AT CANCEL	The HPCC mode was canceled with a cutter compensation value retained.	
PS 634	HPCC:ILLEGAL COMMAND CODE	An invalid code was specified in the HPCC mode. (Refer to 2.1.2). In a block that includes positioning, or auxiliary function, cutter compensation (G41, G42), cancel (G40), vector retention (G38), corner arc (G39), or macro call was specified.	
PS 710	ILLEGAL COMMAND IN SPACE-CIR	An error was found in the specification for three dimensional circular interpolation.	
PS 711	ILLEGAL COMBINATION OF M CODES	M codes of the same group are specified in the same block. Or, an M code which must be specified alone is specified with an other M code in a block.	
PS 805	ILLEGAL COMMAND	A command is specified incorrectly in a block.	
PS 891	ILLEGAL COMMAND G05	G05 was specified in a state in which G05 cannot be specified.	М
PS 895	ILLEGAL PARAMETER IN G02.3/G03.3	The setting (parameter No. 7636) that specifies the axis for which to perform exponential interpolation is incorrect.	М
PS 896	ILLEGAL FORMAT IN G02.3/G03.3	The format for specifying exponential interpolation is incorrect (ad- dresses I, J, or R are not specified, are set to 0, or the span value is negative).	M
PS 897	ILLEGAL COMMAND IN G02.3/G03.3	An illegal value was specified in exponential interpolation (i.e. parameter 1n is negative, etc.)	
PS 898	ILLEGAL PARAMETER IN G54.2	An illegal parameter (6068 to 6076) was specified for fixture offset.	
PS 900	G72.1 NESTING ERROR	G72.1 was specified again during G72.1 rotation copying.	

Number	Message displayed on CRT	Contents	Remarks
PS 901	G72.2 NESTING ERROR	G72.2 was specified again during G72.2 parallel copying.	
PS 920	ILL–COMMAND IN G05.1 Q1	An invalid command was specified in G05.1 Q1 (look–ahead ac- celeration/deceleration before interpolation) mode.	
		(1) F1-digit command	
PS 935	ILLEGAL FORMAT IN G02.2/G03.2	The end point of an involute curve, or I, J, K, or R was not specified.	
PS 936	ILLEGAL COMMAND IN	An illegal value was specified in involute interpolation.	
	G02.2/G03.2	(1) The start point or end point is specified inside the basic circle.	
		(2) I, J, K, or R was specified as 0.	
PS 937	OVER TOLERANCE OF END POINT	The end point is not positioned on the involute curve that passes through the start point (the value specified in parameter No. 2510 is out of range).	
PS 990	SPL : ERROR	The spline interpolation axis command is invalid. In NURBS interpolation by high–precision contour control using a RISC processor:	
		(1) An invalid rank was specified.	
		(2) No knot, or an invalid knot, was specified.	
		(3) Too many axes were specified.	
		(4) Another program error was detected.	
PS 991	SPL : ERROR	A G06.1 command was specified in a G code mode in which the command is not supported.	
PS 992	SPL : ERROR	Movement was specified for an axis other than those used for spline interpolation. In NURBS interpolation by high–precision contour control using a RISC processor:	
		<ol> <li>A program error was detected in the block to be read in ad- vance.</li> </ol>	
		(2) Increase in knots is not monotonous.	
		(3) A mode which cannot be used in NURBS interpolation mode was specified.	
PS 993	SPL : ERROR	A three–dimensional tool offset vector cannot be generated. In NURBS interpolation by high–precision contour control using a RISC processor, the first control point for NURBS is invalid.	
PS 994	SPL : ERROR	In NURBS interpolation by high–precision contour control using a RISC processor, NURBS interpolation was resumed after manual intervention with the manual absolute switch set to ON.	
PS 996	G41.3/G40 FORMAT ERROR	A move command was specified in the block in which the G41.3 or G40 code was specified. A G or M code which suppresses buffering was specified in the block in which the G41.3 code was specified.	
PS 997	ILLEGAL COMMAND IN G41.3	A G code other than G00 or G01 in group 01 was specified in the continuous state of the G41.3 code. An offset command (G code in group 07) was specified in the G41.3 mode. The block following the block in which G41.3 (start up) was specified did not have a move command.	
PS 998	G41.3 ILLEGAL START UP	The G41.3 code (start up) was specified in the continuous state of a G code other than G00 or G01 in group 01. The angle formed by the tool–direction vector and the movement–direction vector was 0 or 180 degrees at start up.	
PS 999	ILLEGAL PARAMETER IN G41.3	A parameter which determines the relationship between the rota- tion axis and rotation plane was erroneously set (parameter Nos. 1022 and 6080 to 6089)	

Number	Message displayed on CRT	Contents	Remarks
SR 160	INTERNAL DATA OVER FLOW	Coordinates specified in an absolute or machine coordinate sys- tem are out of range. In general, this alarm is generated when the rotational axis is ro- tated a number of times and an absolute coordinate becomes greater than +99999.999 or less than –99999.999 (for increment system IS–B). Perform reference position return when this alarm occurs.	
SR 310	H, S, C ERROR	G10.3, G11.3, or G65.3 is used incorrectly.	
SR 311	H, S, C ERROR	A command not permitted during high-speed machining was specified.	
SR 312	H, S, C ERROR	Address P, Q, or L is out of range.	
SR 313	H, S, C ERROR	High-speed machining data does not exist for the number that was called.	
SR 314	H, S, C ERROR	No cluster exists for the number that was called.	
SR 315	H, S, C ERROR	An attempt was made to register a number for which high-speed machining data already exists.	
SR 316	H, S, C ERROR	Memory is full.	
SR 317	H, S, C ERROR	The maximum number of sets of high–speed machining data has been registered (no additional high–speed machining data can be registered).	
SR 318	H, S, C ERROR	An attempt was made to register high-speed machining data dur- ing background editing.	
SR 319	H, S, C ERROR	There is an error in the format of high-speed machining data.	
SR 320	H, S, C ERROR	A macro interrupt occurred during high-speed machining.	
SR 424	OVER MAXIMAM TOOL DATA	An attempt was made to register new tool data even though the maximum number of sets of tool data has already been set (tool No. specified for tool offset).	
SR 590	THERROR	TH alarm (A character with a parity error was entered in a significant data area.)	
SR 591	TV ERROR	TV alarm (The number of characters in a block was not even.)	
SR 592	END OF RECORD	EOR (End of Record) was specified partway through a block.	
SR 600	PARAMETER OF RESTART ERROR	There is an error in the specification of the program restart parameter.	
SR 805	ILLEGAL COMMAND	An attempt was made to use an illegal command for the reader/ punch interface. This is generally a system error.	
SR 806	DEVICE TYPE MISS MATCH	An attempt was made to use a command which is invalid for the currently selected I/O device. For example, this alarm occurs when an attempt is made to perform a file head search even though the medium is not a FANUC floppy disk.	
SR 807	PARAMETER SETTING ER- ROR	An I/O interface which was not selected as an option was speci- fied, or the settings or parameters related to the I/O interface are set incorrectly.	
SR 810	PTR NOT READY	The ready signal for the tape reader is off.	
SR 812	OVERRUN ERROR (PTR)	The next character was received by the tape reader before it could read a previously received character.	
SR 820	DR OFF(1)	The data set ready signal for reader/punch interface 1 went off.	
SR 821	CD OFF(1)	The signal quality detection signal for reader/punch interface 1 went off.	
SR 822	OVERRUN ERROR(1)	The next character was received by reader/punch interface 1 be- fore it could read a previously received character.	
SR 823	FRAMING ERROR(1)	No stop bit was detected for a character received by reader/punch interface 1.	

Number	Message displayed on CRT	Contents	Remarks
SR 824	BUFFER OVERFLOW(1)	The NC received more than ten characters of data from reader/ punch interface 1 even though the NC sent a stop code (DC3) during data reception.	
SR 830	DR OFF(2)	The data set ready signal for reader/punch interface 2 went off.	
SR 831	CD OFF(2)	The signal quality detection signal for reader/punch interface 2 went off.	
SR 832	OVERRUN ERROR(2)	The next character was received by reader/punch interface 2 be- fore it could read a previously received character.	
SR 833	FRAMING ERROR(2)	No stop bit was detected for a character received by reader/punch interface 2.	
SR 834	BUFFER OVERFLOW(2)	The NC received more than ten characters of data from reader/ punch interface 2 even though the NC sent a stop code (DC3) during data reception.	
SR 840	DR OFF(3)	The data set ready signal for reader/punch interface 2 went off.	
SR 841	CD OFF(3)	The signal quality detection signal for reader/punch interface 3 went off.	
SR 842	OVERRUN ERROR(3)	The next character was received by reader/punch interface 3 be- fore it could read a previously received character	
SR 843	FRAMING ERROR(3)	No stop bit was detected for a character received by reader/punch interface 3.	
SR 844	BUFFER OVERFLOW(3)	The NC received more than ten characters of data from reader/ punch interface 3 even though the NC sent a stop code (DC3) during data reception.	
SR 860	DATA SET READY DOWN (ASR33/43)	The data set ready signal for the 20 mA current loop interface went off.	
SR 861	CARRIER DETECT DOWN (ASR33/43)	The signal quality detection signal for the 20 mA current loop inter- face went off.	
SR 862	OVERRUN ERROR (ASR33/43)	The next character was received by the 20 mA current loop inter- face before it could read a previously received character.	
SR 863	FRAMING ERROR (ASR33/ASR44)	No stop bit was detected for a character received by the 20 mA current loop interface.	
SR 864	BUFFER OVERFLOW (ASR33/ASR44)	The NC received more than ten characters of data from the 20 mA current loop interface even though the NC sent a stop code (DC3) during data reception.	
SR 870	DATA SET READY DOWN (RS422)	The data mode signal for the RS-422 interface went off.	
SR 872	OVERRUN ERROR (RS422)	The next character was received by the RS–422 interface before it could read a previously received character.	
SR873	FRAMING ERROR (RS422)	No stop bit was detected for a character received by the RS-422 interface.	
SR 874	BUFFER OVERFLOW (RS422)	The NC received more than ten characters of data from the RS–422 interface even though the NC sent a stop code (DC3) during data reception.	
SR 880	NOT DRAWING	Communication cannot be made with the graphic CPU.	
SR 890	CHECK SUM ERROR (G05)	A check sum error occurred (high-speed remote buffer).	

Number	Message displayed on CRT	Contents	Remarks
OH 000	MOTOR OVERHEAT	A servo motor overheated.	Axis type
OH 001	LOCKER OVERHEAT	The NC cabinet overheated.	

Axis type : Error codes of this type are specified for each axis for which it occurs.

Number	Message displayed on CRT	Contents	Remarks
SB 010	GRAPHIC RAM PARITY	A parity error occurred in the graphic ROM.	
SB 011	GRAPHIC RAM PARITY (WORK)	A parity error occurred in the graphic work RAM.	
SB 011	GRAPHIC RAM PARITY (RED)	A parity error occurred in the RAM for red graphics.	
SB 011	GRAPHIC RAM PARITY (GREEN)	A parity error occurred in the RAM for green graphics.	
SB 011	GRAPHIC RAM PARITY (BLUE)	A parity error occurred in the RAM for blue graphics.	

Number	Message displayed on CRT	Contents	Remarks
SW 000	PARAMETER ENABLE SWITCH ON	Parameter setting is enabled (PWE, a bit of parameter No. 8000 is 1)	

Number	Message displayed on CRT	Contents	Remarks
OT 001	+OVERTRAVEL (SOFT1)	This alarm occurs in the following cases:	Axis type
		<ul> <li>While moving in a positive direction, the tool exceeded the limit set in stored stroke limit 1.</li> </ul>	
		<ul> <li>While moving in the positive direction of a hypothetical axis, the tool exceeded the limit set in the hypothetical axis stroke limit.</li> </ul>	
		<ul> <li>While moving in the positive direction of a hypothetical axis, the eccentric tool length (R) was exceeded.</li> </ul>	
OT 002	-OVERTRAVEL (SOFT1)	This alarm occurs in the following cases:	Axis type
		<ul> <li>While moving in a negative direction, the tool exceeded the limit set in stored stroke limit 1.</li> </ul>	
		<ul> <li>While moving in the negative direction of a hypothetical axis, the tool exceeded the limit set in the hypothetical axis stroke limit.</li> </ul>	
		<ul> <li>While moving in the negative direction of a hypothetical axis, the eccentric tool length (R)was exceeded.</li> </ul>	
OT 003	+OVERTRAVEL (SOFT2)	While moving in a positive direction, the tool exceeded the limit set in stored stroke limit 2, or the tool entered the out–of–bounds chuck/tool stock area.	Axis type
OT 004	-OVERTRAVEL (SOFT2)	While moving in a negative direction, the tool exceeded the limit set in stored stroke limit 2, or the tool entered the out–of–bounds chuck/tool stock area.	Axis type
OT 005	+OVERTRAVEL (SOFT3)	While moving in a positive direction, the tool exceeded the limit set in stored stroke limit 3.	Axis type T
OT 006	-OVERTRAVEL (SOFT3)	While moving in a negative direction, the tool exceeded the limit set in stored stroke limit 3.	Axis type T
OT 007	+OVERTRAVEL (HARD)	The stroke limit switch located at the positive side was turned on.	Axis type
OT 008	-OVERTRAVEL (HARD)	The stroke limit switch located at the negative side was turned on.	Axis type
OT 021	+OVERTRAVEL (PRE–CHECK)	The tool exceeded the limit in the positive direction during the stroke check before movement.	Axis type
OT 022	–OVERTRAVEL (PRE–CHECK)	The tool exceeded the limit in the negative direction during the stroke check before movement.	Axis type
OT 030	EXCESS ERROR ALARM 1	Alarm 1 for excess synchronous error was generated.	Axis type
OT 031	SYNCHRONIZE ADJUST MODE	The system is in synchronous adjustment mode (bit 1 of parameter No. 1803 is set to 1).	Axis type

Number	Message displayed on CRT	Contents	Remarks
OT 032	NEED ZRN (ABS PCDR)	The counter value of the absolute pulse coder does not match the machine coordinates.	Axis type
OT 034	BATTERY ZERO (ABS PCDR)	The battery voltage of the absolute pulse coder is 0 V. Check whether the battery is connected properly. If the battery is connected properly, replace it.	Axis type
O T036	BATTERY DOWN (SPLC)	The battery voltage of the serial pulse coder is low. (Built-in unit)	
O T037	BATTERY DOWN (EX)	The battery voltage of the additional detector is low. (Separate unit)	
O T038	BATTERY ZERO (SPLC)	The serial pulse coder battery voltage is 0 V. (Built-in unit)	
O T039	BATTERY ZERO (EX)	The serial pulse coder battery voltage is 0 V. (Separate unit)	
OT 100	SPINDLE ALARM	The spindle motor alarm was generated, but the code for specify- ing the cause of the alarm is 0.	
OT 101	SPINDLE MOTOR OVERHEAT	The spindle motor overheated.	
OT 102	EXCESS VELOCITY ERROR	The difference between the speed set for the spindle motor and the actual speed of the spindle motor was too great (15% to 20%).	
OT 103	FUSE F7 BLEW	Fuse F7 for the speed control unit of the spindle motor has blown.	
OT 104	FUSE F1, F2 OR F3 BLEW	Fuse F1, F2, or F3 for the speed control unit of the spindle motor has blown.	
OT 105	FUSE AF2 OR AF3 BLEW	Fuse AF2 or AF3 for the speed control unit of the spindle motor has blown.	
OT 106	EXCESS VELOCITY (ANALOG)	The speed of the spindle motor exceeded the maximum rating (analog detection).	
OT 107	EXCESS VELOCITY (DIGITAL)	The speed of the spindle motor exceeded the maximum rating (digital detection).	
OT 108	VOLTAGE (+24V) TOO HIGH	The voltage of the 24 V power supply for the speed control unit of the spindle is too high.	
OT 109	POWER SEMICONDUCTOR OVERLOAD	The power semiconductor overheated.	
OT 110	VOLTAGE (+15) TOO LOW	The voltage of the 15 V power supply for the speed control unit of the spindle motor is too low.	
OT 111	VOLTAGE EXCESS (DC LINK)	The voltage in the DC link for the speed control unit of the spindle motor is too high.	
OT 112	CURRENT EXCESS (DC LINK)	The current in the DC link for the speed control unit of the spindle motor is excessive.	
OT 113	CPU ERROR	The CPU or a peripheral circuit of the speed control unit of the spindle motor is faulty.	
OT 114	ROM ERROR	The ROM of the speed control unit of the spindle motor is faulty.	
OT 115	OPTION ALARM	Optional alarm for the spindle motor.	
OT 116	DISCONNECTION POS CODER	The position coder is disconnected.	
OT 117	SPINDLE OVERHEAT	Spindle alarm was detected by the function for detecting fluctua- tions in spindle speed.	
OT 120	UNASSIGNED ADDRESS (HIGH)	The upper four bits (EIA4 to EIA7) of an external data I/O interface address signal are set to an undefined address (high bits).	
OT 121	UNASSIGNED ADDRESS (LOW)	The lower four bits (EIA0 to EIA3) of an external data I/O interface address signal are set to an undefined address (low bits).	
OT 122	TOO MANY MESSAGES	Requests were made to display more than four external operator messages or external alarm messages at the same time.	
OT 123	MESSAGE NUMBER NOT FOUND	An external operator message or external alarm message cannot be cancelled because no message number is specified.	

Number	Message displayed on CRT	Contents	Remarks
OT 124	OUTPUT REQUEST ERROR	An output request was issued during external data output, or an output request was issued for an address that has no output data.	
OT 125	TOO LARGE NUMBER	A number outside of the range 0 to 999 was specified as the num- ber for an external operator message or an external alarm mes- sage.	
OT 126	SPECIFIED NUMBER NOT	This alarm occurs in the following cases:	
	FOUND	<ul> <li>The number specified for a program number or sequence number search during external data input could not be found.</li> </ul>	
		<ul> <li>The number specified for a workpiece number search could not be found.</li> </ul>	
		<ul> <li>There was an I/O request issued for a pot number or offset (tool data), but either no tool numbers have been input since power–on or there is no data for the entered tool number.</li> </ul>	
OT 127	DI. EIDHW OUT OF RANGE	The value input by external data input signals EID32 to EID47 is out of range.	
OT 128	DI. EIDLL OUT OF RANGE	The value input by external data input signals EID0 to EID31 is out of range.	
OT 129	NEGATE POS CODER 1 REV ON	The CPU or a peripheral circuit of the position coder is faulty.	
OT 130	SEARCH REQUEST NOT ACCEPTED	No requests can be accepted for a program No. or sequence No. search because the system is not in memory mode or the reset state.	
OT 131	EXT–DATA ERROR (OTHER)	<ul> <li>An input request was received for a pot No.or offset value while tool data was being registered with G10.</li> </ul>	
		· An error occurred during reading or writing of tool data.	
OT 132	RETURN ERROR (PTRR)	The tool did not return to the stored position along the axis in tool retraction mode.	Axis type
OT 150	A/D CONVERT ALARM	The A/D converter is faulty.	
OT 151	A/D CONVERT ALARM	The A/D converter is faulty.	
OT 184	PARAMETER ERROR IN TORQUE	An invalid parameter was specified for torque control.	
		(1) The torque constant parameter is set to 0.	
OT 200	INTERFERENCE DATA ERROR	The tool figure data specified for the tool post interference check is incorrect (I > X or K > Z in tool figure data).	TT
OT 208	INTERFERENCE X1 MINUS	An interference alarm occurred while the first tool post was moving in the negative direction along the X axis.	TT
OT 209	INTERFERENCE X1 PLUS	An interference alarm occurred while the first tool post was moving in the positive direction along the X axis.	TT
OT 210	INTERFERENCE Z1 MINUS	An interference alarm occurred while the first tool post was moving in the negative direction along the Z axis.	TT
OT 211	INTERFERENCE Z1 PLUS	An interference alarm occurred while the first tool post was moving in the positive direction along the Z axis.	TT
OT 212	INTERFERENCE X2 MINUS	An interference alarm occurred while the second tool post was moving in the negative direction along the X axis.	TT
OT 213	INTERFERENCE X2 PLUS	An interference alarm occurred while the second tool post was moving in the positive direction along the X axis.	ТТ
OT 214	INTERFERENCE Z2 MINUS	An interference alarm occurred while the second tool post was moving in the negative direction along the Z axis.	TT
OT 215	INTERFERENCE Z2 PLUS	An interference alarm occurred while the second tool post was moving in the positive direction along the Z axis.	ТТ
OT 300	S-SPINDLE LSI ERROR	An error occurred in communication with the spindle.	
OT 301	MOTOR OVERHEAT	Motor overheat	
Number	Message displayed on CRT	Contents	Remarks
--------	------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------
OT 302	EX DEVIATION SPEED	Excessive deviation in speed	
OT 307	OVER SPEED	Excessive speed	
OT 309	OVERHEAT MAIN CIRCUIT	Excessive load on the main circuit	
OT 310	LOW VOLT INPUT POWER	Low voltage in the input power supply	
OT 311	OVERVOLT POW CIRCUIT	Excessive voltage in the DC link	
OT 312	OVERCURRENT POW CIRCUIT	Excessive current in the DC link	
OT 313	DATA MEMORY FAULT CPU	Error in CPU internal data memory	
OT 318	SUMCHECK ERROR PGM DATA	Sum check error in program ROM	
OT 319	EX OFFSET CURRENT U	Excessive offset in U-phase current detection circuit	
OT 320	EX OFFSET CURRENT V	Excessive offset in V-phase current detection circuit	
OT 324	SERIAL TRANSFER ERROR	Error in serial data transfer	
OT 325	SERIAL TRANSFER STOP	Serial data transfer was stopped.	
OT 326	DISCONNECT C-VELO DETCT	The Cs axis control speed detection signal is disconnected.	
OT 327	DISCONNECT POS-CODER	The position coder signal is disconnected.	
OT 328	DISCONNECT C-POS DETCT	The Cs axis control position detection signal is disconnected.	
OT 329	OVERLOAD	Temporary overload	
OT 330	OVERCURRENT POW CIR- CUIT	Excessive current in input circuit	
OT 331	MOTOR LOCK OR V–SIG LOS	The motor locked up alarm is issued or the speed detection signal is disconnected.	
OT 332	RAM FAULT SERIAL LSI	Faulty RAM exists in LSI for serial data transfer.	
OT 333	SHORTAGE POWER CHARGE	Insufficient power charge in DC link	
OT 334	PARAMETER SETTING ER- ROR	Parameter data is out of range.	
OT 335	EX SETTING GEAR RATIO	An excessive gear ratio was set.	
OT336	OVERFLOW ERROR COUNTER	The error counter overflowed.	
OT 399	S-SPINDLE ERROR	A miscellaneous spindle amplifier alarm occurred.	
OT 512	EXCESS VELOCITY	The feedrate specified during polar coordinate interpolation mode (G12.1) was greater than the maximum cutting feedrate.	
OT 513	SYNC EXCESS ERROR	The difference between the positional deviations for the synchro- nized axes during simple synchronization was greater than the limit set in parameter.	Axis type
OT513	SYNC EXCESS ERROR	The difference between the master and slave axes to be synchro- nized with each other has exceeded the maximum compensation value.	Axis type

Number	Message displayed on CRT	Contents	Remarks
PC 010	PC ERROR	A parity error occurred in a PMC ROM.	
PC 020	PC ERROR	A parity error occurred in a PMC RAM.	
PC 030	PC ERROR	An I/O unit was not allocated correctly.	
PC 500	WATCH DOG ALARM	A PMC watch dog alarm occurred.	

Number	Message displayed on CRT	Contents	Remarks
SV 000	TACHOGENERATER DISCONNECT	The tachogenerator is disconnected.	Axis type
SV 001	EXCESS CURRENT IN SERVO	The servo motor was overloaded.	Axis type
SV 002	BREAKER (FEED_CTL_UNIT) OFF	The breaker for the velocity control circuit tripped.	Axis type
SV 003	ABNORMAL CURRENT IN SERVO	Excessive current was detected in the velocity control circuit.	Axis type
SV 004	EXCESS V TO MOTOR	Excessive voltage was detected in the velocity control circuit.	Axis type
SV 005	EXCESS DISCHARGE I FROM MOTOR	Excessive discharge current from the motor was detected in the velocity control circuit.	Axis type
SV 006	VELOCTY UNIT POWER TOO LOW	Low voltage was detected in the velocity control circuit.	Axis type
SV 008	EXCESS ERROR (STOP)	Position deviation when stopped is larger than the value set in parameter No. 1829.	Axis type
SV 009	EXCESS ERROR (MOVING)	Position deviation while moving is larger than the value set in parameter No. 1828.	Axis type
SV 010	EXCESS DRIFT COMPENSATION	Drift compensation is excessive (exceeded 500VELO).	Axis type
SV 011	LSI OVERFLOW	The value specified for position deviation compensation is not within the range of $-32767$ to $+32767$ , or the command value of the D/A converter is not within the range of $-8192$ to $+8192$ . In general, this alarm occurs due to incorrect settings.	Axis type
SV 012	MOTION VALUE OVERFLOW	A speed greater than 512,000 pulses per second (frequency converted into detection units) was specified. In general, this alarm occurs due to incorrect setting of parameter CMR or the feedrate.	Axis type
SV 013	IMPROPER V-READY OFF	The speed control ready signal (VRDY) went off even though the position control ready signal (PRDY) was on. When a multiaxis amplifier is being used, specifying controlled axis detachment for any axis driven by the amplifier causes alarm SV013 to be issued for the other axes driven by that amplifier.	Axis type
SV 014	IMPROPER V-READY ON	The speed control ready signal (VRDY) went on even though the position control ready signal (PRDY) was off.	Axis type
SV 015	PULSE CODER DISCONNECTED	The pulse coder is disconnected.	Axis type
SV 017	ILL POSITION CONTROL LSI	A fault occurred in the LSI for position control.	Axis type
SV 018	INCORRECT DSCG FREQUENCY	A fault was detected in a resolver or inductsyn feedback frequency check.	Axis type
SV 019	INCORRECT PULSE CODER PULSE	A fault was detected in the feedback pulse from the pulse coder.	Axis type
SV 020	INCORRECT PHASE SHIFT VALUE	The resolver or induction phase shift cannot be obtained correctly.	Axis type
SV 021	1-REV PULSE SIGNAL INCORRECT	The single–revolution signal for the pulse coder went on at an in- correct position.	Axis type
SV 022	1-REV PULSE MISSING	The single–revolution signal for the pulse coder did not go on with- in the appropriate range.	Axis type
SV 023	SV OVERLOAD	A servo motor overloaded.	Axis type
SV 024	EXCESS ERROR ALARM 2	Alarm 2 for excess synchronous error was generated.	
SV 025	V–READY ON (INITIALIZING)	During servo control, the speed control ready signal (VRDY) is on even though it is supposed to be off.	Axis type

Number	Message displayed on CRT	Contents	Remarks
SV 026	ILLEGAL AXIS ARRANGE- MENT	Parameter No. 1023 for specifying the arrangement of servo axes is set incorrectly.	
SV 027	ILL DGTL SERVO	There is an illegal digital servo parameter.	
	PARAMETER	<ul> <li>A correct motor model type is not set in parameter No. 1874.</li> </ul>	
		<ul> <li>The number of pulses per motor rotation is not set in parame- ter No. 1876.</li> </ul>	
		<ul> <li>The direction of motor rotation set in parameter No. 1879 is neither 111 nor –111.</li> </ul>	
SV 030	EMERGENCY STOP	Emergency stop occurred (when ENR, a bit of parameter No. 2001, is 1).	
SV 031	EXCESS SPINDLE DIST (SPDL)	Excess position deviation occurred for the spindle during rigid tap- ping.	
SV 032	LSI OVERFLOW (SPDL)	Data for the LSI used for spindle control overflowed during rigid tapping.	
SV 050	ILLEGAL AXIS SYNCHRONIZATION	Parameter No. 1023 is set incorrectly.	
SV 055		Parameter No. 1023 is set incorrectly.	
SV 056		Bit #6 of parameter No. 1817 is set incorrectly.	
SV 99	SPINDLE-AXIS ERROR	An amplifier alarm occurred during spindle contour control.	
SV 100	SACOMP, VALUE OVERFLOW	The value set for straightness compensation is not within the range of –32767 to +32767.	М
SV 101	DATA ERROR (ABS PCDR)	A correct machine position cannot be obtained because the abso- lute pulse coder is faulty or the machine moved too far during pow- er–on.	Axis type
SV 110	PULSE CORDER ALARM (SERIAL A)	An error was detected in the serial pulse coder (serial A) or feed- back cable. Replace the cable or pulse coder. (For details on the alarm, refer to the "FANUC AC Servo Amplifier Maintenance Manual.")	Axis type
SV 111	PULSE CORDER ALARM (SERIAL C)	An error was detected in the serial pulse coder (serial C) or feed- back cable. Replace the cable or pulse coder. (For details on the alarm, refer to the "FANUC AC Servo Amplifier Maintenance Manual.")	Axis type
SV 114	ABNORMAL REV. DATA (SERIAL A)	The serial pulse coder (serial A) is abnormal. Replace it.	Axis type
SV 115	ABNORMAL COMMUNICATION (SPLC)	A serial pulse coder communication failure occurred. Replace the pulse coder, feedback cable, or CNC axis board.	Axis type
SV 116	MCC WELDING ARARM	The contact of the magnetic contractor (MCC) in the servo amplifier has melted. For details, refer to the "FANUC AC Servo Amplifier Maintenance Manual."	Axis type
SV 117	ABNORMAL CURRENT OFFSET	Digital servo current conversion is abnormal. Replace the CNC axis board.	Axis type
SV 118	DETECT ABNORMAL TORQUE	An abnormal servo motor load was detected. Reset to clear the alarm.	Axis
SV 119	DETECT ABNORMAL TORQUE (1ST SPDL)	An abnormal load was detected on the first spindle motor. To reset the alarm, press the RESET button.	
SV 125	EXCESS VELOCITY IN TORQUE	In torque control, the specified maximum allowable velocity was exceeded.	
SV 126	EXCESS ERROR IN TORQUE	In torque control, the maximum allowable accumulated movement, specified with a parameter, was exceeded.	

Number	Message displayed on CRT	Contents	Remarks
SV 323	DISCONNECT ALARM BY SOFT	Disconnection of the serial pulse coder was detected. (Software)	
SV 324	DISCONNECT ALARM BY HARD	Disconnection of the serial pulse coder was detected. (Hardware)	
SV 325	PULSE CODER ALARM1 (SPLC)	An abnormality was detected in the serial pulse coder or feedback cable. (Built-in unit)	
SV 326	PULSE CODER ALARM3 (SPLC)	An abnormality was detected in the serial pulse coder or feedback cable. (Built-in unit)	
SV 327	ABNORMAL REV. DATA (SPLC)	The serial pulse coder is abnormal. Replace the pulse coder. (Built–in unit)	
SV 330	ABNORMAL COMMUNICATION (SPLC)	A serial pulse coder communication error occurred. (Built-in unit)	
SV 331	PULSE CODER ALARM2 (SPLC)	An abnormality was detected in the serial pulse coder or feedback cable. (Built–in unit)	
SV 333	PULSE CODER ALARM4 (EX–LIN)	An abnormality was detected in the serial pulse coder or feedback cable. (Separate linear)	
SV 334	PULSE CODER ALARM5 (EX–ROT)	An abnormality was detected in the serial pulse coder or feedback cable. (Separate rotary)	
SV 335	ABNORMAL REV. DATA (EX–ROT)	The serial pulse coder is abnormal.	
SV 336	BATTERY ZERO (EX)	The serial pulse coder battery voltage is 0 V. (Separate unit)	
SV 338	DETECTOR OVER LOAD (EX)	The serial pulse coder is overloaded. (Separate unit)	
SV 339	ABNORMAL COMMUNICATION (EX)	A communication error occurred in the serial pulse coder. (Separate unit)	
SV 340	PULSE CODER DISCONNECT (EX)	Disconnection of the serial pulse coder was detected. (Separate unit)	

Number	Message displayed on CRT	Contents	Remarks
IO 030	CHECK SUM ERROR	The check sum for a page of NC memory is incorrect.	
IO 031	INVALID CODE	An invalid code was read from NC memory.	
IO 032	OUT OF RANGE MEMORY ACCESS	An attempt was made to read data from or write data to an ad- dress outside of bubble memory.	

Number	Message displayed on CRT	Contents	Remarks
PW 000	POWER MUST BE OFF	A parameter was set for which the power must be turned off then on again.	
PW 100	ILLEGAL PARAMETER	The parameter for setting straightness compensation or the parame- ter for setting inclination compensation is specified incorrectly.	

# C.2 ALARM LIST (PMC)

# (1)PMC–NA

Message	Alarm description
THERE IS NO ALARM	Normal condition. Machine usually operates under this condition.
ER01 ROM CASSETE ROM PARITY	ROM PARITY occurred in the FLASH ROM. (PMC–NA) Corrective action: Refer to the Chapter III–7.5 "Data Input/Output From/To RAM Board (PMC–NA)" in the Programming Manual of FANUC PMC–N/NA (B–61013E).
ER02 PROGRAM DATA ERROR	Sequence data is wrong or corrupt.
ER03 PROGRAM SIZE ERROR	Sequence data exceeding the print board capacity was input.
ER04 SERIES UNMATCH	Sequence data of another series was input. Note) In this case, a ladder program cannot run.
ER10 TCB SETTING ERROR	The task entry address setting. Stack address, level, or starting condi- tion parameter is incorrect.
ER11 NO C LIBRARY OPTION	There is no C library option.
ER12 PASCAL DATA ORIGIN ERROR	Another data area is used instead of the PASCAL DATA AREA, or an odd number address is set.
ER13 PASCAL ORIGIN ERROR	Another area is used instead of the PASCAL AREA, or an odd number address is set.
ER21 SLC ERROR	The I/O Link LSI is defective. Corrective action: Change the PMC print board.
ER22 SLC ERROR (xGROUP)	LSI detection of an I/O device has occurred in the x group, or abnormal communication has occurred. Corrective action: Replace the print board or the I/O device.
ER23 SLOT SETTING ERROR	An attempt was made to specify 11 or greater as a slot number.
ER24 TOO MUCH DATA (xGROUP INPUT)	More than 33 bytes were allocated to the input x group.
ER24 TOO MUCH DATA (xGROUP OUTPUT)	More than 33 bytes were allocated to the output x group.
ER25 I/O SETTING ERROR (XGROUP INPUT)	Insufficient I/O area (allocation after the output x group is invalid).
ER25 I/O SETTING ERROR (xGROUP OUTPUT)	Insufficient I/O area (allocation after the output x group is invalid).
ER26 I/O DEVICES ARE UNLINKED (AFTER xGROUP)	I/O devices are connected only up to the (x–1) group although allocation data is created for the x and subsequent groups.
	Note) If the system is started, the ladder program is not automatically executed. (Pressing the "RUN" key, however, executes the ladder program.)
	Corrective action: Correct I/O device allocation, or check the I/O device configuration.

Message	Alarm description
ER27 I/O DEVICES ARE UNDEFINED (AFTER xGROUP)	The I/O allocation data is created for only up to the $(x-1)$ group although I/O devices are connected to the x and subsequent groups.
	Note) If the system is started with the ROM cassette mounted, the ladder program is not automatically executed. (Pressing the "RUN" key, however, executes the ladder program.)
	Corrective action: Correct I/O device allocation, or check the I/O device configuration.
ER28 I/O ALLOCATION ERROR (xGROUP)	Because I/O UNIT Model A exists in x group, data can not be automat- ically allocated.
	Note) In this case, I/O is not inputted output.
	Corrective action: Press the "IOSTAT" key or power on again after making alloca- tion data.
ER31 I/O DEVICES ARE UNLINKED (AFTER xGROUP)	I/O devices were connected only for groups "X–1" and lower, when they had been assigned for groups X and higher. In addition: Value specified at "NUMBER OF I/O LINK GROUP" on the [MODE] screen > number of connected groups
	Note) In this case, no sequence program is started when the power is switched on. (Pressing the [RUN] key starts a sequence pro- gram, however).
	Corrective action: Correct the I/O device assignment, or check the configuration of the I/O devices.
WR20 NO I/O DEVICE	An I/O device is not connected.
	Corrective action: Confirm the optical cable and I/O power source are properly connected.

### (2) PMC–NB

Message	Contents and solution
ALARM NOTHING	Normal status
ER01 PROGRAM DATA ERROR (RAM)	The sequence program is defective. (solution) Please clear the program and input LADDER again.
ER02 PROGRAM SIZE OVER	The size of sequence program exceeds the maximum size of LAD- DER.
	(solution) Please change MAX LADDER AREA SIZE at the SYSPRM screen and restart the system.
ER03 PROGRAM SIZE ERROR (OPTION)	The size of sequence program exceeds the option specification size. (solution) Please increase the option specification size. Or, reduce the size of sequence program.
ER04 PMC TYPE UNMATCH	The PMC model setting of the sequence program is not corresponding to an actual model.
	(solution) Please change the PMC model setting by the offline programmer.
ER17 PROGRAM PARITY	The parity error occurred on memory for sequence program or the debugging RAM.

Message	Contents and solution
ER18 PROGRAM DATA ERROR BY I/O	Transferring the sequence program from offline programmer was inter- rupted by the power off etc.
	(solution) Please clear the sequence program and transfer the se- quence program again.
ER19 LADDER DATA ERROR	Editing the LADDER was interrupted by the power off or by the switch to the CNC screen by the function key etc.
	(solution) Please edit LADDER once on PMC. Or, please input LADDER again.
ER20 SYMBOL/COMMENT DATA ERROR	Editing the symbol and comment was interrupted by the power off or by the switch to the CNC screen by the function key etc.
	(solution) Please edit symbol and comment once on PMC. Or, please input symbol and comment again.
ER21 MESSAGE DATA ERROR	Editing the message data was interrupted by the power off or the switch to the CNC screen by the function key etc.
	(solution) Please edit message data once on PMC. Or, please input message data again.
ER22 PROGRAM NOTHING	There is no sequence program.
ER23 PLEASE TURN OFF POWER	There is a change in setting LADDER MAX AREA SIZE etc.
	(solution) Please restart the system to make the change effective.
ER32 NO I/O DEVICE	Any DI/DO unit of I/O Unit or the connection unit etc. is not connected. If I/O devices, such as the I/O Unit, are in use: Make sure that power is supplied to the I/O devices. Also check the cable connection.
ER33 SLC ERROR	The LSI for I/O Link is defective.
	(solution) Please exchange the module of PMC engine.
ER34 SLC ERROR (xx)	The communication with the DI/DO units of the xx group failed.
	(solution) Please confirm the connection of the cable connected to the DI/ DO units of the xx group.
	Please confirm whether the DI/DO units turned on earlier than CNC and PMC. Or, please exchange the module of PMC engine on the DI/DO units of the xx group.
ER35 TOO MUCH OUTPUT DATA IN GROUP (xx)	The number of the output data in the xx group exceeded the max. The data, which exceed 32 bytes, become ineffective.
	(solution) Please refer to the following for the number of the data for each group.
	"FANUC I/O Unit-MODEL A connecting and maintenance manual" (B-61813E)
	"FANUC I/O Unit-MODEL B connecting manual"(B-62163E)
ER36 TOO MUCH INPUT DATA IN GROUP (xx)	The number of the input data in the xx group exceeded the max. The data, which exceed 32 bytes, become ineffective.
	(solution) Please refer to the following for the number of the data for each group.
	"FANUC I/O Unit-MODEL A connecting and maintenance manual" (B-61813E)
	"FANUC I/O Unit-MODEL B connecting manual"(B-62163E)

Message	Contents and solution
ER38 MAX SETTING OUTPUT DATA OVER (xx)	<ul><li>The assignment data for a group exceeds 128 bytes.</li><li>(The assignment data of output side of xx group or later become ineffective.)</li><li>(solution) Please reduce the assignment data to 128 bytes or less for the number of the output data of each group.</li></ul>
ER39 MAX SETTING INPUT DATA OVER (xx)	<ul> <li>The assignment data for a group exceeds 128 bytes.</li> <li>(The assignment data of input side of xx group or later become infective.)</li> <li>(solution) Please reduce the assignment data to 128 bytes or less for the number of the input data of each group.</li> </ul>
WN01 LADDER MAX SIZE ERROR	The MAX LADDER AREA SIZE in the system parameter is illegal. (solution) Set the correct value to MAX LADDER AREA SIZE and re start the system.
WN02 OPERATE PANEL ADDRESS ERROR	The address setting data of the operator's panel for FS–0 is illegal. (solution) Please correct the address setting data.
WN03 ABORT NC-WINDOW/EXIN	<ul> <li>LADDER was stopped while CNC and PMC were communicating.</li> <li>The functional instruction WINDR, WINDW, EXIN, DISPB, and etc. may not work normally.</li> <li>(solution) When restarting the system, this alarm will be released. Execute the sequence program(Press RUN key) after confirming whether there is a problem in LADDER or not.</li> </ul>
WN07 LADDER SP ERROR (STACK)	When functional instruction CALL(SUB65) or CALLU(SUB66) was executed, the stack of the LADDER overflowed. (solution) Please reduce the nesting of the subprogram to 8 or less.
WN17 NO OPTION (LANGUAGE)	There is no C language option.
WN18 ORIGIN ADDRESS ERROR	The LANGUAGE ORIGIN address of the system parameter is wrong (solution) Please set the address of symbol RC_CTLB_INIT in the map file to the LANGUAGE ORIGIN of the system parameter.
WN19 GDT ERROR (BASE, LIMIT)	The value of BASE, LIMIT or ENTRY of user defined GDT is illegal. (solution) Please correct the address in link control statement and build file.
WN20 COMMON MEM. COUNT OVER	The number of common memories exceeds 8. (solution) Please reduce the number of common memories to 8 or less. It is necessary to correct a link control statement,build file and the source file for the common memory.
WN21 COMMON MEM. ENTRY ERROR	<ul><li>GDT ENTRY of the common memory is out of range.</li><li>(solution) Please correct the address of GDT ENTRY of the common memory in the link control statement.</li></ul>
WN22 LADDER 3 PRIORITY ERROR	The priority of LADDER LEVEL 3 is out of range. (solution) Please correct the value of LADDER LEVEL 3 in the link con- trol statement within the range of 0 or 10–99 or –1.
WN23 TASK COUNT OVER	<ul> <li>The number of user tasks exceeds 16.</li> <li>(solution) Please confirm TASK COUNT in the link control statement. When the number of tasks is changed, it is necessary to correct the link control statement, build file and the composition of the files to be linked.</li> </ul>

Message	Contents and solution		
WN24 TASK ENTRY ADDR ERROR	The selector of the entry address to the user task is out of range. (solution) Please correct the table of GDT in build file to the value within 32(20H)–95(5FH).		
WN25 DATA SEG ENTRY ERROR	<ul> <li>The entry address of the data segment is out of range.</li> <li>(solution) Please correct DATA SEGMENT GDT ENTRY in the link control statement and the table of GDT in build file within 32(20H)–95(5FH).</li> </ul>		
WN26 USER TASK PRIORITY ERROR	The priority of the user task is out of range. (solution) Please correct the TASK LEVEL in link control statement with- in the range of 10–99 or –1. Note: Only one task can have TASK LEVEL –1 (including LADDER LEVEL 3).		
WN27 CODE SEG TYPE ERROR	<ul><li>The code segment type is illegal. The code segment of RENAMESEG in the binding control file is wrong.</li><li>(solution) Please correct the entry of the code segment in the link control statement to correspond to the entry in the build file.</li></ul>		
WN28 DATA SEG TYPE ERROR	<ul><li>The data segment type is illegal. The data segment of RENAMESEG in the binding control file is wrong.</li><li>(solution) Please correct the entry of the code segment in the link control statement to correspond to the entry in the build file.</li></ul>		
WN29 COMMON MEM SEG TYPE ERROR	The segment type of common memory is illegal. The segment of RE- NAMESEG in the building control file of the common memory is wrong. (solution) Please correct the entry of common memory in the link control statement to correspond to the entry in the build file.		
WN30 IMOPSSIBLE ALLOCATE MEM.	<ul> <li>The memories for the data and stack etc. cannot be allocated.</li> <li>(solution) Please confirm whether the value of code segment in build file and USER GDT ADDRESS in link control statement is correct or not.</li> <li>Or please reduce the value of MAX LADDER AREA SIZE of the system parameter and the size of the stack in link control statement at the least.</li> </ul>		
WN31 IMPOSSIBLE EXECUTE LIBRARY	The library function cannot be executed. (solution) Please confirm the object model of the library. Or, system ROM of PMC must be replaced with one of later ver- sion.		
WN32 LNK CONTROL DATA ERROR	Link control statement data is illegal. (solution) Please confirm whether the address of symbol RC_CTLB_ INIT in map file is set to LANGUAGE ORIGIN of the system pa- rameter. Or, please make the link control statement again.		

APPENDIX

# C.3 PMC ERRORS

The following appears on the screen if an alarm condition (error) occurs: SYSTEM ALARM 08:511D:SERI:0005:0094H581 BUS ERROR FFEC8D (005DC6):PC040 08: : Slot number

511D	: ID number of printed circuit board
SERI	: ROM series
0005	: ROM version
0094h581	: Last 8 digits of drawing number
BUS	: Description of error (See 5.6 (2).)

### (1) Error codes

Error code	Message	Description	
PC010PC ERRORIPC020PC ERRORI		PC ROM parity error	
		PC RAM parity error	
PC030	PC ERROR	NC RAM parity error	
PC040PC ERRORPC050PC ERROR		PC system error	
		Error related to DI/DO	
PC070	PC ERROR	MPC2 watch dog timer alarm	
PC500 WATCH DOG ALARM		PC watch dog timer alarm	

(2) System error messages

(VECTOR: 08H)

(a) BUS ERROR (VEC Bus error (Access was made to an unusable address.) <Message>: 31 characters

BUS ERROR xxxxxx (yyyyyy):PC040

xxxxx: Access address yyyyyy: Execution address

### (b) ADDRESS ERROR

(VECTOR: 0CH)

Address error (Access was made to an odd–numbered address.) </br><Message>: 31 characters

ADR ERROR xxxxxx (yyyyyy):PC040

xxxxx: Access address yyyyyy: Execution address

(c) ILLEGAL INSTRUCTION	
Tried to execute an illegal instructio	n
<message>: 24 characters</message>	

ILG ERROR (yyyyyy):PC040

yyyyyy: Execution address

(d) ZERO DIVIDE Division by 0 was attempted. <Message>: 24 characters (VECTOR: 14H)

(VECTOR: 10H)

ZDV ERROR (yyyyyy):PC040

yyyyy: Execution address

(e) CHK INSTRUCTION (VECTOR: 18H) Register limit check error (Register limit has been exceeded.) <Message>: 24 characters

CHK ERROR (yyyyyy):PC040

yyyyy: Execution address

(f) TRAPV INSTRUCTION Overflow trap <Message>: 24 characters (VECTOR: 1CH)

TRV ERROR (yyyyyy):PC040

yyyyy: Execution address

(g) PRIVILEGE VIOLATION Privileged instruction violation <Message>: 24 characters (VECTOR: 20H)

PRV ERROR (yyyyyy):PC040

yyyyyy: Execution address

(h) TRACE CPU trace (hardware error) <Message>: 24 characters (VECTOR: 24H)

TRC ERROR (yyyyyy):PC040

yyyyy: Execution address

<ul> <li>(i) LINE 1010 EMULATOR</li> <li>Tried to execute an instruction whose operative structure of the structure o</li></ul>	(VECTOR: 28H) eration code is Axxx.
L10 ERROR (yyyyyy):PC040	

yyyyyy: Execution address

(j) LINE 1111 EMULATOR (VECTOR: 2CH) Tried to execute an instruction whose operation code is Fxxx. <Message>: 24 characters

L11 ERROR (yyyyyy):PC040

yyyyyy: Execution address

(k) UNASSIGNED NMI (VECTOR: 30H~5CH) An interrupt occurred when it should not have (hardware error). <Message>: 24 characters

NAE ERROR (yyyyyy):PC040

yyyyyy: Execution address

(1) SPURIOUS INTERRUPT (VECTOR: 60H)
 An interrupt occurred, but its cause was not identified
 (hardware error).
 <Message>: 24 characters

SPI ERROR (yyyyyy):PC040

yyyyyy: Execution address

(m) UNASSIGNED TRAP (VECTOR: 88H~B0H) A trap occurred when it should not have (hardware error). <Message>: 24 characters

NTP ERROR (yyyyyy):PC040

yyyyy: Execution address

(n) ROM PARITY (VECTOR: B4H) PMC ROM parity error (PMC control ROM error) <Message>: 20 or 24 characters

ROM PARITY zzz yyy:PC010

zzz, yyy: ROM number

(o) CNC SYSTEM ERROR CNC system error <Message>: None

(p) TRAP15 I/O error in battery powered RAM (printed circuit board BASE0 faulty) <Message>: 24 characters (VECTOR: BCH)

(VECTOR: B8H)

T15 ERROR (yyyyyy):PC040

yyyyyy: Execution address

(VECTOR: 7CH)

(q) RAM PARITY Memory error (PMC NA faulty) <Message>: 36 characters

RAM ERROR <B.RAM> xx (yyyyyy):PC020 <O.RAM> <S.RAM> <P.RAM> <K.RAM>

- B. RAM: BASIC RAM
- O. RAM: OPTIONAL DRAM
- S. RAM: SRAM
- P. RAM : PMC RAM board
- K. RAM: PMC DATA (battery–powered RAM area)
- XX : Detailed information about RAM parity error
  - bit 0 : Error occurred when the lower byte of the DRAM serial port was read.
  - bit 1 : Error occurred when the upper byte of the DRAM serial port was read.
  - bit 2 : Error occurred when the lower byte of the DRAM RAM port was read.
  - bit 3 : Error occurred when the upper byte of the DRAM RAM port was read.
  - bit 4 : RAM type (0 = Basic RAM, 1 = Optional RAM)
  - bit 5 : Error occurred when SRAM was read.
  - bit 6 : bit 7 bit 6
  - bit 7:0 0: Error occurred during host access.
    - 0 1 : Error occurred during BOC access.
    - 1 0 : Error occurred during direct memory access.
    - 1 1 : BOC racing error during direct memory access.
- yyyyyy : Execution address

(r) SLC ERROR (VECTOR: 7CH) I/O communication error <Message>: 22 characters

SLC ERROR xx (yy):PC050 : Detailed information on host SLC error XX bit 0 : CRC error or framing error (detection of an error such as a reversed bit) bit 1 : Error detected by the slave unit bit 2 : Communication error bit 3 : Internal parity error bit 4 : External parity error bits 5 to 7 : Undefined : Detailed information on slave SLC error уу bits 0 to 4 : Serial alarm number bit 5 : CRC error or framing error detected by the slave unit bit 6 : Error detected by the slave unit bit 7 : Watch dog timer alarm or parity error detected by the slave unit

### NOTE

Subtracting 1 from this number yields the I/O group number. Assume "00011" is displayed. 3 - 2 = 2. Therefore, the alarm occurred in an I/O device in group 2. Note, however, that this information is valid only when bits 0 and 1 of xx (host SLC error detail information) are 1.

	Display error messages	Error contents
1	ROM PARITY add bbb : PC010	PMC ROM parity error has occurred aaa,bbb: defecitive ROM number
2	RAM PARITY <a.ram> bb (yyyyyy) : PC020</a.ram>	PMC RAM parity error has occurred a. RAM: kind of RAM PARITY (B.RAM: BASIC RAM, O.RAM: OPTION RAM S.RAM: STATIC RAM and P.RAM: PMC RAM boards) bb: RAM PARITY ERROR information
3	BUS ERROR xxxxxx (yyyyyy) : PC040	Bus error (impossible to use address access) has occurred
4	ADR ERROR xxxxxx (yyyyyy) : PC040	Address error (odd number address access) has occurred
5	ILG ERROR (уууууу) : PC040	Attempted to execute execution-impossible command
6	ZDV ERROR (уууууу) : PC040	Tried to execute division with a divisor of zero
7	СНК (уууууу) : РС040	Register has exceeded the range in the register limit check
8	TRV (уууууу) : PC040	Overflow trap has occurred
9	PRV (yyyyyy) : PC040	Privilege command violation error has occurred
10	TRC (уууууу) : PC040	CPU has entered the trace status
11	L10 (уууууу) : РС040	Attempted to execute a command with the command code appearing to be Axxx
12	L11 (уууууу) : PC040	Attempted to execute a command with the command code appearing to be Fxxx
13	NAE (уууууу) : PC040	Unexpected interruption has occurred
14	SPI (уууууу) : PC040	Interruption whose cause is unclear has occurred
15	NTP (yyyyyy) : PC040	Unexpected TRAP has occurred
16	SLC ERROR aa : PC040	Abnormality in DI/DO has occurred aa: DI/DO ERROR information
17	PC500 WATCH DOG ALARM	PMC watchdog alarm has occurred

(3)PMC–NA

(xxxxx:access address; yyyyyy: execution address)

Message STATUS   FD	Contents and solution	
	Contents and Solution	
RAM ERROR <a> bbcc xxxx: yyyyyyyy: PC010 STATUS LED ★■ or □★</a>	The parity error occurs on the debugging RAM of PMC. a : RAM which generates RAM parity. B BASIC RAM O OPTION RAM S STATIC RAM bb, cc : RAM PARITY information. xxxx : Segment selector where system error occurred. yyyyyyyy : Offset address where system error occurred.	
ROM ERROR aaaaaaaa: PC020 STATUS LED     ☆★	The parity error occurs in PMC system ROM. aaaaaaaa : ROM parity information	
DIVIDE ERROR xxxx: yyyyyyyy: PC040 STATUS LED     ☆★	Division error occurs such as a divisor is 0 in the division instruction. xxxx : Segment selector where system error occurred. yyyyyyyy : Offset address where system error occurred.	
BUS ERROR xxxx: уууууууу: PC040 STATUS LED     ☆★	The BUS error (access on illegal address). xxxx : Segment selector where system error occurred. yyyyyyyy : Offset address where system error occurred.	
STACK FAULT xxxx: уууууууу: PC040 STATUS LED     ☆★	The stack exception such as the violation of the limit of the stack. xxxx : Segment selector where system error occurred. yyyyyyyy : Offset address where system error occurred.	
GENERAL PROTECTION xxxx: yyyyyyyy: PC040 STATUS LED ☆★	The general protection exception such as segment limit over was generated. xxxx : Segment selector where system error occurred. yyyyyyyy : Offset address where system error occurred.	
SLC ERROR aa (cc) : PC050	<ul> <li>The communication error occurred in the I/O Link.</li> <li>aa, cc : I/O Link error information.</li> <li>This error may occur by the following causes.</li> <li>1. When I/O Unit–MODEL A is used, base1, 2 or 3 is not connected though allocated.</li> <li>2. The connection of cable is insufficient.</li> <li>3. Defects of cable.</li> <li>4. Defects of DI/DO units (I/O unit, Power Mate etc.)</li> <li>5. Defects of PMC board (printed circuit board on host side where I/O Link cable is connected.)</li> <li>(solution) Investigate the cause of error.</li> <li>1. Please confirm the allocation data (by "EDIT"→"MODULE" screen and compare with the actual connection.</li> <li>2. Please confirm whether the cable is correctly connected. If you cannot find the cause with the ways above, it may be the defect of hardware.</li> <li>Please investigate a defective place by the following methods.</li> <li>3. Please confirm the specification of the cable referring to "FANUC I/O Unit–MODEL B connecting manuals(B–62163E)".</li> <li>4. Exchange the interface module of I/O Unit, the cable and the PMO board, etc. one by one and, confirm whether this error occurs again The communication may fail by the noise etc. when this error still oc</li> </ul>	
STATUS LED ■★	Please investigate the cause of noise.	

### (4) PMC–NB

STATUS LED (green) are LED1, LED2 on PMC-NB.

 $\Box$ : Off  $\blacksquare$ : On  $\bigstar \bigstar$ : Blinking



# WARNING MESSAGE LIST

Message	Alarm description	
PARAMETER/SETTING DATA/MACRO VARIABLE CAN'T REWRITE (MDI EXECUTING)	Because MDI operation is being performed, neither parameters, set- ting data, nor macro variables can be rewritten.	
PARAMETER/SETTING DATA/MACRO VARIABLE CAN'T REWRITE (RESETTING)	Because reset operation is being performed, neither parameters, set- ting data, nor macro variables can be rewritten.	
PARAMETER/SETTING DATA/MACRO VARIABLE CAN'T REWRITE (MODE CHANGING)	Because mode switching is being performed, neither parameters, set- ting data, nor macro variables can be rewritten.	
KEY IN DATA	Enter data with keys.	
FORMAT ERROR	The format is illegal.	
WRITE PROTECT (MEMORY PROTECTION KEY IN EFECT)	Input is disabled because the memory protection key (workpiece coor- dinates, offset values, and programs) is on.	
WRITE PROTECT (DATA NUMBER 8000#0/PWE IS 0)	Parameter input is disabled because PWE (bit 0) of parameter No. 8000 (enable/disable parameter write) is set to 0.	
CHANGE TO MDI MODE	An attempt was made to input parameters in mode other than the MDI mode. Place the system in the MDI mode.	
DATA IS OUT OF RANGE	An attempt was made to input a value, but the value exceeded the allowable range.	
TOO MANY DIGITS	An attempt was made to input a value, but it was longer than the maxi- mum allowable number of digits.	
START REJECT	<ul> <li>The start of automatic operation is not accepted.</li> <li>(1) Automatic operation pause signal *SP is low.</li> <li>(2) An alarm exists.</li> <li>(3) The SRN signal has been sent.</li> <li>(4) The program the operator wants to execute is now being edited in the background.</li> <li>(5) PTR is not ready in the tape mode.</li> </ul>	
LOCKED PARAMETER	An attempt was made to enter data for a parameter, but input for that parameter was not allowed.	
DATA NOT FOUND	Data is missing.	
DEVICE IS ALREADY IN USE	The external input/output device channels are being used, so a device cannot be used unless the operation is terminated. To release this state, reset the system.	
NO PROGRAM SELECTED	Although no program was selected, an attempt was made to perform editing. Before editing, select a program by searching for its program number or registering the program.	

Message	Alarm description
ORIGIN IMPOSSIBLE (IN RESET OR FEED HOLD)	ORIGIN operation is disabled because the system is in the reset or feed hold state.
EDIT REJECT (IN RESET OR FEEDHOLD)	Editing is disabled because the system is in the reset or feed hold state. Release the reset or feed hold state.
EDIT REJECT (PROGRAM IN OPERATING)	Editing of a program is disabled because that program is currently running.
ALREADY EXISTS	An attempt was made to register a new program with an existing pro- gram number.
NO MORE PROGRAM CAN'T BE ENTERED	Because the program memory area is full, no more programs can be registered.
NOT EMERGENCY STOP	An attempt was made to register parameters in a state other than the emergency stop state. Place the system in the emergency stop state.
THE NUMBER OF PROGRAMS IS OUT OF RANGE	Because the number of registered programs has reached the maxi- mum allowable number, no more programs can be registered.
GUARDED WORD	An attempt was made to edit a word that cannot be edited. For example, this message appears when an attempt is made to alter or delete a program number.
NO PROGRAM NUMBER	An attempt was made to write a program to tape, but no program num- ber was found at the beginning of the program.
COMMAND ILLEGAL USE	The command cannot be used in the current CNC status. (This mes- sage appears when HERE is specified at the beginning in program verification or when a program restart is specified during program re- start operation.)
BACKGROUND EDIT REJECT (PROGRAM IN OPERATING)	Although a program was running in the background, an attempt was made to edit that program.
BACKGROUND EDIT REJECT (SAME PROGRAM ON THE FOREGROUND)	An attempt was made to edit a program in the background, but the program was being used in the foreground. (The program, however, can be edited in the background when the program is being reset and rewound in the foreground.)
INVISIBLE PROGRAM	The cursor was used to select a program, or an attempt was made to edit a program, but the program could not be displayed (when a pa- rameter is set to suppress the display of that program during operation or when the program is encrypted).
NO OPTION	No option is given to a specified command.
GRAPHIC AXIS NUMBER NOT SET	The parameter for selecting the graphic display axis (parameter No. 7703) is not set.
FAIL TO OCCUPY GRAPHIC CPU	Another user (such as the PC) tried to use the graphic CPU.
EXTERNAL WORKPIECE ZERO NOT INPUT	Workpiece zero point manual setting was performed on the external workpiece zero point offset.
+OVERTRAVEL(SOFT1)	The tool has attempted to enter an area set as inhibited by stored stroke limit 1 during manual movement in the positive direction. Backing out the tool in the negative direction automatically clears this warning message.

Message	Alarm description
-OVERTRAVEL(SOFT1)	The tool has attempted to enter an area set as inhibited by stored stroke limit 1 during manual movement in the negative direction. Backing out the tool in the positive direction automatically clears this warning message.
CAN NOT REPEAT (BUFFER IS EMPTY)	An attempt was made to use the repeat search function when neither the forward nor backward search function had been executed. Before using the repeat search function, execute either the forward or backward function.
CAN NOT REPEAT (FUNCTION IS DIFFERENT)	The previous forward or backward search operation was invalid for the NC mode screen on which you attempted to use the repeat search function. Retry the forward or backward search function by starting from scratch.
ALREADY EXISTS	On the signal selection screen, an attempt was made to newly register a previously registered address.

*≪Numbers*≫

10" LCD, 185, 187
10" PDP, 186
15–MFB data input/output, 222
9.5" LCD, 185
9.5" LCD, 10.4" LCD (graphic function built–in type or for MMC–IV), 187
9" PDP, 186

### ≪A≫

Action against noise, 86 Address, 227 Adjusting the liquid-crystal display, 185 Alarm 700 (overheat at control side), 321 Alarm history display, 13 Alarm history screen, 13 Alarm LED (red) display in the event of an error occurring in the connection unit/operator's panel connection unit, 161 Alarm LED display (red) in the event of an error, 160 Alarm list (CNC), 364 Alarm list (PMC), 383 Alarm OT117 (spindle speed fluctuation detection alarm), 322 Alarm OT300 (spindle serial link cannot be started), 323 Alarm OT32 (need ZRN (ABS PDR)), 314 Alarm OT34 (battery zero (ABS PCDR)), 316 Alarm SV101 (data error (ABS PCDR)), 315 Alarm SV110 (pulse coder alarm1 (serial)), 317 Alarm SV114 (abnormal rev data), 317 Alarm SV115 (abnormal communication (serial PCDR)), 318 Alarm SV23 (SV over load), 319 Automatic operation cannot be done, 288

### ≪**B**≫

Back panel PCB, 165 Boot system, 335 Built–in debug function, 228

# ≪**C**≫

Checking the parameters required for data input/output, 200 CNC parameter input, 214 CNC parameter output, 208

Combining serial spindle and analog spindle, 79

Configuration of additional axis (ADAX) board, 149

Configuration of the axis CPU board (ACPU), 130

Configuration of the CPU board (MAIN-B), 96

Configuration of the high-speed multiaxis main CPU board (MAX MAIN-A), 107

Configuration of the level up multiaxis main CPU board (MAX MAIN-C), 111 Configuration of the main CPU board (MAIN-A), 100 Configuration of the multiaxis buffer board, 133 Configuration of the option 1 board, 152 Configuration of the PMC-NA board, 115 Configuration of the PMC-NA board with or without the conversational function, 118 Configuration of the PMC-NB board with or without the conversational function, 122 Configuration of the PMC-NB/NB2 board with or without the conversational function, 126 Configuration of the power supply unit, 92 Configuration of the RISC board, 134, 137 Configuration of the standard multiaxis sub-CPU board (MAX SUB-B), 143 Configuration of the sub-CPU board (SUB-A), 140 Configuration of the upgraded main CPU board (MAIN-C), 104Configuration of the upgraded sub-CPU board (SUB-C), 146 Connection to  $\alpha$  serial spindle amplifier, 80 Connection to analog spindle amplifier, 81 Connections by type of detectors, 77 Control unit PCB, 164 Control unit rack, 163 Conversational data input, 222 Conversational data input/output, 222 Conversational data output, 223 Corrective action for failures, 271 CRT/MDI unit, 68 Custom macro variable value input, 218 Custom macro variable value output, 212 Cycle start LED signal has turned off, 295

### ≪**D**≫

Data input, 214 Data input/output, 200 Data output, 208 Diagnosis function, 19 Display data, 36 Display format of history data, 13 Display method, 13, 35, 36, 41, 231 Display of wave diagnosis (graph) screen, 30 Display unit, 170 Displaying method, 9 Displaying system configurations, 9 Displaying the diagnosis screen, 19

### ≪**E**≫

Editing a displayed waveform, 34 Environmental requirement, 85

### INDEX

Erasing a displayed waveform, 34 Error code table, 363 Error messages and required countermeasures, 355 Execution period of PMC, 229 External control unit (except I/O unit), 173

# ≪**F**≫

Fuse replacement in power supply unit, 181

### ≪**G**≫

General of interface, 225

### ≪**H**≫

Handle operation cannot be done, 285 Handling memory cards, 192 Hardware, 51 Help function, 15 High–speed DI signal interface, 84 How to replace fan motor, 179 How to replace the batteries, 177 How to replace the card cage in the control unit, 191 How to replace the CRT display, 189 How to replace the MDI keyboard, 190 How to replace the modules, 176

### ≪**I**≫

I/O link, 73 Input and output of data, 196 Inputting CNC parameter, 214 Inputting PMC data, 216 Insertion, 176 Inter-machine connection, 68 Interface between NC and PMC, 224 Internal position compensation data display function, 36 Investigating the conditions under which failure occurred, 271

### ≪J≫

Jog operation cannot be done, 281

# ≪**L**≫

Lighting of alarm LEDs on PCBs, 92 List of the PCBs and units, 163

### LOAD BASIC SYSTEM, 354

### ≪**M**≫

Maintenance of heat pipe type heat exchanger, 182
Maintenance parts, 329
Maintenance parts for the FANUC Series 15–B, 330
Manual pulse generator, 72
MEMORY CARD FORMAT function, 353
Memory cards for use with the boot system, 340
Module (for main CPU board), 166
Module (for PMC/conversational board), 167
Module (for RISC board), 168
Module (for sub CPU board, additional axis board, or axis CPU board), 168
Module (option 1 board), 169
Module (OSI ethernet board), 169
Module information, 12

### ≪**N**≫

Names and functions of the components, 193 NC status display, 28 No manual operation nor automatic operation can be executed, 276 Nothing is displayed on CRT, 297

### ≪**0**≫

Operating monitor screen, 35 Operation, 15 Operation history, 41 Operation list, 46 Operation of MDI panel, 1, 2 OSI ethernet board configuration (10 base 2), 156 OSI ethernet board configuration (10 base 5), 158 Outline of hardware, 53 Outputting PMC parameter, 208

### ≪**P**≫

Part program output, 213 Part program registration, 220 Pitch error compensation data input, 218 Pitch error compensation data output, 212 PMC errors, 388 PMC screen, 231 PMC system configuration, 230 PMCDGN screen, 237 PMCLAD screen, 233 PMCRAM screen, 245 Power cannot be turned on, 273 Power capacity, 86 Power supply unit, 164 Power–up processing sequence display, 336 PS200 (grid synchronous is failed), 311

### ≪**R**≫

Reader/puncher interface, 71 Reference position deviates, 310 Related parameters, 45 Remote buffer interface, 82 Removing, 176 Replace the battery for memory back up, 177 Replacing batteries for separate absolute pulse coder, 178 Replacing the battery, 195 Replacing the fuses of the liquid–crystal displays, 187 Replacing the LCD backlight, 188 Restrictions, 14

# ≪**S**≫

Screen configuration and operating procedure, 341 Screen transition chart, 2 Select DI/DO screen, 44 Servo interface, 76 Setting the parameters required for input/output, 197 Setting the waveform diagnosis parameters, 30 Signal and symbol correspondence table, 253 Slot information, 10 Soft key operation, 41 Software information, 9 Specification, 226 Specification of PMC, 226 SR805 to SR874 (related to reader/punch interface), 298 SRAM DATA BACKUP screen, 348 Starting or terminating data sampling, 34 Starting the boot system, 337 Structure, 52 System alarms and required countermeasures, 357 SYSTEM DATA CHECK screen, 344 SYSTEM DATA LOADING screen, 342 SYSTEM DATA SAVE screen, 347 System file and user file, 338 System reserve area in internal relay, 228

# ≪**T**≫

Tool offset data input, 219 Tool offset data output, 213 Total connection, 56 Troubleshooting, 270

# ≪**U**≫

Using memory cards, 194

### ≪**W**≫

Warning message list, 395 Waveform diagnosis function, 30 Waveform display, 34

	L
0	L
	L
-	L
0	L
<u> </u>	L
~	L
<b>U</b>	L
<b>d</b>	L
-	L
$\sim$	L
<u> </u>	L
	L
	L
	L
_	L
0	L
. <u> </u>	L
	L
CO L	L
	L
-	L
>	L
	L
œ	L
_	L
	L
	L

# FANUC Series 15/150-MODEL B MAINTENANCE MANUAL (B-62075E)

J				1	
					Contents
					Date
					Edition
	Total revision	The following products are added • FANUC Series 150–TB • FANUC Series 150–MB	The explanation of various printed circuit boards was added to the paragraph of the control unit printed circuit boards.		Contents
	May, '98	Feb.,'95	Aug.,'94	Jan., '93	Date
	04	03	02	01	Edition

- No part of this manual may be reproduced in any form.
- All specifications and designs are subject to change without notice.